



# **Transitioning from a stretch to a fabric-attached MetroCluster configuration**

## **ONTAP MetroCluster**

netapp-ivanad, ntap-bmegan, ranuk  
April 20, 2021

This PDF was generated from [https://docs.netapp.com/us-en/ontap-metrocluster/install-stretch/task\\_upgrade\\_the\\_configuration\\_to\\_fabric\\_attached\\_mcc.html](https://docs.netapp.com/us-en/ontap-metrocluster/install-stretch/task_upgrade_the_configuration_to_fabric_attached_mcc.html) on April 28, 2021. Always check docs.netapp.com for the latest.

# Table of Contents

Transitioning from a stretch to a fabric-attached MetroCluster configuration . . . . . 1

# Transitioning from a stretch to a fabric-attached MetroCluster configuration

In a fabric-attached MetroCluster configuration, the nodes are in different locations. This geographical difference increases the disaster protection. To transition from a stretch to a fabric-attached MetroCluster configuration, you must add FC switches and, if necessary, FC-to-SAS bridges to the configuration.

- You must have disabled automatic switchover on both of the clusters by running the `metrocluster modify -auto-switchover-failure-domain auto-disabled` command.
- You must have shut down the nodes.

This procedure is disruptive.

The MetroCluster configuration must be transitioned on both sites. After upgrading the MetroCluster configuration, you must enable automatic switchover on both the clusters. You also must validate the configuration by running the `metrocluster check run` command.

This procedure gives an overview of the required steps. For detailed steps, you must refer to specific sections in the [Fabric-attached MetroCluster Installation and Configuration Guide](#). You do not need to do a full installation and configuration.

## Steps

1. Prepare for the upgrade by carefully reviewing the "Preparing for the MetroCluster installation" section of the [Fabric-attached MetroCluster Installation and Configuration Guide](#).
2. Install, cable, and configure the required switches and FC-to-SAS bridges.



You should use the procedures in the section "Cabling a fabric-attached MetroCluster configuration" of the [Fabric-attached MetroCluster Installation and Configuration Guide](#).

3. Refresh the MetroCluster configuration using the following steps.

Do not use the procedures in the section "Configuring the MetroCluster software in ONTAP" found in the xref: [Fabric-attached MetroCluster Installation and Configuration Guide](#).

- a. Enter advanced privilege mode: + `set -privilege advanced`
- b. Refresh the MetroCluster configuration: + `metrocluster configure -refresh true`

The following command refreshes the MetroCluster configuration on all the nodes in the DR group that contains controller\_A\_1:

```
controller_A_1::*> metrocluster configure -refresh true
[Job 009] Job succeeded: Configure is successful.
```

- c. Return to admin privilege mode: + `set -privilege admin`
4. Check the MetroCluster configuration for errors and verify that it is operational.

You should use the procedures in the following sections of the [Fabric-attached MetroCluster Installation and Configuration Guide](#):

- Checking for MetroCluster configuration errors with Config Advisor
- Verifying local HA operation
- Verifying switchover, healing, and switchback

## Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.