

Power System Toolbox 4

–User Manual–

Documentation Version 0.0.0-a.2

by

Thad Haines

Last Update: September 3, 2020

Introduction

This section should contain props to ol' Graham Rogers and Joe Chow for making this software. It could also provide a bit of history about how PST has developed into its current form.

After all that, a brief explanation of the user manual purpose and content would make sense. Maybe highlight/foreshadow major changes and additions that are explained in more detail later.

Possibly mention the funding that made this work possible.

Table of Contents

Table of Contents	iii
List of Tables	v
List of Figures	vi
List of Equations	vii
Glossary of Terms	viii
1 PST Version History	1
2 Changes and Additions	3
3 General Model or Bug Fixes	4
3.1 PSS model	4
3.2 Sub-transient Machine model	4
3.3 exc_dc12	5
3.4 exc_st3	5
3.5 mac_tra	5
3.6 lmod and rlmod	5
3.7 pwrmod	5
3.8 ivmmmod	5
3.9 livePlot	6
3.10 lmon	6
3.11 area	6
3.12 calcAveF	6
3.13 calcAreaVals	6
3.14 agc	6
3.15 cleanZeros	7
3.16 trimLogs	7
3.17 Variable Time Step Simulation	7
3.18 Global Variables	8
3.18.1 lmod	8
3.18.2 tg	8
3.18.3 rlmod	9
3.18.4 exc	9

3.18.5	mac	9
3.18.6	pss	10
3.18.7	pwr	10
3.18.8	ncl	10
3.18.9	sys	11
3.18.10	svc	11
3.18.11	tcsc	11
3.18.12	igen	12
3.18.13	ind	12
3.18.14	dc	13
3.18.15	bus	14
3.18.16	line	14
3.18.17	int	14
3.18.18	lmon	15
3.18.19	area	16
3.18.20	agc	18
3.18.21	k	20
3.18.22	vts	20
4	PST Operation Overview	21
5	Examples Explained	22
6	Loose Ends	23
7	Bibliography	24
8	Document History	25
A	Appendix A: Formatting Examples	26
A.1	Numberings in Equations	26
A.2	Numberings in Tables	26
A.3	Numberings in Figures	26
A.4	Code using Minted	27

List of Tables

A.14	Another Table.	26
------	------------------------	----

List of Figures

A.67	A boxcat in its natural environment.	26
A.68	Code listing as a figure.	27

List of Equations

A.42	Ohm's Law	26
------	---------------------	----

Glossary of Terms

Term	Definition
AC	Alternating Current
ACE	Area Control Error
AGC	Automatic Generation Control
BA	Balancing Authority
BES	Bulk Electrical System
CTS	Classical Transient Stability
DACE	Distributed ACE
EIA	United States Energy Information Administration
FERC	Federal Energy Regulatory Commission
FTS	Fixed Time Step
Hz	Hertz, cycles per second
IC	Interchange
ISO	Independent Service Operator
J	Joule, Neton meters, Watt seconds
LFC	Load Frequency Control
NERC	North American Electric Reliability Corporation
ODE	Ordinary Differential Equation
P	Real Power
PI	Proportional and Integral
PSS	Power System Stabilizer
PST	Power System Toolbox
PU	Per-Unit
Q	Reactive power
RACE	Reported ACE
RTO	Regional Transmission Organization
SACE	Smoothed ACE
SI	International System of Units
US	United States of America

Term	Definition
VAR	Volt Amps Reactive
VTs	Variable Time Step
W	Watt, Joules per second
WECC	Western Electricity Coordinating Council

1 PST Version History

Current Versions

- 2.3 - Based on PST 2, includes Dan Trudnowski's pwrmod, ivmmmod, and generator tripping modifications.
- 3.0 - From Joe Chow's website. Includes fixes and alterations. Notably multiple DC lines and PSS modifications.
- 3.1 - Based on 3.0, includes Dan Trudnowski's pwrmod and ivmmmod models in non-linear simulation. pwrmod included linear simulation and various model patches. Multiple generator tripping code is included, but untested.
- 3.1.1 - Based on 3.1. Ryan Elliott's version with energy storage and updated linear simulation along with various other fixes and code cleanup alterations.
- SETO - Based on 3.1. New global structure. Includes automatic generation (AGC) models and variable time step (VTS) options. Also includes many patches as documented in PSTsetoVersionChanges. Will become 4.0 after clean up actions taken.
- 4.0.0-aX - Alpha version of PST 4 based on SETO version. Includes a refined VTS routine, confirmed multi-generator tripping, and improved AGC action/modulation. Examples in repository will be re-worked/updated and cleaned to use this version, documentation of changes will be updated, and PST code will be cleaned up where possible. May go into beta, which may then go into the 'release candidate' phase, but may also just turn into 4.0.0.

Planned Versions

- 4.0.0 - Finished VTS, AGC, code cleanup, example library, and documentation work by Thad Haines.

- 4.1.0 - Based on 4.0.x - planned to incorporate energy storage models for non-linear simulation and possibly the updated linear simulation based on 3.1.1. Examples of **ess** model use required.

2 Changes and Additions

It's assumed the last version is 3.

Maybe make a note about Experimental features (VTS, un-tripping)

- License
- IMVMOD
- PWRMOD
- Machine tripping
- Global Variable Structure
- `s_simu` Functionalization / clean up
- AGC
 - areas, average frequency
- VTS
 - differences from FTS (Huen's)
- Speed up
- Zeroing derivatives
- Octave Compatibility

3 General Model or Bug Fixes

This content will likely be separated into the changes/additions section as not all following sections are specific to code fixes but also additions/changes.

The purpose of this section is to record changes of note made to PST over the course of the SETO work that may be worth not forgetting about. It should be noted that PST SETO is based on PST version 3 and not **all** changes are recorded here.

3.1 PSS model

There was a correction to the washout time constant in the PSS model between PST version 2.x and 3. To accommodate for this, the SETO version has two pss files named **pss2** and **pss3** which mimic the computation of each PST version respectively. The idea is to enable a user to specify which model the pss settings use in a particular case. The current usage is similar to:

```
copyfile([PSTpath 'pss2.m'],[PSTpath 'pss.m']); % use version 2 model of PSS
```

Alternatively, a **pssGainFix** variable may be set to 1, or true, which will adjust the version 2 data from a **d_** file to work the same way with the version 3 model. This is accomplished by executing: **pss_con(:,3) = pss_con(:,3)./pss_con(:,4);** While this works, it's kind of confusing and may be removed.

3.2 Sub-transient Machine model

There are three versions of the **mac_sub** model available. The **_ORIG** model is the standard PST model based on the R. P. Schulz, "Synchronous machine modeling" algorithm. The **_NEW** model is based on the PSLF 'genrou' model by John Undrill. The **_NEW2** model is the same as the **_NEW** model with alternative calculations for Any model may be copied over the **mac_sub** file for use.

3.3 exc_dc12

In 2015 there were ‘errors’ corrected in the saturation block that create differences between version 2 and 3 of this model. Effects are noticeable, but a solution hasn’t been investigated yet.

3.4 exc_st3

Corrected theta index to `n_bus` from `n` per Ryan Elliott. Corrected simple `*` to `.*` in the `if ~isempty(nst3_sub)` section.

3.5 mac_tra

Commented out code that prevented the setting equal of the transient reactances.

3.6 lmod and rlmod

Fixed state limiting. While if over-limit, the derivative was set to zero, the state was not set to the maximum/minimum value correctly.

3.7 pwrmod

This is the power or current injection model Dan created for version 2.3. It’s meant to model the ‘grid following’ type of converters. It is included in both the non-linear and linear simulation modes of PST SETO.

3.8 ivmmod

This is the voltage behind an impedance model Dan created. It’s meant to model a ‘grid forming’ converter where voltage and angle are manipulatable. While there are questions about the reality of such operations, the model exists and appears to work in the non-linear simulation of PST SETO.

3.9 livePlot

Function that creates plot during non-linear simulation. While this operation existed in previous versions of pst, it is now functionalized to allow users to more easily define what is displayed (if anything) during simulations. The `livePlot` function is designed to be overwritten in a similar fashion as `pss` or machine models previously described.

3.10 lmon

Coded to actually monitor line current and power flow during non-linear simulation. The `lmon_idx` function creates the required data structures and indices.

3.11 area

Created area functionality via the `area_def`. The `area_idx` function creates the required data structures and indices.

3.12 calcAveF

Calculates system and area weighted average frequency. System values stored in `g.sys.aveF` and area values stored in `g.area.area(x).aveF`.

3.13 calcAreaVals

Calculates total area generation and interchange. Intentions were to also sum total load, but there were complications with that and work in that direction seemed not entirely useful.

3.14 agc

Automatic generation control model that calculates RACE and distributes signal to defined controlled generators according to participation factor. The ACE signal is filtered through a PI before being distributed to each generator through a unique low pass filter that adds the negative of the value to the governor `tg_sig` value. (NOTE: the `tg_sig` value is equivalent to an addition to the governors P_{ref} value) The `agc_idx` function creates the

required data structures and indices.

3.15 **cleanZeros**

Function that cleans all zero variables from the global `g`. Executed at the end of `s_simu_Batch`. Stores cleared variable names in the `clearedVars` cell that is stored in `g.sys`

3.16 **trimLogs**

Function that trims all logged values in the global `g` to a given length `k`. Executed near the end of `s_simu_BatchXXX` before `cleanZeros`.

3.17 **Variable Time Step Simulation**

Variable time step simulations are possible using standard MATLAB ODE solvers. A semi-complete and partially-detailed explanation of the functions and code used to make this happen will *probably* be written in a separate document ‘later’...

3.18 Global Variables

To enable easier manipulation of PST - it was decided to create a global structure that contains all system globals. While this may or may not have been a good idea - it happened. Initial results show a speed up of over 2 times. In other words, it could be assumed previous versions of PST spend half of their computation time loading globals...

Inside the global variable `g` are fields that corresponds to models, or groups, of other globals. For example, the `g.mac.mac_spd` global contains a all machine speeds while the `g.bus.bus_v` contains all bus voltages, etc. As of this writing, compiled on September 3, 2020, the following subparagraphs describe the globals contained in each field of the global `g`.

3.18.1 `lmod`

```
global lmod_con % defined by user
global n_lmod lmod_idx % initialized and created in lm_idx
global lmod_sig lmod_st dlmod_st % initialized in s_simu
global lmod_pot % created/initialized in lmod.m
global lmod_data % added by Trudnowski - doesn't appear to be used?
```

3.18.2 `tg`

```
%% turbine-governor variables

global tg_con tg_pot
global tg1 tg2 tg3 tg4 tg5 dtg1 dtg2 dtg3 dtg4 dtg5
global tg_idx n_tg tg_sig tgh_idx n_tgh
```

It should be noted that the hydro governor model `tgh` has not been modified as no examples seemed to use it.

3.18.3 rlmod

```
global rlmod_con n_rlmod rlmod_idx
global rlmod_pot rlmod_st drlmod_st
global rlmod_sig
```

3.18.4 exc

```
global exc_con exc_pot n_exc
global Efd V_R V_A V_As R_f V_FB V_TR V_B
global dEfd dV_R dV_As dR_f dV_TR
global exc_sig % pm_sig n_pm % not related to exciters?
global smp_idx n_smp dc_idx n_dc dc2_idx n_dc2 st3_idx n_st3;
global smppi_idx n_smppi smppi_TR smppi_TR_idx smppi_no_TR_idx ;
global smp_TA smp_TA_idx smp_noTA_idx smp_TB smp_TB_idx smp_noTB_idx;
global smp_TR smp_TR_idx smp_no_TR_idx ;
global dc_TA dc_TA_idx dc_noTR_idx dc_TB dc_TB_idx dc_noTB_idx;
global dc_TE dc_TE_idx dc_noTE_idx;
global dc_TF dc_TF_idx dc_TR dc_TR_idx
global st3_TA st3_TA_idx st3_noTA_idx st3_TB st3_TB_idx st3_noTB_idx;
global st3_TR st3_TR_idx st3_noTR_idx;
```

3.18.5 mac

```
global mac_con mac_pot mac_int ibus_con
global mac_ang mac_spd eqprime edprime psikd psikq
global curd curq curdg curqg fldcur
global psidpp psiqpp vex eterm ed eq
global pmech pelect qelect
global dmac_ang dmac_spd deqprime dedprime dpsikd dpsikq
global n_mac n_em n_tra n_sub n_ib
```

```

global mac_em_idx mac_tra_idx mac_sub_idx mac_ib_idx not_ib_idx
global mac_ib_em mac_ib_tra mac_ib_sub n_ib_em n_ib_tra n_ib_sub
global pm_sig n_pm
global psi_re psi_im cur_re cur_im

% added

global mac_trip_flags
global mac_trip_states

```

3.18.6 pss

```

global pss_con pss_pot pss_mb_idx pss_exc_idx
global pss1 pss2 pss3 dpss1 dpss2 dpss3 pss_out
global pss_idx n_pss pss_sp_idx pss_p_idx;
global pss_T pss_T2 pss_T4 pss_T4_idx
global pss_noT4_idx % misspelled in pss_idx as pss_noT4

```

Despite the renaming of the `pss_noT4_idx`, it doesn't seem to actually be used anywhere.

3.18.7 pwr

```

global pwrmod_con n_pwrmod pwrmod_idx
global pwrmod_p_st dpwrmod_p_st
global pwrmod_q_st dpwrmod_q_st
global pwrmod_p_sig pwrmod_q_sig
global pwrmod_data

```

There are some cells that contain user defined derivatives that aren't included yet.

3.18.8 ncl

```

global load_con load_pot nload

```

3.18.9 sys

```
global basmva basrad syn_ref mach_ref sys_freq
```

3.18.10 svc

```
global svc_con n_svc svc_idx svc_pot svcll_idx
```

```
global svc_sig
```

```
% svc user defined damping controls
```

```
global n_dcud dcud_idx svc_dsig
```

```
global svc_dc % user damping controls?
```

```
global dxsvc_dc xsvc_dc
```

```
%states
```

```
global B_cv B_con
```

```
%dstates
```

```
global dB_cv dB_con
```

There seems to be some code related to user defined damping control of SVC, but it is not described in the user manual. (Added by Graham around 98/99)

3.18.11 tcsc

```
global tcsc_con n_tcsc tcsvf_idx tcsc_idx
```

```
global B_tcsc dB_tcsc
```

```
global tcsc_sig tcsc_dsig
```

```
global n_tcscud dtcscud_idx %user defined damping controls
```

```
% previous non-globals added as they seem to relavant
```

```
global xtcsc_dc dxtcsc_dc td_sig tcscf_idx
```

```
global tcsc_dc
```

Similar to the SVC, there seems to be some added functionality for controlled damping, but no examples exist? (Added by Graham around 98/99)

3.18.12 igen

```
%% induction genertaor variables - 19

global tmig pig qig vdig vqig idig iqig igen_con igen_pot
global igen_int igbus n_ig

%states

global vdpig vqpig slig

%dstates

global dvdpig dvqpig dslig

% added globals

global s_igen
```

3.18.13 ind

```
%% induction motor variables - 21

global tload t_init p_mot q_mot vdmot vqmot idmot iqmot ind_con ind_pot
global motbus ind_int mld_con n_mot t_mot

% states

global vdp vqp slip

% dstates

global dvdp dvqp dslip

% added globals

global s_mot

global sat_idx dbc_idx db_idx % has to do with version 2 of mac_ind

% changed all pmot to p_mot (mac_ind1 only)
```

Two models of this are included as `mac_ind1` (a basic version from 2.3), and `mac_ind2` which is an updated induction motor model. Default behavior is to use the newer model (`mac_ind2`).

3.18.14 dc

%% HVDC link variables

global dcsp_con dcl_con dcc_con

global r_idx i_idx n_dcl n_conv ac_bus rec_ac_bus inv_ac_bus

global inv_ac_line rec_ac_line ac_line dcli_idx

global tap tapr tapi tmax tmin tstep tmaxr tmaxi tminr tmini tstepr tstepi

global Vdc i_dc P_dc i_dcinj dc_pot alpha **gamma**

global VHT dc_sig cur_ord dcr_dsig dci_dsig

global ric_idx rpc_idx Vdc_ref dcc_pot

global no_cap_idx cap_idx no_ind_idx l_no_cap l_cap

global ndcr_ud ndci_ud dcrud_idx dciud_idx dcrd_sig dcid_sig

% States

%line

global i_dcr i_dci v_dcc

global di_dcr di_dci dv_dcc

global dc_dsig *% added 07/13/20 -thad*

%rectifier

global v_conr dv_conr

%inverter

global v_coni dv_coni

% added to global dc

global xdcr_dc dxdc_r_dc xdci_dc dxdc_i_dc angdcr angdci t_dc

global dcr_dc dci_dc *% damping control*

global ldc_idx

global rec_par inv_par line_par

Some DC related functions reused global variable names for local values but avoided conflict by not importing the specific globals. During global conversion this caused some issues with accidental casting to global and overwriting issues. While the non-linear and linear simulations run, there may be issues with this problem yet to be discovered.

3.18.15 bus

Contains `bus` and all altered bus arrays associated with faults created in `y_switch`. Also contains the `bus_v` and `theta` information related to buses.

3.18.16 line

Contains `line` and all altered line arrays associated with faults created in `y_switch`.

3.18.17 int

Contains reduced Y matrices, voltage recovery matrices, and bus order variables created in `y_switch` associated with faults. Example variables are shown below.

```
>> g.int
ans =
    Y_gprf: [4x4 double]
    Y_gncprf: [4x3 double]
    Y_ncgprf: [3x4 double]
    Y_ncprf: [3x3 double]
    V_rgprf: [10x4 double]
    V_rncprf: [10x3 double]
    bopr: [13x1 double]
    Y_gf: [4x4 double]
    Y_gncf: [4x3 double]
    Y_ncgf: [3x4 double]
    Y_ncf: [3x3 double]
    V_rgf: [10x4 double]
```

```

V_rncf: [10x3 double]
    bof: [13x1 double]
    Y_gpf1: [4x4 double]
Y_gncpf1: [4x3 double]
Y_ncgpf1: [3x4 double]
    Y_ncpf1: [3x3 double]
    V_rgpf1: [10x4 double]
V_rncpf1: [10x3 double]
    bopf1: [13x1 double]
    Y_gpf2: [4x4 double]
Y_gncpf2: [4x3 double]
Y_ncgpf2: [3x4 double]
    Y_ncpf2: [3x3 double]
    V_rgpf2: [10x4 double]
V_rncpf2: [10x3 double]
    bopf2: [13x1 double]

```

3.18.18 lmon

This contains variables for line monitoring not previously collected during simulation. An example of lmon contents is shown below.

```

>> g.lmon
ans =
    lmon_con: [3 10]
    n_lmon: 2
    busFromTo: [2x2 double]
    line: [1x2 struct]
>> g.lmon.line(1)
ans =

```



```

busArrayNdx: 3
    FromBus: 3
        ToBus: 4
            iFrom: [1x8751 double]
                iTo: [1x8751 double]
                    sFrom: [1x8751 double]
                        sTo: [1x8751 double]

```

3.18.19 area

This contains variables for area calculation and operation. An example of area variables are shown below.

```

>> g.area
ans =
    area_def: [13x2 double]
        n_area: 2
            area: [1x2 struct]
>> g.area.area(1)
ans =
    number: 1
    areaBuses: [7x1 double]
    macBus: [2x1 double]
    macBusNdx: [1 2]
    maxCapacity: 1800
    loadBus: [4x1 double]
    loadBusNdx: [3 4 5 10]
    genBus: [3x1 double]
    genBusNdx: [1 2 11]
    totH: [1x8751 double]

```

```
aveF: [1x8751 double]
totGen: [1x8751 double]
totLoad: []
icA: [1x8751 double]
icS: [1x8751 double]
exportLineNdx: []
importLineNdx: [11 12]
n_export: []
n_import: 2
```

3.18.20 agc

This contains variables for agc calculation and operation. An example of AGC variables are shown below

```
>> g.agc

ans =

    agc: [1x2 struct]
    n_agc: 2
>> g.agc.agc(1)

ans =

    area: 1
    startTime: 25
    actionTime: 15
    gain: 2
    Kiace: 3
    Btype: 1
    B: 1
    kBv: []
    condAce: []
    Kp: 0.0400
    a: 1.0000e-03
    ctrlGen_con: [2x3 double]
    n_ctrlGen: 2
    macBusNdx: [1 2]
    tgNdx: [1 2]
    ctrlGen: [1x2 struct]
    race: [1x8751 double]
    d_sace: [1x8751 double]
```

```
sace: [1x8751 double]
ace2dist: [1x8751 double]
iace: []
aceSig: -0.0144
iaceStartNdx: 8439
iaceN: 624
Bcalc: 18
nextActionTime: 130
```

3.18.21 k

To allow for functionalized running, various index values were placed into the global structure

```
global k_inc h ks h_sol
golbal k_incdc h_dc
```

3.18.22 vts

Globals associated with variable time step simulation runs were placed in the `g.vts` field.

```
dataN % used as a the data index for logging values
fsdn % a cell of fields, states, derivatives, and number of states
n_states % total system state count
dxVec % vector used to pass around current dataN derivatives
stVec % vector used to pass around current dataN states
t_block % a list of time blocks collected from sw_con
t_blockN % current time block being executed
iter % counter to monitor number of solutions per step
tot_iter % total number of solutions
slns % a running history of solution iterations
```

4 PST Operation Overview

This is likely to include a flow chart/ multiple flow charts.

Mention partitioned explicit method via Huen's, partitioned implicit via VTS.

Overview of running `s_simu` in batch or stand alone mode.

5 Examples Explained

As github as many examples, this is a chapter to explain what the purpose of them is and detail non-linear vs linear operation of examples that do such things.

- Experimental VTS
- AGC
- Extended term with VTS
- Hiskens NE model via Ryan
- MiniWECC via Dan
- Un-tripping
- Modulation via `_mod` files
- Linear simulation where applicable

6 Loose Ends

As software development is never actually over, this chapter is meant to contain any loose ends that felt relevant. The below is copied from the most recent weekly (09/02/20)

1. As infinite buses don't seem to be used in dynamic simulation, they were not converted to use the global `g`.
2. `tgh` model not converted for use with global `g`. (no examples of `tgh gov`)
3. In original (and current) `s_simu`, the global `tap` value associated with HVDC is overwritten with a value used to compute line current multiple times.
It probably shouldn't be.
4. Constant Power or Current loads seem to require a portion of constant Impedance.
5. PSS design functionality not explored
6. No examples of of delta P omega filter or user defined damping controls for SVC and TCSC models
7. Differences in `mac_ind` between pst 2 and 3 seem backward compatible - untested.
8. DC is not implemented in VTS - Just combine into main routine? Seems counter intuitive to do multi-rate variable time step integration.
9. AGC capacity should consider defined machine limits instead of assuming 1 PU max.
10. AGC should allow for a 'center of inertia' frequency option instead of the weighted average frequency.

7 Bibliography

- [1] Joe Chow, Graham Rogers, *Power System Toolbox Version 3.0 User Manual*, 2008.

8 Document History

It'd make sense if this turned into a table...

- 09/02/20 - 0.0.0-a.1 - document creation...
- 09/03/20 - 0.0.0-a.2 - Population with sections and some previously generated content

A Appendix A: Formatting Examples

This appendix is included to show how appendices work, blowing up of numbering, and to also serve as an easy L^AT_EX formatting template. Despite this being an appendix, it is still numbered like a chapter.

A.1 Numberings in Equations

Additionally, a reminder of Ohm's law

$$V = IR \tag{A.42}$$

shows that equation numbering has blown up. This is to show spacing on the table of contents.

A.2 Numberings in Tables

Table A.14 is full of nonsense data and is numbered artificially large.

Table A.14: Another Table.

One	Two	Three	Four	Five
2.35	45.87	9.00	1.00	0.33
5.88	48.01	7.85	2.35	0.45

A.3 Numberings in Figures

Finally, Figure A.67 shows how figure numbers look when double digit.



Figure A.67: A boxcat in its natural environment.

A.4 Code using Minted

Code can be added using the `minted` package. The example below is for a Python example, but can be configured other ways. Note that a `--shell-escape` command had to be added to the `TeXStudio` build command due to peculiarities with the package. Additionally, the `minted` `LaTeX` package requires python to be installed with the `pygments` package. This can be done via the `'py -m pip install -U pygments'` console command.

```

1  def sumPe(mirror):
2      """Returns sum of all electrical power from active machines"""
3      sysPe = 0.0
4
5      # for each area
6      for area in mirror.Area:
7          # reset current sum
8          area.cv['Pe'] = 0.0
9
10         # sum each active machine Pe to area agent
11         for mach in area.Machines:
12             if mach.cv['St'] == 1:
13                 area.cv['Pe'] += mach.cv['Pe']
14
15         # sum area agent totals to system
16         sysPe += area.cv['Pe']
17
18     return sysPe

```

Figure A.68: Code listing as a figure.

Other packages exist for code insertion, but they may or may not be as pretty. Remember, as with anything, this is totally optional and voluntary...