

Mercedes-Benz model 124 air conditioner (SA code 580) data stream

Lauri Lindholm

July 15, 2023

Contents

1	Disclaimer	2
2	What?	2
3	Packet format	3
3.1	0x00 – temperature setting dial, left INPUT	3
3.2	0x01 – temperature adjustment target, left INTERNAL . .	3
3.3	0x02 – temperature setting dial, right INPUT	3
3.4	0x03 – temperature adjustment target, right INTERNAL . .	3
3.5	0x04 – timer, self-calibration INTERNAL	4
3.6	0x05 – mixing chamber temperature, left INPUT	4
3.7	0x06 – mixing chamber temperature, right INPUT . . .	4
3.8	0x07 – interior air temperature INPUT	4
3.9	0x08 – exterior air temperature INPUT	5
3.10	0x09 – temperature control, left INTERNAL	5
3.11	0x0a – temperature control, right INTERNAL	5
3.12	0x0b – control bias, exterior air temperature INTERNAL . .	5
3.13	0x0c – heater drive, left INTERNAL	5
3.14	0x0d – heater drive, right INTERNAL	5
3.15	0x0e – heater feedback reference, left INTERNAL	6
3.16	0x0f – heater feedback reference, right INTERNAL . . .	6
3.17	0x10 – heating control bias, left, mid INTERNAL	6
3.18	0x11 – heating control bias, right, mid INTERNAL . . .	6
3.19	0x12 – water valve feedback bias, left INTERNAL	6
3.20	0x13 – water valve feedback bias, right INTERNAL . . .	6
3.21	0x14 – water valve solenoid duty cycle, left OUTPUT . .	6

3.22	0x15 – water valve solenoid duty cycle, right	OUTPUT . . .	6
3.23	0x16 – engine coolant temperature	INPUT	7
3.24	0x17 – evaporator temperature	INPUT	7
3.25	0x18 – engine overheat protection status	INTERNAL . . .	7
3.26	0x19 – interior temperature, dampened	INTERNAL . . .	7
3.27	0x1a – user input and intense cooling control	BITMASK . . .	7
3.28	0x1b – circulation timer	INTERNAL	9
3.29	0x1c – actuator control	BITMASK	9
3.30	0x1d – temperature control	BITMASK	10
3.31	0x1e – temperature dial value, dampened, left	INTERNAL . . .	11
3.32	0x1f – time, temperature dial damping, left	INTERNAL . . .	11
3.33	0x20 – temperature dial value, dampened, right	INTERNAL . . .	11
3.34	0x21 – time, temperature dial damping, right	INTERNAL . . .	12
3.35	0x22 – static 0x00	SYNC:INTERNAL	12
3.36	0x23 – static 0x03	SYNC:INTERNAL	12
3.37	0x24 – static 0x04	SYNC:INTERNAL	12
3.38	0x25 – static 0x01	SYNC:INTERNAL	12
3.39	0x26 – static 0x23	SYNC:INTERNAL	12
3.40	0x27 – static 0x02	SYNC:INTERNAL	12
3.41	0x28 – static 0x3b or 0x3c	SYNC:INTERNAL	12
4	Serial data electricals		12
5	Tested vehicles		13
5.1	Known not to work		13

1 Disclaimer

The information in this document is provided as is with no warranty of any kind. The information provided is based on reverse engineering efforts which means that its accuracy cannot be guaranteed.

2 What?

This document describes the format of the raw "actual value" data stream provided by some Mercedes-Benz model 124 air conditioning control modules.

So far it is to be figured out if only certain modules from certain manufacturers supply this stream, but it is known that not all of them do. It may

have been a diagnostic data experiment with the early digital control units or just for manufacturing stage function check.

The terminology used here may differ from the manufacturer's terminology.

See <https://github.com/the1stArchyx/mb124-ac-decoder> for the latest version of this document.

3 Packet format

A whole packet is made of individual 41 bytes. When capturing data all the way from switch-on, the control module will output 32 bytes of garbage before a consistent data packet is transmitted. The FTDI serial cable used during research may catch one or two bytes of 00 before actual data.

3.1 0x00 – temperature setting dial, left INPUT

This is a signed byte in range between -56 (0xc8, 14 °C) and +24 (0x18, 30 °C). The actual temperature value in °C can be calculated with the following formula:

$$\text{actual} = (\text{raw} + 126) / 5$$

This value indicates the user-requested temperature from the dial position on the control unit's panel. Due to mechanical reasons the temperature on the dial most likely will not match the control unit's value exactly.

3.2 0x01 – temperature adjustment target, left INTERNAL

This is a signed byte that indicates the temperature the control module is attempting to adjust to. It is biased by multiple factors, like both user-requested temperatures and the outside air temperature. For actual value, see 0x00 above.

3.3 0x02 – temperature setting dial, right INPUT

See 0x00 above.

3.4 0x03 – temperature adjustment target, right INTERNAL

See 0x01 above.

3.5 0x04 – timer, self-calibration

INTERNAL

Right after switching on ignition this counter counts from 120 (0x78) down to 0 once in about 10 minutes, ie. in 5 second steps. The counter appears to be used for timing some sort of self-calibration. During the calibration time the temperature control may seem erratic.

1. At 120 (10 min. left) — ignition was switched on, counter starts.
2. At 114 (30 s. after, 9 min. 30 s. left) — First self-calibration.
3. At 96 (2 min. after, 8 min. left) — Automatic air recirculation for intense cooling is enabled.
4. At 60 (5 min. after, 5 min. left) — Second self-calibration.
5. At 0 (10 min. after, timer ends) — Third self-calibration.

3.6 0x05 – mixing chamber temperature, left

INPUT

This unsigned byte ranges between 0 (10 °C) and 243 (0xf3, 70.75 °C). The actual value in °C can be calculated with the following formula:

$$\text{actual} = (\text{raw} + 40) / 4$$

The mixing chamber temperature affects the feedback loop for the water valve control.

In some terminology this may be inaccurately called heater core temperature.

3.7 0x06 – mixing chamber temperature, right

INPUT

See 0x05.

3.8 0x07 – interior air temperature

INPUT

This signed byte ranges between -128 (0x80, -0.4 °C) and +126 (0x7e, 50.4 °C). The actual value in °C can be obtained with the following formula:

$$\text{actual} = (\text{raw} + 126) / 5$$

3.9 0x08 – exterior air temperature **INPUT**

This signed byte ranges between -64 (0xc0, -32 °C) and 126 (0x7e, 63 °C). The formula for the actual value in °C is as follows:

$$\text{actual} = \text{raw} / 2$$

3.10 0x09 – temperature control, left **INTERNAL**

This signed byte is the difference of dampened interior temperature (see 0x19) and the temperature adjustment target of the respective side. It ranges between -128 (0x80, -25.6 °C) and +127 (0x7f, +25.4 °C). The actual value in °C can be calculated with the following formula:

$$\text{actual} = \text{raw} / 5$$

Negative values bias towards heating and positive values towards cooling. The effective range for heating control (see 0x0c) is from -50 (-10.0 °C) to +23 (+4.6 °C).

3.11 0x0a – temperature control, right **INTERNAL**

See 0x09 above.

3.12 0x0b – control bias, exterior air temperature **INTERNAL**

This signed byte reacts to change of exterior temperature. The math to its absolute value is not clear, yet. Based on logged data so far the range is from -45 to +34.

As with most other temperature control bias values, negative values bias towards heating and positive values towards cooling.

3.13 0x0c – heater drive, left **INTERNAL**

This unsigned byte ranges between 0 and 255 (0xff). It is used to drive the heating control. 0 calls for no heating and 255 for maximum heating. When the target temperature is reached, this value will balance around 80 (0x50).

Change of 1 unit (0.2 °C) of temperature differential control value affects this value directly about 3-4 units (0.75-1.00 °C).

3.14 0x0d – heater drive, right **INTERNAL**

See 0x0c.

3.15 0x0e – heater feedback reference, left INTERNAL

This value slowly follows the value of 0x0c. This value provides the temperature reference for the valve control feedback loop. The actual value in °C can be calculated with the following formula:

$$\text{actual} = \text{raw} / 4$$

3.16 0x0f – heater feedback reference, right INTERNAL

See 0x0e. This one follows the value of 0x0d instead.

3.17 0x10 – heating control bias, left, mid INTERNAL

This value follows the value of 0x0c with a dampening. It's not yet clear how this value affect the heating control.

3.18 0x11 – heating control bias, right, mid INTERNAL

See 0x10.

This value follows the value of 0x0d with a dampening.

3.19 0x12 – water valve feedback bias, left INTERNAL

This signed byte ranges between -128 (0x80) and +127 (0x7f). Negative values bias towards opening the valve (heating) and positive values bias towards closing the valve (cooling).

It's biased by the heater feedback reference (0x0e) and the mixing chamber temperature (0x05).

3.20 0x13 – water valve feedback bias, right INTERNAL

See 0x12. For this one the biasing values are from 0x0f and 0x06 instead.

3.21 0x14 – water valve solenoid duty cycle, left OUTPUT

This unsigned byte ranges between 0 (0%, valve closed) and 255 (0xff, 100%, valve open).

3.22 0x15 – water valve solenoid duty cycle, right OUTPUT

See 0x14.

3.23 0x16 – engine coolant temperature **INPUT**

This signed byte ranges between 5 and 127 (0x7f) within its functional range. If sensor circuit is shorted, the value will be fixed to -126 (0x82). Within the functional range the raw value is the actual value in °C as is.

Engine coolant temperature is used for prevention of overheating of the engine.

3.24 0x17 – evaporator temperature **INPUT**

This unsigned byte ranges between 0 (0 °C) and 126 (0x7e, 63 °C). This temperature value controls the air conditioner compressor request line. The actual value in °C is calculated with the following formula:

$$\text{actual} = \text{raw} / 2$$

The A/C compressor request turns on when this value is 14 (7 °C) or greater, and off when it falls to 10 (5 °C) or below. The compressor request line is routed through the refrigerant pressure switch to the compressor safety cut-out module.

3.25 0x18 – engine overheat protection status **INTERNAL**

This (most likely) unsigned byte is 0 in normal operation. If the engine coolant temperature sensor circuit is shorted, the value will be 190 (0xbe, -66 if signed). In overheat protection operation the value will count from 64 (0x40) to 103 (0x67).

Engine overheat protection is activated when the engine coolant temperature reaches 122 or above. Once activated, the protection switches off when engine coolant temperature goes down to 117 or below.

During overheat protection the AC compressor request is inhibited.

3.26 0x19 – interior temperature, dampened **INTERNAL**

See 0x07. This value follows the interior temperature sensor in a dampened manner. It is used for temperature control to avoid unnecessary sudden temperature changes.

3.27 0x1a – user input and intense cooling control BITMASK

3.27.1 0x1a bit 7 – unused

Appears to be static 0.

3.27.2 0x1a bit 6 – intense cooling mode **INTERNAL**

This bit is set when the control unit operates in intense cooling mode.

3.27.3 0x1a bit 5 – user intervention, temperature adjustment, right **INTERNAL**

This bit is set when the user is making a temperature adjustment. If the adjustment is larger than three units (0.6 °C), the control unit calculates a timer value for the requested temperature.

3.27.4 0x1a bit 4 - user intervention, mode change **INTERNAL**

This bit is briefly set when the user has made a mode change. Since the bit is typically set for a very short time, it is most often never seen to change state.

3.27.5 0x1a bit 3 – user intervention, temperature adjustment, left **INTERNAL**

See 0x1a bit 5.

3.27.6 0x1a bit 2 – button status: reheat **INPUT**

This bit indicates the status of reheat mode. When this bit is set, the red LED on the button is lit.

When this mode is enabled, the air conditioning compressor is requested whether cooling is needed or not. The primary use for this is to dry the interior air in case the moisture in the air tends to concentrate on the windscreen or other windows.

3.27.7 0x1a bit 1 – button status: economy mode (EC) **INPUT**

This bit indicates the status of economy mode. When this bit is set, the red LED on the button is lit.

When this mode is enabled, the air conditioning compressor request is inhibited and middle vents are set to bypass heating. Air recirculation is limited to five minutes at a time.

3.27.8 0x1a bit 0 – button status: recirculation **INPUT**

This bit indicates the status of manually requested interior air recirculation. When this bit is set, the red LED on the button is lit.

The requested recirculation is always 100% and is limited to 20 minutes with A/C enabled or 5 minutes in economy mode.

3.28 0x1b – circulation timer **INTERNAL**

This (expected to be) unsigned value contains the amount of minutes until air recirculation is automatically switched off to fresh air.

The countdown starts from 20 (0x14) when air conditioning compressor is enabled and 5 when air conditioning is inhibited.

3.29 0x1c – actuator control **BITMASK**

3.29.1 0x1c bit 7 – water circulation pump **OUTPUT**

This bit is set when the water circulation pump is running.

3.29.2 0x1c bit 6 – unused

Appears to be static 0.

3.29.3 0x1c bit 5 – unused

Appears to be static 0.

3.29.4 0x1c bit 4 – A/C compressor request **OUTPUT**

This bit is set when the A/C compressor request line is driven. The heater blower must be on for activation and economy mode (EC) must be off.

3.29.5 0x1c bit 3 – air recirculation, 80% **OUTPUT**

This bit is set when the vacuum valve for 80% air recirculation is driven.

3.29.6 0x1c bit 2 – air recirculation, 100% **OUTPUT**

This bit is set when the vacuum valve for 100% air recirculation is driven. Bit 3 is always set together with this one.

3.29.7 0x1c bit 1 – radiator blower, stage II **OUTPUT**

This bit is set when the relay for radiator blower stage II is driven. Radiator blower is switched on at engine coolant temperature sensor value 107 and off at 100.

Radiator blower stage I is controlled by a refrigerant pressure switch in the high pressure side of the circuit.

3.29.8 0x1c bit 0 – temp-control for middle dash vents **OUTPUT**

This bit is set when the vacuum valve for middle dash vents temperature control flaps is driven.

0 = temperature control bypassed
1 = middle vents temperature-controlled

When the middle vents are temperature-controlled, they can also be closed to "leak air" state by another vacuum actuator. However, there doesn't seem to be a bit indicating its status.

3.30 0x1d – temperature control **BITMASK**

3.30.1 0x1d bit 7 – recirculation enabled for intense cooling **INTERNAL**

This has been observed to be set two minutes after switching on ignition.

3.30.2 0x1d bit 6 – self-calibration **INTERNAL**

When set, the control unit is performing a self calibration. Water circulation pump is switched off during this time.

3.30.3 0x1d bit 5 – temperature control mode **INTERNAL**

0 = heating
1 = cooling

In the heating mode automatic A/C compressor request is suppressed.

3.30.4 0x1d bit 4 – unused

Appears to be static 1.

3.30.5 0x1d bit 3 - defrost, right INPUT

This bit is set when the temperature control dial is turned all the way to its hot end stop.

3.30.6 0x1d bit 2 - max cooling, right INPUT

This bit is set when the temperature control dial is turned all the way to its cold end stop.

3.30.7 0x1d bit 1 - defrost, left INPUT

See 0x1d bit 3

3.30.8 0x1d bit 0 - max cooling, right INPUT

See 0x1d bit 2

3.31 0x1e – temperature dial value, dampened, left INTERNAL

This value follows the value of temperature setting dial. The stepping speed to reach the value is defined by 0x1f in seconds in a manner that the target value is reached in about 5 minutes.

For minor changes up to 0.6 °C, or 3 raw units, the timer is not used.

For range, see 0x00.

3.32 0x1f – time, temperature dial damping, left INTERNAL

When active, this unsigned value ranges between 4 and 75 (0x4b). It's otherwise 0.

By observation this value is a time in seconds to advance the dampened temperature dial value towards the current user requested value.

The temperature change made must be over 0.6 °C, or 3 in raw value to trigger the timer. By minimum change of 0.8 °C the time value is set to 75 seconds, which results in the target being reached in $4 * 75 = 300$ seconds, or five minutes.

3.33 0x20 – temperature dial value, dampened, right INTERNAL

See 0x1e.

3.34 0x21 – time, temperature dial damping, rightINTERNAL

See 0x1f.

3.35 0x22 – static 0x00 SYNC:INTERNAL

This and the following six bytes have been used for data stream synchronisation. The actual meaning of these bytes is mostly unknown but they appear to be static data and therefore useful for easy sync.

3.36 0x23 – static 0x03 SYNC:INTERNAL

3.37 0x24 – static 0x04 SYNC:INTERNAL

3.38 0x25 – static 0x01 SYNC:INTERNAL

3.39 0x26 – static 0x23 SYNC:INTERNAL

Most likely a version number, possibly hardware revision identifier. The number is 35 in base 10.

3.40 0x27 – static 0x02 SYNC:INTERNAL

3.41 0x28 – static 0x3b or 0x3c SYNC:INTERNAL

Most likely a version number, possibly software. 59 (0x3b) has been seen on two cases and 60 (0x3c) on a newer car.

4 Serial data electricals

The serial data supplied from socket 7 of the diagnostics connector block is basically 8-N-1 at 4,800 bps with about 30 ms gaps between frames. The only major difference to RS-232 or TTL are the signal levels used. See the table below:

	RS-232	TTL	MB AC
mark	-15..-3 V	+5.0 V	+8.0 V
space	+3..+15 V	+0.0 V	+0.8 V

For research purposes the output from the vehicle was converted to TTL by means of a simple circuit of diodes and resistors to use an FTDI TTL-232R-5V "USB to TTL Serial Cable". This is what the initial datalogging and decoder programs written in Python were designed around.

5 Tested vehicles

The following vehicles were equipped with basic "Tempmatic" air conditioning, SA code 580.

- 124.092 – 320 TE (the original research platform)
- 124.191 – E 300 DIESEL (facelift; this was the exception that had 0x3c as the last sync byte instead of 0x3b)
- 124.193 – 300 TD TURBODIESEL

5.1 Known not to work

The following vehicle was equipped with fully automatic air conditioning, SA code 581.

- 124.131 – E 300 DIESEL (US version, SA code 494; facelift) – no data stream)