

Mercedes-Benz model 124 air conditioner (SA code 580) data stream

Lauri Lindholm

July 22, 2023

Contents

1	Disclaimer	2
2	What?	2
3	Packet format	3
3.1	0x00 – temperature setting dial, left INPUT	3
3.2	0x01 – temperature adjustment target, left INTERNAL . .	3
3.3	0x02 – temperature setting dial, right INPUT	3
3.4	0x03 – temperature adjustment target, right INTERNAL . .	3
3.5	0x04 – timer, self-calibration INTERNAL	4
3.6	0x05 – mixing chamber temperature, left INPUT	4
3.7	0x06 – mixing chamber temperature, right INPUT . . .	4
3.8	0x07 – interior air temperature INPUT	4
3.9	0x08 – exterior air temperature INPUT	5
3.10	0x09 – temperature control, left INTERNAL	5
3.11	0x0a – temperature control, right INTERNAL	5
3.12	0x0b – control bias, exterior air temperature INTERNAL . .	5
3.13	0x0c – heater drive, left INTERNAL	6
3.14	0x0d – heater drive, right INTERNAL	6
3.15	0x0e – heater feedback reference, left INTERNAL	6
3.16	0x0f – heater feedback reference, right INTERNAL . . .	6
3.17	0x10 – heating control bias, left, mid INTERNAL	6
3.18	0x11 – heating control bias, right, mid INTERNAL . . .	6
3.19	0x12 – water valve feedback bias, left INTERNAL	6
3.20	0x13 – water valve feedback bias, right INTERNAL . . .	7
3.21	0x14 – water valve solenoid duty cycle, left OUTPUT . .	7

3.22	0x15 – water valve solenoid duty cycle, right	OUTPUT . . .	7
3.23	0x16 – engine coolant temperature	INPUT	7
3.24	0x17 – evaporator temperature	INPUT	7
3.25	0x18 – engine overheat protection status	INTERNAL . . .	7
3.26	0x19 – interior temperature, dampened	INTERNAL . . .	8
3.27	0x1a – user input and intense cooling control	BITMASK . . .	8
3.28	0x1b – circulation timer	INTERNAL	9
3.29	0x1c – actuator control	BITMASK	9
3.30	0x1d – temperature control	BITMASK	10
3.31	0x1e – temperature dial value, dampened, left	INTERNAL . . .	12
3.32	0x1f – time, temperature dial damping, left	INTERNAL . . .	12
3.33	0x20 – temperature dial value, dampened, right	INTERNAL . . .	12
3.34	0x21 – time, temperature dial damping, right	INTERNAL . . .	12
3.35	0x22 – static 0x00	SYNC:INTERNAL	12
3.36	0x23 – static 0x03	SYNC:INTERNAL	13
3.37	0x24 – static 0x04	SYNC:INTERNAL	13
3.38	0x25 – static 0x01	SYNC:INTERNAL	13
3.39	0x26 – static 0x23	SYNC:INTERNAL	13
3.40	0x27 – static 0x02	SYNC:INTERNAL	13
3.41	0x28 – static 0x3b or 0x3c	SYNC:INTERNAL	13
4	Serial data electricals		13
5	Tested vehicles		13
5.1	Known not to work		14
6	Unfinished analysis notes		14
6.1	0x0b – exterior temperature bias		14

1 Disclaimer

The information in this document is provided as is with no warranty of any kind. The information provided is based on reverse engineering efforts which means that its accuracy cannot be guaranteed.

2 What?

This document describes the format of the raw "actual value" data stream provided by some Mercedes-Benz model 124 air conditioning control modules.

So far it is to be figured out if only certain modules from certain manufacturers supply this stream, but it is known that not all of them do. It may have been a diagnostic data experiment with the early digital control units or just for manufacturing stage function check.

The terminology used here may differ from the manufacturer's terminology.

See <https://github.com/the1stArchyx/mb124-ac-decoder> for the latest version of this document.

3 Packet format

A whole packet is made of individual 41 bytes. When capturing data all the way from switch-on, the control module will output 32 bytes of garbage before a consistent data packet is transmitted. The FTDI serial cable used during research may catch one or two bytes of 00 before actual data.

3.1 0x00 – temperature setting dial, left INPUT

This is a signed byte in range between -56 (0xc8, 14 °C) and +24 (0x18, 30 °C). The actual temperature value in °C can be calculated with the following formula:

$$\text{actual} = (\text{raw} + 126) / 5$$

This value indicates the user-requested temperature from the dial position on the control unit's panel. Due to mechanical reasons the temperature on the dial most likely will not match the control unit's value exactly.

3.2 0x01 – temperature adjustment target, left INTERNAL

This is a signed byte that indicates the temperature the control module is attempting to adjust to. It is biased by multiple factors, like both user-requested temperatures and the outside air temperature. For actual value, see 0x00 above.

3.3 0x02 – temperature setting dial, right INPUT

See 0x00 above.

3.4 0x03 – temperature adjustment target, right INTERNAL

See 0x01 above.

3.5 0x04 – timer, self-calibration

INTERNAL

Right after switching on ignition this counter counts from 120 (0x78) down to 0 once in about 10 minutes, ie. in 5 second steps. The counter appears to be used for timing some sort of self-calibration. During the calibration time the temperature control may seem erratic.

1. At 120 (10 min. left) — ignition was switched on, counter starts.
2. At 114 (30 s. after, 9 min. 30 s. left) — First self-calibration.
3. At 96 (2 min. after, 8 min. left) — Automatic air recirculation for intense cooling is enabled.
4. At 60 (5 min. after, 5 min. left) — Second self-calibration.
5. At 0 (10 min. after, timer ends) — Third self-calibration.

3.6 0x05 – mixing chamber temperature, left

INPUT

This unsigned byte ranges between 0 (10 °C) and 243 (0xf3, 70.75 °C). The actual value in °C can be calculated with the following formula:

$$\text{actual} = (\text{raw} + 40) / 4$$

The mixing chamber temperature affects the feedback loop for the water valve control.

In some terminology this may be inaccurately called heater core temperature.

3.7 0x06 – mixing chamber temperature, right

INPUT

See 0x05.

3.8 0x07 – interior air temperature

INPUT

This signed byte ranges between -128 (0x80, -0.4 °C) and +126 (0x7e, 50.4 °C). The actual value in °C can be obtained with the following formula:

$$\text{actual} = (\text{raw} + 126) / 5$$

3.9 0x08 – exterior air temperature

INPUT

This signed byte ranges between -64 (0xc0, -32 °C) and 126 (0x7e, 63 °C). The formula for the actual value in °C is as follows:

$$\text{actual} = \text{raw} / 2$$

3.10 0x09 – temperature control, left

INTERNAL

This signed byte is the difference of dampened interior temperature (see 0x19) and the temperature adjustment target of the respective side. It ranges between -128 (0x80, -25.6 °C) and +127 (0x7f, +25.4 °C). The actual value in °C can be calculated with the following formula:

$$\text{actual} = \text{raw} / 5$$

Negative values bias towards heating and positive values towards cooling. The effective range for heating control (see 0x0c) is from -50 (0xce, -10.0 °C) to +23 (0x17, +4.6 °C).

3.11 0x0a – temperature control, right

INTERNAL

See 0x09 above.

3.12 0x0b – control bias, exterior air temperature

INTERNAL

This signed byte reacts to change of exterior temperature and temperature dial values. The exact math to it is not fully known, yet. What is currently known is that...

1. a change of +1 (0.5 °C) exterior temperature affects the bias by +1. In many cases it has been observed that exterior temperature value 50 (25.0 °C) equal bias value 0.
2. setting the temperature of one side higher than the other causes a negative weighting on the bias value.
3. a change of +2 of the bias affects the adjustment targets by -1 (-0.2 °C). (By observation, the change of the least significant bit of the bias is irrelevant.)

Based on logged data so far the range appears to be from -45 to +34.

As with most other temperature control bias values, negative values bias towards heating and positive values towards cooling.

3.13 0x0c – heater drive, left **INTERNAL**

This unsigned byte ranges between 0 and 255 (0xff). It is used to drive the heating control. 0 calls for no heating and 255 for maximum heating. When the target temperature is reached, this value will balance around 80 (0x50).

Change of 1 unit (0.2 °C) of temperature differential control value affects this value directly about 3-4 units (0.75-1.00 °C).

3.14 0x0d – heater drive, right **INTERNAL**

See 0x0c.

3.15 0x0e – heater feedback reference, left **INTERNAL**

This value slowly follows the value of 0x0c. This value provides the temperature reference for the valve control feedback loop. The actual value in °C can be calculated with the following formula:

$$\text{actual} = \text{raw} / 4$$

3.16 0x0f – heater feedback reference, right **INTERNAL**

See 0x0e. This one follows the value of 0x0d instead.

3.17 0x10 – heating control bias, left, mid **INTERNAL**

This value follows the value of 0x0c with a dampening. It's not yet clear how this value affect the heating control.

3.18 0x11 – heating control bias, right, mid **INTERNAL**

See 0x10.

This value follows the value of 0x0d with a dampening.

3.19 0x12 – water valve feedback bias, left **INTERNAL**

This signed byte ranges between -128 (0x80) and +127 (0x7f). Negative values bias towards opening the valve (heating) and positive values bias towards closing the valve (cooling).

It's biased by the heater feedback reference (0x0e) and the mixing chamber temperature (0x05).

3.20 0x13 – water valve feedback bias, right INTERNAL

See 0x12. For this one the biasing values are from 0x0f and 0x06 instead.

3.21 0x14 – water valve solenoid duty cycle, left OUTPUT

This unsigned byte ranges between 0 (0%, valve closed) and 255 (0xff, 100%, valve open).

3.22 0x15 – water valve solenoid duty cycle, right OUTPUT

See 0x14.

3.23 0x16 – engine coolant temperature INPUT

This signed byte ranges between 5 and 127 (0x7f) within its functional range. If sensor circuit is shorted, the value will be fixed to -126 (0x82). Within the functional range the raw value is the actual value in °C as is.

Engine coolant temperature is used for prevention of overheating of the engine.

3.24 0x17 – evaporator temperature INPUT

This unsigned byte ranges between 0 (0 °C) and 126 (0x7e, 63 °C). This temperature value controls the air conditioner compressor request line. The actual value in °C is calculated with the following formula:

$$\text{actual} = \text{raw} / 2$$

The A/C compressor request turns on when this value is 14 (7 °C) or greater, and off when it falls to 10 (5 °C) or below. The compressor request line is routed through the refrigerant pressure switch to the compressor safety cut-out module.

3.25 0x18 – engine overheat protection status INTERNAL

This (most likely) unsigned byte is 0 in normal operation. If the engine coolant temperature sensor circuit is shorted, the value will be 190 (0xbe, -66 if signed). In overheat protection operation the value will count from 64 (0x40) to 103 (0x67).

Engine overheat protection is activated when the engine coolant temperature reaches 122 or above. Once activated, the protection switches off when engine coolant temperature goes down to 117 or below.

During overheat protection the AC compressor request is inhibited.

3.26 0x19 – interior temperature, dampened INTERNAL

See 0x07. This value follows the interior temperature sensor in a dampened manner. It is used for temperature control to avoid unnecessary sudden temperature changes.

3.27 0x1a – user input and intense cooling control BITMASK

3.27.1 0x1a bit 7 – unused

Appears to be static 0.

3.27.2 0x1a bit 6 – intense cooling mode INTERNAL

This bit is set when the control unit operates in intense cooling mode. The switching thresholds from control values 0x09 and 0x0a have been observed to be as follows:

- On when the control values are 17-18 (3.4-3.6 °C) or greater.
- Off when the contro values are 10-12 (2.0-2.4 °C) or less.

The currently available data captures cannot offer less fuzzy thresholds.

3.27.3 0x1a bit 5 – user intervention, temperature adjustment, right INTERNAL

This bit is set when the user is making a temperature adjustment. If the adjustment is larger than three units (0.6 °C), the control unit calculates a timer value for the requested temperature.

3.27.4 0x1a bit 4 - user intervention, mode change INTERNAL

This bit is briefly set when the user has made a mode change. Since the bit is typically set for a very short time, it is most often never seen to change state.

3.27.5 0x1a bit 3 – user intervention, temperature adjustment, left INTERNAL

See 0x1a bit 5.

3.27.6 0x1a bit 2 – button status: reheat **INPUT**

This bit indicates the status of reheat mode. When this bit is set, the red LED on the button is lit.

When this mode is enabled, the air conditioning compressor is requested whether cooling is needed or not. The primary use for this is to dry the interior air in case the moisture in the air tends to concentrate on the windscreen or other windows.

3.27.7 0x1a bit 1 – button status: economy mode (EC) **INPUT**

This bit indicates the status of economy mode. When this bit is set, the red LED on the button is lit.

When this mode is enabled, the air conditioning compressor request is inhibited and middle vents are set to bypass heating. Air recirculation is limited to five minutes at a time.

3.27.8 0x1a bit 0 – button status: recirculation **INPUT**

This bit indicates the status of manually requested interior air recirculation. When this bit is set, the red LED on the button is lit.

The requested recirculation is always 100% and is limited to 20 minutes with A/C enabled or 5 minutes in economy mode.

3.28 0x1b – circulation timer **INTERNAL**

This (expected to be) unsigned value contains the amount of minutes until air recirculation is automatically switched off to fresh air.

The countdown starts from 20 (0x14) when air conditioning compressor is enabled and 5 when air conditioning is inhibited.

3.29 0x1c – actuator control **BITMASK**

3.29.1 0x1c bit 7 – water circulation pump **OUTPUT**

This bit is set when the water circulation pump is running.

3.29.2 0x1c bit 6 – unused

Appears to be static 0.

3.29.3 0x1c bit 5 – unused

Appears to be static 0.

3.29.4 0x1c bit 4 – A/C compressor request OUTPUT

This bit is set when the A/C compressor request line is driven. The heater blower must be on for activation and economy mode (EC) must be off.

3.29.5 0x1c bit 3 – air recirculation, 80% OUTPUT

This bit is set when the vacuum valve for 80% air recirculation is driven.

3.29.6 0x1c bit 2 – air recirculation, 100% OUTPUT

This bit is set when the vacuum valve for 100% air recirculation is driven. Bit 3 is always set together with this one.

3.29.7 0x1c bit 1 – radiator blower, stage II OUTPUT

This bit is set when the relay for radiator blower stage II is driven. Radiator blower is switched on at engine coolant temperature sensor value 107 and off at 100.

Radiator blower stage I is controlled by a refrigerant pressure switch in the high pressure side of the circuit.

3.29.8 0x1c bit 0 – temp-control for middle dash vents OUTPUT

This bit is set when the vacuum valve for middle dash vents temperature control flaps is driven.

0 = temperature control bypassed

1 = middle vents temperature-controlled

When the middle vents are temperature-controlled, they can also be closed to "leak air" state by another vacuum actuator. However, there doesn't seem to be a bit indicating its status.

3.30 0x1d – temperature control BITMASK

3.30.1 0x1d bit 7 – recirculation enabled for intense cooling INTERNAL

This has been observed to be set two minutes after switching on ignition.

3.30.2 0x1d bit 6 – self-calibration **INTERNAL**

When set, the control unit is performing a self calibration. Water circulation pump is switched off during this time.

3.30.3 0x1d bit 5 – temperature control mode **INTERNAL**

If left and right control values (0x09 and 0x0a) are roughly the same, the temperature control switches to cooling when the values go above +3 (+0.6 °C) and heating when the values go below -8 (0xf8, -1.6 °C).

It has been observed that with a temperature setting difference of 1.0 °C both control values must go down to -8 before mode is switched to heating.

0 = heating

1 = cooling

In the heating mode automatic A/C compressor request is inhibited.

3.30.4 0x1d bit 4 – unused

Appears to be static 1.

3.30.5 0x1d bit 3 - defrost, right **INPUT**

This bit is set when the temperature control dial is turned all the way to its hot end stop.

3.30.6 0x1d bit 2 - max cooling, right **INPUT**

This bit is set when the temperature control dial is turned all the way to its cold end stop.

3.30.7 0x1d bit 1 - defrost, left **INPUT**

See 0x1d bit 3

3.30.8 0x1d bit 0 - max cooling, right **INPUT**

See 0x1d bit 2

3.31 0x1e – temperature dial value, dampened, left INTERNAL

This value follows the value of temperature setting dial. The stepping speed to reach the value is defined by 0x1f in seconds in a manner that the target value is reached in about 5 minutes.

For minor changes up to 0.6 °C, or 3 raw units, the timer is not used.

For range, see 0x00.

3.32 0x1f – time, temperature dial damping, left INTERNAL

When active, this unsigned value ranges between 4 and 75 (0x4b). It's otherwise 0.

By observation this value is a time in seconds to advance the dampened temperature dial value towards the current user requested value.

The temperature change made must be over 0.6 °C, or 3 in raw value to trigger the timer. By minimum change of 0.8 °C the time value is set to 75 seconds, which results in the target being reached in $4 * 75 = 300$ seconds, or five minutes.

3.33 0x20 – temperature dial value, dampened, rightINTERNAL

See 0x1e.

3.34 0x21 – time, temperature dial damping, rightINTERNAL

See 0x1f.

3.35 0x22 – static 0x00 SYNC:INTERNAL

This and the following six bytes have been used for data stream synchronisation. The actual meaning of these bytes is mostly unknown but they appear to be static data and therefore useful for easy sync.

5.1 Known not to work

The following vehicle was equipped with fully automatic air conditioning, SA code 581.

- 124.131 – E 300 DIESEL (US version, SA code 494; facelift) – no data stream)

6 Unfinished analysis notes

This section contains notes of observations that aren't necessarily definitive at this point. Some of it may be correct, but much will be incorrect guesses.

6.1 0x0b – exterior temperature bias

The value appears to bias temperature adjustment targets from actual dial values as well as water valve feedback control.

For water valve control the bias temperature seems to be `raw` / 5, but it needs to be verified.

The following observation appears to be correct only if both temperature dials are set at the same value! Whether the temperature control is functioning in heating or cooling mode may also skew the values. Self-calibration can also break logic, as two different data captures seem to show offsetting.

For adjustment targets the no bias spot is at -14/-15 (0xf2/0xf3). To calculate the amount to shift from user-requested temperature to adjustment target, use the following formula (`//` = integer division):

```
adjustment target bias = -1 * (((ext.temp bias + 1) // 2) + 7)
```

If you want the actual temperature difference value in °C, divide the above raw value by 5.