

AZTEC User Guide

The Analyzer of Zero-emission Transportation Energy and Costs (AZTEC) model is an upgraded version of the ICCT's first fleet-level total cost of ownership (TCO) tool, the Toolkit for Urban Bus Operations (TURBO).

Table of Contents

- [Introduction](#)
- [Model Inputs](#)
 - [Overview](#)
 - [General Structure](#)
 - [Example Activity Input](#)
 - [Example Service Lifetime Input](#)
 - [Interpolation](#)
 - [Default inputs](#)
 - [Required inputs](#)
 - [Optional inputs](#)
 - [Energy units](#)
- [Modules](#)
 - [Fleet Turnover](#)
 - [Fleet Growth](#)
 - [Survival Curves](#)
 - [Emissions](#)
 - [GHG Emissions](#)
 - [Transmission and Distribution Losses](#)
 - [Other Air Pollutants](#)
 - [PM_{2.5} Speciation](#)
 - [Total Cost of Ownership](#)
 - [Vehicle/Component](#)
 - [Vehicle/component financing and costs](#)

- Vehicle/component costs, age-specific
- Vehicle/component depreciation
- Vehicle-level costs
- Infrastructure
 - Infrastructure base-year stock
 - Infrastructure purchases
 - Infrastructure financing and costs
 - Infrastructure costs, annual
 - Infrastructure costs, age-specific
 - Infrastructure depreciation
- Energy
 - Energy usage share
 - Energy costs
- Revenue
 - Revenue
- Taxes and subsidies
 - Taxes and subsidies
- Stakeholders
 - Stakeholders
- Cost and activity discounting
 - Discount rate
- Run Settings
- Outputs
- Appendix
 - Retrofits

Introduction

The AZTEC model supports the technical analysis of vehicle fleets in two key areas:

1. Fleet level emissions modeling

- Annual air pollutant and GHG emissions by vehicle type, powertrain technology, and fuel type for user defined procurement pathways
- Evaluate scale and pace of emissions changes resulting from fleet technology transitions
- Route level energy demand modeling

- *Example application: Evaluation of São Paulo Climate Change Law*

2. Fleet level TCO assessment

- Comparative assessment of the TCO of conventional and alternative fleet technologies and fuels
- *Example application: TCO assessments for São Paulo and Johannesburg*

Model Inputs

Inputs to AZTEC are defined in the configuration file. These inputs define how the model should be run, including what data to use, which modules to include, and basic run settings.

This section outlines what inputs are required, what detail they should have, and what are the default options.

Overview

AZTEC comes with a few default inputs, but most of the required data sets are specific to the region of analysis. Each input data set is expected to follow a common format and be saved as a .csv file. All inputs should be self-descriptive, and to help enforce this they are required to have a *Variable* or *Parameter* column, as well as a *Unit* column. Below are a couple examples of data inputs.

General Structure

Data inputs will contain a subset of these standard columns:

Column	Example Values	Description
Scenario	"Baseline", "Scen 1"	The name of the scenario.
Region	"IND", "Bangalore"	The region of analysis.
Route	"Route 1", "51A"	Used to distinguish between multiple routes within a single region.
Vehicle	"Single Bus 12 M", "Articulated"	The types of vehicles in your current or projected fleet. Vehicle names can be

Column	Example Values	Description
		arbitrary, but must remain consistent across all inputs.
Technology	"diesel", "EV", "hybrid", "CNG"	The engine powertrain technology. Any value is accepted, but default PM_{2.5} speciation profiles are only provided for gasoline, diesel, biodiesel, ethanol, and CNG vehicles.
Control	"Euro V", "BEV", "EV_324kWh"	The emissions control technology used by the engine. Any value is accepted, but default PM_{2.5} speciation profiles are only provided for "Euro 0" through "Euro VI".
Fuel	"B20", "CNG", "electricity", "diesel"	Specific fuel type used by the vehicle. Fuels must match values in <code>fuel_shares</code> and <code>ghg_emission_rates</code> inputs.
Component	"Battery", "Other Components"	Constituent part of vehicle. May be purchased, financed, and sold independently of vehicle.
Replacement	"0", "1", "2"	0 for original component, 1 for first replacement, 2 for second replacement, etc.
InfrastructureType	"Fast Charging Station", "Fuel Station"	Infrastructure used to deliver energy to vehicle fleet.
CostTier	"Tier 1", "Tier 2"	Different tiers for energy costs, to capture, e.g., different energy prices at different times of day.

Two important points about the data requirements:

1. Units are automatically checked before running. Required units are shown in the tables below.
2. Two different years are used in AZTEC: calendar year (CY), i.e., the year the action, cost, or payment occurs; and model year (MY), i.e. the year the object entered the

fleet. To eliminate the possibility of confusion, only CY data should be pivoted wide (i.e. provided as additional columns).

Example Activity Input

The *Region* column is required for most variables. Average annual vehicle activity per vehicle (km/yr/vehicle) can be specified for the whole fleet by leaving out the *Vehicle* column.

Note: The ellipsis '...' in the following table indicates that columns could be added for additional years; however, '...' is not a valid column name or value.

Region	Variable	Unit	Vehicle	2018	2019	...	2030
Bangalore	Activity	km/yr/vehicle	Midi	70000	70000	...	70000
Bangalore	Activity	km/yr/vehicle	Standard	70000	70000	...	70000

Example Service Lifetime Input

Some variables are not temporal. In this case, the column containing the values should be called *Value*.

Region	Variable	Unit	Vehicle	Value
Bangalore	Vehicle service lifetime	Year	Midi	12
Bangalore	Vehicle service lifetime	Year	Standard	12

More examples can be found in AZTEC's `example/inputs/` directory.

Interpolation

For many inputs, AZTEC interpolates between missing years, allowing for smaller and clearer input tables. Missing values are generally filled in with a basic linear interpolation. While there cannot be missing values for the base year, missing future years are forward filled from the last existing value.

As an example, consider a scenario where projected sales for *standard* type buses switch from Euro V to Euro VI in 2023, then steadily switch to BEB until 2028.

This input could look as follows:

Region	Variable	Unit	Vehicle	Technology	Control	2020	202
São Paulo	Sales	vehicle	standard	diesel	Euro V	500	50
São Paulo	Sales	vehicle	standard	diesel	Euro VI	0	
São Paulo	Sales	vehicle	standard	electricity	BEB	0	

The above table is interpreted by AZTEC identically to the following table:

Region	Variable	Unit	Vehicle	Technology	Control	2020	202
São Paulo	Sales	vehicle	standard	diesel	Euro V	500	50
São Paulo	Sales	vehicle	standard	diesel	Euro VI	0	
São Paulo	Sales	vehicle	standard	electricity	BEB	0	

These input files will not be interpolated. So, users must specify them for all years and ages, where relevant.

- Stock
- Transmission loss
- ISO map
- PM profiles
- Projections
- Survival curves
- Infrastructure base year stock
- Vehicle service lifetime
- Stakeholders

These input files will have missing calendar years filled in with a linear interpolation where possible. Additionally, the last provided value will be forward filled to all future years.

- Sales

- Activity
- Energy intensity
- Fuel shares
- Grid mix
- Emission factors
- GHG emission rates
- GHG electric generation
- Infrastructure annual costs
- Vehicle-level costs
- Energy costs
- Energy usage share
- Revenue
- Taxes and subsidies

These input files are specially interpolated.

- Infrastructure purchases: Forward filled by calendar year, including for missing intermediate years.
- (Vehicle/component and Infrastructure) financing and costs: "Cost", "Incentive", and "Down payment" are linearly interpolated by model year (MY), and all other parameters are forward filled. For the vehicle/component financing and costs, "Useful lifetime" is also backfilled to the earliest MY present in the base-year stock, so that we have information about when those components will need replacing.
- (Vehicle/component and Infrastructure) age-specific costs: Linearly by calendar year AND age.
- (Vehicle/component and Infrastructure) depreciation: Linearly by age.

Default inputs

The variables below provide default values that are used in the emissions calculations unless specific inputs are provided by the user. To overwrite or add to the default inputs, just include the custom values as an input in the configuration file. For example, GHG emission intensities for a specific fuel can be added/overwritten by including the input `ghg_emission_rates = my_fuel_ghg_efs.csv` in the configuration file.

Note that although the default versions of `ghg_emission_rates` and `ghg_electric_generation` are not annual (i.e., they do not vary across years), user inputs that override these defaults may optionally have a "CY" column or specify the years wide.

See [Energy units](#) for more information about what units are supported if you wish to overwrite these defaults.

Variable Name	Units	Columns	Description
ghg_emission_rates	g/mmBTU	Region, Fuel, [years]	WTT, TTW, and WTW emission factors of CO ₂ , CH ₄ , and N ₂ O. Defaults for 18 fuels are taken from AFLEET .
ghg_electric_generation	g/mmBTU	Region, Electricity_source, [years]	WTW emission rates of CO ₂ , CH ₄ , and N ₂ O per unit of electricity generation by source (power plant type), before transmission and distribution losses are considered.
transmission_loss	g/mmBTU	Region, [year]	Electricity transmission and distribution losses (see Transmission Loss).
pm_profiles	share	Technology, Control, Value	PM _{2.5} speciation profiles for BC and OC (see PM_{2.5}).

Required inputs

AZTEC's three modules – Fleet Turnover, Emissions, and Total Cost of Ownership (TCO) – are not independent. Emissions requires Fleet Turnover to be run, and TCO requires that both Fleet Turnover and Emissions be run. The *Module* column in the table below specifies for which module(s) the following inputs are required.

Note: All inputs are required to have the columns Variable and Unit.

Variable Name	Units	Columns	Module	Description
stock	vehicle	Vehicle, Technology, Control, Age, [baseline year]	Fleet Turnover, Emissions	Number of vehicles in the base year fleet.
activity	km/yr/vehicle	Vehicle (optional), [years]	Emissions, TCO	Average annual vehicle activity per vehicle for each year. If <i>Vehicle</i> column is not given, the inputs provided are applied to all vehicle types.
sales	vehicle, share	Vehicle, Technology, Control, [years]	Fleet Turnover	Number of vehicles sold by year or share of vehicles sold <i>within</i> each vehicle type.
energy_intensity	See Energy units	Vehicle, Technology, Control, [baseline year]	Emissions, TCO	Energy intensity by vehicle type, technology, and control level.
fuel_shares	share	Technology, Fuel, [years]	Fleet Turnover, Emissions	Share of each fuel consumed by a given vehicle technology.

Variable Name	Units	Columns	Module	Description
<code>service_lifetime</code>	year	Vehicle (optional), Value	All	Fixed-length lifetime of the vehicle (may differ from lifetimes of components within the vehicle). Required if <code>turnover_method</code> is "service_lifetime" (see Fleet Turnover), or if TCO is enabled.
all TCO inputs except <code>stakeholders</code>	mixed	mixed	TCO	TCO inputs. See TCO .

Optional inputs

Variable Name	Units	Columns	Description
<code>emission_factors</code>	g/km	Vehicle, Technology, Control, [years]	Air pollutant emission factors
<code>grid_mix</code>	share	Region, Electricity_source	Share of electricity generation by power plant type. This is required for scenarios where electricity is a fuel. If local grid distribution data is not available, country-level generation mixes can be sourced from the IEA (see GHG Emissions).
<code>iso_map</code>	unitless	Region, ISO	Map of modeled regions to standard ISO codes,

Variable Name	Units	Columns	Description
			to look up default transmission loss data. Required if grid mix provided.
<code>projections</code>	vehicle	Vehicle (optional), [years]	Projected total stock. Required if <code>growth_method</code> is "projected" (see Fleet Turnover).
<code>survival_curves</code>	unitless	tm, km	Parameters for survival curves. Required if <code>turnover_method</code> is "survival_curve" (see Survival Curves).
<code>stakeholders</code>	unitless	Vehicle (optional), FinanceModule, CostStakeholder, RevenueStakeholder	Assigns different stakeholders (e.g., Transit Authority) to different cash flows (see Stakeholders).

Energy units

All inputs which concern quantities related to energy (e.g, energy intensity, emissions factors, energy costs) support automatic unit conversion to MJ from the following units:

- kWh
- DLE
- GLE
- mmBTU
- m3 (for natural gas)
- kg (for hydrogen)

All energy-related outputs report in MJ.

Modules

Fleet Turnover

One of the core features of AZTEC is projecting fleet turnover. The vehicle fleet at a given year is a function of three inputs:

- **Purchases** - how many new vehicles are sold
- **Growth** - how much the total fleet grows
- **Retirements** - how many vehicles are retired from the fleet

Any of these three factors can be calculated from the other two. AZTEC supports the following:

Configuration	Required Inputs	Description
<code>growth_method = projected , purchase_method = scheduled</code>	<ul style="list-style-type: none">• <code>sales</code>• <code>projections</code>	This configuration is modeling a scheduled vehicle procurement plan. The <code>sales</code> input gives the number of vehicles purchased by year. Oldest vehicles are retired first, such that <code>Retirements = Purchases + Growth</code> , where fleet growth is the number of vehicles specified by <code>projections</code> .
<code>growth_method = constant , purchase_method = scheduled</code>	<ul style="list-style-type: none">• <code>sales</code>	This configuration is the same as above, but keeping the fleet size constant rather than projecting growth. Since growth is constant, <code>Retirements = Purchases</code> .
<code>growth_method = projected , turnover_method = service_lifetime</code>	<ul style="list-style-type: none">• <code>sales</code> (shares)• <code>projections</code>• <code>service_lifetime</code>	For this configuration, <code>sales</code> is the share of purchases by technology type and does not determine total sales. To calculate absolute sales, first retirements are determined from the service lifetime and the age distribution of the fleet.

Configuration	Required Inputs	Description
		Then, purchases are calculated as $\text{Purchases} = \text{Retirements} + \text{Growth}$.
<pre>growth_method = constant, turnover_method = service_lifetime</pre>	<ul style="list-style-type: none"> <code>sales</code> (shares) <code>service_lifetime</code> 	This configuration is the same as above, but keeping the fleet size constant rather than projecting growth. Retirements are calculated in the same way, then $\text{Purchases} = \text{Retirements}$.
<pre>growth_method = projected, turnover_method = survival_curves</pre>	<ul style="list-style-type: none"> <code>sales</code> (shares) <code>projections</code> <code>survival_curves</code> 	Turnover is calculated similarly to using the <code>service_lifetime</code> turnover method, but using a survival curve function to retire vehicles.
<pre>growth_method = constant, turnover_method = survival_curves</pre>	<ul style="list-style-type: none"> <code>sales</code> (shares) <code>projections</code> 	This configuration is the same as above, but keeping the fleet size constant rather than projecting growth.

Fleet Growth

To model a projected change in either the number of vehicles of a specific type or the total number in the fleet, make sure that both `growth_method` is set to `projected` and that the input `projections` is given. The `projections` input should point to a file containing number of vehicles by vehicle type (optional) and year (required). Any number of years can be given; intermediate years are linearly interpolated.

Survival Curves

Retiring vehicles using survival curves is best suited for modeling the natural retirement of vehicles. This is more applicable for private vehicles than public bus fleets, and is generally DISCOURAGED.

The survival curve used in AZTEC is based on the survival function of a Weibull distribution. There are two distribution parameters that we use to define the curves:

- **Tm**: The scale parameter of the Weibull distribution

- **Km:** The shape (steepness) parameter of the Weibull distribution

For more details on this methodology see [Hao et al., 2011](#).

Emissions

GHG Emissions

Greenhouse gas emissions are calculated for each year with the formula:

$$\text{emissions} = \text{stock} * \text{activity} * \text{energy intensity} * \text{emission factor}$$

Emission factors for greenhouse gases are fuel specific and take into account fuel lifecycle (WTW) emissions, whereas emission factors for other air pollutants are distance/technology specific and cover only TTW emissions. Default values for many fuels are provided by the AFLEET model and include both WTT and TTW emissions.

To use the AFLEET defaults, all fuels specified in the `fuel_shares` input must match one of the following:

- canola-based BD100
- canola-based RDII 100
- diesel
- corn oil-based BD100
- palm FFB-based RDII 100
- soybean-based BD100
- soybean-based RDII 100
- tallow-based BD100
- CNG
- CNG shale
- H2 central plants
- H2 refueling electrolysis
- H2 refueling natural gas
- gasoline
- LNG animal waste
- LNG wastewater
- LNG LFG
- LNG conventional

Note: Land-use change emissions are not included in the AFLEET defaults.

GHG emissions from electricity production are also sourced from the AFLEET model. The emissions, in g/mmBTU, are given for 5 power plant types (oil, natural gas, coal, biomass, nuclear) and "other", which can be used for renewable sources. The user-defined input `grid_mix` defines the share of generation by power plant type. These values can be found on the IEA's public [Data and statistics](#) website (Data browser --> Topic: Energy supply, Indicator: Electricity generation by source).

Transmission and Distribution Losses

The default values for electricity transmission and distribution losses are from the IEA's public [Data and statistics](#) website. Currently default values are provided most countries and a few larger regions, but users will need to update the default file for smaller regions such as cities if they have higher resolution data. To use the default country-level data, users must map their custom regions to standard ISO codes with the `iso_map` input. Transmission and distribution losses are calculated as electricity losses (Losses) divided by total electricity production (Total production).

Other Air Pollutants

Air pollutant emissions are calculated for each year with the formula:

$$\text{emissions} = \text{stock} * \text{activity} * \text{emission factor}$$

The stock data for all years following the base year are the results of the fleet turnover calculations. Activity data are required inputs, and are either linearly interpolated between multiple input years or assumed to remain constant after the base year.

Unless specific emission factors are provided, BC and OC are [calculated from PM_{2.5} emissions](#).

PM_{2.5} Speciation

Unless BC and OC emission factors are specified by the user, they are calculated from PM_{2.5} using speciation profiles. Default speciation profiles are from US EPA's MOVES2014 model ([EPA 2014, MOVES2014 speciation](#), Table C-1), however alternative values can be given with the `pm_profiles` input. Speciation is only done if either BC or OC is missing from the emission factor inputs; if just one is provided, it is not used. Default PM_{2.5} speciation is done for the following vehicle technologies and control levels:

- Vehicle technologies: gasoline, diesel, biodiesel, ethanol, CNG

- Control levels: Euro 0, Euro I, Euro II, Euro III, Euro IV, Euro V, Euro VI

Total Cost of Ownership

The total cost of ownership (TCO) module calculates the costs of vehicle acquisition, maintenance, and operation for each bus type in the fleet. To enable this module, set the input `use_tco` equal to `True`.

For the TCO calculations, AZTEC relies on activity, energy intensity, fleet, and emissions information from the earlier two modules. The other TCO inputs must be specified separately in the following files. All TCO inputs are required and must be specified for every vehicle type.

In general, all costs should be provided in real, not nominal, terms. If it is strictly necessary for your project to use nominal inputs, please make sure you have applied your inflation rate consistently to all inputs, and provide the [discount rate](#) in nominal terms as well.

Vehicle/Component

Vehicles may be specified by their individual components (e.g., chassis, battery, motor, etc.) or for the whole vehicle. The following inputs contain information about costs and parameters of and related to vehicles or vehicle components.

Note that replacement components are not able to change operational parameters about the vehicle, e.g., energy efficiency or emissions intensity. For help modeling retrofits that you expect to alter vehicle performance, please see the [retrofits](#) section.

Vehicle/component financing and costs

- **Contents:** The anticipated costs and financing structure and details for a specific component (or the full vehicle).
- **Please Exclude:** Monthly payments, this input is specifically for annualized or lump sum elements
- **Example:** `example/inputs/tco/vehicle_component_costs.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, Component, Replacement, MY, Parameter, Unit, Value
- **Interpolation:** For these, "Cost", "Incentive", and "Down payment" are linearly interpolated by MY, and all other parameters are forward filled. For the vehicle/component financing and costs, "Useful lifetime" is also backfilled to the earliest MY present in the base-year stock, so that we have information about when those components will need replacing.

- Parameters included in file:

Parameter	Allowable Units	Description
Useful lifetime	Years	Expected length of time a particular vehicle component will be in use. If component useful lifetime exceeds remaining vehicle service lifetime, the component will be sold when the vehicle retires.
Cost	Currency (\$)	Expected total component cost. The sticker price of the component
Incentive	Currency (\$)	Any incentives (rebates, discounts) that will be applied to the purchase price directly
Down payment	Currency (\$)	Upfront payment applied to the principal
Finance model	Type	Method for payment of the remaining principal (cost less incentive less down payment): Loan, Lease, or Cash
Interest rate	Percentage	(Loans only) Annually accruing interest rate
Number of years	Years	(Leases and loans only) Length of the lease or loan term
Number of grace years	Years	(Loans only) Years in which payments (on principal, interest or both) are temporarily suspended. Should be zero if Grace type = 0, and should be a positive integer if Grace type = 1 or 2
Grace type	Type	(Loans only) 0 – no grace period 1 – grace period for interest only 2 – grace period for interest and principal
Payment per period	Currency (\$)	(Leases only) Annual lease payment amount

For any vehicles or components still in the fleet at the end of the analysis period, any outstanding loan balances will be paid off and they will be sold at their depreciated value. For clarity, the resulting cash flows will be reported in the following year.

Vehicle/component costs, age-specific

- **Contents:** Any costs for vehicles/components that depend on age
- **Please Exclude:** age-independent costs, which may be specified in vehicle-level costs
- **Example:** `example/inputs/tco/vehicle_component_costs_age_specific.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, Component, Replacement, Age, CY (wide or long), Parameter, Unit, Value
- **Interpolation:** Linearly, by calendar year and age
- **Parameters included in file:**

Parameter	Allowable Units	Description
Age-specific variable cost	\$/km	Variable (activity-dependent) costs that vary with age
Age-specific fixed cost	\$/vehicle	Fixed (activity-independent) costs that vary with age

Vehicle/component depreciation

- **Contents:** The expected depreciation schedule of a vehicle or component
- **Please Exclude:**
- **Example:** `example/inputs/tco/vehicle_component_depreciation.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, Component, Replacement, Age, Parameter, Unit, Value
- **Interpolation:** Linearly by age
- **Parameters included in file:**

Parameter	Allowable Units	Description
Depreciation	Percentage (%)	Annual depreciation, always referenced to the original cost

Vehicle-level costs

- **Contents:** Any additional vehicle level costs for operation and maintenance
- **Please Exclude:** Age-specific costs
- **Example:** `example/inputs/tco/vehicle_level_costs.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, CY (wide or long), Parameter, Unit, Value
- **Interpolation:** Linearly by calendar year
- **Parameters included in file:**

Parameter	Allowable Units	Description
Driver payment	\$/vehicle	Annual salary for drivers
Conductor payment	\$/vehicle	Annual salary for conductors
Other staff payment	\$/vehicle	Other staff related annual costs
Other fixed costs	\$/vehicle	Other miscellaneous fixed vehicle costs
Maintenance and other variable costs	\$/km	Maintenance and other related costs that depend on activity
Opportunity Cost	\$/vehicle	The opportunity cost of investment in a vehicle

Infrastructure

The AZTEC model allows users to configure and build a full fleet of infrastructure to supply energy to their fleet of vehicles.

Infrastructure base-year stock

- **Contents:** The expected stock of infrastructure units at the start of the model
- **Please Exclude:** Component useful lifetime (which should be in infrastructure costs)
- **Example:** `example/inputs/tco/infrastructure_base_year_stock.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, InfrastructureType, Age, CY (wide or long), Parameter, Unit, Value, Stock
- **Interpolation:** None
- **Parameters included in file:**

Parameter	Allowable Units	Description
Stock	number	Number of infrastructure units already online at the start of the analysis period

Infrastructure purchases

- **Contents:** The expected purchase schedule of infrastructure units
- **Please Exclude:** infrastructure purchased prior to the study period (should be listed instead in infrastructure base year stock)
- **Example:** `example/inputs/tco/infrastructure_purchases.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, InfrastructureType, CY (wide or long), Parameter, Unit, Value
- **Interpolation:** Forward filled by calendar year
- **Parameters included in file:**

Parameter	Allowable Units	Description
Purchases	number	The number of unit purchases of infrastructure

Infrastructure financing and costs

- **Contents:** The anticipated costs and financing structure and details for a specific infrastructure element
- **Please Exclude:** Monthly payments, this input is specifically for annualized or lump sum elements
- **Example:** `example/inputs/tco/infrastructure_costs.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, InfrastructureType, MY, Parameter, Unit, Value
- **Interpolation:** For these, "Cost", "Incentive", and "Down payment" are linearly interpolated by MY, and all other parameters are forward filled.
- **Parameters included in file:**

Parameter	Allowable Units	Description
Cost	Currency (\$)	Expected total infrastructure cost. The sticker price of the infrastructure

Parameter	Allowable Units	Description
Incentive	Currency (\$)	Any incentives (rebates, discounts) that will be applied to the purchase price directly
Down payment	Currency (\$)	Upfront payment applied to the principal
Finance model	Type	Method for payment of the remaining principal (cost less incentive less down payment): Loan, Lease, or Cash
Interest rate	Percentage	(Loans only) Annually accruing interest rate
Number of years	Years	(Leases and loans only) Length of the lease or loan term
Number of grace years	Years	(Loans only) Years in which payments (on principal, interest or both) are temporarily suspended. Should be zero if Grace type = 0, and should be a positive integer if Grace type = 1 or 2
Grace type	Type	(Loans only) 0 – no grace period 1 – grace period for interest only 2 – grace period for interest and principal
Payment per period	Currency (\$)	(Leases only) Annual lease payment amount

Note that if any infrastructure installations still have outstanding loan balances at the end of the analysis period, they will be paid off and reported as a capital cost (for clarity) in the following year.

Infrastructure costs, annual

- **Contents:** Operating expenses for infrastructure that recur annually
- **Please Exclude:** Any costs that vary with age (those should be specified instead in age-specific infrastructure costs below)
- **Example:** `example/inputs/tco/infrastructure_annual_costs.csv`

- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, InfrastructureType, CY (wide or long), Parameter, Unit, Value
- **Interpolation:** Linearly by calendar year
- **Parameters included in file:**

Parameter	Allowable Units	Description
Annual variable cost	Currency/energy (see Energy units)	Annual variable (dependent on energy use) costs
Annual fixed cost	Currency/infrastructure unit (\$/station)	Annual fixed (independent of energy use) costs

Infrastructure costs, age-specific

- **Contents:** Any costs for infrastructure that depend on age
- **Please Exclude:** Age-independent annual costs
- **Example:** `example/inputs/tco/infrastructure_costs_age_specific.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, InfrastructureType, Age, CY (wide or long), Parameter, Unit, Value
- **Interpolation:** Linearly by calendar year and by age
- **Parameters included in file:**

Parameter	Allowable Units	Description
Age-specific variable cost	Currency/energy (see Energy units)	Annual variable (dependent on energy use) costs that vary with age
Age-specific fixed cost	Currency/infrastructure unit (\$/station)	Annual fixed (independent of energy use) costs that vary with age

Infrastructure depreciation

- **Contents:** The expected depreciation schedule of the infrastructure
- **Please Exclude:**
- **Example:** `example/inputs/tco/infrastructure_depreciation.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, InfrastructureType, Age, Parameter, Unit, Value
- **Interpolation:** Linearly by age

- **Parameters included in file:**

Parameter	Allowable Units	Description
Depreciation	Percentage (%)	Depreciation in value by percentage of infrastructure components given a certain age

Energy

The energy related input CSVs are an area to define any tiered or station specific energy use rates.

Energy usage share

- **Contents:** The expected usage share of a vehicle-related infrastructure technology
- **Please Exclude:** Any vehicle/infrastructure stock related items, this input is for usage, not relative availability
- **Example:** `example/inputs/tco/energy_usage_share.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, InfrastructureType, CY (wide or long), Parameter, Unit, Value,
- **Interpolation:** Linearly by CY
- **Parameters included in file:**

Parameter	Allowable Units	Description
Usage share	Share (fraction)	The related usage share of the infrastructure technology

Energy costs

- **Contents:** The expected costs of using a vehicle-related infrastructure technology
- **Please Exclude:** Any vehicle/infrastructure stock related items, this input is for usage, not relative availability
- **Example:** `example/inputs/tco/energy_costs.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, InfrastructureType, Age, CY (wide or long), Parameter, Unit, Value, CostTier
- **Interpolation:** Linearly by calendar year
- **Parameters included in file:**

Parameter	Allowable Units	Description
Usage share of tier	Share (fraction)	The related usage share of the infrastructure technology at a certain cost tier. For example: if 40% of all charging comes from fast chargers, and 80% of the energy drawn by fast chargers is consumed during hours with Tier 1 pricing, the percent of total energy which comes from fast chargers at Cost Tier 1 is $0.40 * 0.80 = 32\%$.
Cost	Currency per unit energy (see Energy units)	The cost per unit energy of using the infrastructure technology. May vary between cost tiers.
Additional charge	Currency (\$)	Any flat additional charges associated with usage

Revenue

Revenue

- **Contents:** The expected usage share of a vehicle-related infrastructure technology
- **Please Exclude:** Any vehicle/infrastructure stock related items, this input is for usage, not relative availability
- **Example:** `example/inputs/tco/revenue.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, CY (wide or long), Parameter, Unit, Value
- **Interpolation:** Linearly by calendar year
- **Parameters included in file:**

Parameter	Allowable Units	Description
Load factor	Passengers or cargo per vehicle (p/veh or t/veh)	Average amount of passengers or cargo on the vehicle
Fare	Currency per Passenger-Distance or Cargo-Distance (\$/pkm or /tkm)	The cost of transporting one passenger (or one ton of cargo) one kilometer

Taxes and subsidies

Taxes and subsidies

- **Contents:** Taxes paid and subsidies earned
- **Please Exclude:** Revenue from fares
- **Example:** `example/inputs/tco/taxes_and_subsidies.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, CY (wide or long), Parameter, Unit, Value
- **Interpolation:** Linearly by calendar year
- **Parameters included in file:**

Parameter	Unit	Description
<Emission> tax	\$/tonne	e.g., "GHG GWP20 tax".
Flat tax/subsidy	\$	Flat amount applied every year.
Purchase tax/subsidy	\$/vehicle	Applied only in year of purchase.
Annual vehicle tax/subsidy	\$/vehicle	Applied every year.
Mileage tax/subsidy	\$/km	Applied based on vehicle mileage.
Activity tax/subsidy	\$ / p-km or \$ / ton-km	Applied based on product of mileage and load factor.
Energy tax/subsidy	\$ / DLE, \$ / MJ, etc.	Applied per unit of energy consumed.

There are some taxes that reference TTW emissions, and others that reference WTW emissions.

Valid TTW emission taxes are: "CO2 tax", "NOx tax", "PM tax", "BC tax", "CO tax", "HC tax", "NH3 tax", "OC tax", "PN tax", "SO2 tax".

Valid WTW emission taxes are: "GHG GWP20 tax", "GHG GWP100 tax".

Stakeholders

The stakeholder input is designed to let users assign different stakeholders (e.g., Transit Authority, Private Operator, Battery Owner, etc.) to different cash flows. The file is organized by finance module and parameter, which are described below.

For each value in the FinanceModule column, "All" may be specified in the Parameter column to indicate that the user wishes to assign those stakeholders to all relevant parameters in that finance module. The bracket notation means that you can specify any value from that column in the relevant input; for example, <Component> means you may specify any value present in the Component column, like 'Battery' or 'Other Components'.

Stakeholders

- **Contents:** Cost and revenue stakeholders for different cash flows
- **Please Exclude:**
- **Example:** `example/inputs/tco/stakeholders.csv`
- **Valid columns:** Scenario, Region, Route, Vehicle, Technology, Control, FinanceModule, Parameter, Share, CostStakeholder, RevenueStakeholder
- **Interpolation:** None
- **Parameters included in file:**

Finance Module	Possible parameters	Description
Component capital costs	<Component>	Stakeholders for CAPEX of specific components
Component annual costs	<Component>	Stakeholders for OPEX of specific components
Vehicle-level costs	Driver payment, Conductor payment, Other staff payment, Other fixed costs, Maintenance and other variable costs, Opportunity cost	Stakeholders for different types of vehicle-level costs (Vehicle/Technology columns allow you to vary these assignments across vehicle types)
Revenue	Fare	Stakeholders for earned revenue; 'Fare' is only acceptable parameter
Infrastructure capital costs	<InfrastructureType>	Stakeholders for CAPEX of specific types of infrastructure
Infrastructure annual costs	<InfrastructureType>	Stakeholders for OPEX of specific types of infrastructure

Finance Module	Possible parameters	Description
Energy costs	<InfrastructureType>	Stakeholders for energy costs associated with specific types of infrastructure
Taxes and subsidies	<Emission> tax, Flat tax/subsidy, Purchase tax/subsidy, Annual vehicle tax/subsidy, Mileage tax/subsidy, Activity tax/subsidy, Energy tax/subsidy	Stakeholders for different taxes and subsidies

Cost and activity discounting

Final summary outputs are provided in un-discounted and discounted terms. In order to perform cost and activity discounting, a discount rate is required.

Discount rate

- **Contents:** The discount rate (in real terms, unless you provided nominal cost inputs)
- **Please Exclude:**
- **Example:** `example/inputs/tco/discount_rate.csv`
- **Valid columns:** CY (wide or long), Parameter, Unit, Value
- **Interpolation:** Linearly by calendar year
- **Parameters included in file:**

Parameter	Allowable Units	Description
Discount rate	%	Percentage by which future costs are discounted

Run Settings

These inputs define the scope of the analysis and must be specified in the `Settings` section of the configuration file.

Variable Name	Description
<code>scenario</code>	The name of the scenario.
<code>region</code>	The region of analysis.
<code>base_year</code>	The base year for which stock data are provided. All required temporal inputs should have this year as a column.
<code>end_year</code>	The last year of analysis (inclusive).
<code>data_dir</code>	Path to the directory where the inputs will be read from.
<code>output_dir</code>	Path to the directory where the outputs will be written.
<code>log_level</code>	Level of detail in the output log (<i>turbo.log</i>). Set to <code>debug</code> for the most detail, <code>info</code> for regular reporting, <code>warning</code> for only warnings, and <code>error</code> for no output except errors.
<code>growth_method</code>	Fleet growth method for fleet turnover calculations. One of <code>constant</code> , <code>projected</code> or <code>None</code> .
<code>purchase_method</code>	Method for purchasing new vehicles for fleet turnover calculations. One of <code>scheduled</code> or <code>None</code> .
<code>turnover_method</code>	Method for retiring vehicles for fleet turnover calculations. One of <code>service_lifetime</code> , <code>survival_curves</code> or <code>None</code> .
<code>fleet</code>	Run the Fleet Turnover module? <code>True</code> or <code>False</code> .
<code>emissions</code>	Run the Emissions module? <code>True</code> or <code>False</code> .
<code>use_tco</code>	Run the Total Cost of Ownership module? <code>True</code> or <code>False</code> .
<code>use_stakeholders</code>	Are you supplying a cost/revenue stakeholder map? <code>True</code> or <code>False</code> .
<code>export_detailed_tco</code>	Would you like to report detailed costs (broken down by MY/Age in addition to CY)? <code>True</code> or <code>False</code> .

Outputs

Model outputs are written out to the directory specified by the configuration's `output_dir` setting. The outputs from each module are listed below.

Fleet:

- `fleet.csv` : turned-over fleet showing annual breakdown of Stock, Purchases, and Retirements by Technology, Age, etc.

Emissions:

- `energy_use.csv` : estimated energy consumption
- `emissions.csv` : local pollutant and greenhouse gas emissions
- `ghg_efs.csv` : the `g/km` equivalents of the `g/mmBTU` emission factors specified for GHG pollutants

TCO:

- `component_costs.csv` : capital and operating expenses for components
- `vehicle_costs.csv` : vehicle-level cost payments
- `infrastructure_costs.csv` : same as `component_costs` , but for infrastructure
- `energy_costs.csv` : costs incurred to procure energy
- `revenue.csv` : revenue earned.
- `taxes_and_subsidies.csv` : taxes paid and subsidies earned
- `combined_costs` : combination of costs from all other TCO outputs
- `tco_summary.csv` : combined costs aggregated by Stakeholder and CY, with cost discounting applied

If [Stakeholders](#) are provided, they will be attached to all TCO outputs. If

`export_detailed_tco` is set to `True` , all TCO outputs will also have a `MY` column.

Appendix

Retrofits

A scheme for modeling retrofits that alter operational parameters of the vehicle (e.g., emission factor, load factor, energy efficiency, etc.) is described below.

- Vehicles that will be retrofitted need to be separated out from vehicles that will not be retrofitted. In the "Vehicle" column in the base stock, these could be called "standard_AC" and "standard_AC_to_be_retrofitted", e.g. They should have identical operational parameters.
- However, the vehicle service lifetime of the "standard_AC_to_be_retrofitted" should be decreased so that the vehicles "retire" at the time of the retrofit. Make sure that the depreciation schedule on these vehicles (and any components they contain) is

sufficiently quick such that they have zero residual value (i.e., net depreciation = 100%) at the time of retirement (since they aren't actually taken off the road or sold in the real world).

- In the input files, a new vehicle category called something like "standard_AC_with_retrofit" should be introduced, and it should have its stock projection set to the number of buses that will have been retrofitted in a given year (should start at zero if there are no retrofitted vehicles in the base fleet). Or, if a sales schedule is specified, the sales of "standard_AC_with_retrofit" would be used to define the times at which the "standard_AC_to_be_retrofitted" are retrofitted. Either way, the rate of introduction of "standard_AC_with_retrofit" should match the rate of retirement of "standard_AC_to_be_retrofitted".
- The changes in operational parameters should be reflected in different values between "standard_AC_with_retrofit" and "standard_AC_to_be_retrofitted" in the relevant input files, like emission factors, load factor, energy efficiency, etc.
- The "standard_AC_with_retrofit" should have zero cost associated with vehicle components that are retained from the vehicle before the retrofit, e.g. vehicle body. Its only capital costs should be related to whatever component is installed as a retrofit.
- To get the TCO of retrofitted vehicles over their lifetime, the costs from the "standard_AC_to_be_retrofitted" and "standard_AC_with_retrofit" vehicle categories should be combined.