

One Finger Gestures

Gesture	Action
Touch or move around the screen	Speaks and select the item under your finger
Tap 2 times fast	Activate the selected item. (open app, press button)
Tap 2 times and hold	Activates "drag-mode" (move icons, swipe-delete)
Tap 3 times fast	Double presses a button (see tip below)
Swipe left or right	Selects the previous or next item
Swipe up or down	Preforms or move to the selected rotor option
Note: Tap 2 times on the clock in status bar to scroll to top in any app.	

Two Finger Gestures

Gesture	Action
Hold 1 finger & tap with another	Select when dragging, activate with tap (aka split-tap)
Tap once	Pause/resume speech
Tap 2 times fast	Preforms special action
Tap 2 times and hold	Add label to selected item
Tap 3 times	Open Item Chooser for current area
Swipe up	Read all from first object in selected area
Swipe down	Read all from selected item
Scrub back and forth	Go back, cancel, close pop-up
Pinch out/in	Select/deselect
Hold and twist left or right	Select the next or previous rotor item
Note: You can use the scrub gesture to split/merge keyboard when it's selected	

Three Finger Gestures

Gesture	Action
Tap once	Speaks the current page number and position
Tap 2 times fast	Toggle speech on/off (good for braille use)
Tap 3 times fast	Toggle screen curtain on/off (VO works but screen is off)
Swipe left or right	Move to previous or next horizontal screen/page
Swipe up or down	Move/scroll down or up (like moving a paper)

Note: To open notification center select the status bar and swipe 3 fingers down. Also 3 fingers up/down works for pulling down to refresh in many apps.

Four and Five Finger Gestures

Gesture	Action
Tap the upper half with 4 fingers	Select the first item in the area
Tap the lower half with 4 fingers	Select the last item in the area
Swipe left or right	When in an app, switch to next or previous app
Swipe up or down	Open or close multitask pane
Pinch in	Go to home screen