

Configuration options and common use cases

Pieter P

Configuration options

The code is very flexible and can be used in many different ways by changing the configuration options in `main.cpp:Config`. The settings are all compile-time constants, resulting in more efficient code and allowing for useful error messages when some options conflict or are invalid.

```

90 // ----- Configuration ----- //
91
92 // Enable MIDI input/output.
93 #define WITH_MIDI 0
94 // Print to the Serial monitor instead of sending actual MIDI messages.
95 #define MIDI_DEBUG 0
96
97 struct Config {
98     // Print the control loop and interrupt frequencies to Serial at startup:
99     static constexpr bool print_frequencies = true;
100     // Print the setpoint, actual position and control signal to Serial.
101     // Note that this slows down the control loop significantly, it probably
102     // won't work if you are using more than one fader without increasing
103     // `interrupt_divisor`:
104     static constexpr bool print_controller_signals = false;
105     static constexpr uint8_t controller_to_print = 0;
106     // Follow the test reference trajectory (true) or receive the target
107     // position over I²C or Serial (false):
108     static constexpr bool test_reference = false;
109     // Increase this divisor to slow down the test reference:
110     static constexpr uint8_t test_reference_speed_div = 4;
111     // Allow control for tuning and starting experiments over Serial:
112     static constexpr bool serial_control = true;
113     // I²C slave address (zero to disable I²C):
114     static constexpr uint8_t i2c_address = 8;
115     // The baud rate to use for the Serial interface (e.g. for MIDI_DEBUG,
116     // print_controller_signals, serial_control, etc.)
117     static constexpr uint32_t serial_baud_rate = 1000000;
118     // The baud rate to use for MIDI over Serial.
119     // Use 31'250 for MIDI over 5-pin DIN, HIDUINO/USBMidiKlik.
120     // Hairless MIDI uses 115'200 by default.
121     // The included python/SerialMIDI.py script uses 1'000'000.
122     static constexpr uint32_t midi_baud_rate = serial_baud_rate;
123
124     // Number of faders, must be between 1 and 4:
125     static constexpr size_t num_faders = 1;
126     // Actually drive the motors. If set to false, runs all code as normal, but
127     // doesn't turn on the motors.
128     static constexpr bool enable_controller = true;
129     // Use analog pins (A0, A1, A6, A7) instead of (A0, A1, A2, A3), useful for
130     // saving digital pins on an Arduino Nano:
131     static constexpr bool use_A6_A7 = false;
132     // Use pin A2 instead of D13 as the motor driver pin for the fourth fader.
133     // Allows D13 to be used as overrun indicator, and avoids issues with the
134     // bootloader blinking the LED.
135     // Can only be used if `use_A6_A7` is set to true.
136     static constexpr bool fader_3_A2 = false;
137
138     // Capacitive touch sensing RC time threshold.
139     // Increase this time constant if the capacitive touch sense is too
140     // sensitive or decrease it if it's not sensitive enough:
141     static constexpr float touch_rc_time_threshold = 150e-6; // seconds
142     // Bit masks of the touch pins (must be on port B):
143     static constexpr uint8_t touch_masks[] = {1 << PB0, 1 << PB1, 1 << PB2,
144                                               1 << PB4};
145
146     // Use phase-correct PWM (true) or fast PWM (false), this determines the
147     // timer interrupt frequency, prefer phase-correct PWM with prescaler 1 on
148     // 16 MHz boards, and fast PWM with prescaler 1 on 8 MHz boards, both result
149     // in a PWM and interrupt frequency of 31.250 kHz
150     // (fast PWM is twice as fast):
151     static constexpr bool phase_correct_pwm = true;
152     // The fader position will be sampled once per `interrupt_divisor` timer
153     // interrupts, this determines the sampling frequency of the control loop.
154     // Some examples include 20 → 320 µs, 30 → 480 µs, 60 → 960 µs,
155     // 90 → 1,440 µs, 124 → 2,016 µs, 188 → 3,008 µs, 250 → 4,000 µs.
156     // 60 is the default, because it works with four faders. If you only use
157     // a single fader, you can go as low as 20 because you only need a quarter
158     // of the computations and ADC time:
159     static constexpr uint8_t interrupt_divisor = 60 / (1 + phase_correct_pwm);
160     // The prescaler for the timer, affects PWM and control loop frequencies:
161     static constexpr unsigned prescaler_fac = 1;
162     // The prescaler for the ADC, affects speed of analog readings:
163     static constexpr uint8_t adc_prescaler_fac = 64;
164
165     // Turn off the motor after this many seconds of inactivity:
166     static constexpr float timeout = 2;
167
168     // EMA filter factor for fader position filters:
169     static constexpr uint8_t adc_ema_K = 2;
170     // SMA filter length for setpoint filters, improves tracking of ramps if the
171     // setpoint changes in steps (e.g. when the DAW only updates the reference
172     // every 20 ms). Powers of two are significantly faster (e.g. 32 works well):
173     static constexpr uint8_t setpoint_sma_length = 0;
174
175     // ----- Computed Quantities ----- //
176
177     // Sampling time of control loop:
178     constexpr static float Ts = 1. * prescaler_fac * interrupt_divisor * 256 *
179         (1 + phase_correct_pwm) / F_CPU;
180     // Frequency at which the interrupt fires:
181     constexpr static float interrupt_freq =
182         1. * F_CPU / prescaler_fac / 256 / (1 + phase_correct_pwm);
183     // Clock speed of the ADC:

```

```

184     constexpr static float adc_clock_freq = 1. * F_CPU / adc_prescaler_fac;
185     // Pulse pin D13 if the control loop took too long:
186     constexpr static bool enable_overnrun_indicator =
187         num_faders < 4 || fader_3_A2;
188
189     static_assert(0 < num_faders && num_faders <= 4,
190         "At most four faders supported");
191     static_assert(use_A6_A7 || !fader_3_A2,
192         "Cannot use A2 for motor driver "
193         "and analog input at the same time");
194     static_assert(!WITH_MIDI || !serial_control,
195         "Cannot use MIDI and Serial control at the same time");
196     static_assert(!WITH_MIDI || !print_controller_signals,
197         "Cannot use MIDI while printing controller signals");
198 };

```

Use cases

Control over I²C

This is the default configuration that is enabled out of the box. It allows another Arduino to read the position and the touch status of each fader, and to update the setpoint of each controller. Communication happens over I²C, and the message format is explained [here](#). You can have multiple motor drivers on the same bus by giving them different addresses, using the `i2c_address` option.

The included example [MIDI-Controller.ino](#) uses this mode, and it can be used as a reference implementation for sending and receiving the right messages.

Control over Serial


The `serial_control` option is also enabled by default. It allows you to use the included [Python/Tuning.py](#) script to change the tuning of the controllers on the fly, and to log and plot their behavior.

See [PID Tuning](#) and [Architecture: Communication](#) for more details.

Quick test to verify that everything is working

Setting `test_reference = true` will result in the fader tracking a test sequence, as shown in the [demo video](#).

If you also set `print_controller_signals = true`, you can open the serial plotter (**Ctrl+Shift+L**) at the correct baud rate (`serial_baud_rate = 1000000` by default), and view the reference position, the actual fader position, and the control output, as shown in the figure below.



The `controller_to_print` option specifies the (zero-based) index of the fader to print/plot the data for.

Direct MIDI control

Although the ATmega328P doesn't have native USB support, it does support MIDI over Serial. After changing the `WITH_MIDI` macro to `1` and setting `serial_control = false`, you can send MIDI Pitch Bend messages to the serial port of the motor controller to

change the setpoints of the controllers. Fader touch changes are reported back using MIDI Note On/Off messages, and while touched, the fader positions are sent as MIDI Pitch Bend messages.

In this mode, you can use the included [Python/SerialMIDI.py](#) script to test whether the MIDI communication works correctly. Instructions are at the top of the script (in particular, make sure that the serial port and baud rate are correct).

To use the motor controller directly with 5-pin MIDI or with custom USB MIDI firmware, you have to select the correct MIDI baud rate: set `midi_baud_rate = 31250`.

If you plan to use a software Serial-to-MIDI bridge, you'll have to select an appropriate baud rate as well. For example, for Hairless MIDI, set `midi_baud_rate = 115200`.

Debugging direct MIDI control

The binary MIDI messages can be annoying to debug sometimes, so in addition to the `WITH_MIDI = 1` option described in the previous section, you can also set `MIDI_DEBUG` to `1` to make the motor controller send the MIDI messages as readable text. If you open the serial monitor at the correct baud rate (`serial_baud_rate`), you'll see messages similar to the following when touching and moving the fader:

Note On	Channel: 1	Data 1: 0x68	Data 2: 0x7f
Pitch Bend	Channel: 1	Data 1: 0x30	Data 2: 0x00 (48)
Pitch Bend	Channel: 1	Data 1: 0x40	Data 2: 0x00 (64)
Pitch Bend	Channel: 1	Data 1: 0x50	Data 2: 0x00 (80)
Pitch Bend	Channel: 1	Data 1: 0x60	Data 2: 0x00 (96)
Note Off	Channel: 1	Data 1: 0x68	Data 2: 0x7f

You can also change the setpoint of the faders from the serial monitor. The format is `Ei ll hh` (hexadecimal), where `i` is the zero-based index of the fader (0-3), `ll` are the seven low bits of the 14-bit setpoint, and `hh` are the seven high bits of the setpoint. For example, typing `E0 00 40` into the serial monitor and pressing enter causes the first fader to move to the middle position. For subsequent setpoint changes to the same fader, you don't have to repeat the first byte (`Ei`), and the spaces between the bytes are optional. For example, first sending `E00040` moves the first fader to the middle position, and then sending `7F7F` moves the same fader to the highest position.

Improved pin assignments for Arduino Nano

The Arduino Nano has additional analog inputs A6 and A7. You can use these instead of A2 and A3 to make room for two more digital inputs. To this end, set `use_A6_A7 = true`. You can then use pin A2 for driving the fourth fader by setting `fader_3_A2 = true`, thereby freeing up pin D13 and the built-in LED. See also [Hardware: Connections](#).