

PSBE 10000 series: register list for devices with KE firmware from V3.02 (check the installed version in your device's MENU in item INFO HW, SW)																	
Modbus address (dec)	Modbus address (hex)	Read coils (0x01)	Read holding registers (0x03)	Write single coil (0x05)	Write single register (0x06)	Write multiple registers (0x10)	Description	Access	Data type	Data length in bytes	Number of registers	Data	Example	Profibus slot	Profibus Index	Profinet Index (hex)	EtherCAT SDO/PDO?
0	0x0000	x					Device class	R	uint(16)	2	1		See programming guide in section "A"	1	0	0x0100	x
1	0x0001						Device type	R	char	40	20	ASCII	PSBE 10080-1000	1	1	0x0101	x
21	0x0015						Manufacturer	R	char	40	20	ASCII		1	2	0x0102	x
41	0x0029						Manufacturer address	R	char	40	20	ASCII		1	3	0x0103	x
61	0x003D						Manufacturer ZIP code	R	char	40	20	ASCII		1	4	0x0104	x
81	0x0051						Manufacturer phone number	R	char	40	20	ASCII		1	5	0x0105	x
101	0x0065						Manufacturer website	R	char	40	20	ASCII		1	6	0x0106	x
121	0x0079						Nominal voltage	R	float	4	2	Floating point number IEEE754	80	1	7	0x0107	x
123	0x007B						Nominal current	R	float	4	2	Floating point number IEEE754	1000	1	8	0x0108	x
125	0x007D						Nominal power	R	float	4	2	Floating point number IEEE754	30000	1	9	0x0109	x
131	0x0083						Article no.	R	char	40	20	ASCII	30000841	1	12	0x010C	x
151	0x0097						Serial no.	R	char	40	20	ASCII	1234560001	1	13	0x010D	x
171	0x00AB				x		User text	RW	char	40	20	ASCII		1	14	0x010E	x
191	0x00BF						Firmware version (KE)	R	char	40	20	ASCII		1	15	0x010F	x
211	0x00D3						Firmware version (HM)	R	char	40	20	ASCII		1	16	0x0110	x
231	0x00E7						Firmware version (DR)	R	char	40	20	ASCII		1	17	0x0111	x
402	0x0192	x		x			Remote mode	RW	uint(16)	2	1	Coil : Remote	0x0000 = off; 0x0FF0 = on	2	1	0x0200	x
405	0x0195	x		x			DC output/input	RW	uint(16)	2	1	Coil : Output/input	0x0000 = off; 0x0FF0 = on	2	4	0x0203	x
407	0x0197	x					Condition of DC output/input after power fail alarm	RW	uint(16)	2	1	Coil : Auto-On	0x0000 = off; 0x0FF0 = auto	3	30	0x031C	x
408	0x0198		x		x		Condition of DC output/input after powering the device	RW	uint(16)	2	1	Reg : Power-On	0x0FFF = off; 0x0FFE = restore	2	6	0x0205	x
410	0x019A						Restart of the device (warm start)	W	uint(16)	2	1	Coil : Restart	0x0FF0 = execute	2	8	0x0207	x
411	0x019B				x		Acknowledge alarms	W	uint(16)	2	1	Coil : Alarms	0x0FF0 = acknowledge	2	9	0x0208	x
416	0x01AD	x		x			Analog interface: Reference voltage (pin VREF)	RW	uint(16)	2	1	Coil : VREF	0x0000 = 10V; 0x0FF0 = 5V	2	14	0x020D	x
417	0x01A1	x		x			Analog interface: REM-SB level	RW	uint(16)	2	1	Coil : REM-SB Level	0x0000 = normal; 0x0FF0 = inverted	2	36	0x0223	x
418	0x01A2				x		Analog interface: REM-SB action	RW	uint(16)	2	1	Coil : REM-SB Action	0x0000 = off; 0x0FF0 = auto	2	37	0x0224	x
425	0x01A9				x		Condition of DC output/input after leaving remote	RW	uint(16)	2	1	Coil : Condition	0x0000 = off; 0x0FF0 = unchanged	2	42	0x0229	x
427	0x01AB		x		x		Voltage Controller Speed	RW	uint(16)	2	1	Level	0x0000 = Normal (default); 0x0001 = Slow; 0x0002 = Fast;	2	60	0x023B	x
428	0x01AC		x		x		SEMI F47	RW	uint(16)	2	1	On/Off	0x0000 = off; 0x0001 = on;	2	61	0x023C	x
432	0x01B0	x		x			Reset device to factory settings	RW	uint(16)	2	1	Coil : Condition	0x0FF0 = Trigger reset	2	43	0x022A	x
440	0x01B8				x		Analog interface: Pin 14 configuration	RW	uint(16)	2	1	Alarms 1	0x0000 = OVP (default); 0x0001 = OCP; 0x0002 = OPP; 0x0003 = OVP + OCP; 0x0004 = OVP + OPP; 0x0005 = OCP + OPP; 0x0006 = OVP + OCP + OPP	2	44	0x022B	x
441	0x01B9																
441	0x01B9		x		x		Analog interface: Pin 6 configuration	RW	uint(16)	2	1	Alarms 2	0x0000 = OT + PF (default); 0x0001 = OT; 0x0002 = PF	2	45	0x022C	x
442	0x01BA				x		Analog interface: Pin 15 configuration	RW	uint(16)	2	1	Status DC / reg. mode	0x0000 = CV; 0x0001 = DC output status	2	46	0x022D	x
443	0x01BB		x		x		Analog interface: Pins 9 and 10 configuration	RW	uint(16)	2	1	Current and voltage monitor	0x0000 = Default (VMON on pin 9 and CMON on Pin 10 / Pin 10 signals current from source or sink); 0x0001 = Pin 10 (CMON) only signals sink current (EL); 0x0002 = Pin 10 (CMON) only signals source current (PS); 0x0003 = Current mode A [source current (PS) on pin 9 and sink current (EL) on pin 10 (full range)]; 0x0004 = Current mode B [source current (PS) on pin 10 and sink current (EL) on pin 9 (full range)]; 0x0005 = Pin 10 (CMON) signals EL/PS current (0...10 V ≙ -100%...0...100%, half range signal)	2	50	0x0231	x
498	0x01F2		x		x		Sink mode: Set power value	RW	uint(16)	2	1	0x0000 - 0x0DE5 (0 - 102%)	Power value (for translation see programming guide)	2	21	0x0214	x
499	0x01F3		x		x		Sink mode: Set current value	RW	uint(16)	2	1	0x0000 - 0x0DE5 (0 - 102%)	Current value (for translation see programming guide)	2	20	0x0213	x
500	0x01F4		x		x		Set voltage value	RW	uint(16)	2	1	0x0000 - 0x0DE5 (0 - 102%)	Voltage value (for translation see programming guide)	2	23	0x0216	x
501	0x01F5		x		x		Source mode: Set current value	RW	uint(16)	2	1	0x0000 - 0x0DE5 (0 - 102%)	Current value (for translation see programming guide)	2	24	0x0217	x
502	0x01F6		x		x		Source mode: Set power value	RW	uint(16)	2	1	0x0000 - 0x0DE5 (0 - 102%)	Power value (for translation see programming guide)	2	25	0x0218	x
505	0x01F9		x				Device state	R	uint(32)	4	2	Bit 0-4 : Control location Bit 6 : Master-slave type Bit 7 : Output state Bit 9-10 : Regulation mode Bit 11 : Remote Bit 12 : PSB/PSBE operation mode Bit 14 : External sense Bit 15 : Alarms Bit 16 : OVP Bit 17 : OCP Bit 18 : OPP Bit 19 : OT Bit 21 : Power fail Bit 29 : MSP Bit 30 : REM-SB Bit 31 : OCP/OPP cause	0x00 = free; 0x01 = local; 0x03 = USB; 0x04 = analog; 0x05 = Profibus; 0x06 = Ethernet; 0x08 = Master/Slave; 0x09 = RS232; 0x10 = CANopen; 0x12 = Modbus TCP 1P; 0x13 = Profinet 1P; 0x14 = Ethernet 1P; 0x15 = Ethernet 2P; 0x16 = Modbus TCP 2P; 0x17 = Profinet 2P; 0x18 = GPB; 0x19 = CAN; 0x1A = EtherCAT; 0x1C = free (due to communication timeout (CTO)) 0 = Slave; 1 = Master 0 = off; 1 = on 00 = CV; 10 = CC; 11 = CP 0 = off; 1 = on 0 = source; 1 = sink 0 = off; 1 = on 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active 0 = DC enabled; 1 = REM-SB disables power output 0 = source mode; 1 = sink mode	2	27	0x021A	x
507	0x01FB		x				Actual voltage	R	uint(16)	2	1	0x0000 - 0xFFFF (0 - 125%)	Actual voltage (for translation see programming guide)	2	28	0x021B	x
508	0x01FC		x				Actual current	R	uint(16)	2	1	0x0000 - 0xFFFF (0 - 125%)	Actual current (for translation see programming guide)	2	29	0x021C	x
509	0x01FD		x				Actual power	R	uint(16)	2	1	0x0000 - 0xFFFF (0 - 125%)	Actual power (for translation see programming guide)	2	30	0x021D	x
511	0x01FF		x				Device state 2	R	uint(32)	4	2	Bit 1 : SF alarm Bit 4 : Power derating Bit 5 : Semi F47	0 = none; 1 = active 0 = none; 1 = active 0 = none; 1 = active	2	19	0x02	