

Visual Studio PlatformIO Installation

Dec. 27, 2020

<https://docs.platformio.org/en/latest/boards/espressif32/featheresp32.html>


1. Installation

1.1 [Download](https://code.visualstudio.com/docs/?dv=win) and install official Microsoft's Visual Studio Code, PlatformIO IDE is built on top of it

<https://code.visualstudio.com/docs/?dv=win>

1. 2. Quickstart Platform IO

<https://docs.platformio.org/en/latest/integration/ide/vscode.html#quick-start>



1.2.1 **Open** VSCode Package Manager (#1)

1.2.2 select PlatformIO IDE 2.2.1 (#2)

1.2.3 select install (#3)

1.2.4 select reload VS window

1.3. Click on “New Project”, select a board and create new PlatformIO Project

1.3.1 Board: espressif32: adafruit ESP32 Feather, framework Arduino, default location, finish

(wait for tools to be installed)

1.4. Build (check mark on bottom of tool bar), upload (right arrow on bottom of tool bar)

(LED on feather board should blink).

2. Install ESP-IDF framework

2.1. Click on “New Project”, select a board and create new PlatformIO Project

2.2 Board: espressif32: adafruit ESP32 Feather, Framework: Espressif IoT Development Framework, default location, finish

(wait for tools to be installed)

Configuration File\r\n\r\nError: Processing featheresp32 (platform: espressif32; board: featheresp32; framework: espidf)\r\n—

Error: Detected a whitespace character in project paths.\r\n

Make sure Name: does not contain space or will crash

WiFi node example:

https://docs.platformio.org/en/latest/tutorials/espressif32/espidf_debugging_unit_testing_analysis.html#tutorial-espressif32-espidf-debugging-unit-testing-analysis

2.3 Make sure this new file main.c is registered as source file using idf_component_register function in src/CMakeLists.txt file:

```
idf_component_register(SRCS "main.c")
```

2.4 allow vscode to install CMake Tools.

3. Hello World example for platformio

Examples setup for platformio are located in:

~/home/.platformio/platforms/espressif32/examples

The other examples (see later sections) were set up for command line tools, and need slightly different setup.

Examples setup for platformio:

<https://github.com/platformio/platform-espressif32/tree/master/examples>

~/home/.platformio/platforms/espressif32/examples ← already has platformio.ini

3.1 File-> Open Folder -> examples/espidf-hello-world

(also can be downloaded from github:

https://github.com/platformio/platform-espressif32/blob/master/examples/esp-idf-hello-world/src/hello_world_main.c

3.2 update the `platformio.ini` file:

```
[env:featheresp32]
platform = espressif32
framework = esp-idf
board = featheresp32
monitor_speed = 115200
```

3.3 delete the other boards in `platformio.ini` as they are not used.

3.3 build (takes about 6 minutes)/upload for project toolbar on bottom of window (right arrow symbol)

3.4 upload

3.5 works in putty terminal

7. SkeletonHuzzah32

7.1 git clone <https://github.com/ucb-ee192/SkeletonHuzzah32>

7.2 build in platformio (first time will also build libraries for esp-idf framework)

7.3 flash, and monitor in either built-in terminal or putty terminal

8. SoftWiFi Access Point

https://github.com/espressif/esp-idf/tree/release/v4.1/examples/wifi/getting_started/softAP

also `~/home/.platformio/packages/framework-esp-idf/examples/wifi/getting_started`

8.1 VS: PlatformIO (ant icon) -> PIO Home -> Projects and Configuration -> + create new project

Name: softAP [no space!]

Board: Adafruit ESP32 Feather (can type esp32, and Feather will be an option)

Framework: Espressif IoT Development Framework,

Uncheck use default location

[choose location such as `~/home/EE192/`]

Finish

Get ESPRESSIF window. Ignore.

Would you like to configure 'UDPSockets' -> yes

8.2 Edit platformio.ini to add `monitor_speed = 115200`

8.3 copy files into `src` directory

`softap_example_main.c`

8.3.1 copy

[examples/common_components/protocol_examples/common/connect.c](#),

into `src` directory

8.4 copy needed header file

`./examples/common_components/protocol_examples_common/include/protocol_examples_common.h`

8.4 add defines to `platformio.ini`

(note extra single quotes)

`build_flags =`

```
'-D CONFIG_ESP_WIFI_SSID="Huzzah32" '
'-D CONFIG_ESP_WIFI_PASSWORD="1234" '
-D CONFIG_ESP_MAX_STA_CONN=2
-D CONFIG_ESP_WIFI_CHANNEL=1
```

9. Other Examples

Application programming interface (API) description can be found here:

<https://docs.espressif.com/projects/esp-idf/en/latest/esp32/api-reference/index.html>

Other example code for esp32 can be found here (missing `platformio.ini`, which needs to be added):

<https://github.com/espressif/esp-idf/tree/master/examples>

`~/home/.platformio/packages/framework-esp-idf/examples/protocols/sockets`

8.1 VS: PlatformIO (ant icon) -> -> Projects and Configuration -> + create new project

Name: UDPSockets [no space!]

Board: Adafruit ESP32 Feather (can type esp32, and Feather will be an option)

Framework: Espressif IoT Development Framework,

Uncheck use default location

[choose location such as `~/home/EE192/Sockets`]

Finish

Get ESPRESSIF window. Ignore.

Would you like to configure 'UDPSockets' -> yes

8.2 Edit platformio.ini to add `monitor_speed = 115200`

8.3 copy file such as `udp_server.c` into `src` directory

8.3.1 copy

[examples/common_components/protocol_examples/common/connect.c](#),

into `src` directory

8.4 copy needed header file

`./examples/common_components/protocol_examples_common/include/protocol_examples_common.h`

into `include` directory

8.4 add defines to `udp_server.c`

`build_flags =`

`-DCONFIG_EXAMPLE_CONNECT_IPV4`

`-DCONFIG_EXAMPLE_CONNECT_WIFI`

`-DCONFIG_EXAMPLE_PORT=3333`

Build/upload (`CMakeLists.txt` seems to work with `src/*.*`)

Python examples at:

[~/home/.platformio/packages/framework-esp8266/examples/protocols/sockets/scripts](#)

8.1 Adding files to project folder (VS: file -> open file)

`CMakeLists.txt`: `idf_component_register(SRCS "hello_world_main.c"`
`"other1.c" INCLUDE_DIRS "")`

note that `platformio.ini` should be copied as above for `featheresp32`

9. Basic Text IO

Debugging real-time code on the Huzzah is a challenge. In particular, print statements can be slow and disrupt control loops.

9.1 LED to blink

Sometimes toggling an LED can help to find code which is not entered or not exited.

```
#define BLINK_GPIO 13 // IO13
```

The LED can be turned on using

```
gpio_set_level(BLINK_GPIO, 1);
```

Other GPIO lines are available, see Huzzah32 schematic to see unused GPIO lines. Remember to use a resistor in series with an LED to prevent burning out IO line.

9.2 printf

The normal C printf works. Some points to note:

- Tasks need to have a bigger stack configMINIMAL_STACK_SIZE + 2048
- make sure to use flush(stdout); to make sure print finishes.
- snprintf is recommended, as buffer length is specified
- printing a floating point number to a string is slow: almost 1000 us
- print an int and long to a string: about 400 us
- integer to ascii: itoa()
- printf-stdarg.c does not handle floating point but uses much less stack space

The log task saved almost 800 bytes of stack space by eliminating printf

```
void printString(char *string)
{
    int i=0;
    while (string[i] != '\0')
// print single character, avoid printf to save on stack
    {
        fputc(string[i], stdout);
        i++;
    }
}
```

9.3 Text input

It is recommended that advanced text input such as for parameters be handled by remote Python, and then numbers sent directly by WiFi (see next subsection), so that parsing is not needed on the Huzzah32.

A discussion of input suggestions in 'C' are suggested here:

<https://stackoverflow.com/questions/58403537/what-can-i-use-for-input-conversion-instead-of-scanf>

- `scanf` does not work, and is not recommended due to input insecurity (buffer overflow attacks)
- `fgetc(stdin)` and `fputc(char, stdout)` work. However, `0xFF` needs to be ignored.

```
ch = fgetc(stdin);
if (ch!=0xFF) // discard idle character (non-input)
```
- <https://docs.espressif.com/projects/esp-idf/en/latest/esp32/api-reference/system/console.html>
ESP-IDF provides `console` component, which includes building blocks needed to develop an interactive console over serial port. Since much interaction with the car can be remote (not connected through the USB cable), effort is better spent on a remote Python interface.

9.4 Advanced IO

To use WiFi for debugging/data logging, use

```
#define WIFILOG
```

In `SkeletonHuzzah32`. Then `Huzzah32` is a soft access point, connect and use python script to get debugging/log info.

To add a debugging message, do:

```
snprintf(log, sizeof(log), printf args here);
log_add(log);
```

`log_add()` takes about 40 us. However the `snprintf` command can be quite slow compared to `itoa()`.

The Python script running on a WiFi connected laptop, `print-client-udp.py`, will connect through 192.168.4.2.

See section below for details on using WiFi.

10. Configuring Options

There are many, many options to configure setting up the ESP32 hardware and software environment. The readable settings file is `sdkconfig`, which is autogenerated. Editing `sdkconfig` manually will be overwritten. These parameters are accessible to your program if needed through `sdkconfig.h` (also autogenerated).

For version control, this file may be storing setup information, but not yet verified:

```
.pio/build/featheresp32/config/kconfig_menus.json
```

WARNING: `idf.py menuconfig` is incompatible with `platformio` and will mess up build.

10.1 Menuconfig

1. (optional) Exit VS so there is not a conflict with sdkconfig. Make a backup copy of sdkconfig just in case.
2. To edit sdkconfig use command prompt or shell:
 - a. `C:> ~/.platformio/penv/Scripts/pio.exe run -t menuconfig`
(if pio.exe is not in search path, add)
 - b. Alternatively, there is a command line interface (CLI) inside platformio, but up down arrow keys do not work.
From VS, PlatformIO icon (ant) => QUICK ACCESS => Miscellaneous => PlatformIO Core CLI
Then `pio.exe run -t menuconfig`
3. In menuconfig, use slash to find symbol if option is hard to find from menus.
4. Save, then exit.
5. After restarting VS, allow VS to automatically remake CMakeList
6. Would you like to configure project 'SkeletonHuzzah32'? YES
7. If getting strange results,
 - a. If get something like:
Error: Couldn't find target config target-__idf_cbor-a7ffc6f8bf1ed76651c1.json
Then do 'clean' from toolbar in platformio.
 - b. the sdkconfig may have been corrupted. Start over with a fresh version, such as from examples directory.
8. May be possible to close and open project folder in VS to read sdkconfig?

10.2 Useful menuconfig things to change

The documentation describes all the options:

<https://docs.espressif.com/projects/esp-idf/en/latest/esp32/api-reference/kconfig.html#component-config>

1. CONFIG_FREERTOS_HZ
[Component config](#) > [FreeRTOS](#) (-> Tick rate (Hz)
Tick rate (Hz) set to 1000 Hz (can update steering servo at 5 ms interval). This is a reasonable tradeoff considering task switch overhead, and gives potentially 1 ms slice for each task.
2. CONFIG_FREERTOS_GENERATE_RUN_TIME_STATS
[Component config](#) > [FreeRTOS](#) -> Enable FreeRTOS to collect run time stats
`vTaskGetRunTimeStats()` will display the run time of each task as a % of the total run time of all CPUs (task run time / no of CPUs) / (total run time / 100)
3. CONFIG_ESP_COREDUMP_TO_FLASH_OR_UART
Component config → Core dump (22 down) → Data destination -> UART
Select place to store core dump: flash, uart or none (to disable core dumps generation).
4. CONFIG_ESP_SYSTEM_PANIC_PRINT_REBOOT or
ESP_SYSTEM_PANIC_PRINT_HALT
Component config → ESP32-specific (8 down)→ Panic handler behavior -> Print Registers and halt

Outputs the relevant registers over the serial port and halt the processor. Needs a manual reset to restart.

5. CONFIG_COMPILER_OPTIMIZATION

Compiler options -> Optimization Level

Optimization level: "None" with -O0 produces compiled code without optimization.

(sometimes needed if scanning a value which is changed by an external routine such as an IO line or an interrupt.)

6. CONFIG_COMPILER_STACK_CHECK_MODE

Compiler options -> Stack smashing protection mode

Stack smashing protection mode, Emit extra code to check for buffer overflows, such as stack smashing attacks

7. CONFIG_ESP_MAIN_TASK_STACK_SIZE

[Component config](#) > [Common ESP-related](#) (11 from top) -> Main task stack size

check stack size here if run out, default is 3584 bytes. ~450 doubles

8. CONFIG_ESP_INT_WDT

Component config → Common ESP-related -> Interrupt Watchdog

This watchdog timer can detect if the FreeRTOS tick interrupt has not been called for a certain time, either because a task turned off interrupts and did not turn them on for a long time, or because an interrupt handler did not return. (300 ms default timeout). Make this higher than the FreeRTOS tick rate.

The INT WDT timeout should always be longer than the period between FreeRTOS ticks (see [CONFIG_FREERTOS_HZ](#)).

9. CONFIG_ESP_TASK_WDT_TIMEOUT_S.

[Component config](#) > [Common ESP-related](#) > Task Watchdog timeout period (seconds)

Watch dog timer triggered (5 seconds by default) if a task does not yield.

The Task Watchdog Timer can be used to make sure individual tasks are still running. Enabling this option will cause the Task Watchdog Timer to be initialized automatically at startup. The Task Watchdog timer can be initialized after startup as well (see Task Watchdog Timer API Reference)

A task can then subscribe to the TWDT using [esp_task_wdt_add\(\)](#) in order to be watched.

Each subscribed task must periodically call [esp_task_wdt_reset\(\)](#) to reset the TWDT.

Failure by any subscribed tasks to periodically call [esp_task_wdt_reset\(\)](#) indicates that one or more tasks have been starved of CPU time or are stuck in a loop somewhere.

11. FreeRTOS

ESP-IDF FreeRTOS is based on the Xtensa port of FreeRTOS v8.2.0 with significant modifications for SMP compatibility (see [ESP-IDF FreeRTOS SMP Changes](#)). SMP= Symmetric Multi Processing

Furthermore, float cannot be used in interrupt service routines. (probably due to saving state of FPU registers?) Be careful on this. Double is ok, and it may be possible to save FPU state.

<https://docs.espressif.com/projects/esp-idf/en/latest/esp32/api-reference/system/freertos.html>

<https://github.com/espressif/esp-idf/tree/master/components/freertos>

Level 1 so ok to use FPU (it will be interrupted by higher priority process)

- Timer 0 (int 6, level 1) (FREERTOS_CORETIMER_0) Select this to use timer 0

Enable FreeRTOS static allocation API: avoids problems with alloc/fragmentation. Probably safer for production code

The function `vTaskGetRunTimeStats()` will also be available if `FREERTOS_USE_STATS_FORMATTING_FUNCTIONS` and `FREERTOS_USE_TRACE_FACILITY` are enabled. `vTaskGetRunTimeStats()` will display the run time of each task as a % of the total run time of all CPUs (task run time / no of CPUs) / (total run time / 100)

When creating tasks, make sure stack space is sufficient (good to use for debugging)

See in `hello_world_main.c` `print_tasks()`

[Component config](#) > [FreeRTOS](#) -> Allow use of float inside Level 1 ISR (EXPERIMENTAL)

When enabled, the usage of float type is allowed inside Level 1 ISRs.

https://hop.freertos.org/Documentation/RTOS_book.html

Make sure IDLE process is not starved. It is critical for proper operation. Using `vTaskDelay()` gives other processes a chance to run.

Task examples

11.1 Getting System Time

System time is read from an interrupt and made available to other processes through a queue. The queue avoids the problem of reading a 64 bit value in the middle of an update, giving an inconsistent time value.

Timer can also be read directly (this is a safe 64 bit read, protected by a spinlock).

```
timer_get_counter_value(timer_group_t group_num, timer_idx_t
timer_num, uint64_t *timer_val)
```

xQueuePeek: reads queue without emptying

xQueueOverwriteFromISR: overwriting data that is already held in the queue.

xQueueOverwriteFromISR() is intended for use with queues that have a length of one, meaning the queue is either empty or full.

Time stamp is used for delay measurement such as velocity estimate, and for debugging to keep track of events

11.2 Monitoring Tasks

Things to watch out for:

Running out of stack space (printf uses a lot of stack space) for a task

Starving the ``idle'' process (will cause a crash). Make sure every process has vTaskDelay() for a lower priority process to run

SkeletonHuzzah32 includes void print_tasks()

```
# of tasks 12
IDLE0      283440623    49%
usertask   142791054    24%
IDLE1      145004887    25%
heartbeat   6661        <1%
timer_evt_task 194739    <1%
Tmr Svc     55          <1%
control_task 60360      <1%
esp_timer   209         <1%
ipc0        10215       <1%
main        95764       <1%
log_task    13490       <1%
ipc1        15121       <1%
```

Shows how many cycles each task has been using. Make sure IDLE0 and IDLE1 are getting cycles, otherwise there will be a ``watch dog timer`` wdt reset.

```
vTaskList:
Name           State   Priority  Stack   Task#
control_task   R       2        348     14
usertask        R       0        504     16
IDLE1           R       0       1116     7
IDLE0           R       0       1012     6
heartbeat       B       1       1584    15
timer_evt_task  B       2        756    13
Tmr Svc         B       1       1592     8
main            S       1       2476     5
log_task        B       1        856    12
esp_timer       B      22       3640     1
ipcl            B      24        596     3
ipc0            B      24        564     2
```

Priority: 0 is lowest priority. Usertask is also low priority as it busy waits for input

Task #: order of task startup

State: R running, B blocked

12. Debugging Tools

Useful menuconfig things to change:

12.1 Core dump

https://docs.espressif.com/projects/esp-idf/en/latest/esp32/api-guides/core_dump.html?highlight=assert

1. Copy and paste base64 encoded core dump to a text file.
2. Remove ===== CORE DUMP START =====
3. And ===== CORE DUMP END =====
From text file
4. `espcoredump.py info_corefile -t b64 -c
</path/to/saved/base64/text> </path/to/program/elf/file>`

```
c:>python c:\Users\ronf\esp\esp-idf\components\espcoredump\espcoredump.py info_corefile -t b64 -c  
coredump.txt .pio\build\featheresp32\firmware.elf
```

Shows lots of information, not so easy to parse, but does show active tasks/threads. Perhaps dbgcorefile (using gdb) would be more useful.

12.2 Error Codes

https://docs.espressif.com/projects/esp-idf/en/latest/esp32/api-reference/system/esp_err.html

Convert error codes: `esp_err_to_name()` and `esp_err_to_name_r()`

12.3 Watchdog timers

Watchdogs are useful for detecting stuck code.

Use RTC watchdog in start code: causes watchdog if startup fails

Task Watchdog Timer API Reference

<https://docs.espressif.com/projects/esp-idf/en/latest/esp32/api-reference/system/wdts.html?highlight=task%20watchdog%20timer%20api%20reference>

The Interrupt Watchdog Timer and the Task Watchdog Timer (TWDT). The Interrupt Watchdog Timer and the TWDT can both be enabled using [Project Configuration Menu](#), however the TWDT can also be enabled during runtime.

CONFIG_ESP_INT_WDT

Component config → Common ESP-related → Interrupt Watchdog

Useful `menuconfig` things to change:

Have to make sure idle can run, otherwise will get watchdog timeout. For example, if `main()` is waiting for keyboard input, then idle can be starved. Always use a

`vTaskDelay(1000 / portTICK_PERIOD_MS);` to temporarily block process.

13. Virtual file system:

<https://docs.espressif.com/projects/esp-idf/en/latest/esp32/api-reference/storage/vfs.html>

included by default in sdkconfig. This component allows C library functions, such as `fopen` and `fprintf`, to work with FS drivers.

14. ERRATA

1. Windows filenames:

ccache: error: Failed to create temporary file

It looks like you might be running up against path length limitations on Windows. Windows is limited to 260 character paths by default, and it looks like the total path length for some of these build files is pushing up against that.

Use short directory names

2. Furthermore, `float` cannot be used in interrupt service routines. (probably due to saving state of FPU registers?) Be careful on this. `double` is ok, and it may be possible to save FPU state.

3. If get weird errors in compiling, use PlatformIO: Clean (the empty trash symbol). This will clean out temporary files, and a fresh build should be working again.

4. If adding extra files to src, make sure to manually add file to CMakeLists.txt

```
CMakeLists.txt: idf_component_register(SRCS "hello_world_main.c"
"other1.c"    INCLUDE_DIRS "")
```

5. Running out of stack space (`printf` uses a lot of stack space) for a task

6. Starving the ``idle'' process (will cause a crash). Make sure every process has `vTaskDelay()` for a lower priority process to run

7. When creating tasks, make sure stack space is sufficient (good to use for debugging)

15. Floating Point and Interrupts

From forum: <https://esp32.com/viewtopic.php?f=19&t=1292&p=6078&hilit=FPU+state#p6078>

Yes, it is solvable: it means messing with the assembler in the coprocessor handler to add the code to store the FPU state when an interrupt happens and restoring it when the interrupt is done. I have it on my list, but it's fairly low-priority: you can expect a fix eventually, but I don't know the timeframe for that.

```
uint32_t timer0_int = 0;
float timer0_float = 0.0;
DRAM_ATTR float timer0_k = 1.111111;

uint32_t cp0_regs[18];

void IRAM_ATTR timer0_intr() // Interrupt handler for timer 0
{
    // get FPU state
    uint32_t cp_state = xthal_get_cpenable();

    if(cp_state) {
        // Save FPU registers
        xthal_save_cp0(cp0_regs);
    } else {
        // enable FPU
        xthal_set_cpenable(1);
    }

    timer0_int++;
    timer0_float = timer0_int * timer0_k;

    if(cp_state) {
        // Restore FPU registers
        xthal_restore_cp0(cp0_regs);
    } else {
        // turn it back off
        xthal_set_cpenable(0);
    }
}
```

<https://docs.espressif.com/projects/esp-idf/en/latest/esp32/api-guides/freertos-smp.html#floating-points>

Likewise due to Lazy Context Switching, only interrupt service routines of lowest priority (that is it the Level 1) can use `float`, higher priority interrupts do not support FPU usage.

6. SSH/WiFi

<https://libraries.io/platformio/LibSSH-ESP32>

<https://libraries.io/cargo/esp32-hal>

<https://github.com/espressif/esp-drone/blob/master/docs/en/rst/communication.rst>

<https://github.com/espressif/esp-idf/tree/master/examples/protocols/sockets>

https://github.com/espressif/esp-idf/blob/master/examples/protocols/sockets/udp_client/example_test.py

https://freertos.org/FreeRTOS-Plus/FreeRTOS_Plus_TCP/API/socket.html

Tutorial here: <https://realpython.com/python-sockets/>

esp_netif_lwip: DHCP server assigned IP to a station, IP is:
192.168.4.2