



# **SIM800 Series \_Bluetooth\_ Application Note\_V1.05**



<b>Document Title</b>	SIM800 Series_Bluetooth_Application Note
<b>Version</b>	1.05
<b>Date</b>	2015-08-06
<b>Status</b>	Release
<b>Document Control ID</b>	SIM800 Series_Bluetooth_Application Note_V1.05

### General Notes

Simcom offers this information as a service to its customers, to support application and engineering efforts that use the products designed by Simcom. The information provided is based upon requirements specifically provided to Simcom by the customers. Simcom has not undertaken any independent search for additional relevant information, including any information that may be in the customer's possession. Furthermore, system validation of this product designed by SIMCOM within a larger electronic system remains the responsibility of the customer or the customer's system integrator. All specifications supplied herein are subject to change.

### Copyright

This document contains proprietary technical information which is the property of SIMCOM Limited., copying of this document and giving it to others and the using or communication of the contents thereof, are forbidden without express authority. Offenders are liable to the payment of damages. All rights reserved in the event of grant of a patent or the registration of a utility model or design. All specification supplied herein are subject to change without notice at any time.

**Copyright © SIMCom Wireless Solutions Ltd. 2015**

## Content

<b>1. Bluetooth Function.....</b>	<b>7</b>
1.1. Bluetooth Introduction .....	7
1.2. Bluetooth Profile .....	7
1.3. Bluetooth Device Address.....	7
1.4. AT Interface for Bluetooth Function .....	7
1.5. Multi Device Connection .....	8
1.6. Function Differences .....	8
<b>2. AT Command .....</b>	<b>9</b>
2.1. AT+BTHOST Inquiry and set host device name .....	10
2.2. AT+BTSTATUS Inquiry current BT device status.....	10
2.3. AT+BTPOWER Power on/off BT radio .....	11
2.4. AT+BTPAIR Pair BT device.....	12
2.5. AT+BTUNPAIR Unpair BT device .....	13
2.6. AT+BTSCAN Scan surrounding BT device .....	13
2.7. AT+BTCONNECT Connect paired BT device .....	14
2.8. AT+BTDISCONN Disconnect BT connection.....	14
2.9. AT+BTGETPROF Get profile provided by paired device.....	15
2.10. AT+BTACPT Accept connecting request.....	15
2.11. AT+BTOPPACPT Accept OPP service.....	16
2.12. AT+BTOPPPUSH Push OPP object to paired device.....	17
2.13. AT+BTSPGET Get data based on SPP service.....	17
2.14. AT+BTSPSEND Send data based on SPP service.....	18
2.15. AT+BTATA Answer incoming call.....	19
2.16. AT+BTATDL Redial last number .....	19
2.17. AT+BTATH Hung up voice call.....	20
2.18. AT+BTVGS Configure voice volume.....	20
2.19. AT+BTVGM Configure MIC gain level.....	20
2.20. AT+BTATD Dial voice call.....	21
2.21. AT+BTRSSI Get RSSI of connected BT device.....	21
2.22. AT+BTVTS Send DTMF tone.....	22
2.23. AT+BTCIND Get status of smartphone.....	22
2.24. AT+BTCLCC Get call status of smartphone .....	23
2.25. AT+BTPBSYNC Sync phonebook from remote by BT .....	24
2.26. AT+BTPBF Find name or number from remote by BT .....	26
2.27. AT+BTAVRCOP AVRCP operation .....	28
2.28. AT+BTVIS Set visibility of BT .....	28
2.29. AT+BTSPPCFG SPP configuration.....	29
2.30. AT+BTPAIRCFG Set BT pairing mode.....	30
2.31. AT+CPBFEX Find name or number in module phonebook .....	30
2.32. AT+BTRING Control ring playing transferred from phone .....	31
2.33. AT+BTACI Set report mode of BT audio service state change .....	32

2.34.	AT+BTHFGOP	Set action mode of MS when earphone button is pressed during BT link	32
2.35.	AT+BTSPPURC	Set the report format of command +BTSPSEND	33
2.36.	AT+BTCLCCS	Get call status of smartphone	34
2.37.	AT+BTSPPCFD	Set string of SPP switching work mode	35
2.38.	AT+BTCOD	Set the Bluetooth Class of Device	36
<b>3.</b>	<b>CME Error Code</b>		<b>37</b>
<b>4.</b>	<b>Examples</b>		<b>39</b>
4.1.	Accept request from other BT device		39
4.2.	Send pairing request to other BT device		39
4.3.	Get the profile provided by paired device		40
4.4.	Connect service		41
4.5.	Accept file from paired device		41
4.6.	Send file to other paired BT device		41
4.7.	Create SPP's link as a client		41
4.8.	SPP's link be create as a server		42
4.9.	Configurate SPP		42
4.10.	Send data as a SPP's client		43
4.11.	As a SPP's server worked in AT mode		43
4.12.	As a SPP's server worked in APP mode and multi-connection		44
4.13.	Sync phonebook from remote by BT		45
4.14.	Find name or number from remote by BT		45
4.15.	Play music and so on by AVRCP		46
4.16.	Add phonebook records to ME or SM phonebook from VCARD file		47
4.17.	Set BT pairing mode		48
<b>5.</b>	<b>Differences between bluetooth version and standard Version</b>		<b>50</b>
5.1.	ATD<str>		50
5.2.	AT+CPBF		50
5.3.	AT+CMUX		50
5.4.	AT+CNUM		50
5.5.	AT+CMGS		51
5.6.	AT+CMSS		51
5.7.	AT+CPMS		51
5.8.	AT+CHFA		51
5.9.	TTS function		51
<b>Appendix</b>			<b>52</b>
A.	Reference		52
B.	Profile		52
C.	Glossary and Abbreviation		53

## Version History

Date	Version	Description	Author
2013-11-07	1.00	Original	Ping Zhang
2014-03-26	1.01	Chapter 1.4, Add “power-saving mode” description Chapter 2.6, AT+BTSCAN add <rss> parameter Chapter 2.13, Modify AT+BTSPGET parameter Chapter 2.14, Modify AT+BTSPSEND parameter Chapter 2.22, Add AT+BTVTS command Chapter 2.23, Add AT+BTCIND command Chapter 2.24, Add AT+BTCLCC command Chapter 2.25, Add AT+BTPBSYNC command Chapter 2.26, Add AT+BTPBF command Chapter 2.27, Add AT+BTAVRCOP command Chapter 2.28, Add AT+BTVIS command Chapter 2.29, Add AT+BTSPPCFG command Chapter 2.30, Add AT+BTPAIRCFC command Chapter 3, Add Error Code 1051,1056--1058,1060 Chapter 4, Add 4.7----4.17	Ping Zhang
2014-06-30	1.02	Chapter 2.13, Modify AT+BTSPGET and <command> description Chapter 2.31, Add AT+CPBFEX command Chapter 2.32, Add AT+BTRING command Chapter 4.12, Modify demo Chapter 5, Add	Ping Zhang
2015-01-12	1.03	Chapter 2.14, Modify AT+BTSPSEND usage Chapter 2.25, Modify description of <fail_num> Chapter 2.29, Modify AT+BTSPPCFG command Chapter 2.3, Modify AT+BTPOWER command note Chapter 2.31, Modify AT+CPBFEX command Chapter 2.32, Modify AT+BTRING command Chapter 2.33, Add AT+BTACI command Chapter 2.34, Add AT+ BTHFGOP command Chapter 2.35, Add AT+BTSPPURC command Chapter 5.2, Modify CPBF command difference	Chen Yan ZhuDingFen
2015-2-9	1.04	Add SIM800C Chapter 2.36, Add AT+BTCLCCS command	Ping Zhang
2015-8-6	1.05	Add SIM800A, SIM800F Chapter 1.5, Add	Chen Yan

		Chapter 1.6, Add Chapter 2.37, Add AT+BTSPPCFD command Chapter 2.38, Add AT+BTCOD command	
--	--	---	--

## Scope

This document describes how to use the AT command about Bluetooth and some application note. The document can apply to SIM800, SIM800M64, SIM808, SIM800H, SIM800C, SIM800A, SIM800F Series version with Bluetooth function.

## 1. Bluetooth Function

### 1.1. Bluetooth Introduction

Bluetooth is a wireless technology standard for exchanging data over short distances (using short-wavelength radio transmissions in the ISM band from 2400–2480 MHz) from fixed and mobile devices, creating personal area networks (PANs) with high levels of security. Bluetooth was standardized as IEEE 802.15.1.

The bluetooth version is BT3.0.

### 1.2. Bluetooth Profile

To use Bluetooth wireless technology, a device has to be able to interpret certain Bluetooth profiles, which are definitions of possible applications and specify general behaviors that Bluetooth enabled devices use to communicate with other Bluetooth devices. These profiles include settings to parametrize and to control the communication from start. Adherence to profiles saves the time for transmitting the parameters anew before the bi-directional link becomes effective. There are a wide range of Bluetooth profiles that describe many different types of applications or use cases for devices.

### 1.3. Bluetooth Device Address

The Bluetooth device address stores the network address of a Bluetooth-enabled device. It is used to identify a particular device during operations such as connecting to, pairing with, or activating the device.

A Bluetooth-enabled device address is a unique, 48 bits address containing the following three fields:

- LAP field: lower part of the address containing 24 bits.
- UAP field: upper part of the address containing 8 bits.
- NAP field: non-significant part of the address containing 16 bits.

The LAP and the UAP represent the significant address part (SAP) of the Bluetooth device address.

### 1.4. AT Interface for Bluetooth Function

As module solution, we provide series of AT interface to operate Bluetooth function, including pairing, bonding, pushing or receiving file.

Also including interface for SPP service which could communicate between Bluetooth device and others via serial port.

When the module as a Bluetooth headset role, we provide a set of AT commands to control the

remote smart phones, such as phone calls, turn on or hang up calls and so on.

By default, the module operates in power-saving mode, which means that the module can be simultaneously connected to a Bluetooth device. When the module to establish a connection with a device, other devices can not be scanned into the module, the module can not get Profile, will not be able to establish new connections and modules. If the customer's application scenario, the module needs to be multiple Bluetooth devices (currently up to three) connection, you need to use the AT+BTSPPCFG=1 command to turn off the power saving mode. It should be noted that the power saving mode does not affect the module initiative to connect to other Bluetooth devices.

### 1.5. Multi Device Connection

For the MTK6260 platform module, by default, the module works in power saving mode, which means that the module can only be connected to a Bluetooth device. When the module is connected with a certain device, other devices can not scan to the module, but also unable to obtain the module's Profile and can not establish a new connection with the module. If the customer's application scenario, the need for the module is connected to a number of Bluetooth devices (currently up to three), then you need to use the AT+BTSPPCFG=1 command to shut down the power saving mode. Note that the power saving mode does not affect the module's initiative to connect to other Bluetooth devices.

### 1.6. Function Differences

The current Bluetooth module series can be divided into two platforms, these two platforms to support the Bluetooth function will be different, divided as follows:

MTK6260 platforms: SIM800, SIM800M64, SIM800H.

MTK6261 platforms: SIM808, SIM800C, SIM800A, SIM800F.

- support Profile

All of the SIM800 series module have four basic profiles, they are OPP, HSP/HFP, SPP.

For the MTK6260 platform module, support A2DP, AVRCP, PBAP all the roles.

For the MTK6261 platform module, support PBAP all the roles and only supports A2DP, AVRCP mobile role.

- Multi-device connection

For the MTK6260 platform module, supports simultaneous connection of multiple devices, up to 3.

For the MTK6261 platform module, only supports the simultaneous connection of 1 device.

- The difference of the AT command

For the MTK6260 platform module, access to the phone call status of the AT command is: AT+BTCLCC; the default SPP server mode is AT channel mode; Bluetooth open state will be saved when shutdown.

For the MTK6261 platform module, access to the phone call status of the AT command is: AT+BTCLCCS; the default SPP server mode is the APP data mode; Bluetooth open state is not saved when shutdown.



## 2. AT Command

Command	Description
AT+BTHOST	Inquiry and set host device name
AT+BTSTATUS	Inquiry current BT device status
AT+BTPOWER	Power on or power off BT radio
AT+BTPAIR	Pair BT device
AT+BTSCAN	Scan surrounding BT device
AT+BTUNPAIR	Unpair BT device
AT+BTCONNECT	Connect paired BT device
AT+BTDISCONN	Disconnect BT device
AT+BTGETPROF	Get profile provided by paired device
AT+BTACPT	Accept connecting request
AT+BTOPPACPT	Accept OPP service
AT+BTOPPPUSH	Push OPP object to paired device
AT+BTSPSEND	Send data based on SPP service
AT+BTSPGET	Get data based on SPP service
AT+BTATA	Answer incoming call
AT+BTATDL	Redial last number
AT+BTATH	Hung up voice call
AT+BTVGS	Configure voice volume
AT+BTVGM	Configure MIC volume
AT+BTATD	Dial up a voice call
AT+BTRSSI	Get RSSI of connected device
AT+BTVTS	Send DTMF tone
AT+BTCIND	Get status of smartphone
AT+BTCLCC	Get call status of smartphone
AT+BTPBSYNC	Sync phonebook from remote by BT
AT+BTPBF	Find name or number from remote by BT
AT+BTAVRCOP	AVRCP Operation
AT+BTVIS	Set visibility of BT
AT+BTSPPCFG	SPP's config
AT+BTPAIRCFG	Set BT pairing mode
AT+CPBFEX	Find name or number in module phonebook
AT+BTRING	Control ring playing transfered from phone
AT+BTACI	Set report mode of BT audio service state change
AT+BTHFGOP	Set action mode of MS when earphone button is pressed during BT link
AT+BTSPPURC	Set the report format of command +BTSPSEND

AT+BTCLCCS	Get call status of smartphone
AT+BTSPPCFD	Set string of SPP switching work mode
AT+BTCOD	Set the bluthtooth class of device

## 2.1. AT+BTHOST Inquiry and set host device name

AT+BTHOST Inquiry and set host device name	
Test command AT+BTHOST=?	Response +BTHOST: (1-18)  <b>OK</b>  Parameters See Write Command
Read command AT+BTHOST?	Response +BTHOST: <name>, <address>  <b>OK</b>  Parameters See Write Command
Write command AT+BTHOST=<name>	Response <b>OK</b>  Parameters <name> device name <address> device address
Note	Max length of <name> is 18 bytes, and display in UTF-8 code.

## 2.2. AT+BTSTATUS Inquiry current BT device status

AT+BTSTATUS Inquiry current BT device status	
Test Command AT+BTSTATUS=?	Response <b>OK</b>  Parameters See Read Command
Read Command AT+BTSTATUS?	Response If unpaired before: +BTSTATUS: <status> If paired before but unconnected: +BTSTATUS: <status> <b>P: &lt;paired id&gt;, &lt;name&gt; &lt;address&gt;</b> If paired and connected: +BTSTATUS: <status> <b>P: &lt;paired id&gt;, &lt;name&gt; &lt;address&gt;</b> <b>C: &lt;connected id&gt;, &lt;name&gt;, &lt;address&gt;, &lt;profile name&gt;</b>

	<b>OK</b>
	Parameters <status>      0   Initial 1   Disactivating 2   Activating 5   Idle 6   Inquiry 7   Inquiry Res Ind 8   Cancelling inquiry 9   Bonding 11   Pairing 12   Connecting 14   Deleting paired device 15   Deleting all paired device 19   Pairing confirm while passive pairing 20   Waiting for remote confirm while passive pairing 25   Accepting connection 26   SDC refreshing 29   Setting host name <paired id>    paired device ID <connected id> connected device ID <name>        device name <address>     device address <profile name> profile
Note	Max length of <name> is 18 bytes, 18 bytes in UTF-8 code

### 2.3. AT+BTPOWER      Power on/off BT radio

AT+BTPOWER	Power on/off BT radio
Test Command <b>AT+BTPOWER</b> <b>=?</b>	Response <b>+BTPOWER:</b> (list of supported <n>s)  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+BTPOWER</b> <b>=&lt;n&gt;</b>	Response <b>OK</b>  parameter <n>    0   power off BT radio 1   power on BT radio
Note	After turning off, the BT radio shall not be re-opened until the status of BT is changed to 0. So wait for some seconds is needed. The status can be obtained by using AT+BTSTATUS.

## 2.4. AT+BTPAIR Pair BT device

AT+BTPAIR Pair BT device	
Test Command <b>AT+BTPAIR=?</b>	<p>Response</p> <p>+BTPAIR: 0,(list of supported &lt;device ID&gt;s) +BTPAIR: 1,(list of supported &lt;confirm&gt;s) +BTPAIR: 2,( length of supported &lt;passkey&gt;s)</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
<p>Write Command</p> <p>1) active <b>AT+BTPAIR=0,&lt;device ID&gt;</b></p> <p>2) passive with digital key request <b>AT+BTPAIR=1,&lt;confirm&gt;</b></p> <p>3) passive with passkey request <b>AT+BTPAIR=2,&lt;passkey&gt;</b></p>	<p>Response</p> <p><b>OK</b></p> <p>If digital key exchanged +BTPAIRING: &lt;name&gt;,&lt;address&gt;,&lt;passcode&gt;</p> <p>If passkey exchanged: +BTPAIRING: &lt;name&gt;,&lt;address&gt;</p> <p>If passive mode with success: +BTPAIR: &lt;id&gt;,&lt;name&gt;,&lt;address&gt;</p> <p>If passive mode with failure: +BTPAIR: 0</p> <p>Parameters</p> <p>&lt;device ID&gt; BT device ID &lt;confirm&gt; 1 accept 0 reject &lt;passkey&gt; passkey, length is (4-16) &lt;id&gt; 0 paired failed &gt;=1 paired device ID &lt;name&gt; BT device name &lt;address&gt; BT device address &lt;passcode&gt; Digital password</p> <p>URC</p> <p>If there is incoming request: +BTPAIRING: &lt;name&gt;,&lt;address&gt;,&lt;passcode&gt; or +BTPAIRING: &lt;name&gt;,&lt;address&gt;</p> <p>Parameters</p> <p>&lt;name&gt; device name &lt;address&gt; device address &lt;passcode&gt; digital password</p>
Note	1. Max length of <name> is 18 bytes, 18 bytes in UTF-8 code

2. Pairing timeout is around 15s each side

## 2.5. AT+BTUNPAIR Unpair BT device

AT+BTUNPAIR Unpair BT device	
Test Command <b>AT+BTUNPAIR=?</b>	Response <b>+BTUNPAIR:</b> (list of supported <device ID>s)  <b>OK</b>
	Parameter See Write Command
Write Command <b>AT+BTUNPAIR=&lt;device ID&gt;</b>	Response <b>OK</b>
	Parameter <device ID>    Paired Device ID. 0    delete all the paired device 1    delete the the paired device corresponding to ID

## 2.6. AT+BTSCAN Scan surrounding BT device

AT+BTSCAN Scan surrounding BT device	
Test Command <b>AT+BTSCAN=?</b>	Response <b>+BTSCAN:</b> (list of supported <switch>s), (list of supported <Timer>s)  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+BTSCAN=&lt;switch&gt;[,&lt;Timer&gt;]</b>	Response <b>OK</b>  If BT device scanned: <b>+BTSCAN:</b> <status>,<device ID>,<name>,<address>,<rss> If terminate: <b>+BTSCAN:</b> <status>
	Parameters <switch>        1 start 0 stop <status>        0 BT device found 1 scanning finished 2 scanning stop 3 scanning failed <Timer>        scanning time 10-60s <device ID>    BT device ID scanned

	<p><b>&lt;name&gt;</b> BT device name</p> <p><b>&lt;address&gt;</b> BT device address</p> <p><b>&lt;rssi&gt;</b> -127...0 RSSI value of BT device</p>
Note	<p>1. Max length of &lt;name&gt; is 18 bytes, 18 bytes in UTF-8 code</p> <p>2. If &lt;timer&gt; omitted, the default value is 30s</p>

## 2.7. AT+BTCONNECT Connect paired BT device

AT+BTCONNECT Connect paired BT device	
Test Command <b>AT+BTCONNECT=?</b>	<p>Response</p> <p><b>+BTCONNECT:</b> (list of supported &lt;device ID&gt;s), (list of supported &lt;profile ID&gt;s)</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Write Command <b>AT+BTCONNECT=&lt;device ID&gt;,&lt;profile ID&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>If OK: <b>+BTCONNECT:</b> &lt;id&gt;,&lt;name&gt;,&lt;address&gt;,&lt;profile name&gt;</p> <p>If failed: <b>+BTCONNECT: 0</b></p> <p>Parameters</p> <p><b>&lt;device ID&gt;</b> ID of paired BT device</p> <p><b>&lt;profile ID&gt;</b> BT profile ID</p> <p><b>&lt;id&gt;</b> ID of connected BT device</p> <p><b>&lt;name&gt;</b> BT device name</p> <p><b>&lt;address&gt;</b> BT device address</p> <p><b>&lt;profile name&gt;</b> BT device service name</p>
Note	<p>1. Max length of &lt;name&gt; is 18 bytes, 18 bytes in UTF-8 code</p> <p>2. Connection timeout is around 20s</p> <p>3. if incoming request, there will be URC <b>+BTCONNECTING:</b> &lt;address&gt;,&lt;profile name&gt;</p>

## 2.8. AT+BTDISCONN Disconnect BT connection

AT+BTDISCONN Disconnect BT connection	
Test Command <b>AT+BTDISCONN=?</b>	<p>Response</p> <p><b>+BTDISCONN:</b> (list of supported &lt;device ID&gt;s)</p> <p><b>OK</b></p> <p>Parameters See Write Command</p>
Write Command	Response

<b>AT+BTDISCON</b> <b>N=&lt;device ID&gt;</b>	<b>OK</b>  <b>+BTDISCONN: &lt;name&gt;,&lt;address&gt;,&lt;profile name&gt;</b>
	Parameters <b>&lt;device ID&gt;</b> connected device ID <b>&lt;name&gt;</b> device name <b>&lt;address&gt;</b> devie address <b>&lt;profile name&gt;</b> profile service
Note	1. Max length of <name> is 18 bytes, 18 bytes in UTF-8 code 2. If disconnected by remote, there still be URC: +BTDISCONN

## 2.9. AT+BTGETPROF Get profile provided by paired device

<b>AT+BTGETPROF Get profile provided by paired device</b>	
Test Command <b>AT+BTGETPROF=?</b>	Response <b>+BTGETPROF: (list of supported &lt;device ID&gt;s)</b>  <b>OK</b>  Parameters See Write Command
Write Command <b>AT+BTGETPROF=&lt;device ID&gt;</b>	Response <b>OK</b>  <b>+BTGETPROF: &lt;profile ID&gt;,&lt;profile name&gt;</b>  Parameters <b>&lt;device ID&gt;</b> Paired Device ID <b>&lt;profile ID&gt;</b> profile ID <b>&lt;profile name&gt;</b> profile name

## 2.10. AT+BTACPT Accept connecting request

<b>AT+BTACPT Accept connecting request</b>	
Test Command <b>AT+BTACPT=?</b>	Response <b>+BTACPT: (list of supported &lt;confirm&gt;s)</b>  <b>OK</b>
Write Command <b>AT+BTACPT=&lt;confirm&gt;</b>	Response <b>OK</b>  If connected successfully, then will report: <b>+BTCONNECT: &lt;id&gt;,&lt;name&gt;,&lt;address&gt;,&lt;profile name&gt;</b> If connecting failed:

	<b>+ BTDISCONN: &lt;name&gt;,&lt;address&gt;,&lt;profile name&gt;</b>
	Parameters <confirm>      1 accept 0 reject <id>              >0 connected device ID <name>           device name <address>        device address <profile name>   profile name
	URC If incoming connecting request: <b>+BTCONNECTING: &lt;address&gt;,&lt;profile name&gt;</b>  Parameters <address>        device address <profile name>   profile name
Note	Max length of <name> is 18 bytes, 18 bytes in UTF-8 code

## 2.11. AT+BTOPPACPT Accept OPP service

AT+BTOPPACPT Accept OPP service	
Test Command <b>AT+BTOPPACPT=?</b>	Response <b>+BTOPPACPT:</b> (list of supported <confirm>s),(list of supported<drv>)  <b>OK</b>
Write Command <b>AT+BTOPPACPT=&lt;confirm&gt;[,&lt;drv&gt;]</b>	Response <b>OK</b>  <b>+BTOPPPUSH: &lt;status&gt;</b>  Parameters <confirm>      1 Accept 0 Reject <drv>            0 internal flash memory 1 external memory card <status>        0 failed 1 successful
	URC: If there has an incoming opp file, there will be a URC report. <b>+BTOPPPUSHING: &lt;name&gt;,&lt;file name&gt;</b>  Parameters <name>           device name



	<b>&lt;file name&gt;</b> file name
Note	1. Max length of <name> is 18 bytes, 18 bytes in UTF-8 code 2. File is stored in path: C:\User\BtReceived\ for internal memory card, D:\BtReceived\ for external memory card. At the first time to use SD card, customer must execute “AT+SD2PCM=0” and “AT&W”, then reboot the module.

## 2.12. AT+BTOPPPUSH Push OPP object to paired device

AT+BTOPPPUSH Push OPP object to paired device	
Test Command <b>AT+BTOPPPUSH=?</b>	Response <b>+BTOPPPUSH:</b> (list of supported <device ID>s), (length of supported <string>s)  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+BTOPPPUSH=&lt;device ID&gt;,&lt;string&gt;</b>	Response <b>OK</b>  <b>+BTOPPPUSH:</b> <para>
	Parameters <device ID> Paired Device ID <string> file name include complete path, length (4-259) <para> 0 Send failed 1 Send successfully 2 Server issue
Note	

## 2.13. AT+BTSPGET Get data based on SPP service

AT+BTSPGET Get data based on SPP service	
Test Command <b>AT+BTSPGET=?</b>	Response <b>+BTSPGET:</b> (list of supported <command>s), (list of supported <connectId>), (list of supported <reqLength>s), (list of supported <showWithHex>s)  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+BTSPGET?</b>	Response <b>+BTSPGET:</b> <command>  <b>OK</b>

	Parameters See Write Command
Write Command 1).If AT+BTSPPCFG= "MC",2 response 1(Enable multi-connect) AT+BTSPPGET =<command>[,<c onnectId> ], <reqLength> ],<s howWithHex>] 2).If AT+BTSPPCFG= "MC",2 response 0(Disable multi-connect) AT+BTSPPGET =<command>[, <reqLength> ],<s howWithHex>]	Response <b>OK</b> <b>or</b> <b>ERROR</b> If command value is 2,return: <b>+BTSPPGET: &lt;connectId&gt;,&lt;cnfLen1&gt;</b> <b>OK</b> If command value is 3,return: <b>+BTSPPGET: &lt;connectId&gt;,&lt;cnfLen1&gt; ,&lt;data string&gt;]</b> <b>OK</b>  Parameters <command> 0 Auto mode. Data will be output in decimal system. 1 Manual mode. There will be an indication when first package arrives. 2 Inquiry data length in manual mode.If multi-connect enabled,this command need parameter <connectId>. 3 Getting data in manual mode. If multi-connect enabled,this command need parameter <connectId>.You can input params of <reqLength> and <showWithHex> when you need.  <reqLength> 1-1024 , the length of data requested, only valid in manual mode <showWithHex> 1, displayed in hex, only valid in manual mode  <connectId> connection's ID <cnfLen1> 0-1024, character length <data string> string printed
Note	URC When the module receives data by SPP,there will be URC report: 1. Auto mode <b>+BTSPPDAT: &lt;connectId&gt;,&lt;cnfLen2&gt;,&lt;data string&gt;</b> 2. Manual mode <b>+BTSPPMAN: &lt;connectId&gt;</b>  Parameter <cnfLen2> 1-1024, length of printed character

## 2.14. AT+BTSPSEND Send data based on SPP service

**AT+BTSPSEND Send data based on SPP service**

<p>Write Command</p> <p>1).If AT+BTSPPCFG= "MC",2 response 1(Enable multi-connect) AT+BTSPPSSEN D=&lt;connectId&gt;,&lt; length&gt; 2).If AT+BTSPPCFG= "MC",2 response 0(Disable multi-connect) AT+BTSPPSSEN D=&lt;length&gt;</p>	<p>Response</p> <p>&gt;</p> <p>If successful, <b>SEND OK</b></p> <p>If failed, <b>SEND FAIL</b></p> <p>Or if this connectId is not allowed to send data, <b>ERROR</b></p> <p>Parameters</p> <p><b>&lt;connectId&gt;</b> connection's ID.If disable multi-connection, this param is no need.</p> <p><b>&lt;length&gt;</b> 1-1024, the length of data will be sent.</p> <p>When the length of inputing data is up to &lt;length&gt; specified, the package will be sent out automatically.</p>
<p>Execute Command AT+BTSPPSSEN D</p>	<p>Response</p> <p>&gt;</p> <p>If successful, <b>SEND OK</b></p> <p>Or failed, <b>SEND FAIL</b></p> <p>Or if this connectId is not allowed to send data, <b>ERROR</b></p> <p>1.If multi-connection function is enabled, this command will be disabled. 2.In this mode, &lt;Ctrl+z&gt; will send the package immediately, and ESC will quit the process.</p>

## 2.15. AT+BTATA Answer incoming call

AT+BTATA Answer incoming call	
<p>Execute Command</p> <p>AT+BTATA</p>	<p>Response</p> <p><b>OK</b></p> <p>URC</p> <p>If there is incoming Call on remote phone, will report below: <b>BTRING</b></p>
<p>Note</p>	<p>When module connected with smartphone as an earphone,if here comes incoming call,the call would be answered through this command</p>

## 2.16. AT+BTATDL Redial last number

AT+BTATDL Redial last number	
<p>Execute Command</p> <p>AT+BTATDL</p>	<p>Response</p> <p><b>OK</b></p>

Note	When module connected with smartphone as an earphone, would redial last number through this command
------	---

## 2.17. AT+BTATH Hung up voice call

AT+BTATH Hung up voice call	
Execute Command <b>AT+BTATH</b>	Response <b>OK</b>
Note	When module connected with smartphone as an earphone, the incoming call would be hung up through this command

## 2.18. AT+BTVGS Configure voice volume

AT+BTVGS Configure voice volume	
Test Command <b>AT+BTVGS=?</b>	Response <b>+BTVGS: (&lt;gain&gt; range)</b>  <b>OK</b>
	Parameters See Write Command
Read Command <b>AT+BTVGS?</b>	Response <b>+BTVGS: &lt;gain&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+BTVGS=&lt;gain&gt;</b>	Response <b>OK</b>  Parameter <b>&lt;gain&gt;</b> volume This command is used configure call volume when the module is connected with smartphone as an earphone
Note	For some smartphone, after connected with BT earphone, the current call volume may not be transmitted to earphone, thus the return value of the read command may be 0. But after setting once, the value would be correct.

## 2.19. AT+BTVGM Configure MIC gain level

AT+BTVGM Configure MIC gain level	
Test Command <b>AT+BTVGM=?</b>	Response <b>+BTVGM: (&lt;gain&gt; range)</b>  <b>OK</b>

Read Command <b>AT+BTVGM?</b>	Response <b>+BTVGM: &lt;gain&gt;</b>  <b>OK</b>
Write Command <b>AT+BTVGM=&lt;gain&gt;</b>	Response <b>OK</b>  Parameter <b>&lt;gain&gt;</b> MIC gain level This command is used set MIC volume when the module is connected with smartphone as an earphone
Note	For some smartphone,after connected with BT earphone,the current MIC volume may not be transmitted to earphone,thus the return value of the read command may be 0.But after setting once,the value would be correct.

## 2.20. AT+BTATD Dial voice call

<b>AT+BTATD Dial voice call</b>	
Test Command <b>AT+BTATD=?</b>	Response <b>+BTATD: (&lt;number&gt; length range)</b>  <b>OK</b>
Write Command <b>AT+BTATD=&lt;number&gt;</b>	Response <b>OK</b>  Parameter <b>&lt;number&gt;</b> phone number Module as earphone connected to smartphone, this command could make an outgoing call
Note	

## 2.21. AT+BTRSSI Get RSSI of connected BT device

<b>AT+BTRSSI Get RSSI of connected BT device</b>	
Test Command <b>AT+BTRSSI=?</b>	Response <b>+BTRSSI: (list of supported &lt;device ID&gt;s)</b>  <b>OK</b>
Write Command <b>AT+BTRSSI=&lt;device ID&gt;</b>	Response <b>+BTRSSI: &lt;rss&gt;</b>  <b>OK</b>

	Parameters <b>&lt;device ID&gt;</b> Connected Device ID <b>&lt;rssi&gt;</b> -127...0    RSSI value of BT device
Note	RSSI value is negative, the smaller value represents the worse signal

## 2.22. AT+BTVTS    Send DTMF tone

AT+BTVTS    Send DTMF tone	
Test Command <b>AT+BTVTS=?</b>	Response <b>+BTVTS: (&lt;dtmf&gt;'s cope)</b>  <b>OK</b>
Write Command <b>AT+BTVTS=&lt;dtmf&gt;</b>	Response <b>OK</b>  Parameter <b>&lt;dtmf&gt;</b> DTMF tone
Note	When module connected with smartphone as an earphone,would send DTMF tone through this command

## 2.23. AT+BTCIND    Get status of smartphone

AT+BTCIND    Get status of smartphone	
Test Command <b>AT+BTCIND=?</b>	Response <b>+BTCIND: (0,1)</b>  <b>OK</b>
Write Command <b>AT+BTCIND=&lt;mode&gt;</b>	Response <b>OK</b>  Parameter <b>&lt;mode&gt;</b> 1 auto report open 0 auto report close  Unsolicited Result Code When <b>&lt;mode&gt;=1</b> , any changed in <b>&lt;service&gt;,&lt;call&gt;,&lt;call_setup&gt;,&lt;held&gt;,&lt;signal&gt;,&lt;roam&gt;,&lt;battchg&gt;</b> , an unsolicited result code is returned: <b>+BTCIND:</b> <b>1,&lt;service&gt;,&lt;call&gt;,&lt;call_setup&gt;,&lt;held&gt;,&lt;signal&gt;,&lt;roam&gt;,&lt;battchg&gt;</b>
Read Command	Response

<b>AT+BTCIND?</b>	<b>+BTCIND:</b> <b>&lt;mode&gt;,&lt;service&gt;,&lt;call&gt;,&lt;call_setup&gt;,&lt;held&gt;,&lt;signal&gt;,&lt;roam&gt;,&lt;battchg&gt;</b>  <b>OK</b>  Parameters <b>&lt;service&gt;</b> 0   no net service 1   net service is normal <b>&lt;call&gt;</b> 0   not active 1   active <b>&lt;call_setup&gt;</b> 0   set up complete 1   incoming call 2   outgoing call 3   remote alert <b>&lt;held&gt;</b> 0   no held call 1   active calls be placed or switched 2   active calls be palced and no active call <b>&lt;signal&gt;</b> 0..5   net work signal <b>&lt;roam&gt;</b> 0   no roaming 1   in roaming <b>&lt;battchg&gt;</b> 0..5   power level
Note	When module connected with smartphone as an earphone, these statuses can be getted.

## 2.24. AT+BTCLCC Get call status of smartphone

<b>AT+BTCLCC Get call status of smartphone</b>	
Test Command <b>AT+BTCLCC=?</b>	Response <b>OK</b>
Read Command <b>AT+BTCLCC?</b>	Response <b>OK</b> When call is active: <b>+BTCLCC: &lt;index&gt;,&lt;dir&gt;,&lt;stat&gt;,&lt;mode&gt;,&lt;mpty&gt;,&lt;number&gt;,&lt;type&gt;</b> ... When no call: <b>+BTCLCC: 0</b>  Parameters <b>&lt;idx&gt;</b> 1..7   Call identification number <b>&lt;dir&gt;</b> 0   Mobile originated (MO) call 1   Mobile terminated (MT) call <b>&lt;stat&gt;</b> State of the call: 0   Active

	1 Held 2 Dialing(MO call) 3 Alerting (Mo call) 4 Incoming (MT call) 5 Waiting (MT call) <mode> Bearer/tele service 0 Voice 1 Data 2 Fax <mpty> 0 Call is not one of multiparty (conference) call parties 1 Call is one of multiparty (conference) call parties <number> String type (string should be included in quotation marks) phone number in format specified by <type>. <type> Type of address
Note	<ul style="list-style-type: none"> <li>If there are mulit calls, multi "+BTCLCC" will be reported, but &lt;index&gt; is different</li> <li>MTK_6261 platform does not support this command.</li> </ul>

## 2.25. AT+BTPBSYNC Sync phonebook from remote by BT

AT+BTPBSYNC Sync phonebook from remote by BT	
Test Command AT+BTPBSYNC =?	Response +BTPBSYNC: (0,1),(1-10),(0,1),(0,1),(0,1)  OK
Write Command AT+BTPBSYNC =<mode>,<storag e>,<loc>[,<loc_p hb>[,<loc_mode> ]]	Response OK  If sync phonebook succeed in mode 0 +BTPBSYNC: <mode>,<result>,<length>  If sync phonebook failed in mode 0 +BTPBSYNC: <mode>,<result>  If in mode 1 +BTPBSYNC: <mode>,<sync2loc_result>,<succ_num>,<fail_num>  If error is related to ME functionality: +CME ERROR: <err>
	Parameterss <mode> sync mode 0 Get remote phonebook and save in file system. This file will store phonebook in VCARD format.



1 Add phonebook records to ME or SM phonebook from VCARD file. Should get remote phonebook file by mode 0 first.

**<storage>** Phonebook storage to sync.

- 1 phonebook on phone storage
- 2 incoming call list on phone storage
- 3 outgoing call list on phone storage
- 4 missed call list on phone storage
- 5 all call list in storage 2, 3, 4
- 6 phonebook on sim card
- 7 incoming call list on sim card
- 8 outgoing call list on sim card
- 9 missed call list on sim card
- 10 all call list in storage 7, 8, 9

**<loc>** file saved in ROM or SD card.

- 0 saved in ROM  
file will be saved in "C:\user\bt\remotePb<n>.txt"
- 1 saved in SD card  
file will be saved in "D:\bt\remotePb<n>.txt"

The 'n' in angle brackets is corresponding with **<storage>**, from 1 to 10.

**<result>** sync phonebook result

- 0 sync phonebook succeed
- 1 fail to get phonebook on remote phone
- 2 save phonebook fail

**<length>** file length

**<loc\_phb>** save phb file to ME or SM. Just use in mode 1.

- 0 SM phonebook
- 1 ME phonebook

**<loc\_mode>** append or overwrite local phonebook. Just use in mode 1.

- 0 append mode. Phonebook records in VCARD file will add in not used index of local phonebook.
- 1 overwrite mode. Local phonebook records will be delete first.

**<sync2loc\_result>** sync result in mode 1

- 0 sync in mode 1 succeed
- 1 function has already run
- 2 local phonebook(ME or SM) full
- 3 not enough memory
- 4 error when read VCARD file.
- 5 error when analyze VCARD file
- 6 local phonebook not ready
- 7 sim card not ready

**<succ\_num>** num of phonebook records succeed add to local phonebook

**<fail\_num>** num of phonebook records failed add to local phonebook.

The most common reason of add failed is name and number field of

	VCARD phonebook record is both empty
Note	

## 2.26. AT+BTPBF Find name or number from remote by BT

### AT+BTPBF Find name or number from remote by BT

Test Command <b>AT+BTPBF=?</b>	Response <b>+BTPBF: (0,1),(32,64),(1-10),(0-2)</b>  <b>OK</b>
Write Command <b>AT+BTPBF=&lt;mode&gt;,&lt;string&gt;[,&lt;storage&gt;[,&lt;order&gt;]]</b>	Response <b>OK</b>  If find name by number succeed <b>+BTPBF: 1,&lt;phb_total&gt;</b> <b>+BTPBF: 1,&lt;phb_index&gt;,&lt;name&gt;</b> ...  If find number by name succeed <b>+BTPBF: 0,&lt;phb_total&gt;</b> <b>+BTPBF: 0,&lt;phb_index&gt;,&lt;num_total&gt;</b> <b>+BTPBF: 0,&lt;phb_index&gt;,&lt;num_index&gt;,&lt;number&gt;,&lt;type&gt;</b> ...  If find name by number failed or find number by name failed at get list step. <b>+BTPBF: &lt;mode&gt;,&lt;error&gt;</b>  If find number by name failed at get entry step <b>+BTPBF: &lt;mode&gt;,&lt;phb_index&gt;,&lt;error&gt;</b>  If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>  Parameters <b>&lt;mode&gt;</b> find mode 0 find number by name 1 find name by number <b>&lt;string&gt;</b> string to be searched. If use mode 0, it should be alphanumeric ASCII text string up to 32 characters If use mode 1, it should be ucs2(big endian) value form with alphanumeric ASCII text string. Max length is 64 <b>&lt;storage&gt;</b> see AT+BTPBSYNC. Default value is 1. <b>&lt;order&gt;</b> search results order

	<p>0 order by indexed</p> <p><u>1</u> order by alpha</p> <p>2 order by sound</p> <p>&lt;phb_total&gt; total number of phonebook record be found. We support max 5 phonebook records.</p> <p>&lt;phb_index&gt; index of phonebook record</p> <p>&lt;name&gt; The name found by number. It will be ucs2(big endian) value.</p> <p>&lt;num_total&gt; total number of &lt;number&gt; in one phonebook record. We support max 4 number in one phonebook record.</p> <p>&lt;num_index&gt; index of &lt;number&gt;</p> <p>&lt;number&gt; The number found by name.</p> <p>&lt;type&gt; type of &lt;number&gt;</p> <p>0 voice</p> <p>1 cell</p> <p>2 home</p> <p>3 work</p> <p>4 fax</p> <p>&lt;error&gt; find error</p> <p>255 fail to find</p>
Note	<p>The support of this function on different brands of mobile phone is different.</p>

SIMCOM CONFIDENTIAL

## 2.27. AT+BTAVRCOP AVRCP operation

AT+ BTAVRCOP AVRCP operation	
Test Command <b>AT+BTAVRCO P=?</b>	Response <b>+BTAVRCOP:</b> <b>(0-STOP,1-PLAY,2-PAUSE,3-FORWARD,4-BACKWARD,5-VOL_</b> <b>UP,6-VOL_DOWN)</b>  <b>OK</b>
Write Command <b>AT+BTAVRCO P=&lt;operator&gt;</b>	Response <b>OK</b>  If error is related to ME functionality: <b>+CME ERROR: &lt;err&gt;</b>  Parameters <b>&lt;operator&gt;</b> <ul style="list-style-type: none"> <li>0 stop the music</li> <li>1 play the music</li> <li>2 pause the music</li> <li>3 play the next song</li> <li>4 play the back song</li> <li>5 increase the volume</li> <li>6 decrease the volume</li> </ul>
Note	

## 2.28. AT+BTVIS Set visibility of BT

AT+BTVIS Set visibility of BT	
Test Command <b>AT+BTVIS=?</b>	Response <b>+BTVIS: (0,1)</b>  <b>OK</b>
Read Command <b>AT+BTVIS?</b>	Response <b>+BTVIS: &lt;visibility&gt;</b>  <b>OK</b>  Response See Write Command
Write Command <b>AT+BTVIS=&lt;visi</b> <b>bility&gt;</b>	Response <b>OK</b>  Parameters <b>&lt;visibility&gt;</b> visibility of BT

	<p>1 open visibility</p> <p>0 close visibility</p>
Note	

## 2.29. AT+BTSPPCFG SPP configuration

AT+BTSPPCFG SPP configuration	
Test Command <b>AT+BTSPPCFG=?</b>	<p>Response</p> <p><b>+BTSPPCFG: (list of supported &lt;btSppCfg&gt;s)</b></p> <p><b>OK</b></p>
Write Command <b>AT+BTSPPCFG=&lt;btSppCfg&gt;,&lt;mode&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>Or</p> <p><b>ERROR</b></p> <p>Parameters</p> <p><b>&lt;btSppCfg&gt;</b> “MC” Multi-connection, enable this function to make the module support to connect double SPP’s client at the same time.</p> <p>“TT” Transparent transmission mode, this function makes the module automatically enter the data mode after the SPP connection is established.</p> <p><b>&lt;mode&gt;</b> 0 Disable</p> <p>1 Enable</p> <p>2 Query</p>
Read Command <b>AT+BTSPPCFG?</b>	<p>Response</p> <p>Every SPP’s link has been connected as server,output: <b>+BTSPPCFG: S,&lt;connectId&gt;,&lt;serverMode&gt;</b></p> <p>Every SPP’s link has been connected as client,output: <b>+BTSPPCFG: C,&lt;connectId&gt;</b></p> <p><b>OK</b></p> <p>Parameters</p> <p><b>&lt;connectId&gt;</b> connection’s ID</p> <p><b>&lt;serverMode&gt;</b> 0 AT mode</p> <p>1 APP mode</p>
Note	<p>In AT mode, module of server can’t execute AT+BTSPPSSEND and AT+BTSPPGET commands.</p> <p>In APP mode, module of server can execute AT+BTSPPSSEND and AT+BTSPPGET commands.</p>

## 2.30. AT+BTPAIRCFG Set BT pairing mode

AT+BTPAIRCFG Set BT pairing mode	
Test Command <b>AT+BTPAIRCFG G=?</b>	<p>Response</p> <p><b>+BTPAIRCFG:</b> (list of supported <b>&lt;mode&gt;</b>s)</p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Read Command <b>AT+BTPAIRCFG G?</b>	<p>Response</p> <p>If <b>mode=1</b>, the notification information is:</p> <p><b>+BTPAIRCFG: &lt;mode&gt;,&lt;pin_code&gt;</b></p> <p><b>OK</b></p> <p>If <b>mode=0</b> or <b>2</b>, the notification information is:</p> <p><b>+BTPAIRCFG: &lt;mode&gt;</b></p> <p><b>OK</b></p> <p>Parameters</p> <p>See Write Command</p>
Write Command 1) if PIN-Code inputted by manual while pairing <b>AT+BTPAIRCFG G=1,&lt;pin_code&gt;</b> <b>1</b> 2) if using random PIN-Code while pairing <b>AT+BTPAIRCFG G=&lt;mode&gt;</b>	<p>Response</p> <p><b>OK</b></p> <p>Parameters</p> <p><b>&lt;mode&gt;</b>      0 random PIN-Code, and need confirm the pairing request                  1 PIN-Code inputted by manual                  2 random PIN-Code, and response the pairing request                  automatic</p> <p><b>&lt;pin_code&gt;</b> PIN-Code, the length is four. default value is 0000</p>
Note	<p>When <b>mode</b> is 0 or 2, it is random PIN-Code</p> <p>When mode is 2, it has no <b>+BTPAIRING</b> information, and response the pairing request automatic;</p> <p>When mode is 0, it has <b>+BTPAIRING</b> information, and need input <b>AT+BTPAIR=1,1</b> to confirm pairing request.</p> <p>The setting will be valid after reboot.</p>

## 2.31. AT+CPBFEX Find name or number in module phonebook

AT+CPBFEX Find name or number in module phonebook
---

Test Command <b>AT+CPBFEX=?</b>	Response <b>+CPBFEX: (0,1),40</b>  <b>OK</b>
Write Command <b>AT+CPBFEX=&lt;mode&gt;,&lt;value&gt;</b>	Response TA returns phone book entries, which contains alphanumeric string <text>.  <b>[+CPBFEX: &lt;text&gt;]</b>  <b>OK</b>
	Parameters <b>&lt;mode&gt;</b> find mode 0 find name by number 1 find number by name <b>&lt;value&gt;</b> String type field of maximum length 40. When select <b>&lt;mode&gt;</b> 1, <b>&lt;value&gt;</b> should set in current TE character set specified by +CSCS. <b>&lt;text&gt;</b> String type field. When select <b>&lt;mode&gt;</b> 0, <b>&lt;text&gt;</b> will return in current TE character set specified by +CSCS.
Note	AT+CPBFEX will only return the first find result. AT+CPBFEX could find name or number which CPBFEX could not display when use BTPBSYNC sync PHB to ME phonebook.

### 2.32. AT+BTRING Control ring playing transferred from phone

<b>AT+BTRING</b> Control ring playing transferred from phone	
Test Command <b>AT+BTRING=?</b>	Response <b>+BTRING: (0,1)</b>  <b>OK</b>
Read Command <b>AT+BTRING?</b>	Response <b>+BTRING:&lt;mode&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+BTRING=&lt;mode&gt;</b>	Response <b>OK</b>
	Parameters <b>&lt;mode&gt;</b> 0 not play ring transferred from mobile phone

	<u>1</u> play ring transferred from mobile phone
Note	<ul style="list-style-type: none"> <li>This command takes effect when module acts as earphone in BT link.</li> <li>This command doesn't support power off save.</li> </ul>

### 2.33. AT+BTACI Set report mode of BT audio service state change

AT+BTACI Set report mode of BT audio service state change	
Test Command AT+BTACI=?	Response +BTACI: (0,1)  OK
Read Command AT+BTACI?	Response +BTACI:<mode>,<state>  OK  Parameters See Write Command
Write Command AT+BTACI=<mode>	Response OK  Parameters <mode> set URC report or not when audio service state change <u>0</u> no URC report when audio service state change 1 URC report when audio service state change <state> BT audio State <u>0</u> idle 1 SCO service 2 A2DP service  Unsolicited Result Code When <mode> is set to 1, URC +BTACI:<state> will report when BT audio service state change
Note	This command doesn't support power off save.

### 2.34. AT+BTHFGOP Set action mode of MS when earphone button is pressed during BT link

AT+BTHFGOP Set action mode of MS when earphone button is pressed during BT link	
Test Command AT+BTHFGOP=?	Response +BTHFGOP: (0-2)  OK



Read Command <b>AT+BTHFGOP?</b>	Response <b>+BTHFGOP: &lt;mode&gt;,&lt;event&gt;</b>  <b>OK</b>
	Parameters See Write Command
Write Command <b>AT+BTHFGOP= &lt;mode&gt;</b>	Response <b>OK</b>
	Parameters <mode> Set action mode of MS when earphone button is pressed during BT link <u>0</u> MS acts normally 1 URC is reported and RI pin will be pulled down for 120ms,MS will suspend earphone events and take no action. 2 Clear event to 0,mode not change <event> Earphone event <u>0</u> No event 1 Call redial 2 Answer incoming call 3 Call hang up
	Unsolicited Result Code When <mode> is set to 1, URC <b>+BTHFGOP: &lt;event&gt;</b> will report when earphone event has been changed.
Execute Command <b>AT+BTHFGOP</b>	Execute command will restore earphone events of MS. Execute command can't execute when no event.  Response <b>OK</b>
Note	This command doesn't support power off save.

### 2.35. AT+BTSPPURC Set the report format of command +BTSPSEND

<b>AT+BTSPPURC</b> Set the report format of command +BTSPSEND	
Test Command <b>AT+BTSPPURC =?</b>	Response <b>+BTSPPURC: (0-1)</b>  <b>OK</b>
Read Command <b>AT+BTSPPURC ?</b>	Response <b>+BTSPPURC: &lt;mode&gt;, &lt;succ_str&gt;, &lt;fail_str&gt;</b>

	<b>OK</b>
	Parameters See Write Command
Write Command <b>AT+BTSPPURC</b> <b>=&lt;mode&gt;</b>	Response <b>OK</b>
	Parameters <mode> Set the report format of command +BTSPSEND <u>0</u> Common URC of data mode 1 Special URC of Bluetooth data mode <succ_str> <u>SEND OK</u> Common URC for success BT SEND OK Special URC for success <fail_str> <u>SEND FAIL</u> Common URC for failure BT SEND FAIL Special URC for failure
Note	This command doesn't support power off save. The default value of <mode> is 0.

## 2.36. AT+BTCLCCS Get call status of smartphone

<b>AT+BTCLCCS Get call status of smartphone</b>	
Test Command <b>AT+BTCLCCS=?</b>	Response <b>+BTCLCCS: (0,1)</b>
	<b>OK</b>
	Parameters See Write Command
	Response <b>OK</b>
Write Command <b>AT+BTCLCCS=&lt;mode&gt;</b>	Parameters <mode> Auto report state 1 Active <u>0</u> Deactive
	Unsolicited Result Code When <mode> is set to 1, URC will report when call state change: <b>+BTCLCCS: 1,&lt;call_stat&gt;,&lt;number&gt;,&lt;call_id&gt;</b>
Read Command <b>AT+BTCLCCS?</b>	Response <b>+BTCLCCS: &lt;mode&gt;</b>
	<b>OK</b>

	Parameters See Write Command
Execute Command <b>AT+BTCLCCS</b>	<p>Response</p> <p><b>OK</b></p> <p>When call is active:</p> <p><b>+BTCLCCS: &lt;mode&gt;,&lt;call_stat&gt;,&lt;number&gt;,&lt;call_id&gt;</b></p> <p>...</p> <p>When no call:</p> <p><b>+BTCLCCS: &lt;mode&gt;,0,,0</b></p>
	<p>Parameters</p> <p><b>&lt;mode&gt;</b> Auto report state</p> <p>1 Active</p> <p>0 Deactive</p> <p><b>&lt;call_stat&gt;</b> state of call</p> <p>0 Idle</p> <p>1 Dialing(MO call)</p> <p>2 Incoming (MT call)</p> <p>4 Active</p> <p>8 Hold</p> <p><b>&lt;number&gt;</b> String type (string should be included in quotation marks) phone number in format specified by &lt;type&gt;.</p> <p><b>&lt;call_id&gt;</b> 1..7 Call identification number</p>
Note	<ul style="list-style-type: none"> <li>● If there are mulit calls, multi “+BTCLCCS” will be reported, but &lt;index&gt; is different</li> <li>● Only MTK_6261 platform support this command.</li> </ul>

### 2.37. AT+BTSPPCFD Set string of SPP switching work mode

<b>AT+BTSPPCFD</b>	<b>Set string of SPP switching work mode</b>
Test Command <b>AT+BTSPPCFD</b> <b>=?</b>	<p>Response</p> <p><b>+BTSPPCFD: (list of supported &lt;switchStr&gt;)</b></p> <p><b>OK</b></p>
	Parameters See Write Command
Write Command <b>AT+BTSPPCFD</b> <b>=&lt;switchStr&gt;</b>	<p><b>OK</b></p> <p>or</p> <p><b>ERROR</b></p>
	Parameters <b>&lt;switchStr&gt;</b> String used to switch work mode from AT mode to data mode
Read Command	Response

AT+BTSPPCFD ?	+BTSPPCFD: <switchStr>
	OK
	Parameters See Write Command
Note	<p>The usage of this command depends on the model of modules:</p> <ol style="list-style-type: none"> <li>1. When any module except SIM800C acts as the SPP server, the default connection type is AT mode. User needs to input special strings in order to switch to data mode. If the string is null (AT+BTSPPCFD=""), SPP server will directly enter data mode after any data is received from client during the next connection.</li> <li>2. When SIM800C acts as the SPP server, the default connection type is APP data mode. User needs to input special strings in order to switch to the AT mode. If the string is null (AT+BTSPPCFD=""), SPP server will never enter into the data mode.</li> </ol>

### 2.38. AT+BTCOD Set the Bluetooth Class of Device

AT+BTCOD Set the Bluetooth Class of Device	
Test Command AT+BTCOD=?	Response OK
	Parameters See Write Command
Write Command  AT+BTCOD=<en>[,<mjr_srv>[,<mjr_cls>[,<mnr_cls>]]]	Response OK or ERROR
	Parameters <en>      0 - Disable customized COD 1 - Enable customized COD <mjr_srv>   Major service code <mjr_cls>   Major class code <mnr_cls>   Minor class code
Read Command AT+BTCOD?	Response +BTCOD: <en>,<mjr_srv>,<mjr_cls>,<mnr_cls>
	OK
	Parameters See Write Command
Note	The setting does not support power-off preservation. This command only be used when the Bluetooth is power down.

### 3. CME Error Code

The following error message is associated with the Bluetooth operation following format: +CME ERROR: <err>, the specific error code and error message in the following table:

Code	Description
1000	Return fail
1002	Not power on
1003	State not idle
1004	Malloc error
1010	Scan fail
1011	scan return error
1020	Out of scanning count
1021	Out of profile id count
1025	Out of pairing count
1026	Bond error
1027	Device has Bonded
1030	Debond error
1031	Get device info error
1032	Service refresh error
1033	Profile connect error
1034	HF attach error
1040	OPP handle error
1041	OPP send error
1042	OPP received path error
1043	SD card not exist
1044	OPP file path error
1045	OPP send error by server
1046	Get index by profile error
1047	Connect not support
1048	Disconnect not support
1049	Active or address error
1050	Only connect one device
1051	Out of max connection
1055	SPP is not connect
1056	Spp server isn't work at send mode
1057	Input data length beyond
1058	SPP port is not create
1060	Pls connect A2DP first

1061	Connected device exceed max
1099	BTAUD attach error

SIMCOM CONFIDENTIAL FILE

## 4. Examples

There are some examples to explain how to use these commands.

In the "Grammar" columns of following tables, inputs of AT commands are in black, module return values are in blue.

### 4.1. Accept request from other BT device

Command	Description
AT+BTPOWER=1 OK	Power on BT radio
+BTPAIRING: "PC-NS130100361",34:c7:31:aa:37:5b,763191	Incoming digital key request from other BT device
AT+BTPAIR=1,1 OK +BTPAIR: 1,"PC-NS130100361",34:c7:31:aa:37:5b	Accept pairing request, and paired successfully
+BTPAIRING: "Jabra BT160",00:16:8f:0d:65:82	Incoming passkey request from other BT device
AT+BTPAIR=2,0000 OK +BTPAIR: 2,"LBH505",50:5b:0b:0a:10:32	Accept pairing request, and paired successfully.Default passkey of other BT device is 0000.If not, please change this value according to other device's passkey.

### 4.2. Send pairing request to other BT device

Command	Description
AT+BTPOWER=1 OK	Power on BT radio
AT+BTSCAN=1,20 OK +BTSCAN: 0,1,"PC-NS130100361",34:c7:31:aa:37:5b,-34  +BTSCAN: 0,2,"ADMIN-9A6E040AC",68:5d:43:ec:fe:72,-44  +BTSCAN: 0,3,"LIB-PC",c8:f7:33:43:48:e6,-54  +BTSCAN:	Inquiring surrounding BT device

0,4,"MK-FUJIANJUN",88:53:2e:e8:9d:0f,-33  +BTSCAN: 0,5,"MTKBTDEVICE",45:8c:96:3e:66:01,-56  +BTSCAN: 0,6,"MK-ZHANZHIMIN",00:1a:7d:da:71:10,-67  +BTSCAN: 0,7,"Jabra BT160",00:16:8f:0d:65:82,-55  +BTSCAN: 1	
AT+BTPAIR=0,6 OK	Try to pair the sixth BT device in the view list
+BTPAIRING: "MK-ZHANZHIMIN",00:1a:7d:da:71:10,76319 1 AT+BTPAIR=1,1 OK  +BTPAIR: 1,"MK-ZHANZHIMIN",00:1a:7d:da:71:10	Answer to the pairing request in digital key mode
AT+BTPAIR=0,7 OK	Try to pair the seventh BT device in the view list
+BTPAIRING: "Jabra BT160",00:16:8f:0d:65:82 AT+BTPAIR=2,0000 OK +BTPAIR: 2,"Jabra BT160",00:16:8f:0d:65:82	Answer to the pairing request in passkey mode

### 4.3. Get the profile provided by paired device

Command	Description
	Configure based on example 4.2
AT+BTGETPROF=1 +BTGETPROF: 1,"A2DP(Source)" +BTGETPROF: 2,"HFP(AG)" +BTGETPROF: 8,"AVRCP(Target)" +BTGETPROF: 3,"A2DP" +BTGETPROF: 4,"SPP" +BTGETPROF: 6,"HFP" +BTGETPROF: 5,"HSP"  OK	Get the profile of first paired device in list



#### 4.4. Connect service

Command	Description
	Get Profile based on example 4.3
AT+BTCONNECT=1,2 OK  +BTCONNECT: 1,"MK-ZHANZHIMIN",00:1a:7d:da:71:10,"HFP(AG)"	Connect with the second profile service of first paired device, "HFP(AG)"

#### 4.5. Accept file from paired device

Command	Description
	Pairing device based on example 4.2
+BTOPPPUSHING: "MK-ZHANZHIMIN","link.txt"	Incoming opp pushing service from paired device
AT+BTOPPACPT=1 OK  +BTOPPPUSH: 1	Accept file(stored in internal memory card by default,input "AT+BTOPPACPT=1,1" if want it stored in external memory

#### 4.6. Send file to other paired BT device

Command	Description
	Pairing device based on example 4.2
AT+BTOPPPUSH=1,c:\User\BtReceived\link.txt OK  +BTOPPPUSH: 1	Sending file and waiting for response

#### 4.7. Create SPP's link as a client

Command	Description
	Suppose this device's ID is 12:34:56:78:90:12,name is IT;Another ID is 34:c7:31:aa:37:5b,name is ME.they make pair successfully.
AT+BTCONNECT=1,4 OK  +BTCONNECT: 1,"IT",12:34:56:78:90:12,"SPP"	Try to build a SPP's connection to server.  If successfully, output these URC.

#### 4.8. SPP's link be create as a server

Command	Description
	Suppose this device's ID is 12:34:56:78:90:12, name is IT; The other ID is 34:c7:31:aa:37:5b, name is ME.they make pair successfully.
+BTCONNECTING: "34:c7:31:aa:37:5b","SPP" AT+BTACPT=1 OK	Receive a request from client which build a connection. Accept it.
+BTCONNECT: 1,"ME",34:c7:31:aa:37:5b,"SPP"	Build success.

#### 4.9. Configure SPP

Command	Description
	Get Profile based on example 4.3. Suppose this device's ID is 12:34:56:78:90:12, and name is IT;The other ID is 34:c7:31:aa:37:5b, and name is ME.This module has had a server-type link of SPP.
AT+BTSPPCFG? +BTSPPCFG: S,1,0  OK AT OK AT OK	There is a link.It's a server; Connection's ID is 1; It's not allowed to send data to client. If there is a request from another device which tries to build a connection, no URC will be reported. Because this module disable multi-connection function.
AT+BTSPPCFG="MC",1 OK	Enable multi-connection function.
AT+BTSPPCFG="MC",2 +BTSPPCFG: MC,1  OK	Inquire whether the multi-connection is enabled. Enable.
+BTCONNECTING: "0c:c5:95:09:62:60","SPP" AT+BTACPT=1 OK	There is a request that tries to build a SPP's connection.
+BTCONNECT: 1,"THIRD",0c:c5:95:09:62:60,"SPP" +BTSPPCFG: 2,15,SIMCOMSPPFORAPP AT OK	Build connection successfully.  Receive the message of switching mode to

AT+BTSPPCFG? +BTSPPCFG: S,1,0 +BTSPPCFG: S,2,1  OK	APP mode from the second client's link.   Allow to send data to second client's link.
--	--

#### 4.10. Send data as a SPP's client

A SPP connection has two modules. One is client, and the other is server. Let us see the demo with client module.

Command	Description
	Based on example 4.7, as a client.
AT+BTSPPCFG? +BTSPPCFG: C,1  OK AT+BTSPSEND >AT+CREG? <input type="checkbox"/> SEND OK  +BTSPDATA: 19,1,A  +BTSPDATA: 19,3,T+C  +BTSPDATA: 19,25,REG?  +CREG: 0,0  OK AT+BTSPSEND=10 >1234567890 <input type="checkbox"/> SEND OK	There is a link, client-type, and allowed to send data to the server.     If the client sends AT command to the server, this command and its response will output to client.    "AT+CREG?" are input characters.  "+CREG: 0,0" and "OK" are responses.   If the multi-connection function is disabled, we don't need to input connection's ID. Input data(1234567890) and press Ctrl+Z keys, the data will be sent.

#### 4.11. As a SPP's server worked in AT mode

SPP's connection as a server has two mode. One is AT mode. In this mode, we can't use AT+BTSPSEND/BTSPGET commands to send data to the client or get data from the client. We can only receive data from the client.

Command	Description
	Based on example 4.8, as a server.
AT+BTSPPCFG? +BTSPPCFG: S,1,0	There is a link. Server-type; connection's ID is 1; It's not allowed to send data to the

OK	client.
AT+BTSPSEND=10 ERROR	Fail to send.
AT+BTSPSEND ERROR	Fail to send.

#### 4.12. As a SPP's server worked in APP mode and multi-connection

Another SPP's link mode as a server is the APP mode. In this mode, we can execute AT+BTSPSEND and AT+BTSPGET commands.

Command	Description
	Based on example 4.7, as a server.
+BTSPDATA: 1,15,SIMCOMSPPFORAPP AT OK AT OK AT+BTSPPCFG? +BTSPPCFG: S,1,1  OK AT+BTSPSEND >12345 SEND OK AT+BTDISCONN=1 OK  +BTDISCONN: "SIM800H",34:c7:31:aa:37:5b,"SPP" AT+BTSPGET=1 OK  +BTCONNECTING: "34:c7:31:aa:37:5b","SPP" AT+BTACPT=1 OK  +BTCONNECT: 1,"SIM800H",34:c7:31:aa:37:5b,"SPP"  +BTSPPMAN: 1 AT OK AT+BTSPGET=2,1 +BTSPGET: 1,15	Receive the specified data package from the first client's link which means switching the mode to APP mode(This data package must be the first package recieved).After excuting AT+BTSPPCFD="",client will enter APP mode when sending data package without specified strings.  Allow to send data to the client.  Send succesefully.  Disconnect this link of client.  Switch to manual mode.  Recieve the connecting request from the client.  Build link succesefully.  Receive the data from the client whose connection's ID is 1.  Connection's ID is 1, and the data length is

<p>OK</p> <p>AT+BTSPGET=3,1,15</p> <p>+BTSPGET: 1,15,SIMCOMSPPFORAPP</p> <p>OK</p> <p>AT+BTSPSEND</p> <p>&gt; 1234567890□</p> <p>SEND OK</p>	<p>15.</p> <p>Get data, length is 15(This data package means switching the mode to APP mode).</p> <p>Send data to the client.</p> <p>Send successfully.</p>
<p>AT+BTSPGET=?</p> <p>+BTSPGET: (0-3),(1-6),(1-1024),1</p> <p>OK</p>	

#### 4.13. Sync phonebook from remote by BT

Command	Description
	Based on example 4.2
<p>AT+BTGETPROF=1</p> <p>+BTGETPROF: 10,"PBAP"</p> <p>+BTGETPROF: 1,"A2DP(Source)"</p> <p>+BTGETPROF: 2,"HFP(AG)"</p> <p>+BTGETPROF: 8,"AVRCP(Target)"</p> <p>OK</p>	Get the profile of first paired device in list
<p>AT+BTCONNECT=1,10</p> <p>OK</p> <p>+BTCONNECT:</p> <p>1,"LG-P705",00:aa:70:23:7d:06,"PBAP(C)"</p>	<p>Connect server</p> <p>Report automatically once ready</p>
<p>AT+BTPBSYNC=0,1,0</p> <p>OK</p> <p>+BTPBSYNC: 0,0,53786</p>	<p>Sync phonebook</p> <p>Sync succeed. File size is 53786 bytes.</p>

#### 4.14. Find name or number from remote by BT

Command	Description
	Based on example 4.2
<p>AT+BTGETPROF=1</p> <p>+BTGETPROF: 10,"PBAP"</p> <p>+BTGETPROF: 1,"A2DP(Source)"</p>	Get the profile of first paired device in list

+BTGETPROF: 2,"HFP(AG)" +BTGETPROF: 8,"AVRCP(Target)"  OK	
AT+BTCONNECT=1,10 OK  +BTCONNECT: 1,"LG-P705",00:aa:70:23:7d:06,"PBAP(C)"	Connect server  Report automatically once ready
AT+BTPBF=1,"135",1 OK  +BTPBF: 1,5  +BTPBF: 1,1,0031003300350038003500380038003700370 0370035  +BTPBF: 1,2,5170621056FD  +BTPBF: 1,3,521800206587660E  +BTPBF: 1,4,52186021  +BTPBF: 1,5,5362592A592A	Find name whose number contain "135".  Find succeed. Five names found.
AT+BTPBF=0,"0063",1 OK  +BTPBF: 0,1  +BTPBF: 0,1,1  +BTPBF: 0,1,1,*****,,1	Find number which owner's name contain char "c" (format with use2 value is "0063").  Find succeed. One phonebook record found.  First phonebook record contain one number



#### 4.15. Play music and so on by AVRCP

Command	Description
	Based on example 4.2
AT+BTGETPROF=1 +BTGETPROF: 1,"A2DP(Source)" +BTGETPROF: 2,"HFP(AG)" +BTGETPROF: 8,"AVRCP(Target)"  OK	Get the profile of first paired device in list

<p>AT+BTCONNECT=1,1 OK</p> <p>+BTCONNECT: 1,"Lenovo A780",d8:71:57:2b:02:66,"A2DP"</p> <p>+BTCONNECT: 2,"Lenovo A780",d8:71:57:2b:02:66,"AVRCP"</p> <p>+BTCONNECT: 3,"Lenovo A780",d8:71:57:2b:02:66,"HFP(AG)"</p>	<p>Connect with the first profile service of first paired device, "A2DP", For the service of "AVRCP" depends on the "A2DP". After connected with "A2DP" successfully, the modem will connect to the service of "AVRCP" automatically.</p> <p>Report automatically once ready.</p>
<p>AT+BTAVRCOP=1 OK</p> <p>AT+BTAVRCOP=2 OK</p> <p>AT+BTAVRCOP=1 OK</p> <p>AT+BTAVRCOP=3 OK</p> <p>AT+BTAVRCOP=4 OK</p> <p>AT+BTAVRCOP=5 OK</p> <p>AT+BTAVRCOP=6 OK</p> <p>AT+BTAVRCOP=0 OK</p>	<p>Play music The sound can be heard from the modem</p> <p>Pause music The music will be paused</p> <p>Play music again The music will be played</p> <p>Play the next song The next song will be played</p> <p>Play the back song The back song will be played</p> <p>Increase the volume The volume of the music will be increased</p> <p>Decrease the volume The volume of the music will be Decreased</p> <p>Stop music The music will be stopped</p>

#### 4.16. Add phonebook records to ME or SM phonebook from VCARD file

Command	Description
	Based on example 4.13
<p>AT+BTPBSYNC=1,1,0,0,1 OK</p>	Sync file "c:\user\bt\remotePb1.txt" to SM phonebook with overwrite mode

+BTPBSYNC: 1,0,214,67	Sync finished. 214 phonebook records add succeed and 67 records failed.
AT+CPBR=1,250 +CPBR: 1,"",129,"Me" ... OK	Read phonebook records.

#### 4.17. Set BT pairing mode

Command	Description
AT+BTPOWER=1 OK	Power on BT radio
AT+BTPAIRCFCG=1 OK	Set paring mode is PIN-Code inputted by manual (mode=1), and the default PIN-Code value is 0000, if you want to set other PIN-Code, follow it: AT+BTPAIRCFCG=1,<pin_code>
	BT reboot
AT+BTSCAN=1 OK  +BTSCAN: 0,1,"XT615 ",00:11:94:cb:20:d2,-34  +BTSCAN: 0,2,"LIB-PC",c8:f7:33:43:48:e6,-45 AT+BTPAIR=0,1 OK  +BTSCAN: 2  +BTPAIR: 1,"XT615 ",00:11:94:cb:20:d2	Inquiring surrounding BT device and pair, input PIN-Code by opposite side, the default value is 0000
AT+BTPAIRCFCG=2 OK	Set pairing mode is random PIN-Code(mode = 2). (mode = 0, reference 4.2 section)
	BT reboot
AT+BTSCAN=1 OK +BTSCAN: 0,1,"XT615 ",00:11:94:cb:20:d2,-44  +BTSCAN: 0,2,"MK-ZHANZHIMIN",00:1a:7d:da:71:10,-55 AT+BTPAIR=0,1 OK	Inquiring surrounding BT device and pair, and wait to confirm pairing request by opposite side.



+BTSCAN: 2

+BTPAIR: 1,"XT615 ",00:11:94:cb:20:d2

SIMCOM CONFIDENTIAL FILE

## 5. Differences between bluetooth version and standard Version

*Note: In this chapter, SIM800 BT indicates SIM800 series BT version, SIM800 indicates SIM800 series standard version. Differences among SIM800 series standard version, please refer to chapter 21 for details in doc "SIM800 Series AT Command Manual".*

### 5.1.ATD<str>

SIM800 BT does not support finding number by name.

### 5.2.AT+CPBF

SIM800 BT	SIM800
Max length of <findtext> is always 40 bytes.	Max length of <findtext> depends on AT+CSCS
Results will order by phonebook index when select "SM" or "ME" phonebook, from small to large.	Results will order by the order user inputs phonebooks.
<findtext> must match <text> from the leftmost side, when select "SM" or "ME" phonebook	No this limit
Difference	There are multi difference of AT+CPBF between SIM800 BT and SIM800.

### 5.3.AT+CMUX

SIM800 BT does not support MUX function.

### 5.4.AT+CNUM

SIM800 BT	SIM800
+CNUM: [<alpha>],<number>,<type>,<service>	+CNUM: <alpha>,<number>,<type>,<speed>,<service>
Difference	<alpha> of SIM800 BT does not display if length of <alpha> is 0. SIM800 BT does not support <speed> field and left blank.

## 5.5.AT+CMGS

SIM800 BT does not support sending message by phonebook index or name.

## 5.6.AT+CMSS

SIM800 BT does not support sending message from storage.

## 5.7.AT+CPMS

SIM800 BT	SIM800
<b>AT+CPMS=?</b> <b>+CPMS:</b> <b>("SM","ME","MT"),("SM","ME","MT"),("SM","ME","MT")</b>  <b>OK</b>	<b>AT+CPMS=?</b> <b>+CPMS:</b> <b>("SM","ME","SM_P","ME_P","MT"),("SM","ME","SM_P","ME_P","MT"),("SM","ME","SM_P","ME_P","MT")</b>  <b>OK</b>
<b>Difference</b>	<b>SIM800 BT supports three modes: "SM","ME","MT".</b> <b>SIM800 supports "SM","ME","SM_P","ME_P","MT" modes.</b>

## 5.8.AT+CHFA

SIM800 BT	SIM800
<b>AT+CHFA=?</b> <b>+CHFA: (0=NORMAL_AUDIO,</b> <b>1=AUX_AUDIO, 2=HANDFREE_AUDIO,</b> <b>3=AUX_HANDFREE_AUDIO,</b> <b>4=PCM_AUDIO,5=BT_CHANNEL)</b>  <b>OK</b>	<b>AT+CHFA=?</b> <b>+CHFA: (0=NORMAL_AUDIO,</b> <b>1=AUX_AUDIO, 2=HANDFREE_AUDIO,</b> <b>3=AUX_HANDFREE_AUDIO,</b> <b>4=PCM_AUDIO)</b>  <b>OK</b>
<b>Difference</b>	<b>Value of parameter &lt;n&gt; has BT audio channel in SIM800 BT.</b> <b>BT channel can be set when BT link is established and module acts as mobile phone. After switch to BT channel, local sound can be transferred to BT earphone. If BT link is disconnected, audio channel will restore to the original channel and URC +CHFA: &lt;n&gt; is reported. Because the audio service is always on after switch to BT channel, consumption current is bigger than normal.</b>

## 5.9.TTS function

SIM800 BT which module memory is 32M does not support TTS function.

## Appendix

### A. Reference

ID	Document	Remark
[1]	SIM800 Series_AT Command Manual	

### B. Profile

Profile	Introduction
SPP	Abbreviation of Serial Port Profile, to implement BT serial port function. Module can transmit data to connected BT device through AT+BTSPSEND after successfully applying this profile. The module will receive data report +BTSPDATA in automatic mode, and +BTSPPMAN in manual mode.
OPP	Abbreviation of OPP Object Push Profile, to implement pushing BT object. This function is used between the two paired BT devices, AT+BTOPPPUSH to push file, AT+OPACPT to receive the pushed file.
HFP/HSP	Abbreviation of Handsfree Profile/Headset Profile, i.e. BT earphone function. HFP is the enhanced version of HSP, so even if the other BT device just supports HSP, SIM800H still can connect the BT device with HFP. Module's call voice would be displayed from BT earphone after this profile being connected. When the module plays a role as smart phone, BT earphone could control the call operation (e.g. hang up, answer, redial).
A2DP	Abbreviation of Advanced Audio Distribution Profile, which is advanced protocol for audio frequency distribution. Earphone will activate AVRCP connection after the profile being connected. It is mainly used for BT earphone to transmit Hi-Q audio frequency. If be suffixed with source, it means this device is audio frequency source, i.e. play a role as smartphone.
AVRCP	Abbreviation of Audio Video Remote Control Profile, is AV remote control protocol. This profile depends on A2DP and only could be connected after the A2DP connection is established. It is mainly used for BT earphone to control the media function of smartphone. If be suffixed with target, it means this device is controlling target, i.e. play a role as smart phone.
HFP(AG)	This profile is HFP, i.e. play a role as BT earphone. After the module connected with smartphone, the call voice of smartphone could be displayed by the module's audio channel. Also the call operation of smartphone can be controlled by those commands such as AT+BTATD, AT+BTATH, AT+BTATA.
HFG	This profile is HFP, but plays a role as smartphone at this moment. After the

	module connected with smartphone,there will display such information indicates profile being connected successfully.If the module plays a role of earphone,then the information displayed after connection will be HFP(AG).
PBAP	Phone Book Access Profile (PBAP) is a profile that allows exchange of Phone Book Objects between devices.

### C. Glossary and Abbreviation

Glossary	Discription
EVb	Evaluation Board
BT	Blue tooth
PROFILE	Bluetooth function protocol
SPP	Serial Port Profile
OPP	OPP Object Push Profile
A2DP	Advanced Audio Distribution Profile
AVRCP	Audio Video Remote Control Profile
HSP	BT handset protocol
HFP	HandFree application protocol
URC	Unsolicited Result Code
TE	Terminal Equipment
TA	Terminal Adapter
DTE	Data Terminal Equipment
DCE	Data Communication Equipment
ME	Mobile Equipment
MS	Mobile station
PBAP	Phone Book Access Profile

**Contact us:**

**Shanghai SIMCom Wireless Solutions Co.,Ltd.**

Address: Building A, SIM Technology Building, No. 633, Jinzhong Road, Shanghai,  
P. R. China 200335

Tel: +86 21 3252 3300

Fax: +86 21 3252 3020

URL: [www.sim.com/wm](http://www.sim.com/wm)

SIMCOM CONFIDENTIAL FILE