



Mellanox MLNX-OS™ Command Reference Guide for Ethernet

Rev 1.5.3
Software Ver. 3.2.0506

NOTE:

THIS HARDWARE, SOFTWARE OR TEST SUITE PRODUCT (“PRODUCT(S)”) AND ITS RELATED DOCUMENTATION ARE PROVIDED BY MELLANOX TECHNOLOGIES “AS-IS” WITH ALL FAULTS OF ANY KIND AND SOLELY FOR THE PURPOSE OF AIDING THE CUSTOMER IN TESTING APPLICATIONS THAT USE THE PRODUCTS IN DESIGNATED SOLUTIONS. THE CUSTOMER'S MANUFACTURING TEST ENVIRONMENT HAS NOT MET THE STANDARDS SET BY MELLANOX TECHNOLOGIES TO FULLY QUALIFY THE PRODUCT(S) AND/OR THE SYSTEM USING IT. THEREFORE, MELLANOX TECHNOLOGIES CANNOT AND DOES NOT GUARANTEE OR WARRANT THAT THE PRODUCTS WILL OPERATE WITH THE HIGHEST QUALITY. ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT ARE DISCLAIMED. IN NO EVENT SHALL MELLANOX BE LIABLE TO CUSTOMER OR ANY THIRD PARTIES FOR ANY DIRECT, INDIRECT, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES OF ANY KIND (INCLUDING, BUT NOT LIMITED TO, PAYMENT FOR PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY FROM THE USE OF THE PRODUCT(S) AND RELATED DOCUMENTATION EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.



Mellanox Technologies
350 Oakmead Parkway Suite 100
Sunnyvale, CA 94085
U.S.A.
www.mellanox.com
Tel: (408) 970-3400
Fax: (408) 970-3403

Mellanox Technologies, Ltd.
Beit Mellanox
PO Box 586 Yokneam 20692
Israel
www.mellanox.com
Tel: +972 (0)4 909 7200 ; +972 (0)74 723 7200
Fax: +972 (0)4 959 3245

© Copyright 2012. Mellanox Technologies. All rights reserved.

Mellanox®, Mellanox Logo®, BridgeX®, ConnectX®, CORE-Direct®, InfiniBridge®, InfiniHost®, InfiniScale®, PhyX®, SwitchX®, Virtual Protocol Interconnect® and Voltaire® are registered trademarks of Mellanox Technologies, Ltd.

FabricIT™, MLNX-OS™, Unbreakable-Link™, UFM™ and Unified Fabric Manager™ are trademarks of Mellanox Technologies, Ltd.

All other trademarks are property of their respective owners.

Mellanox MLNX-OS™ Command Reference Guide for Ethernet

Table of Contents

Table of Contents	1
Document Revision History	9
About this Manual	10
Chapter 1 Using the Command Line Interface	15
1.1 CLI Modes	15
1.2 Syntax Conventions	16
1.3 Getting Help	16
1.4 Prompt and Response Conventions	18
1.5 User Roles (Capabilities)	19
1.6 Using the Negation Form	19
1.7 Parameter Key	20
Chapter 2 System Management	22
2.1 Management Interfaces	22
interface	22
ip address	22
alias	24
mtu	25
duplex	26
speed	27
dhcp	28
shutdown	29
zeroconf	30
comment	31
ipv6 enable	32
ipv6 address	33
show interface	35
hostname	36
ip name-server	37
ip domain-list	38
ip/ipv6 host	38
ip/ipv6 map-hostname	39
show hosts	40
ip/ipv6 route	41
ip/ipv6 default-gateway	42
show ip/ipv6 route	42
show ip/ipv6 default-gateway	43
ip arp	44
show ip arp	45
ipv6 neighbor	45
clear ipv6 neighbors	46
show ipv6 neighbors	47
ip dhcp	47
show ip dhcp	48

	ipv6 enable	49
	ping	50
	traceroute.	51
	tcpdump.	53
2.2	License Keys - - - - -	54
	license	54
	show licenses	55
2.3	NTP, Clock & Time Zones - - - - -	55
	clock set	55
	clock timezone	56
	ntp	57
	ntpdate.	57
	show clock	58
	show ntp	58
2.4	Software Management - - - - -	59
	image boot.	59
	boot next	60
	image default-chip-fw	60
	image delete	61
	image fetch	61
	image install	62
	image install-chip-fw	63
	image move.	64
	image options	64
	show bootvar.	65
	show images	65
2.5	File Management- - - - -	66
	ftp-server enable	66
	show ftp-server	67
	debug generate dump	67
	file debug-dump	68
	file stats.	69
	file tcpdump	69
	show files debug-dump.	70
	show files stats	71
	show files system	71
	show files tcpdump	72
	configuration audit	73
	configuration copy	73
	configuration delete	74
	configuration fetch	74
	configuration jump-start	75
	configuration merge	76
	configuration move.	76
	configuration new	77
	configuration revert.	77
	configuration switch-to.	78
	configuration text fetch.	79
	configuration text file	80

	configuration text generate	80
	configuration upload	81
	write	82
	show configuration	83
	show running-config	84
2.6	Local and Remote Logging - - - - -	85
	logging local	85
	logging local override	86
	logging <syslog IP address>	88
	logging receive	89
	logging format	90
	logging fields	91
	logging level	92
	logging files delete	93
	logging files rotation	93
	logging files upload	95
	show logging	95
	show log	96
2.7	Maintenance Tools - - - - -	97
	reload	97
	reset factory	98
2.8	User management and AAA - - - - -	99
	username	99
	show usernames	100
	show users	101
	show whoami	101
	aaa accounting	102
	aaa authentication	103
	aaa authorization	104
	show aaa	105
	radius-server	106
	radius-server host	107
	show radius	108
	tacacs-server	108
	tacacs-server host	109
	show tacacs	111
	ldap base-dn	112
	ldap bind-dn/bind-password	113
	ldap group-attribute/group-dn	114
	ldap host	115
	ldap login-attribute	116
	ldap port	117
	ldap referrals	118
	ldap scope	119
	ldap ssl	120
	ldap timeout	121
	ldap version	122
	show ldap	123
2.9	CLI Session - - - - -	123

	cli clear-history	124
	cli default	124
	cli session	126
	show cli	127
2.10	Banner - - - - -	128
	banner login	128
	banner motd	128
	show banner	129
2.11	SSH - - - - -	130
	ssh server enable	130
	ssh server host-key	130
	ssh server listen	132
	ssh server min-version	133
	ssh server ports	133
	ssh server x11-forwarding	134
	ssh client global	135
	ssh client user	136
	slogin	137
	show ssh client	138
	show ssh server	139
2.12	Remote Login - - - - -	139
	telnet-server enable	139
	show telnet-server	140
2.13	XML Gateway - - - - -	140
	xml-gw enable	140
	show xml-gw	141
2.14	Web Server - - - - -	142
	web auto-logout	142
	web enable	143
	web http	144
	web httpd	145
	web https	146
	web session	147
	web proxy auth	148
	web proxy host	149
	show web	150
2.15	SNMP - - - - -	150
	snmp-server community	151
	snmp-server contact	152
	snmp-server enable	152
	snmp-server host	154
	snmp-server listen	155
	snmp-server location	156
	snmp-server port	157
	snmp-server traps	158
	snmp-server user	159
	show snmp	160
2.16	Scheduled Jobs - - - - -	161
	job	161

	command	162
	comment	162
	enable	163
	execute	163
	fail-continue	164
	name	164
	schedule type	165
	schedule <recurrence type>	166
	show jobs	166
2.17	Event Notification	167
	email autosupport	167
	email dead-letter	168
	email domain	168
	email mailhub	169
	email mailhub-port	170
	email notify event	170
	email notify recipient	171
	email return-addr	172
	email return-host	173
	email send-test	174
	show email	174
2.18	Statistics and Alarms	175
	stats alarm <alarm-id> clear	175
	stats alarm <alarm-id> enable	176
	stats alarm <alarm-id> event-repeat	177
	stats alarm <alarm-id> {rising falling}	178
	stats alarm <alarm-id> rate-limit	179
	stats chd <chd-id> clear	180
	stats chd <chd-id> enable	181
	stats chd <chd-id> compute time	182
	stats sample <sample-id> clear	183
	stats sample <sample-id> enable	184
	stats sample <sample-id> interval	185
	stats clear-all	185
	stats export	186
	show stats alarm	187
	show stats chd	188
	show stats cpu	188
	show stats sample	189
2.19	Chassis Management	190
	health	190
	power enable	191
	usb eject	191
	system profile	192
	show fan	192
	show version	193
	show inventory	194
	show module	194
	show memory	195

show asic-version	196
show power	196
show power consumers	197
show temperature	198
show voltage	199
show health-report	199
show resources	200
show system profile	201
show system capabilities	201
show system mac	202

Chapter 3 Ethernet Switching 203

3.1 Interface-	203
interface ethernet	203
flowcontrol	203
mtu	204
shutdown	204
description	205
speed	206
clear counters	206
show interfaces ethernet	207
show interfaces ethernet [<inf>] capabilities	208
show interfaces ethernet [<inf>] description	208
show interfaces ethernet [<inf>] status	209
show interfaces ethernet [<inf>] transceiver	209
module-type	210
3.2 Link Aggregation Group (LAG) and LACP-	211
interface port-channel	211
lacp	212
lacp system-priority	212
lacp (interface)	213
port-channel load-balance	214
channel-group	214
show lacp system-identifier	215
show lacp counters	216
show lacp interface ethernet	217
show lacp interface neighbor	217
show lacp interfaces port-channel	218
3.3 VLANs	219
vlan	219
name	220
show vlan	220
switchport mode	221
switchport access	222
switchport {hybrid, trunk} allowed vlan	223
show interface switchport	224
3.4 MAC Address Table	225
mac-address-table aging-time	225
mac-address-table static	226

	clear mac-address-table dynamic	227
	show mac-address-table	227
	show mac-address-table aging-time	228
3.5	Spanning Tree-	229
	spanning-tree	229
	spanning-tree (timers)	229
	spanning-tree port type (default global)	230
	spanning-tree priority	231
	spanning-tree port-priority	231
	spanning-tree cost	232
	spanning-tree port type	233
	spanning-tree guard	233
	spanning-tree bpdudfilter	234
	clear spanning-tree counters	235
	show spanning-tree	235
3.6	IGMP Snooping	236
	ip igmp snooping (admin)	236
	ip igmp snooping (config)	237
	ip igmp snooping fast-leave	238
	ip igmp snooping static-group	239
	ip igmp snooping mrouter	240
	ip igmp snooping unregistered multicast	240
	show ip igmp snooping	241
	show ip igmp snooping groups	242
	show ip igmp snooping vlan	243
	show ip igmp snooping mrouter	243
	show ip igmp snooping interfaces	244
	show ip igmp snooping statistics	244
3.7	Link Layer Discovery Protocol (LLDP)	245
	lldp	245
	lldp reinit	246
	lldp timer	246
	lldp tx-delay	247
	lldp tx-hold-multiplier	247
	lldp {receive transmit}	248
	lldp tlv-select	248
	show lldp local	249
	show lldp interface	250
	show lldp interface ethernet <inf> remote	250
	show lldp timers	251
	show lldp statistics global	251
	show lldp statistics [interface ethernet <inf>]	252
3.8	Quality of Service	253
	dcb ets enable	253
	dcb ets tc bandwidth	254
	vlan map-priority	254
	show dcb ets	255
	show dcb ets interface	256
	dcb priority-flow-control enable	258

	dcb priority-flow-control priority	259
	dcb priority-flow-control mode on	260
	show dcb priority-flow-control	261
3.9	Access Control List - - - - -	262
	ipv4/mac access-list	262
	ipv4/mac port access-group	262
	deny/permit (MAC ACL rule)	263
	deny/permit (IPv4 ACL rule)	264
	deny/permit (IPv4 TCP/UDP ACL rule)	265
	access-list action	266
	vlan-map	266
	show access-list action	267
	show mac/ipv4 access-lists	268
	show mac/ipv4 access-lists summary	268
Chapter 4	IP Routing	270
4.1	General - - - - -	270
	ip routing	270
	show ip routing	270
4.2	IP Interface - - - - -	271
	interface vlan	271
	ip address	272
	counters	272
	description	273
	mtu	274
	shutdown	275
	clear counters	275
	show interfaces vlan	276
4.3	Routing and ECMP - - - - -	277
	ip route	277
	ip load-sharing	278
	show ip route	278
	show ip load-sharing	279
4.4	Network to Media Resolution (ARP) - - - - -	280
	ip arp	280
	ip arp timeout	280
	clear ip arp	281
	show ip arp	282
4.5	IP Diagnostic Tools - - - - -	282
	ping	283
	traceroute	283
	tcpdump	285

Document Revision History

Table 1 - Document Revision History - Ethernet

Document Revision	Date	Changes
Rev 1.5.2	June 2012	Added “igmp snooping unregistered multicast” command Update “switchport access” command.
Rev 1.5.1	May, 2012	Added LLDP commands
Rev 1.5.0	May, 2012	Initial version

About this Manual

This Manual provides general information concerning MLNX-OS Command Line Interface.

Intended Audience

This manual is intended for network administrators who are responsible for configuring and managing Mellanox Technologies' MLNX-OS Switch Platforms.

Related Documentation

The following table lists the documents referenced in this *User's Manual*.

Table 2 - Reference Documents





Document Name	Description
InfiniBand Architecture Specification, Vol. 1, Release 1.2.1	The InfiniBand Architecture Specification that is provided by IBTA.
SwitchX® Hardware Installation Guide	Each Mellanox Technologies' switch platform is shipped with an <i>Installation Guide</i> document to bring-up and initialize the switch platform.
SwitchX® Hardware User Manual	This document contains HW descriptions, LED assignments and HW specifications among other things.
Switch Errata	For any possible errata due to hardware issues see the switch support product page. This requires a customer support login.
MX-OS Software WebUI User's Manual	WebUI user's manual for MX-OS.
Mellanox MLNX-OS SwitchX Software User Manual	This document contains information regarding configuring and managing Mellanox Technologies' SwitchX® Switch Platforms.
Mellanox MLNX-OS Software Configuration Guide	Configuration Guide for MLNX-OS displaying different configuration scenarios.

All of these documents can be found on the Mellanox Website. They are available either through the product pages or through the support page with a login and password.

Documentation Conventions

Typographical Conventions

Table 3 - Typographical Conventions

Description	Convention	Example
File names	file.extension	
Directory names	directory	
Commands and their parameters	command param1	sx10xx-1 > show hosts
Required item	< >	
Optional item	[]	
Mutually exclusive parameters	{p1, p2, p3} or {p1 p2 p3}	
Optional mutually exclusive parameters	[p1 p2 p3]	
Prompt of a command in Standard mode	hostname >	sx10xx-1 >
Prompt of a command in Enable mode	hostname #	sx10xx-1 #
Prompt of a command in Config mode	hostname (config) #	sx10xx-1 (config) #
Comments to explain command examples	//	// This is a comment
Variables for which users supply specific values	Italic font	<i>enable</i>
Emphasized words	Italic font	<i>These are emphasized words</i>
Note	 <text>	 This is a note.
Warning	 <text>	 Make sure to connect to the RS-232 RJ-45 port of the switch and not to the MGT port.

Glossary

Table 4 - Glossary

AAA	Authentication, Authorization, and Accounting: <ul style="list-style-type: none"> • Authentication - verifies user credentials (username and password) • Authorization - grants or refuses privileges to a user/client for accessing specific services • Accounting - tracks network resources consumption by users
ARP	Address Resolution Protocol. A protocol that translates IP addresses into MAC addresses for communication over a local area network (LAN).
BOARD_MONITOR	Board temperature sensor for the selected Leaf or Spine module.
CA (Channel Adapter)	A device which terminates an Infiniband link, and executes transport level functions.
CLI	Command Line Interface. A user interface in which you type commands at the prompt.
DCB	Data Center Bridging.
DCBX	DCBX protocol is an extension of the Link Layer Discovery Protocol (LLDP). DCBX end points exchange request and acknowledgment messages. For flexibility, parameters are coded in a type-length-value (TLV) format.
DHCP	The Dynamic Host Configuration Protocol (DHCP) is an automatic configuration protocol used on IP networks.
Director Class Switch	A high density InfiniBand chassis switch system.
DMA (Direct Memory Access)	Allowing Hardware to move data blocks directly to the memory, bypassing the CPU.
DNS	Domain Name System. A hierarchical naming system for devices in a computer network.
Edge Switch	A switch system with a 1RU form factor.
ETS	ETS provides a common management framework for assignment of bandwidth to traffic classes.
Fabric Management	The use of a set of tools (APIs) to configure, discover, and manage a group of devices organized as a connected fabric.
FTP	File Transfer Protocol (FTP) is a standard network protocol used to transfer files from one host to another over a TCP-based network, such as the Internet.
Gateway	A network node that interfaces with another network using a different network protocol.
GID (Global IDentifier)	A 128-bit number used to identify a Port on a network adapter (see below), a port on a Router, or a Multicast Group.
GUID (Globally Unique IDentifier)	A 64-bit number that uniquely identifies a device or component in a subnet.
HA (High Availability)	A system design protocol that provides redundancy of system components, thus enables overcoming single or multiple failures in minimal downtime.

Table 4 - Glossary

IB	InfiniBand.
LACP	Link Aggregation Control Protocol (LACP) provides a method to control the bundling of several physical ports together to form a single logical channel. LACP allows a network device to negotiate an automatic bundling of links by sending LACP packets to the peer (directly connected device that also implements LACP).
LDAP	The Lightweight Directory Access Protocol is an application protocol for reading and editing directories over an IP network.
LID (Local IDentifier)	A 16 bit address assigned to end nodes by the subnet manager Each LID is unique within its subnet.
LLDP	Link Layer Discovery Protocol (LLDP) is an industry standard protocol designed to supplant proprietary Link-Layer protocols such as Extreme's EDP (Extreme Discovery Protocol) and CDP (Cisco Discovery Protocol). The goal of LLDP is to provide an inter-vendor compatible mechanism to deliver Link-Layer notifications to adjacent network devices.
MAC	A Media Access Control address (MAC address) is a unique identifier assigned to network interfaces for communications on the physical network segment. MAC addresses are used for numerous network technologies and most IEEE 802 network technologies including Ethernet.
MTU (Maximum Transfer Unit)	The maximum size of a packet payload (not including headers) that can be sent /received from a port.
PFC/FC	Priority Based Flow Control applies pause functionality to traffic classes OR classes of service on the Ethernet link.
QoS or Quality of Service	Quality of service is the ability to manage different applications or users by priority such that a required bit rate, delay, packet dropping probability, and/or other measures may be guaranteed.
QSFP_AMBIENT_TEMP	Ambient temperature sensor of the QSFP cage for the selected Leaf or Spine module
RADIUS	Remote Authentication Dial In User Service. A networking protocol that enables AAA centralized management for computers to connect and use a network service.
RDMA (Remote Direct Memory Access)	Accessing memory in a remote side without involvement of the remote CPU.
RSTP	Rapid Spanning Tree Protocol. A spanning-tree protocol used to prevent loops in bridge configurations. RSTP is not aware of VLANs and blocks ports at the physical level.
SA (Subnet Administrator)	The interface for querying and manipulating subnet management data.
SCP	Secure Copy or SCP is a means of securely transferring computer files between a local and a remote host or between two remote hosts. It is based on the Secure Shell (SSH) protocol.

Table 4 - Glossary

SM (Subnet Manager)	An entity that configures and manages the subnet, discovers the network topology, assign LIDs, determines the routing schemes and sets the routing tables. There is only one master SM and possible several slaves (Standby mode) at a given time. The SM administers switch routing tables thereby establishing paths through the fabric.
SNMP	Simple Network Management Protocol. A network protocol for the management of a network and the monitoring of network devices and their functions.
SNTP	Network Time Protocol. A protocol for synchronizing computer clocks in a network.
SSH	Secure Shell. A protocol (program) for securely logging in to and running programs on remote machines across a network. The program authenticates access to the remote machine and encrypts the transferred information through the connection.
syslog	A standard for forwarding log messages in an IP network.
TACACS+	Terminal Access Controller Access-Control System Plus. A networking protocol that enables access to a network of devices via one or more centralized servers. TACACS+ provides separate AAA services.
TCA (Target Channel Adapter)	A Channel Adapter that is not required to support verbs, usually used in I/O devices.
WebUI	Web User Interface. A user interface in which you select commands from drop down menus or by clicking on icons.
XML Gateway	Extensible Markup Language Gateway. Provides an XML request-response protocol for setting and retrieving HW management information.

1 Using the Command Line Interface

This chapter explains how to use the command line interface (CLI) of MLNX-OS SwitchX®.

1.1 CLI Modes

The CLI can be in one of three modes, and each mode makes available a certain group (or level) of commands for execution. The different CLI configuration modes are:

Table 1 - CLI Modes and Config Context

Mode/Context	Description
Standard	When the CLI is launched, it begins in Standard mode. This is the most restrictive mode and only has commands to query a restricted set of state information. Users cannot take any actions that directly affect the system, nor can they change any configuration.
Enable	The “enable” command moves the user to Enable mode. This mode offers commands to view all state information and take actions like rebooting the system, but it does not allow any configuration to be changed. Its commands are a superset of those in Standard mode. To return to Standard mode, enter “disable”.
Config	The “configure terminal” command moves the user from Enable mode to Config mode. Config mode is allowed only for user accounts in the “admin” role (or capabilities) – see “User Roles (Capabilities)”. This mode has a full unrestricted set of commands to view anything, take any action, or change any configuration. Its commands are a superset of those in Enable mode. To return to Enable mode, enter “exit” or “no configure”. Note that moving directly from/to Standard mode to/from Config mode is not possible.
Config Interface Management	Configuration mode for management interface mgmt0, mgmt1 and loopback.
Config interface ethernet	Configuration mode for Ethernet interface.
Config Interface Port Channel	Configuration mode for Port channel (LAG).
Config Vlan	Configuration mode for VLAN.
Any Command Mode	Several commands such as “show” can be applied within any context.

1.2 Syntax Conventions

To help you identify the parts of a CLI command, this section uses conventions to show the syntax of commands.

Table 2 - Syntax Conventions

Syntax Convention	Description	Example
< > Angled brackets	Indicates a value/variable that must be replaced.	<1...65535> or <switch interface>
[] Square brackets	Encloses optional parameters. However, only one parameter out of the list of parameters listed can be used. You cannot have a combination of the parameters unless otherwise stated.	[destination-ip destination-port destination-mac]
{ } Braces	Encloses alternatives or variables that are required for the parameter in square brackets.	[mode {active on passive}]
Vertical bar	Identifies mutually exclusive choices.	active on passive



Do not enter the angled or square brackets, vertical bar, or braces in command lines. This guide uses these symbols only to show the types of entries.



CLI commands and options are in lowercase and are case-sensitive. For example, when you enter the `enable` command, enter it all in lowercase, not `ENABLE` or `Enable`. Text entries you create are also case-sensitive. For example, if you set a LAG name to `Lag1`, enter it exactly, not `lag1` or `LAG1`.

1.3 Getting Help

You may request context-sensitive help at any time by pressing “?” on the command line. This will show a list of choices for the word you are on, or a list of top-level commands if you have not typed anything yet.

For example, if you are in Standard mode and you type “?” at the command line, then you will get the following list of available commands

```

switch [standalone: master] > ?

cli          Configure CLI shell options
enable       Enter enable mode
exit         Log out of the CLI
help         View description of the interactive help system
no           Negate or clear certain configuration options
ping         Send ICMP echo requests to a specified host
show         Display system configuration or statistics
slogin       Log into another system securely using ssh
switch       Configure switch on system
telnet       Log into another system using telnet
terminal     Set terminal parameters
traceroute   Trace the route packets take to a destination

switch-11a596 [standalone: master] >

```

If you type a legal string and then you press “?” *without* a space character before it, then you will either get a description of the command that you have typed so far or the possible command/parameter completions. If you press “?” *after* a space character and “<cr>” is shown, this means that what you have entered so far is a complete command, and that you may press Enter (carriage return) to execute it.

Try the following to get started:

```

?
show ?
show c?
show clock?
show clock ?
show interfaces ?    (from enable mode)

```

You can also enter “help” to view a description of the interactive help system.

Note also that the CLI supports command and/or parameter tab-completions and their shortened forms. For example, you can enter “en” instead of the “enable” command, or “cli cl” instead of “cli clear-history”. In case of ambiguity (more than one completion option is available, that is), then you can click double tabs to obtain the disambiguation options. Thus, if you are in Enable mode and you wish to learn which commands start with the letter “c”, type “c” and click twice on the tab key to get the following:

```

switch [standalone: master] # c<tab>

```

```
clear      cli      configure
switch-1 [standalone: master] # c
```

(There are three commands that start with the letter “c”: clear, cli and configure.)

1.4 Prompt and Response Conventions

The prompt always begins with the hostname of the system. What follows depends on what command mode the user is in. To demonstrate by example, and assuming the machine name is “switch-1”, the prompts for each of the modes are:

```
switch [standalone: master] >          (Standard mode)
switch [standalone: master] #          (Enable mode)
switch [standalone: master] (config) # (Config mode)
```

The following session shows how to move between command modes:

```
switch [standalone: master] >          (You start in Standard mode)
switch [standalone: master] > enable    (Move to Enable mode)
switch [standalone: master] #          (You are in Enable mode)
switch [standalone: master] # configure terminal (Move to Config mode)
switch [standalone: master] (config) #  (You are in Config mode)
switch [standalone: master] (config) # exit (Exit Config mode)
switch [standalone: master] #          (You are back in Enable mode)
switch [standalone: master] # disable    (Exit Enable mode)
switch [standalone: master] >          (You are back in Standard mode)
```

Commands that succeed do not print any response and simply show the command prompt after you press <Enter>.

If an error is encountered in executing a command, the response will begin with “%”, followed by some text describing the error.

1.5 User Roles (Capabilities)

There are two user *roles* or account types: admin and monitor. As “admin”, the user is privileged to run *all* the available commands. As “monitor”, the user can run commands that show system configuration and status, or set terminal settings.

Table 3 - User Roles (Accounts) and Default Passwords

User Role	Default Password
admin	admin
monitor	monitor

1.6 Using the Negation Form

Several Config mode commands offer the negation form using the keyword “no”. This no form can be used to disable a function or to cancel certain command parameters or options. To re-enable a function or to set cancelled command parameters or options, enter the command without the “no” keyword (with parameter values if necessary).

The following example performs the following:

1. Displays the current CLI session options.
2. Disables auto-logout.
3. Displays the new CLI session options (auto-logout is disabled).
4. Re-enables auto-logout (after 15 minutes).
5. Displays the final CLI session options (auto-logout is enabled).

```
// 1. Display the current CLI session options
switch-1 [standalone: master] (config) # show cli
CLI current session settings:
Maximum line size:      8192
Terminal width:         157 columns
Terminal length:        60 rows
Terminal type:          xterm
Auto-logout:            15 minutes
Paging:                 enabled
Progress tracking:      enabled
Prefix modes:           enabled
...
// 2. Disable auto-logout
switch-1 [standalone: master] (config) # no cli session auto-logout
```

```
// 3. Display the new CLI session options
switch-1 [standalone: master] (config) # show cli
CLI current session settings:
    Maximum line size:      8192
    Terminal width:         157 columns
    Terminal length:        60 rows
    Terminal type:          xterm
    Auto-logout:            disabled
    Paging:                 enabled
    Progress tracking:      enabled
    Prefix modes:           enabled
    ...

// 4. Re-enable auto-logout after 15 minutes
switch-1 [standalone: master] (config) # cli session auto-logout 15

// 5. Display the final CLI session options
switch-1 [standalone: master] (config) # show cli
CLI current session settings:
    Maximum line size:      8192
    Terminal width:         157 columns
    Terminal length:        60 rows
    Terminal type:          xterm
    Auto-logout:            15 minutes
    Paging:                 enabled
    Progress tracking:      enabled
    Prefix modes:           enabled
    ...
```

1.7 Parameter Key

This section is a key to the meaning and format of all of the angle-bracketed parameters in all the commands that are listed in this document.

<domain>	A domain name, e.g. “mellanox.com”.
<hostname>	A hostname, e.g. “switch-1”.

<ifname>	An interface name, e.g. “mgmt0”, “mgmt1”, “lo” (loopback), etc.
<index>	A number to be associated with aliased (secondary) IP addresses.
<IP address>	An IPv4 address, e.g. “192.168.0.1”.
<log level>	A syslog logging severity level. Possible values, from least to most severe, are: “debug”, “info”, “notice”, “warning”, “error”, “crit”, “alert”, “emerg”.
<GUID>	Globally Unique Identifier. A number that uniquely identifies a device or component.
<MAC address>	A MAC address. The segments may be 8 bits or 16 bits at a time, and may be delimited by “:” or “.”. So you could say “11:22:33:44:55:66”, “1122:3344:5566”, “11.22.33.44.55.66”, or “1122.3344.5566”.
<netmask>	A netmask (e.g. “255.255.255.0”) or mask length prefixed with a slash (e.g. “/24”). These two express the same information in different formats.
<network prefix>	An IPv4 network prefix specifying a network. Used in conjunction with a netmask to determine which bits are significant. e.g. “192.168.0.0”.
<regular expression>	An extended regular expression as defined by the “grep” in the man page. (The value you provide here is passed on to “grep -E”.)
<node id>	ID of a node belonging to a cluster. This is a numerical value greater than zero.
<cluster id>	A string specifying the name of a cluster.
<port>	TCP/UDP port number.
<TCP port>	A TCP port number in the full allowable range [0..65535].
<URL>	<p>A normal URL, using any protocol that wget supports, including http, https, ftp, sftp, and tftp; or a pseudo-URL specifying an scp file transfer. The scp pseudo-URL format is scp://username:password@hostname/path/filename.</p> <p>Note that the path is an absolute path. Paths relative to the user's home directory are not currently supported. The implementation of ftp does not support authentication, so use scp or sftp for that.</p> <p>Note also that if you omit the “:password” part, you may be prompted for the password in a follow up prompt, where you can type it securely (without the characters being echoed). This prompt will occur if the “cli default prompt empty-password” setting is true; otherwise, the CLI will assume you do not want any password. If you include the “:” character, this will be taken as an explicit declaration that the password is empty, and you will not be prompted in any case.</p>

2 System Management

2.1 Management Interfaces

2.1.1 Interface

This chapter describes the commands should be used to configure and monitor the management interface.

interface

interface {mgmt0 | mgmt1 | lo}

Enters a management interface context.

Syntax Description	mgmt0	Management port 0 (out of band).
	mgmt1	Management port 1 (out of band).
	lo	Loopback interface.
	ib0	IP over IB in-band management, relevant only for InfiniBand switch systems.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # interface mgmt0 switch (config interface mgmt0) #</pre>	
Related Commands	show interfaces <ifname>	
Note		

ip address

ip address <IP address> <netmask>
no ip address

Sets the IP address and netmask of this interface.
 The no form of the command clears the IP address and netmask of this interface.

Syntax Description	IP address	IPv4 address
	netmask	Subnet mask of IP address

Default	0.0.0.0/0
Modes/Context	Config Interface Management
History	3.1.0000
Role	admin
Example	<pre> switch (config) # interface mgmt0 switch (config interface mgmt0) # ip address 10.10.10.10 255.255.255.0 switch (config interface mgmt0) # show interfaces mgmt0 Interface mgmt0 state Admin up: yes Link up: yes IP address: 10.10.10.10 Netmask: 255.255.255.0 IPv6 enabled: yes Autoconf enabled: no Autoconf route: yes Autoconf privacy: no IPv6 addresses: 1 IPv6 address: fe80::202:c9ff:fe5e:a5d8/64 Speed: 1000Mb/s (auto) Duplex: full (auto) Interface type: ethernet Interface ifindex: 2 Interface source: physical MTU: 1500 HW address: 00:02:C9:5E:A5:D8 Comment: RX bytes: 2946769856 TX bytes: 467577486 RX packets: 44866091 TX packets: 1385520 RX mcast packets: 0 TX discards: 0 RX discards: 0 TX errors: 0 RX errors: 0 TX overruns: 0 RX overruns: 0 TX carrier: 0 RX frame: 0 TX collisions: 0 TX queue len: 1000 switch (config interface mgmt0) # </pre>
Related Commands	show interfaces <ifname>
Note	If DHCP is enabled on the specified interface, then the DHCP IP assignment will hold until DHCP is disabled.

alias

alias <index> ip address < IP address> <netmask>
no alias <index>

Adds an additional IP address to the specified interface. The secondary address will appear in the output of “show interface” under the data of the primary interface along with the alias.

The no form of the command removes the secondary address to the specified interface.

Syntax Description	index	A number that is to be aliased to (associated with) the secondary IP.	
	IP address	Additional IP address.	
	netmask	Subnet mask of the IP address.	
Default	N/A		
Modes/Context	Config Interface Management		
History	3.1.0000		
Role	admin		
Example	<pre>switch (config interface mgmt0) # alias 2 ip address 9.9.9.9 255.255.255.255 switch (config interface mgmt0) # show interfaces mgmt0 Interface mgmt0 state Admin up: yes Link up: yes IP address: 172.30.2.2 Netmask: 255.255.0.0 Secondary address: 9.9.9.9/32 (alias: 'mgmt0:2') IPv6 enabled: yes Autoconf enabled: no Autoconf route: yes Autoconf privacy: no IPv6 addresses: 1 IPv6 address: fe80::202:c9ff:fe5e:a5d8/64 Speed: 1000Mb/s (auto) Duplex: full (auto) Interface type: ethernet Interface ifindex: 2 Interface source: physical MTU: 1500 HW address: 00:02:C9:5E:A5:D8 Comment: RX bytes: 2970074221 TX bytes: 468579522 RX packets: 44983023 TX packets: 1390539 RX mcast packets: 0 TX discards: 0 RX discards: 0 TX errors: 0 RX errors: 0 TX overruns: 0 RX overruns: 0 TX carrier: 0 RX frame: 0 TX collisions: 0 TX queue len: 1000 switch (config interface mgmt0) #</pre>		

Related Commands	show interfaces <ifname>
Note	<ul style="list-style-type: none"> If DHCP is enabled on the specified interface, then the DHCP IP assignment will hold until DHCP is disabled More than one additional IP address can be added to the interface

mtu

mtu <bytes>
no mtu <bytes>

Sets the Maximum Transmission Unit (MTU) of this interface.
The no form of the command resets the MTU to its default.

Syntax Description	bytes	The entry range is 68-1500.
Default	1500	
Modes/Context	Config Interface Management	
History	3.1.0000	
Role	admin	

Example

```
switch (config interface mgmt0) # mtu 1500
switch (config interface mgmt0) # show interfaces mgmt0
Interface mgmt0 state
  Admin up:          yes
  Link up:           yes
  IP address:        172.30.2.2
  Netmask:           255.255.0.0
  Secondary address: 9.9.9.9/32 (alias: 'mgmt0:2')
  IPv6 enabled:      yes
  Autoconf enabled:  no
  Autoconf route:    yes
  Autoconf privacy:  no
  IPv6 addresses:    1
  IPv6 address:      fe80::202:c9ff:fe5e:a5d8/64
  Speed:             1000Mb/s (auto)
  Duplex:            full (auto)
  Interface type:    ethernet
  Interface ifindex: 2
  Interface source:  physical
  MTU:               1500
  HW address:        00:02:C9:5E:A5:D8
  Comment:

  RX bytes:          2970074221      TX bytes:          468579522
  RX packets:        44983023       TX packets:        1390539
  RX mcast packets: 0               TX discards:       0
  RX discards:       0               TX errors:          0
  RX errors:         0               TX overruns:        0
  RX overruns:       0               TX carrier:         0
  RX frame:          0               TX collisions:      0
                                      TX queue len:      1000

switch (config interface mgmt0) #
```

Related Commands	show interfaces <ifname>
-------------------------	--------------------------

Note

duplex

duplex <duplex>
no duplex

Sets the interface duplex.
 The no form of the command resets the duplex setting for this interface to its default value.

Syntax Description	duplex	Sets the duplex mode of the interface. The following are the possible values: <ul style="list-style-type: none"> • half - half duplex • full - full duplex • auto - auto duplex sensing (half or full)
Default	auto	
Modes/Context	Config Interface Management	
History	3.1.0000	
Role	admin	

Example

```

switch (config interface mgmt0) # duplex auto
switch (config interface mgmt0) # show interfaces mgmt0
Interface mgmt0 state
  Admin up:          yes
  Link up:           yes
  IP address:        172.30.2.2
  Netmask:           255.255.0.0
  Secondary address: 9.9.9.9/32 (alias: 'mgmt0:2')
  IPv6 enabled:      yes
  Autoconf enabled:  no
  Autoconf route:    yes
  Autoconf privacy:  no
  IPv6 addresses:    1
  IPv6 address:      fe80::202:c9ff:fe5e:a5d8/64
  Speed:             1000Mb/s (auto)
  Duplex:            full (auto)
  Interface type:    ethernet
  Interface ifindex: 2
  Interface source:  physical
  MTU:               1500
  HW address:        00:02:C9:5E:A5:D8
  Comment:

  RX bytes:          2970074221      TX bytes:          468579522
  RX packets:        44983023       TX packets:        1390539
  RX mcast packets: 0               TX discards:       0
  RX discards:       0               TX errors:          0
  RX errors:         0               TX overruns:        0
  RX overruns:       0               TX carrier:         0
  RX frame:          0               TX collisions:      0
                                         TX queue len:      1000

switch (config interface mgmt0) #

```

Related Commands

show interfaces <ifname>

Note

- Setting the duplex to “auto” also sets the speed to “auto”
- Setting the duplex to one of the settings “half” or “full” also sets the speed to a manual setting which is determined by querying the interface to find out its current auto-detected state

speed

speed <speed>

no speed

Sets the interface speed.

The no form of the command resets the speed setting for this interface to its default value.

Syntax Description

speed

Sets the speed of the interface. The following are the possible values:

- 10 - fixed to 10Mbps
- 100 - fixed to 1000Mbps
- 1000 - fixed to 1000Mbps
- auto - auto speed sensing (10/100/1000Mbps)

Default

auto

Modes/Context	Config Interface Management	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config interface mgmt0) # speed auto switch (config interface mgmt0) # show interfaces mgmt0 Interface mgmt0 state Admin up: yes Link up: yes IP address: 172.30.2.2 Netmask: 255.255.0.0 Secondary address: 9.9.9.9/32 (alias: 'mgmt0:2') IPv6 enabled: yes Autoconf enabled: no Autoconf route: yes Autoconf privacy: no IPv6 addresses: 1 IPv6 address: fe80::202:c9ff:fe5e:a5d8/64 Speed: 1000Mb/s (auto) Duplex: full (auto) Interface type: ethernet Interface ifindex: 2 Interface source: physical MTU: 1500 HW address: 00:02:C9:5E:A5:D8 Comment: RX bytes: 2970074221 TX bytes: 468579522 RX packets: 44983023 TX packets: 1390539 RX mcast packets: 0 TX discards: 0 RX discards: 0 TX errors: 0 RX errors: 0 TX overruns: 0 RX overruns: 0 TX carrier: 0 RX frame: 0 TX collisions: 0 TX queue len: 1000 switch (config interface mgmt0) # </pre>	
Related Commands	show interfaces <ifname>	
Note	<ul style="list-style-type: none"> Setting the speed to “auto” also sets the duplex to “auto” Setting the speed to one of the manual settings (generally “10”, “100”, or “1000”) also sets the duplex to a manual setting which is determined by querying the interface to find out its current auto-detected state 	

dhcp

dhcp [renew]
no dhcp

Enables DHCP on the specified interface.
The no form of the command disables DHCP on the specified interface.

Syntax Description	renew	Forces a renewal of the IP address. A restart on the DHCP client for the specified interface will be issued.
---------------------------	-------	--

Default	Could be enabled or disabled (per part number) manufactured with 3.2.0500
Modes/Context	Config Interface Management
History	3.1.0000
Role	admin
Example	<pre> switch (config interface mgmt0) # dhcp switch (config) # show interfaces mgmt0 configured Interface mgmt0 configuration Enabled: yes DHCP: yes Zeroconf: no IP address: Netmask: IPv6 enabled: yes Autoconf enabled: no Autoconf route: yes Autoconf privacy: no IPv6 addresses: 0 Speed: auto Duplex: auto MTU: 1500 Comment: </pre>
Related Commands	show interfaces <ifname> configured
Note	<ul style="list-style-type: none"> • When enabling DHCP, the IP address and netmask are received via DHCP hence, the static IP address configuration is ignored • Enabling DHCP disables zeroconf and vice versa • Setting a static IP address and netmask does not disable DHCP. DHCP is disabled by using the “no” form of this command, or by enabling zeroconf.

shutdown

shutdown
no shutdown

Disables the specified interface.
The no form of the command enables the specified interface.

Syntax Description	N/A
Default	no shutdown
Modes/Context	Config Interface Management
History	3.1.0000
Role	admin

Example

```

switch (config interface mgmt0) # no shutdown
switch (config) # show interfaces mgmt0 configured
Interface mgmt0 configuration
  Enabled:          yes
  DHCP:             yes
  Zeroconf:         no
  IP address:
  Netmask:
  IPv6 enabled:     yes
  Autoconf enabled: no
  Autoconf route:   yes
  Autoconf privacy: no
  IPv6 addresses:   0
  Speed:            auto
  Duplex:            auto
  MTU:              1500
  Comment:
switch (config) #

```

Related Commands

show interfaces <ifname> configured

Note

zeroconf

zeroconf**no zeroconf**

Enables zeroconf on the specified interface. It randomly chooses a unique link-local IPv4 address from the 169.254.0.0/16 block. This command is an alternative to DHCP.

The no form of the command disables the use of zeroconf on the specified interface.

Syntax Description	N/A
Default	no zeroconf
Modes/Context	Config Interface Management
History	3.1.0000
Role	admin

Example

```

switch (config interface mgmt0) # zeroconf
switch (config) # show interfaces mgmt0 configured
Interface mgmt0 configuration
  Enabled:                yes
  DHCP:                   no
  Zeroconf:               yes
  IP address:
  Netmask:
  IPv6 enabled:          yes
  Autoconf enabled:      no
  Autoconf route:        yes
  Autoconf privacy:      no
  IPv6 addresses:        0
  Speed:                 auto
  Duplex:                 auto
  MTU:                   1500
  Comment:

```

Related Commands

show interfaces <ifname> configured

Note

Enabling zeroconf disables DHCP and vice versa.

comment

comment <comment>

no comment

Adds a comment for an interface.

The no form of the command removes a comment for an interface.

Syntax Description	comment	A free-form string that has no semantics other than being displayed when the interface records are listed.
Default	no comment	
Modes/Context	Config Interface Management	
History	3.1.0000	
Role	admin	

Example

```

switch (config interface mgmt0) # comment my-interface
switch (config interface mgmt0) # show interfaces mgmt0
Interface mgmt0 state
  Admin up:          yes
  Link up:           yes
  IP address:        172.30.2.2
  Netmask:           255.255.0.0
  IPv6 enabled:      yes
  Autoconf enabled:  no
  Autoconf route:    yes
  Autoconf privacy:  no
  IPv6 addresses:    1
  IPv6 address:      fe80::202:c9ff:fe5e:a5d8/64
  Speed:             1000Mb/s (auto)
  Duplex:            full (auto)
  Interface type:    ethernet
  Interface ifindex: 2
  Interface source:  physical
  MTU:              1500
  HW address:        00:02:C9:5E:A5:D8
  Comment:           my-interface

  RX bytes:          962067812      TX bytes:          40658219
  RX packets:        3738865       TX packets:        142345
  RX mcast packets:  0             TX discards:       0
  RX discards:       0             TX errors:         0
  RX errors:         0             TX overruns:       0
  RX overruns:       0             TX carrier:        0
  RX frame:          0             TX collisions:     0
                                      TX queue len:      1000

switch (config interface mgmt0) #

```

Related Commands	N/A
-------------------------	-----

Note

ipv6 enable

ipv6 enable
no ipv6 enable

Enables all IPv6 addressing for this interface.
 The no form of the command disables all IPv6 addressing for this interface.

Syntax Description	N/A
Default	IPv6 addressing is disabled
Modes/Context	Config Interface Management
History	3.1.0000
Role	admin

Example

```

switch (config interface mgmt0) # ipv6 enable
switch (config interface mgmt0) # show interfaces mgmt0
Interface mgmt0 state
  Admin up:          yes
  Link up:           yes
  IP address:        172.30.2.2
  Netmask:           255.255.0.0
  IPv6 enabled:      yes
  Autoconf enabled:  no
  Autoconf route:    yes
  Autoconf privacy:  no
  IPv6 addresses:    1
  IPv6 address:      fe80::202:c9ff:fe5e:a5d8/64
  Speed:             1000Mb/s (auto)
  Duplex:            full (auto)
  Interface type:    ethernet
  Interface ifindex: 2
  Interface source:  physical
  MTU:               1500
  HW address:        00:02:C9:5E:A5:D8
  Comment:           my-interface

  RX bytes:          962067812      TX bytes:          40658219
  RX packets:        3738865       TX packets:        142345
  RX mcast packets:  0             TX discards:       0
  RX discards:       0             TX errors:         0
  RX errors:         0             TX overruns:       0
  RX overruns:       0             TX carrier:        0
  RX frame:          0             TX collisions:     0
                                      TX queue len:    1000

switch (config interface mgmt0) #

```

Related Commands

ipv6 address
show interface <ifname>

Note

- The interface identifier is a 64-bit long modified EUI-64, which is based on the MAC address of the interface
- If IPv6 is enabled on an interface, the system will automatically add a link-local address to the interface. Link-local addresses can only be used to communicate with other hosts on the same link, and packets with link-local addresses are never forwarded by a router.
- A link-local address, which may not be removed, is required for proper IPv6 operation. The link-local addresses start with “fe80::”, and are combined with the interface identifier to form the complete address.

ipv6 address

ipv6 address {<IPv6 address/netmask> | autoconfig [default | privacy]}
no ipv6 {<IPv6 address/netmask> | autoconfig [default | privacy]}

Configures IPv6 address and netmask to this interface, static or autoconfig options are possible.

The no form of the command removes the given IPv6 address and netmask or disables the autoconfig options.

Syntax Description	IPv6 address/netmask	Configures a static IPv6 address and netmask. Format example: 2001:db8:1234::5678/64.
	autoconfig	Enables IPv6 stateless address auto configuration (SLAAC) for this interface. An address will be automatically added to the interface based on an IPv6 prefix learned from router advertisements, combined with an interface identifier.
	autoconfig default	Enables default learning routes. The default route will be discovered automatically, if the autoconfig is enabled.
	autoconfig privacy	Uses privacy extensions for SLAAC to construct the autoconfig address, if the autoconfig is enabled.
Default	No IP address available, auto config is enabled	
Modes/Context	Config Interface Management	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config interface mgmt0) # ipv6 fe80::202:c9ff:fe5e:a5d8/64 switch (config interface mgmt0) # show interfaces mgmt0 Interface mgmt0 state Admin up: yes Link up: yes IP address: 172.30.2.2 Netmask: 255.255.0.0 IPv6 enabled: yes Autoconf enabled: no Autoconf route: yes Autoconf privacy: no IPv6 addresses: 1 IPv6 address: fe80::202:c9ff:fe5e:a5d8/64 Speed: 1000Mb/s (auto) Duplex: full (auto) Interface type: ethernet Interface ifindex: 2 Interface source: physical MTU: 1500 HW address: 00:02:C9:5E:A5:D8 Comment: my-interface RX bytes: 962067812 TX bytes: 40658219 RX packets: 3738865 TX packets: 142345 RX mcast packets: 0 TX discards: 0 RX discards: 0 TX errors: 0 RX errors: 0 TX overruns: 0 RX overruns: 0 TX carrier: 0 RX frame: 0 TX collisions: 0 TX queue len: 1000 switch (config interface mgmt0) # </pre>	

Related Commands	ipv6 enable show interface <ifname>
Note	<ul style="list-style-type: none"> Unlike IPv4, IPv6 can have multiple IPv6 addresses on a given interface For Ethernet, the default interface identifier is a 64-bit long modified EUI-64, which is based on the MAC address of the interface

show interface

show interface {<ifname> [configured | brief]}

Displays information about the specified interface, configuration status, and counters.

Syntax Description	ifname	The interface name e.g., “mgmt0”, “mgmt1”, “lo” (loopback), etc.
	configured	Displays the interface configuration.
	brief	Displays a brief info on the interface configuration and status.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.0000	
Role	admin	

Example

```

switch (config) #show interfaces mgmt0 configured
Interface mgmt0 configuration
  Enabled:          yes
  DHCP:            yes
  Zeroconf:        no
  IP address:
  Netmask:
  IPv6 enabled:    yes
  Autoconf enabled: no
  Autoconf route:  yes
  Autoconf privacy: no
  IPv6 addresses:  0
  Speed:           auto
  Duplex:          auto
  MTU:             1500
  Comment:         my-interface
switch (config) # show interfaces mgmt0 brief
Interface mgmt0 state
  Admin up:        yes
  Link up:         yes
  IP address:      172.30.2.2
  Netmask:         255.255.0.0
  IPv6 enabled:    yes
  Autoconf enabled: no
  Autoconf route:  yes
  Autoconf privacy: no
  IPv6 addresses:  1
  IPv6 address:    fe80::202:c9ff:fe5e:a5d8/64
  Speed:           1000Mb/s (auto)
  Duplex:          full (auto)
  Interface type:  ethernet
  Interface ifindex: 2
  Interface source: physical
  MTU:             1500
  HW address:      00:02:C9:5E:A5:D8
  Comment:         my-interface
switch (config) #

```

Related Commands N/A
Note

2.1.2 Hostname Resolution

hostname

hostname <hostname>**no hostname**

Sets a static system hostname.

The no form of the command clears the system hostname.

Syntax Description	hostname	A free-form string.
Default	Default hostname	

Modes/Context	Config
History	3.1.0000
Role	admin
Example	switch (config) # hostname my-switch-hostname my-switch-hostname (config) #
Related Commands	show hosts
Note	“.” is not permitted as a valid character of the hostname.

ip name-server

ip name-server <IPv4/IPv6 address>
no name-server <IPv4/IPv6 address>

Sets the static name server.
The no form of the command clears the name server.

Syntax Description	IPv4/v6 address	IPv4 or IPv6 address.
Default	No server name	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # ip name-server 9.9.9.9 switch (config) # show hosts Hostname: switch Name server: 9.9.9.9 (configured) Name server: 10.211.0.121 (dynamic) Name server: 172.30.0.126 (dynamic) Name server: 10.4.0.135 (dynamic) Domain name: lab.mtl.com (dynamic) Domain name: vmlab.mtl.com (dynamic) Domain name: yok.mtl.com (dynamic) Domain name: mtl.com (dynamic) IP 127.0.0.1 maps to hostname localhost IPv6 ::1 maps to hostname localhost6 Automatically map hostname to loopback address: yes Automatically map hostname to IPv6 loopback address: no switch (config) #</pre>	
Related Commands	show hosts	
Note		

ip domain-list

ip domain-list <domain-name>
no ip domain-list <domain-name>

Sets the static domain name.
 The no form of the command clears the domain name.

Syntax Description	domain-name	The domain name in a string form. A domain name is an identification string that defines a realm of administrative autonomy, authority, or control in the Internet. Domain names are formed by the rules and procedures of the Domain Name System (DNS).
Default	No static domain name	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # ip domain-list mydomain.com switch (config) # show hosts Hostname: switch Name server: 10.211.0.121 (dynamic) Name server: 172.30.0.126 (dynamic) Name server: 10.4.0.135 (dynamic) Domain name: mydomain.com (configured) Domain name: lab.mtl.com (dynamic) Domain name: vmlab.mtl.com (dynamic) Domain name: yok.mtl.com (dynamic) Domain name: mtl.com (dynamic) IP 1.1.1.1 maps to hostname p IP 127.0.0.1 maps to hostname localhost IPv6 ::1 maps to hostname localhost6 Automatically map hostname to loopback address: yes Automatically map hostname to IPv6 loopback address: no switch (config) #</pre>	
Related Commands	show hosts	
Note		

ip/ipv6 host

{ip | ipv6} host <hostname> <IP Address>
no {ip | ipv6} host <hostname> <IP Address>

Configures the static hostname IPv4 or IPv6 address mappings.
 The no form of the command clears the static mapping.

Syntax Description	hostname	The hostname in a string form.
	IP Address	The IPv4 or IPv6 address.
Default	No static domain name.	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # ip host my-host 2.2.2.2 switch (config) # ipv6 host my-ipv6-host 2001::8f9 switch (config) # show hosts Hostname: switch Name server: 9.9.9.9 (configured) Name server: 10.211.0.121 (dynamic) Name server: 172.30.0.126 (dynamic) Name server: 10.4.0.135 (dynamic) Domain name: mydomain.com (configured) Domain name: lab.mtl.com (dynamic) Domain name: vmlab.mtl.com (dynamic) Domain name: yok.mtl.com (dynamic) Domain name: mtl.com (dynamic) IP 1.1.1.1 maps to hostname p IP 127.0.0.1 maps to hostname localhost IP 2.2.2.2 maps to hostname my-host IPv6 2001::8f9 maps to hostname my-ipv6-host IPv6 ::1 maps to hostname localhost6 Automatically map hostname to loopback address: yes Automatically map hostname to IPv6 loopback address: yes switch (config) # </pre>	
Related Commands	show hosts	
Note		

ip/ipv6 map-hostname

{ip |ipv6} map-hostname
no {ip | ipv6} map-hostname

Maps between the currently-configured hostname and the loopback address 127.0.0.1.
The no form of the command clears the mapping.

Syntax Description	N/A
Default	IPv4 mapping is enabled by default IPv6 mapping is disabled by default
Modes/Context	Config
History	3.1.0000
Role	admin

Example

```

switch (config) # ip map-hostname
switch (config) # # show hosts
Hostname: switch
Name server: 9.9.9.9 (configured)
Name server: 10.211.0.121 (dynamic)
Name server: 172.30.0.126 (dynamic)
Name server: 10.4.0.135 (dynamic)
Domain name: mydomain.com (configured)
Domain name: lab.mtl.com (dynamic)
Domain name: vmlab.mtl.com (dynamic)
Domain name: yok.mtl.com (dynamic)
Domain name: mtl.com (dynamic)
IP 1.1.1.1 maps to hostname p
IP 127.0.0.1 maps to hostname localhost
IP 2.2.2.2 maps to hostname my-host
IPv6 2001::8f9 maps to hostname my-ipv6-host
IPv6 ::1 maps to hostname localhost6
Automatically map hostname to loopback address: yes
Automatically map hostname to IPv6 loopback address: yes
switch (config) #
switch (config) # ping my-host-name
PING localhost (127.0.0.1) 56(84) bytes of data.
64 bytes from localhost (127.0.0.1): icmp_seq=1 ttl=64 time=0.078 ms
64 bytes from localhost (127.0.0.1): icmp_seq=2 ttl=64 time=0.052 ms
64 bytes from localhost (127.0.0.1): icmp_seq=3 ttl=64 time=0.058 ms

```

Related Commands

show hosts

Note

- If no mapping is configured, a mapping between the hostname and the IPv4 loopback address 127.0.0.1 will be added
- The no form of the command maps the hostname to the IPv6 loopback address if there is no statically configured mapping from the hostname to an IPv6 address (disabled by default)
- Static host mappings are preferred over DNS results. As a result, with this option set, you will not be able to look up your hostname on your configured DNS server; but without it set, some problems may arise if your hostname cannot be looked up in DNS.

show hosts**show hosts**

Displays hostname, DNS configuration, and static host mappings.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.0000
Role	admin

Example

```

switch (config) # show hosts
Hostname: my-host-name
Name server: 9.9.9.9 (configured)
Name server: 10.211.0.121 (dynamic)
Name server: 172.30.0.126 (dynamic)
Name server: 10.4.0.135 (dynamic)
Domain name: mydomain.com (configured)
Domain name: lab.mtl.com (dynamic)
Domain name: vmlab.mtl.com (dynamic)
Domain name: yok.mtl.com (dynamic)
Domain name: mtl.com (dynamic)
IP 1.1.1.1 maps to hostname p
IP 127.0.0.1 maps to hostname localhost
IP 2.2.2.2 maps to hostname my-host
IPv6 ::1 maps to hostname localhost6
Automatically map hostname to loopback address: yes
Automatically map hostname to IPv6 loopback address: no
switch (config) #

```

Related Commands

N/A

Note

2.1.3 Routing

ip/ipv6 route

{ip | ipv6} route <network-prefix> <netmask> {<nexthop-address> | <ifname>}
no ip route <network-prefix> <netmask> {<nexthop-address> | <ifname>}

Sets a static route for a given IP.

The no form of the command deletes the static route.

Syntax Description	network-prefix	IPv4 or IPv6 network prefix.
	netmask	IPv4 netmask formats are: <ul style="list-style-type: none"> • /24 • 255.255.255.0 IPv6 netmask format is: <ul style="list-style-type: none"> • /48 (as a part of the network prefix)
	nexthop-address	The IPv4 or IPv6 address of the next hope router for this route.
	ifname	The interface name (e.g., mgmt0, mgmt1).
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example	switch (config) # ip route 20.20.20.0 255.255.255.0 mgmt0				
	switch (config) # show ip route				
	Destination	Mask	Gateway	Interface	Source
	default	0.0.0.0	172.30.0.1	mgmt0	DHCP
	10.10.10.10	255.255.255.255	0.0.0.0	mgmt0	static
	20.10.10.10	255.255.255.255	172.30.0.1	mgmt0	static
	20.20.20.0	255.255.255.0	0.0.0.0	mgmt0	static
	172.30.0.0	255.255.0.0	0.0.0.0	mgmt0	interface
Related Commands	show ip route				
Note					

ip/ipv6 default-gateway

{ip | ipv6} default-gateway {<ip-address> | <ifname>}
no ip default-gateway

Sets a static default gateway.
The no form of the command deletes the default gateway.

Syntax Description	ip address	The default gateway IP address (IPv4 or IPv6).
	ifname	The interface name (e.g., mgmt0, mgmt1).
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # ip default-gateway 172.30.0.1 switch (config) # show ip default-gateway static Configured default gateway: switch (config) #</pre>	
Related Commands	show ip route	
Note	The configured default gateway will not be used if DHCP is enabled.	

show ip/ipv6 route

show {ip | ipv6} route [static]

Displays the routing table in the system.

Syntax Description	static	Filters the table with the static route entries.
Default	N/A	

Modes/Context	Any Command Mode
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show ip route Destination Mask Gateway Interface Source default 0.0.0.0 172.30.0.1 mgmt0 DHCP 10.10.10.10 255.255.255.255 0.0.0.0 mgmt0 static 20.10.10.10 255.255.255.255 172.30.0.1 mgmt0 static 20.20.20.0 255.255.255.0 0.0.0.0 mgmt0 static 172.30.0.0 255.255.0.0 0.0.0.0 mgmt0 interface switch (config) # show ipv6 route Destination prefix Gateway Interface Source ----- ::/0 :: mgmt0 static ::1/128 :: lo local 2222:2222:2222::/64 :: mgmt1 interface switch (config) #</pre>
Related Commands	show ip default-gateway
Note	

show ip/ipv6 default-gateway

show {ip | ipv6} default-gateway [static]

Displays the default gateway.

Syntax Description	static	Displays the static configuration of the default gateway.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # ip default-gateway 10.10.10.10 switch (config) # show ip default-gateway Active default gateways: 172.30.0.1 (interface: mgmt0) switch (config) # show ip default-gateway static Configured default gateway: 10.10.10.10</pre>	
Related Commands	show ip default-gateway	
Note	The configured IPv4 default gateway will not be used if DHCP is enabled.	

2.1.4 Network to Media Resolution (ARP & NDP)

IPv4 network use Address Resolution Protocol (ARP) to resolve IP address to MAC address, while IPv6 network uses Network Discovery Protocol (NDP) that performs basically the same as ARP.

ip arp

ip arp <IP address> <MAC address>
no ip arp <IP address> <MAC address>

Sets a static ARP entry.
 The no form of the command deletes the static ARP.

Syntax Description	IP address	IPv4 address.		
	MAC address	MAC address.		
Default	N/A			
Modes/Context	Config Interface Management			
History	3.2.0500			
Role	admin			
Example	switch (config interface mgmt0) #ip arp 20.20.20.20 aa:aa:aa:aa:aa:aa			
	switch (config interface mgmt0) # show ip arp			
	ARP Timeout: 1500			
	Total number of entries: 6			
	Address	Type	MAC Address	Interface
	10.209.1.103	Dynamic	00:02:C9:11:A1:78	mgmt0
	10.209.1.168	Dynamic	00:02:C9:5E:C3:28	mgmt0
	10.209.1.104	Dynamic	00:02:C9:11:A1:E6	mgmt0
	10.209.1.153	Dynamic	00:02:C9:11:A1:86	mgmt0
	10.209.1.105	Dynamic	00:02:C9:5E:0B:56	mgmt0
10.209.0.1	Dynamic	00:00:5E:00:01:01	mgmt0	
20.20.20.20	Static	AA:AA:AA:AA:AA:AA	mgmt0	
	switch (config interface mgmt0) #			
Related Commands	show ip arp ip route			
Note	•			

show ip arp

show ip arp [count]

Shows the ARP table

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.2.0500
Role	admin
Example	<pre>switch (config) # show ip arp ARP Timeout: 1500 Total number of entries: 9 Address Type MAC Address Interface 10.209.1.105 Dynamic 00:02:C9:5E:0B:56 mgmt0 10.209.1.168 Dynamic 00:02:C9:5E:C3:28 mgmt0 10.209.0.1 Dynamic 00:00:5E:00:01:01 mgmt0 10.209.1.226 Dynamic 00:02:C9:62:6A:54 mgmt0 1.1.1.1 Static 00:00:00:00:00:01 Vlan1 1.1.2.1 Static 00:00:00:00:00:02 Vlan1 1.1.3.1 Static 00:00:00:00:00:03 Vlan1 1.1.4.1 Static 00:00:00:00:00:04 Vlan1 1.1.5.1 Static 00:00:00:00:00:05 Vlan1 ARP Timeout: 1500 switch (config) # show ip arp count ARP Table size: 9 (inband:5, out of band:4) switch (config) #</pre>
Related Commands	ip arp
Note	•

ipv6 neighbor

ipv6 neighbor <IPv6 address> <ifname> <MAC address>
no ipv6 neighbor <IPv6 address> <ifname> <MAC address>

Adds a static neighbor entry.
The no form of the command deletes the static entry.

Syntax Description	IPv6 address	The IPv6 address.
	ifname	The management interface (i.e. mgmt0, mgmt1).
	MAC address	The MAC address.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # ipv6 neighbor 2001:db8:701f::8f9 mgmt0 00:11:22:33:44:55 switch (config) #</pre>	
Related Commands	<pre>show ipv6 neighbor ipv6 route arp clear ipv6 neighbors</pre>	
Note	<ul style="list-style-type: none"> • ARP is used only with IPv4. In IPv6 networks, Neighbor Discovery Protocol (NDP) is used similarly. • Use The no form of the command to remove static entries. Dynamic entries can be cleared via the “clear ipv6 neighbors” command. 	

clear ipv6 neighbors

clear ipv6 neighbors

Clears the dynamic neighbors cache.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # clear ipv6 neighbors switch (config) #</pre>
Related Commands	<pre>ipv6 neighbor show ipv6 neighbor arp</pre>
Note	<ul style="list-style-type: none"> • Clearing Neighbor Discovery Protocol (NDP) cache removes only the dynamic entries learned and not the static entries configured • Use the no form of the ipv6 neighbor command to remove static entries

show ipv6 neighbors

show ipv6 neighbors [static]

Displays the Neighbor Discovery Protocol (NDP) table.

Syntax Description	static	Filters only the table of the static entries.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # show ipv6 neighbors IPv6 Address Age MAC Address State Interf ----- 2001::2 9428 AA:AA:AA:AA:AA:AA permanent mgmt0 switch (config) #</pre>	
Related Commands	<pre>ipv6 neighbor clear ipv6 neighbor show ipv6</pre>	
Note		

2.1.5 DHCP

ip dhcp

```
ip dhcp {default-gateway yield-to-static| hostname <hostname>| primary-intf
<ifname> | send-hostname }
no ip dhcp {default-gateway yield-to-static| hostname || primary-intf | send-host-
name}
```

Sets global DHCP configuration.

The no form of the command deletes the DHCP configuration.

Syntax Description	yield-to-static	Does not allow you to install a default gateway from DHCP if there is already a statically configured one.
	hostname	Specifies the hostname to be sent during DHCP client negotiation if send-hostname is enabled.
	primary-intf <ifname>	Sets the interface from which a non-interface-specific configuration (resolver and routes) will be accepted via DHCP.
	send-hostname	Enables the DHCP client to send a hostname during negotiation.
Default	no ip dhcp yield-to-static no ip dhcp hostname ip ip dhcp primary-intf mgmt0 no ip dhcp send-hostname	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # ip dhcp default-gateway yield-to-static switch (config) # show ip dhcp DHCP primary interface: Configured: mgmt0 Active: mgmt0 DHCP: yield default gateway to static configuration: yes DHCP Client Options: Send Hostname: no Client Hostname: switch (using system hostname) switch config) #</pre>	
Related Commands	show ip dhcp dhcp [renew]	
Note	DHCP is supported for IPv4 networks only.	

show ip dhcp

show ip dhcp

Displays the DHCP configuration and status.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.0000

Role	admin
Example	<pre>switch (config) # show ip dhcp DHCP primary interface: Configured: mgmt0 Active: mgmt0 DHCP: yield default gateway to static configuration: yes DHCP Client Options: Send Hostname: no Client Hostname: switch (using system hostname) switch config) #</pre>
Related Commands	<pre>ip dhcp dhcp [renew]</pre>
Note	

2.1.6 General IPv6 Commands

ipv6 enable

ipv6 enable
no ipv6 enable

Enables IPv6 globally on the management interface.
The no form of the command disables IPv6 globally on the management interface.

Syntax Description	N/A
Default	IPv6 is disabled
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # ipv6 enable switch (config) # show ipv6 IPv6 summary IPv6 supported: yes IPv6 admin enabled: yes IPv6 interface count: 2 switch (config) #</pre>

Related Commands	ipv6 default-gateway ipv6 host ipv6 map-hostname ipv6 neighbor ipv6 route show ipv6 show ipv6 default-gateway show ipv6 route
Note	

2.1.7 IP Diagnostic Tools

ping

ping [-LRUbdnqrVvA] [-c count] [-i interval] [-w deadline] [-p pattern] [-s packetsize] [-t ttl] [-I interface or address] [-M mtu discovery hint] [-S sndbuf] [-T timestamp option] [-Q tos] [hop1 ...] destination

Sends ICMP echo requests to a specified host.

Syntax Description	Linux Ping options http://linux.about.com/od/commands/l/blcmdl8_ping.htm
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre> switch (config) # ping 172.30.2.2 PING 172.30.2.2 (172.30.2.2) 56(84) bytes of data. 64 bytes from 172.30.2.2: icmp_seq=1 ttl=64 time=0.703 ms 64 bytes from 172.30.2.2: icmp_seq=2 ttl=64 time=0.187 ms 64 bytes from 172.30.2.2: icmp_seq=3 ttl=64 time=0.166 ms 64 bytes from 172.30.2.2: icmp_seq=4 ttl=64 time=0.161 ms 64 bytes from 172.30.2.2: icmp_seq=5 ttl=64 time=0.153 ms 64 bytes from 172.30.2.2: icmp_seq=6 ttl=64 time=0.144 ms ^C --- 172.30.2.2 ping statistics --- 6 packets transmitted, 6 received, 0% packet loss, time 5004ms rtt min/avg/max/mdev = 0.144/0.252/0.703/0.202 ms switch (config) # </pre>
Related Commands	tracertoutes
Note	

traceroute

traceroute [-46dFITUnrAV] [-f first_ttl] [-g gate,...] [-i device] [-m max_ttl] [-N squeries] [-p port] [-t tos] [-l flow_label] [-w waittime] [-q nqueries] [-s src_addr] [-z sendwait] host [packetlen]

Traces the route packets take to a destination.

Syntax Description	-4	Uses IPv4.
	-6	Uses IPv6.
	-d	Enables socket level debugging.
	-F	Sets DF (do not fragment bit) on.
	-I	Uses ICMP ECHO for tracerouting.
	-T	Uses TCP SYN for tracerouting.
	-U	Uses UDP datagram (default) for tracerouting.
	-n	Does not resolve IP addresses to their domain names.
	-r	Bypasses the normal routing and send directly to a host on an attached network.
	-A	Performs AS path lookups in routing registries and print results directly after the corresponding addresses.
	-V	Prints version info and exit.
	-f	Starts from the first_ttl hop (instead from 1).
	-g	Routes packets throw the specified gateway (maximum 8 for IPv4 and 127 for IPv6).
	-i	Specifies a network interface to operate with.
	-m	Sets the max number of hops (max TTL to be reached). Default is 30.
	-N	Sets the number of probes to be tried simultaneously (default is 16).
	-p	Uses destination port. It is an initial value for the UDP destination port (incremented by each probe, default is 33434), for the ICMP seq number (incremented as well, default from 1), and the constant destination port for TCP tries (default is 80).
	-t	Sets the TOS (IPv4 type of service) or TC (IPv6 traffic class) value for outgoing packets.
	-l	Uses specified flow_label for IPv6 packets.
	-w	Sets the number of seconds to wait for response to a probe (default is 5.0). Non-integer (float point) values allowed too.
	-q	Sets the number of probes per each hop. Default is 3.
	-s	Uses source src_addr for outgoing packets.
	-z	Sets minimal time interval between probes (default is 0). If the value is more than 10, then it specifies a number in milliseconds, else it is a number of seconds (float point values allowed too).

Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # traceroute 192.168.10.70 traceroute to 192.168.10.70 (192.168.10.70), 30 hops max, 40 byte pack- ets 1 172.30.0.1 (172.30.0.1) 3.632 ms 2.849 ms 3.544 ms 2 10.222.128.46 (10.222.128.46) 3.176 ms 3.289 ms 3.656 ms 3 10.158.128.30 (10.158.128.30) 15.331 ms 15.819 ms 16.388 ms 4 10.158.128.65 (10.158.128.65) 20.468 ms 7.893 ms 12.27 ms 5 10.7.34.115 (10.7.34.115) 16.405 ms 11.985 ms 12.264 ms 6 192.168.10.70 (192.168.10.70) 16.377 ms 16.091 ms 20.475 ms switch (config) #</pre>
Related Commands	
Note	

tcpdump

```
tcpdump [-aAdefILnNOPqRStuUvxX] [-c count] [-C file_size]
        [-E algo:secret] [-F file] [-i interface] [-M secret]
        [-r file] [-s snaplen] [-T type] [-w file]
        [-W filecount] [-y datalinktype] [-Z user]
        [ expression ]
```

Invokes standard binary, passing command line parameters straight through. Runs in foreground, printing packets as they arrive, until the user hits Ctrl+C.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # tcpdump 09:37:38.678812 IP 192.168.10.7.ssh > 192.168.10.1.54155: P 1494624:1494800(176) ack 625 win 90 <nop,nop,timestamp 5842763 858672398> 09:37:38.678860 IP 192.168.10.7.ssh > 192.168.10.1.54155: P 1494800:1495104(304) ack 625 win 90 <nop,nop,timestamp 5842763 858672398> ... 9141 packets captured 9142 packets received by filter 0 packets dropped by kernel switch (config) #</pre>

Related Commands	N/A
-------------------------	-----

Note

2.2 License Keys

license

license {delete <license number> | install <license key>}
no license install <license key>

Activates features using license keys.

The no form of the command uninstalls an existing license key. If the key specified was not already installed, an error is returned.

Syntax Description	delete	Uninstalls an existing license key. Note that this has the same effect as the “no license install”, except that you specify the license by its ID instead of by repeating the license key.
	install	Installs a new license key. If the key is invalid (i.e. it could never have been a valid license), an error message is printed and it is not added. If the license is valid but there is something else wrong with it (i. e. it names a nonexistent feature, it is expired, etc.) a warning message is printed but it is added.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # license install <license key> switch (config) # show licenses License 1: <license key> Feature: SX_CONFIG Valid: yes Active: yes switch (config) #</pre>	
Related Commands	show licenses	
Note		

show licenses

show licenses

Displays a list of all installed licenses. For each license, the following is displayed:

- a unique ID which is a small integer
- the text of the license key as it was added
- whether or not it is valid and active
- which feature(s) it is activating
- a list of all licensable features specifying whether or not it is currently activated by a license

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	monitor/admin
Example	<pre>switch (config) # show licenses License 1: <license key> Feature: SX_CONFIG Valid: yes Active: yes switch (config) #</pre>
Related Commands	license
Note	

2.3 NTP, Clock & Time Zones

clock set

clock set <hh:mm:ss> [<yyyy/mm/dd>]

Sets the time and date.

Syntax Description	hh:mm:ss	Time.
	yyyy/mm/dd	Date.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	

Role	admin
Example	<pre>switch (config) # clock set 23:23:23 2010/08/19 switch (config) # show clock Time: 23:23:26 Date: 2010/08/19 Time zone: UTC (Etc/UTC) UTC offset: same as UTC switch (config) #</pre>
Related Commands	show clock
Note	If not specified, the date will be left the same.

clock timezone

clock timezone [<zone word> [<zone word> [<zone word>] [<zone word>]]]

Sets the system time zone. The time zone may be specified in one of three ways:

- A nearby city whose time zone rules to follow. The system has a large list of cities which can be displayed by the help and completion system. They are organized hierarchically because there are too many of them to display in a flat list. A given city may be required to be specified in two, three, or four words, depending on the city.
 - An offset from UTC. This will be in the form UTC-offset UTC, UTC-offset UTC+<0-14>, UTC-offset UTC-<1-12>.
 - UTC (Universal Time, which is almost identical to GMT), and this is the default time zone
- The no form of the command resets time zone to its default (GMT).

Syntax Description	zone word	The possible forms this could take include: continent, city, continent, country, city, continent, region, country, city, ocean, and/or island.
Default	GMT	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # clock timezone America North United_States Other New_York switch (config) # show clock Time: 04:21:44 Date: 2012/02/26 Time zone: America North United_States Other New_York switch (config) #</pre>	
Related Commands	show clock	
Note		

ntp

ntp {disable | enable | {peer | server} <IP address> [version <number> | disable]}
no ntp {disable | enable | {peer | server} <IP address> [disable]}

Configures NTP.
 The no form of the command negates NTP options.

Syntax Description	disable	Disables NTP.
	enable	Enables NTP.
	peer or server	Configures an NTP peer or server node.
	IP address	IPv4 or IPv6 address.
	version <number>	Specifies the NTP version number of this peer. Possible values are 3 or 4.
Default	NTP is enabled. NTP version number is 4.	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # no ntp peer 192.168.10.24 disable switch (config) #</pre>	
Related Commands	N/A	
Note		

ntpdate

ntpdate <IP address>

Sets the system clock using the specified SNTP server.

Syntax Description	IP address	IP.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example	<pre>switch (config) # ntpdate 192.168.10.10 26 Feb 17:25:40 ntpdate[15206]: adjust time server 192.168.10.10 offset -0.000092 sec switch (config) #</pre>
Related Commands	N/A
Note	This is a one-time operation and does not cause the clock to be kept in sync on an ongoing basis. It will generate an error if SNTP is enabled since the socket it requires will already be in use.

show clock

show clock

Displays the current system time, date and time zone.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show clock Time: 04:21:44` Date: 2012/02/26 Time zone: America North United_States Other New_York switch (config) #</pre>
Related Commands	N/A
Note	

show ntp

show ntp

Displays the current NTP settings.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000

Role	admin
Example	switch (config) # show ntp NTP is enabled. Clock is unsynchronized. No NTP peers or servers configured. switch (config) #
Related Commands	N/A
Note	

2.4 Software Management

This chapter displays all the relevant commands used to manage the system software image.

image boot

image boot {location <location ID> | next}

Specifies the default location where the system should be booted from.

Syntax Description	location ID	Specifies the default destination location. There can be up to 2 images on the system. The possible values are 1 or 2.
	next	Sets the boot location to be the next once after the one currently booted from, thus avoiding a cycle through all the available locations.
Default	N/A	
Modes/Context	enable/config	
History	3.1.0000	
Role	admin	
Example	switch (config) # image boot location 2 switch (config) #	
Related Commands	show images	
Note		

boot next

boot next fallback-reboot enable
no boot next fallback-reboot enable

Sets the default setting for next boot. Normally, if the system fails to apply the configuration on startup (after attempting upgrades or downgrades, as appropriate), it will reboot to the other partition as a fallback.

The no form of the command tells the system not to do that, only for the next boot.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.2.0504
Role	admin
Example	<pre>switch (config) # boot fallback-reboot enable switch (config) #</pre>
Related Commands	show images
Note	<p>Normally, if the system fails to apply the configuration on startup (after attempting upgrades or downgrades, as appropriate), it will reboot to the other partition as a fallback. The 'no' variant of this command tells the system NOT to do that, ONLY for the next boot. Note that this setting is not persistent, and will go back to enabled automatically after every boot.</p> <p>Note that if you are downgrading to an older software version which has never been run yet on this system, the "fallback reboot" will ALWAYS happen, unless you use "no boot next fallback-reboot enable" first. This is also true in some other cases, such as when you have run the older software version before, but you have switched to a different configuration file since upgrading. In general, a downgrade will only work (without having the fallback reboot forcibly disabled) if it can find a snapshot of the configuration file (by the same name as the currently active one) which was taken when you earlier upgraded from the older software version. If it doesn't find this file, it will do a fallback reboot in preference to falling back to the initial database, since the latter will generally involve a loss of network connectivity, and avoid that is considered of paramount importance.</p>

image default-chip-fw

image default-chip-fw <file name>

Sets the default firmware package to be installed.

Syntax Description	filename	Specifies the firmware filename.
---------------------------	----------	----------------------------------

Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # image default-chip-fw image-SX_PPC_M460EX-ppc-m460ex- 20120122-084759.img switch (config) #</pre>
Related Commands	<pre>image install-chip fw show images</pre>
Note	

image delete

image delete <image name>

Deletes the specified image file.

Syntax Description	image name	Specifies the image name.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # image delete image-MLXNX-OS-201140526-010145.img switch (config) #</pre>	
Related Commands	show images	
Note		

image fetch

image fetch <URL> [<filename>]

Downloads an image from the specified URL or via SCP.

Syntax Description	URL	HTTP, HTTPS, FTP, TFTP, SCP and SFTP are supported. Example: scp://username[:password]@host-name/path/filename.
	filename	Specifies a filename for this image to be stored as locally.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # image fetch scp://<username>@192.168.10.125/var/www/ html/<image_name> Password ***** 100.0%[#####] switch (config) #</pre>	
Related Commands	show images	
Note	<ul style="list-style-type: none"> • Please delete the previously available image, prior to fetching the new image • See section “Upgrading MLNX-OS SX Software,” in the <i>Mellanox SwitchX® User Manual</i> for a full upgrade example 	

image install

image install <image filename> [location <location ID>] | [progress <prog-options>] [verify <ver-options>]

Installs the specified image file.

Syntax Description	image filename	Specifies the image name.
	location ID	Specifies the image destination location.
	prog-options	<ul style="list-style-type: none"> • “no-track” overrides CLI default and does not track the installation progress • “track” overrides CLI default and tracks the installation progress
	ver-options	<ul style="list-style-type: none"> • “check-sig” requires an image to have either a valid signature or no signature • “ignore-sig” allows unsigned or invalidly signed images to be installed • “require-sig” requires from the installed image to have a valid signature. If a valid signature is not found on the image, the image cannot be installed.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	

Role	admin
Example	<pre>switch (config) # image install SX_PPC_M460EX 3.0.0000-dev-HA 2012-01-22 08:47:59 ppc Step 1 of 4: Verify Image 100.0% [#####] Step 2 of 4: Uncompress Image 100.0% [#####] Step 3 of 4: Create Filesystems 100.0% [#####] Step 4 of 4: Extract Image 100.0% [#####] switch (config) #</pre>
Related Commands	show images
Note	<ul style="list-style-type: none"> The image cannot be installed on the “active” location (the one which is currently being booted) On a two-location system, the location is chosen automatically if no location is specified

image install-chip-fw

image install-chip-fw {<module name> | <group of modules>}

Installs a chip firmware image.

Syntax Description	module name	Specifies the module name, e.g. S01/S02/L01/L02/SX.
	group of modules	Specifies the group of modules, e.g. Leafs/Spines.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # image install-chip-fw SX switch (config) #</pre>	
Related Commands	<pre>image install-chip-fw show images</pre>	
Note	This command is rarely used and only in scenarios when a firmware upgrade is released without a software release.	

image move

image move <src image name> <dest image name>

Renames the specified image file.

Syntax Description	src image name	Specifies the old image name.
	dest image name	Specifies the new image name.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # image move image1.img image2.img switch (config) #</pre>	
Related Commands	show images	
Note		

image options

image options require-sig
no image options require-sig

Requires from all the installed images a valid signature.
 The no form of the command does not require a signature. However if one is present, it must be valid.

Syntax Description	require-sig	Requires images to be signed by a trusted signature.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # image options require-sig switch (config) #</pre>	
Related Commands	show images	
Note		

show bootvar

show bootvar

Displays the installed system images and the boot parameters.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show bootvar Installed images: Partition 1: SX_PPC_M460EX 3.0.0000-dev-HA 2012-01-22 08:47:59 ppc Last dobincp: 2012/01/23 14:54:23 Partition 2: SX_PPC_M460EX 3.0.0000-dev-HA 2012-01-18 09:52:41 ppc Last dobincp: 2012/01/19 16:48:23 Last boot partition: 1 Next boot partition: 1 Boot manager password is set. No image install currently in progress. Image signing: trusted signature always required Admin require signed images: yes Settings for next boot only: Fallback reboot on configuration failure: yes (default) switch (config) #</pre>
Related Commands	N/A
Note	

show images

show image

Displays information about the system images and boot parameters.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode

History	3.1.0000
Role	admin
Example	<pre> switch (config) # show images Images available to be installed: image-SX_PPC_M460EX-ppc-m460ex-20120122-084759.img SX_PPC_M460EX 3.0.0000-dev-HA 2012-01-22 08:47:59 ppc Installed images: Partition 1: SX_PPC_M460EX 3.0.0000-dev-HA 2012-01-22 08:47:59 ppc Last dobincp: 2012/01/23 14:54:23 Partition 2: SX_PPC_M460EX 3.0.0000-dev-HA 2012-01-18 09:52:41 ppc Last dobincp: 2012/01/19 16:48:23 Last boot partition: 1 Next boot partition: 1 Boot manager password is set. No image install currently in progress. Image signing: trusted signature always required Admin require signed images: yes Settings for next boot only: Fallback reboot on configuration failure: yes (default) switch (config) # </pre>
Related Commands	N/A
Note	

2.5 File Management

2.5.1 File Transfer

ftp-server enable

ftp-server enable
no ftp-server enable

Enables the FTP server.
The no form of the command disables the FTP server.

Syntax Description	N/A
Default	The FTP server is disabled
Modes/Context	Config
History	3.1.0000

Role	admin
Example	switch (config) # ftp-server enable switch (config) # show ftp-server FTP server enabled: yes
Related Commands	show ftp-server
Note	

show ftp-server

show ftp-server

Displays FTP server settings.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	switch (config) # show ftp-server FTP server enabled: yes switch (config) #
Related Commands	ftp-server enable
Note	

2.5.2 File System

debug generate dump

debug generate dump

Generates a debug dump.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin

Example	switch (config) # debug generate dump Generated dump sysdump-switch-112104-201140526-091707.tgz switch (config) #
Related Commands	file debug-dump
Note	The dump can then be manipulated using the “file debug-dump...” commands.

file debug-dump

file debug-dump {delete <filename> | email <filename> | upload {<filename> | <URL>}}

Manipulates debug dump files.

Syntax Description	delete <filename>	Deletes a debug dump file.
	email <filename>	Emails a debug dump file to pre-configured recipients for “informational events”, regardless of whether they have requested to receive “detailed” notifications or not.
	upload <filename>	Uploads a debug dump file to a remote host.
	URL	HTTP, HTTPS, FTP, TFTP, SCP and SFTP are supported. Example: scp://username[:password]@host-name/path/filename.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	switch (config) # file debug-dump email sysdump-switch-112104-20114052-091707.tgz switch (config) #	
Related Commands	show files debug-dump	
Note		

file stats

file stats {delete <filename> | move {<source filename> | <destination filename>} | upload <filename> <URL>}

Manipulates statistics report files.

Syntax Description	delete <filename>	Deletes a stats report file.
	move <source filename> <destination filename>	Renames a stats report file.
	upload <filename> <URL>	Uploads a stats report file. URL - HTTP, HTTPS, FTP, TFTP, SCP and SFTP are supported. Example: scp://username[:password]@host-name/path/filename.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # file stats move memory-1.csv memory-2.csv switch (config) #</pre>	
Related Commands	<pre>show files stats show files stats <filename></pre>	
Note		

file tcpdump

file tcpdump {delete <filename> | upload <filename> <URL>}

Manipulates tcpdump output files.

Syntax Description	delete <filename>	Deletes the specified tcpdump output file.
	upload <filename> <URL>	Uploads the specified tcpdump output file to the specified URL. URL - HTTP, HTTPS, FTP, TFTP, SCP and SFTP are supported. Example: scp://username[:password]@host-name/path/filename.
Default	N/A	
Modes/Context	Config	

History	3.1.0000
Role	admin
Example	switch (config) # file tcpdump delete my-tcpdump-file.txt switch (config) #
Related Commands	show files stats tcpdump
Note	

show files debug-dump

show files debug-dump [<filename>]

Displays a list of debug dump files.

Syntax Description	filename	Displays a summary of the contents of a particular debug dump file.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # show files debug-dump sysdump-switch-112104-20114052-091707.tgz System information: Hostname: switch-112104 Version: SX_PPC 3.1.0000 2011-05-25 13:59:00 ppc Date: 2012-01-26 09:17:07 Uptime: 0d 18h 47m 48s ===== Output of 'uname -a': Linux switch-112104 2.6.27-MELLANOXuni-m405ex SX_PPC 3.1.0000 #1 2012-01-25 13:59:00 ppc ppc ppc GNU/Linux ===== switch (config) #</pre>	
Related Commands	file debug-dump	
Note		

show files stats

show files stats <filename>

Displays a list of statistics report files.

Syntax Description	filename	Display the contents of a particular statistics report file.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # show files stats memory-201140524-111745.csv switch (config) #</pre>	
Related Commands	file stats	
Note		

show files system

show files system [detail]

Displays usage information of the file systems on the system.

Syntax Description	detail	Displays more detailed information on file-system.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example	<pre> switch (config) # show files system Statistics for /config filesystem: Bytes Total 100 MB Bytes Used 3 MB Bytes Free 97 MB Bytes Percent Free 97% Bytes Available 97 MB Inodes Total 0 Inodes Used 0 Inodes Free 0 Inodes Percent Free 0% Statistics for /var filesystem: Bytes Total 860 MB Bytes Used 209 MB Bytes Free 651 MB Bytes Percent Free 75% Bytes Available 651 MB Inodes Total 0 Inodes Used 0 Inodes Free 0 Inodes Percent Free 0% switch (config) # </pre>
Related Commands	N/A
Note	

show files tcpdump

show files tcpdump

Displays a list of statistics report files.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre> switch (config) # show files stats test dump3 switch (config) # </pre>
Related Commands	<pre> file tcpdump tcpdump </pre>
Note	

2.5.3 Configuration File

configuration audit

configuration audit max-changes <number>

Chooses settings related to configuration change auditing.

Syntax Description	max-changes	Set maximum number of audit messages to log per change.
Default	1000	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # configuration audit max-changes 100 switch (config) # show configuration audit Maximum number of changes to log: 100 switch (config) #</pre>	
Related Commands	show configuration	
Note	N/A	

configuration copy

configuration copy <source name> <dest name>

Copies a configuration file.

Syntax Description	source name	Name of source file.
	dest name	Name of destination file. If the file of specified file-name does not exist a new file will be created with said filename.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # configuration copy initial.bak example switch (config) #</pre>	

Related Commands

Note

- This command does not affect the current running configuration
- The active configuration file may not be the target of a copy. However, it may be the source of a copy in which case the original remains active.

configuration delete

configuration delete <filename>

Deletes a configuration file.

Syntax Description	filename	Name of file to delete.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # show configuration files example initial initial.bak initial.prev switch (config) # configuration delete example switch (config) # show configuration files initial initial.bak initial.prev switch (config) #</pre>	
Related Commands	show configuration	
Note	<ul style="list-style-type: none"> • This command does not affect the current running configuration • The active configuration file may not be deleted 	

configuration fetch

configuration fetch <URL or scp or sftp://username:password@hostname[:port]/path/filename> [<name>]

Downloads a configuration file from a remote host.

Syntax Description	name	The configuration file name.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example	<pre>switch (config) # configuration fetch scp://root:password@ 192.168.10.125/tmp/conf1 switch (config) #</pre>
Related Commands	configuration switch-to
Note	<ul style="list-style-type: none"> • The downloaded file should not override the active configuration file, using the <name> parameter • If no name is specified for a configuration fetch, it is given the same name as it had on the server • No configuration file may have the name “active”

configuration jump-start

configuration jump-start

Runs the initial-configuration wizard.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # configuration jump-start Mellanox configuration wizard Step 1: Hostname? [switch-3cc29c] Step 2: Use DHCP on mgmt0 interface? y Step 3: Admin password (Enter to leave unchanged)? You have entered the following information: 1. Hostname: switch-3cc29c 2. Use DHCP on mgmt0 interface: yes 3. Enable IPv6: yes 4. Enable IPv6 autoconfig (SLAAC) on mgmt0 interface: yes 53. Admin password (Enter to leave unchanged): (unchanged) To change an answer, enter the step number to return to. Otherwise hit <enter> to save changes and exit. Choice: Configuration changes saved. switch (config) #</pre>
Related Commands	N/A
Note	<ul style="list-style-type: none"> • The wizard is automatically invoked whenever the CLI is launched when the active configuration file is fresh (i.e. not modified from its initial contents) • This command invokes the wizard on demand – see chapter “Initializing the Switch for the First Time” in the Mellanox <i>MLNX-OS SwitchX User Manual</i>

configuration merge

configuration merge <filename>

Merges the “shared configuration” from one configuration file into the running configuration.

Syntax Description	filename	Name of file from which to merge settings.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # configuration merge new-config-file switch (config) #</pre>	
Related Commands		
Note	<ul style="list-style-type: none"> • No configuration files are modified during this process • The configuration name must be a non-active configuration file 	

configuration move

configuration move <source name> <dest name>

Moves a configuration file.

Syntax Description	source name	Old name of file to move.
	dest name	New name for moved file.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # show configuration files example1 initial initial.bak initial.prev switch (config) # configuration move example1 example2 switch (config) # show configuration files example2 initial initial.bak initial.prev switch (config) #</pre>	

Related Commands	show configuration	
Note	<ul style="list-style-type: none"> This command does not affect the current running configuration The active configuration file may not be the target of a move 	

configuration new

configuration new <filename> [factory [keep-basic] [keep-connect]]

Creates a new configuration file under the specified name. The parameters specify what configuration, if any, to carry forward from the current running configuration.

Syntax Description	filename	Names for new configuration file.
	factory	Creates new file with only factory defaults.
	keep-basic	Keeps licenses and host keys.
	keep-connect	Keeps configuration necessary for connectivity (interfaces, routes, and ARP).
Default	Keeps licenses and host keys	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # show configuration files initial initial.bak initial.prev switch (config) # configuration new example2 switch (config) # show configuration files example2 initial initial.bak initial.prev switch (config) #</pre>	
Related Commands	show configuration	
Note		

configuration revert

configuration revert {factory [keep-basic | keep-connect]| saved}

Reverts the system configuration to a previous state.

Syntax Description	factory	Reverts running and saved configurations to factory defaults. If no parameter is set the default is to keep licenses and host keys.
	keep-basic	Keeps licenses and host keys.
	keep-connect	Keeps configuration necessary for connectivity (interfaces, routes, and ARP).
	saved	Reverts running configuration to last saved configuration.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # configuration revert saved switch (config) #</pre>	
Related Commands	show configuration	
Note		

configuration switch-to

configuration switch-to <filename>

Loads the configuration from the specified file and makes it the active configuration file.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show configuration files initial (active) newcon initial.prev initial.bak switch (config) # configuration switch-to newcon switch (config) # show configuration files initial newcon (active) initial.prev initial.bak switch (config) #</pre>

Related Commands	show configuration files
Note	The current running configuration is lost and not automatically saved to the previous active configuration file.

configuration text fetch

configuration text fetch <download URL> [apply] [discard] [fail-continue] [filename <file>] [verbose]

Downloads a text-based configuration file from a remote host.

Syntax Description	download URL	Supported types are HTTP, HTTPS, FTP, TFTP, SCP and SFTP. For example: scp://username[:password]@hostname/path/filename.
	filename <file>	Specifies filename for saving downloaded text file.
	apply	Applies the configuration on the system.
	discard	Deletes the configuration text after applying it.
	fail-continue	Continues execution of the commands even if some commands fail.
	verbose	Displays all commands being executed and their output, instead of just those that get errors.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # configuration text fetch example@host.com switch (config) #</pre>	
Related Commands	show configuration files	
Note		

configuration text file

configuration text file <filename> {**apply** [**fail-continue**] [**verbose**] | **delete** | **rename** <filename> | **upload** <URL>}

Performs operations on text-based configuration files.

Syntax Description	filename <file>	Specifies the filename.
	apply	Applies the configuration on the system.
	fail-continue	Continues execution of the commands even if some commands fail.
	verbose	Displays all commands being executed and their output, instead of just those that get errors.
	delete	Deletes the file.
	rename <filename>	Renames the file.
	upload <URL>	Supported types are HTTP, HTTPS, FTP, TFTP, SCP and SFTP. For example: scp://username[:password]@hostname/path/filename.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # configuration text file my-config-file delete switch (config) #</pre>	
Related Commands	show configuration files	
Note		

configuration text generate

configuration text generate {**active** {**running** | **saved**} | **file** <filename> } {**save** <filename> | **upload** <URL>}

Generates a new text-based configuration file from this system's configuration.

Syntax Description	active	Generates from currently active configuration.
	running	Uses running configuration.
	saved	Uses saved configuration.
	file <filename>	Generates from inactive saved configuration.
	save	Saves new file to local persistent storage.
	upload <URL>	Supported types are HTTP, HTTPS, FTP, TFTP, SCP and SFTP. For example: scp://username[:password]@hostname/path/filename.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # configuration text generate file initial.prev save example switch (config) # show configuration files initial (active) initial.prev initial.bak Active configuration: initial Unsaved changes: yes switch (config) #</pre>	
Related Commands	show configuration files	
Note		

configuration upload

configuration upload {active | <name>} <URL or scp or sftp://username:password@hostname[:port]/path/filename>

Uploads a configuration file to a remote host.

Syntax Description	active	Upload the active configuration file.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # configuration upload active scp://root:password@ 192.168.10.125/tmp/conf1 switch (config) #</pre>	

Related Commands	N/A
Note	No configuration file may have the name “active”.

write

write {memory [local] | terminal}

Saves or displays the running configuration.

Syntax Description	memory	Saves running configuration to the active configuration file. It is the same as “configuration write”.
	local	Saves the running configuration only on the local node. It is the same as “configuration write local”.
	terminal	Displays commands to recreate current running configuration. It is the same as “show running-config”.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```
switch (config) # write terminal
##
## Running database "initial"
## Generated at 20114/05/27 10:05:16 +0000
## Hostname: switch
##
##
## Network interface configuration
##
interface mgmt0 comment ""
interface mgmt0 create
interface mgmt0 dhcp
interface mgmt0 display
interface mgmt0 duplex auto
interface mgmt0 mtu 1500
no interface mgmt0 shutdown
interface mgmt0 speed auto
no interface mgmt0 zeroconf
##
## Local user account configuration
##
username a** capability admin
no username a** disable
username a** disable password
.....
switch (config) #
```

Related Commands	show running-config configuration write
-------------------------	--

Note

show configuration

show configuration [audit | | files [<filename>] | full | running [full] | text files]

Displays a list of CLI commands that will bring the state of a fresh system up to match the current persistent state of this system.

Syntax Description	audit	Displays settings for configuration change auditing.
	files [<filename>]	Displays a list of configuration files in persistent storage if no filename is specified. If a filename is specified, it displays the commands to recreate the configuration in that file. In the latter case, only non-default commands are shown, as for the normal “show configuration” command.
	full	Does not exclude commands that set default values.
	running	Displays commands to recreate current running configuration. Same as “show configuration” except that it applies to the currently running configuration, rather than the current persisted configuration.
	text files	Displays names of available text-based configuration files.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	monitor/admin	

Example

```

switch (config) # show configuration
##
## Active saved database "newcon"
## Generated at 20114/05/25 10:18:52 +0000
## Hostname: switch-3cc29c
##
##
## Network interface configuration
##
interface mgmt0 comment ""
interface mgmt0 create
interface mgmt0 dhcp
interface mgmt0 display
interface mgmt0 duplex auto
interface mgmt0 mtu 1500
no interface mgmt0 shutdown
interface mgmt0 speed auto
no interface mgmt0 zeroconf
switch (config) #

```

Related Commands	N/A
-------------------------	-----

Note**show running-config****show running-config [full]**

Displays commands to recreate current running configuration.

Syntax Description	full	Does not exclude commands that set default values.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	monitor/admin	

Example

```

switch (config) # show running-config
##
## Running database "initial"
## Generated at 2012/02/28 14:59:02 +0000
## Hostname: switch-5ea5d8
##

##
## License keys
##
    license install LK2-EFM_SX-5M11-5K11-5HGL-0KAL-64QK-8C2Q-60Q3-6C1G-
88A1-F5DF-
2KGK-8
    license install LK2-RESTRICTED_CMDS-88A0-RFD7-W4CF-Y

##
## Network interface configuration
##
    interface mgmt0 create
    interface mgmt0 comment ""
    interface mgmt0 dhcp
    interface mgmt0 display
    interface mgmt0 duplex auto
    interface mgmt0 mtu 1500
no interface mgmt0 shutdown
...
switch (config) #

```

Related Commands

show configuration running

Note

Same as “show configuration running” except that it applies to the currently running configuration, rather than the current persisted configuration.

2.6 Local and Remote Logging

logging local

logging local <log-level>

no logging local

Sets the minimum severity of log messages to be saved in log files on local persistent storage.

The no form disables the ability to log messages locally and remotely.

Syntax Description

log-level

- alert - alert notification, action must be taken immediately
- crit - critical condition
- debug - debug level messages
- emerg - system is unusable (emergency)
- err - error condition
- info - informational condition
- none - disables the logging locally and remotely
- notice - normal, but significant condition
- warning - warning condition

Default	info
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre> switch (config) # logging local info switch (config) # show logging Local logging level: info Default remote logging level: notice No remote syslog servers configured. Allow receiving of messages from remote hosts: no Number of archived log files to keep: 10 Log rotation size threshold: 5.000% of partition (43 megabytes) Log format: standard Subsecond timestamp field: disabled Levels at which messages are logged: CLI commands: notice Audit messages: notice switch (config) # </pre>
Related Commands	<pre> show logging logging local override </pre>
Note	<p>The commands “logging local none” and “no logging local” have the same effect. Disabling the logging messages will disable all logging:</p> <ul style="list-style-type: none"> • Local logging • Logging messages sent from hosts to be logged in the system • Remote logging (syslog)

logging local override

logging local override [class <class> priority <log-level>]
no logging local override [class <class> priority <log-level>]

Enables class-specific overrides to the local log level.
The no form of the command disables all class-specific overrides to the local log level without deleting them from the configuration, but disables them so that the logging level for all classes is determined solely by the global setting.

Syntax Description	override	Enables class-specific overrides to the local log level.
	class	<p>Sets or removes a per-class override on the logging level. All classes which do not have an override set will use the global logging level set with “logging local <log level>”. Classes that do have an override will do as the override specifies. If “none” is specified for the log level, MLNX-OS will not log anything from this class.</p> <p>Classes available:</p> <ul style="list-style-type: none"> • iss-modules - protocol stack • mgmt-back - system management back-end • mgmt-core - system management core • mgmt-front - system management front-end • mlx-daemons - management daemons • sx-sdk - switch SDK
	log-level	<ul style="list-style-type: none"> • alert - alert notification, action must be taken immediately • crit - critical condition • debug - debug level messages • emerg - system is unusable (emergency) • err - error condition • info - informational condition • none - disables the logging locally and remotely • notice - normal, but significant condition • warning - warning condition
Default	Override is disabled.	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # logging local override class mgmt-front priority warning switch (config) # show logging Local logging level: info Override for class mgmt-front: warning Default remote logging level: notice No remote syslog servers configured. Allow receiving of messages from remote hosts: no Number of archived log files to keep: 10 Log rotation size threshold: 5.000% of partition (43 megabytes) Log format: standard Subsecond timestamp field: disabled Levels at which messages are logged: CLI commands: notice Audit messages: notice switch (config) #</pre>	
Related Commands	<pre>show logging logging local</pre>	
Note		

logging <syslog IP address>

logging <syslog IP address> [trap {<log-level> | override class <class> priority <log-level>}]

no logging <syslog IP address> [trap {<log-level> | override class <class> priority <log-level>}]

Enables (by setting the IP address) sending logging messages, with ability to filter the logging messages according to their classes.

The no form of the command stops sending messages to the remote syslog server.

Syntax	Description
syslog IP address	IPv4 address of the remote syslog server.
log-level	<ul style="list-style-type: none"> • alert - alert notification, action must be taken immediately • crit - critical condition • debug - debug level messages • emerg - system is unusable (emergency) • err - error condition • info - informational condition • none - disables the logging locally and remotely • notice - normal, but significant condition • warning - warning condition
class	<p>Sets or removes a per-class override on the logging level. All classes which do not have an override set will use the global logging level set with “logging local <log level>”. Classes that do have an override will do as the override specifies. If “none” is specified for the log level, MLNX-OS will not log anything from this class.</p> <p>Classes available:</p> <ul style="list-style-type: none"> • iss-modules - protocol stack • mgmt-back - system management back-end • mgmt-core - system management core • mgmt-front - system management front-end • mlx-daemons - management daemons • sx-sdk - switch SDK
log-level	<ul style="list-style-type: none"> • alert - alert notification, action must be taken immediately • crit - critical condition • debug - debug level messages • emerg - system is unusable (emergency) • err - error condition • info - informational condition • none - disables the logging locally and remotely • notice - normal, but significant condition • warning - warning condition
Default	Remote logging is disabled
Modes/Context	Config
History	3.1.0000
Role	admin

Example	<pre> switch (config) # logging local info switch (config) # show logging Local logging level: info Default remote logging level: notice No remote syslog servers configured. Allow receiving of messages from remote hosts: no Number of archived log files to keep: 10 Log rotation size threshold: 5.000% of partition (43 megabytes) Log format: standard Subsecond timestamp field: disabled Levels at which messages are logged: CLI commands: notice Audit messages: notice switch (config) # </pre>
Related Commands	<pre> show logging logging local override </pre>
Note	

logging receive

logging receive
no logging receive

Enables receiving logging messages from a remote host.
The no form of the command disables the option of receiving logging messages from a remote host.

Syntax Description	N/A
Default	Receiving logging is disabled
Modes/Context	Config
History	3.1.0000
Role	admin

Example

```

switch (config) # logging receive
switch (config) # show logging
Local logging level: info
Default remote logging level: notice
No remote syslog servers configured.
Allow receiving of messages from remote hosts: yes
Number of archived log files to keep: 10
Log rotation size threshold: 5.000% of partition (43 megabytes)
Log format: standard
Subsecond timestamp field: disabled
Levels at which messages are logged:
    CLI commands: notice
    Audit messages: notice
switch (config) #

```

Related Commands	show logging logging local logging local override
Note	<ul style="list-style-type: none"> • This does not log to the console TTY port • Inband management should be enabled in order to open a channel from the host to the CPU • If enabled, only log messages matching or exceeding the minimum severity specified with the “logging local” command will be logged, regardless of what is sent from the remote host

logging format

logging format {standard | welf [fw-name <hostname>]}
no logging format {standard | welf [fw-name <hostname>]}

Sets the format of the logging messages.
The no form of the command resets the format to its default.

Syntax Description	standard	Standard format.
	welf	WebTrends Enhanced Log file (WELF) format.
	hostname	Specifies the firewall hostname that should be associated with each message logged in WELF format. If no firewall name is set, the hostname is used by default.
Default	standard	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # logging format standard switch (config) # show logging Local logging level: info Default remote logging level: notice No remote syslog servers configured. Allow receiving of messages from remote hosts: yes Number of archived log files to keep: 10 Log rotation size threshold: 5.000% of partition (43 megabytes) Log format: standard Subsecond timestamp field: disabled Levels at which messages are logged: CLI commands: notice Audit messages: notice switch (config) #</pre>	
Related Commands	show logging	
Note		

logging fields

logging fields seconds {enable | fractional-digits <f-digit> | whole-digits <w-digit>}

no logging fields seconds {enable | fractional-digits <f-digit> | whole-digits <w-digit>}

Specifies whether to include an additional field in each log message that shows the number of seconds since the Epoch or not.

The no form of the command disallows including an additional field in each log message that shows the number of seconds since the Epoch.

Syntax Description	enable	Specifies whether to include an additional field in each log message that shows the number of seconds since the Epoch or not.
	f-digit	The fractional-digits parameter controls the number of digits to the right of the decimal point. Truncation is done from the right. Possible values are: 1, 2, 3, or 6.
	w-digit	The whole-digits parameter controls the number of digits to the left of the decimal point. Truncation is done from the left. Except for the year, all of these digits are redundant with syslog's own date and time. Possible values: 1, 6, or all.
Default	disabled	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # logging fields seconds enable switch (config) # logging fields seconds whole-digits 1 switch (config) # show logging Local logging level: info Override for class mgmt-front: warning Default remote logging level: notice No remote syslog servers configured. Allow receiving of messages from remote hosts: no Number of archived log files to keep: 10 Log rotation size threshold: 5.000% of partition (43 megabytes) Log format: standard Subsecond timestamp field: enabled Subsecond timestamp precision: 1 whole digit; 3 fractional digits Levels at which messages are logged: CLI commands: notice Audit messages: notice switch (config) # </pre>	

Related Commands	show logging
Note	This is independent of the standard syslog date and time at the beginning of each message in the format of “July 15 18:00:00”. Aside from indicating the year at full precision, its main purpose is to provide subsecond precision.

logging level

logging level {cli commands <log-level> | audit mgmt <log-level>}

Sets the severity level at which CLI commands or the management audit message that the user executes are logged. This includes auditing of both configuration changes and actions.

Syntax Description	cli commands	Sets the severity level at which CLI commands which the user executes are logged.
	audit mgmt	Sets the severity level at which all network management audit messages are logged.
	log-level	<ul style="list-style-type: none"> • alert - alert notification, action must be taken immediately • crit - critical condition • debug - debug level messages • emerg - system is unusable (emergency) • err - error condition • info - informational condition • none - disables the logging locally and remotely • notice - normal, but significant condition • warning - warning condition
Default	CLI commands and audit message are set to notice logging level	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # logging level cli commands info switch (config) # show logging Local logging level: info Override for class mgmt-front: warning Default remote logging level: notice No remote syslog servers configured. Allow receiving of messages from remote hosts: no Number of archived log files to keep: 10 Log rotation size threshold: 5.000% of partition (43 megabytes) Log format: standard Subsecond timestamp field: enabled Subsecond timestamp precision: 1 whole digit; 3 fractional digits Levels at which messages are logged: CLI commands: info Audit messages: notice switch (config) #</pre>	

Related Commands	show logging
-------------------------	--------------

Note

logging files delete

logging files delete {current | oldest [<number of files>]}

Deletes the current or oldest log files.

Syntax Description	current	Deletes current log file.
	oldest	Deletes oldest log file.
	number of files	Sets the number of files to be deleted.
Default	CLI commands and audit message are set to notice logging level (TBD)	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # logging files delete current switch (config) #</pre>	
Related Commands	<pre>show logging show log files</pre>	
Note		

logging files rotation

logging files rotation {criteria { frequency <freq> | size <size-mb>| size-pct <size-percentage>} | force | max-number <number-of-files>}

Sets the rotation criteria of the logging files.

Syntax Description	freq	Sets rotation criteria according to time. Possible options are: <ul style="list-style-type: none"> • Daily • Weekly • Monthly
	size-mb	Sets rotation criteria according to size in mega bytes. The range is 1-9999.
	size-percentage	Sets rotation criteria according to size in percentage of the partition where the logging files are kept in. The percentage given is truncated to three decimal points (thousandths of a percent).
	force	Forces an immediate rotation of the log files. This does not affect the schedule of auto-rotation if it was done based on time: the next automatic rotation will still occur at the same time for which it was previously scheduled. Naturally, if the auto-rotation was based on size, this will delay it somewhat as it reduces the size of the active log file to zero.
	number-of-files	The number of log files will be kept. If the number of log files ever exceeds this number (either at rotation time, or when this setting is lowered), the system will delete as many files as necessary to bring it down to this number, starting with the oldest.
Default	10 files are kept by default with rotation criteria of 5% of the log partition size	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # logging files rotation criteria size-pct 6 switch (config) # show logging Local logging level: info Override for class mgmt-front: warning Default remote logging level: notice No remote syslog servers configured. Allow receiving of messages from remote hosts: no Number of archived log files to keep: 10 Log rotation size threshold: 6.000% of partition (51.60 megabytes) Log format: standard Subsecond timestamp field: enabled Subsecond timestamp precision: 1 whole digit; 3 fractional digits Levels at which messages are logged: CLI commands: info Audit messages: notice switch (config)</pre>	
Related Commands	<pre>show logging show log files</pre>	
Note		

logging files upload

logging files upload {current | <file-number>} <url>

Uploads a log file to a remote host.

Syntax Description	current	The current log file. The current log file will have the name “messages” if you do not specify a new name for it in the upload URL.
	file-number	An archived log file. The archived log file will have the name “messages<n>.gz” (while “n” is the file number) if you do not specify a new name for it in the upload URL. The file will be compressed with gzip.
	url	Uploads URL path. FTP, TFTP, SCP, and SFTP are supported. For example: scp://username[:password]@hostname/path/file-name.
Default	10 files are kept by default with rotation criteria of 5% of the log partition size	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	switch (config) # logging files uplaod 1 scp://admin@scpserver	
Related Commands	show logging show log files	
Note		

show logging

show logging

Displays the logging configurations.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.0000
Role	admin

Example

```
switch (config) # show logging
Local logging level: info
  Override for class mgmt-front: warning
Default remote logging level: notice
No remote syslog servers configured.
Allow receiving of messages from remote hosts: no
Number of archived log files to keep: 10
Log rotation size threshold: 5.000% of partition (43 megabytes)
Log format: standard
Subsecond timestamp field: enabled
Subsecond timestamp precision: 1 whole digit; 3 fractional digits
Levels at which messages are logged:
  CLI commands: info
  Audit messages: notice
switch (config) #
```

Related Commands

```
logging fields
logging files rotation
logging level
logging local
logging receive
logging <syslog IP address>
```

Note

show log

show log [continues | files [<file-number>] | [[not] matching <reg-exp>]

Displays the log file with optional filter criteria.

Syntax Description	continues	Displays the last few lines of the current log file and then continues to display new lines as they come in until the user hits Ctrl+C, similar to LINUX “tail” utility.
	files	Displays the list of log files.
	<file-number>	Displays an archived log file, where the number may range from 1 up to the number of archived log files available.
	[not] matching <reg-exp>	The file is piped through a LINUX “grep” utility to only include lines either matching, or not matching, the provided regular expression.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.0000	
Role	admin	

Example

```
switch (config) # show log matching INFO
Feb  1 10:57:04 switch clusterd[2659]: [4.193] [clusterd.INFO]: master
browse reply: add service 0x20000 mxyzyz--0002c95ea5d8
_tms_cluster._tcp. local.
Feb  1 10:57:04 switch clusterd[2659]: [4.199] [clusterd.INFO]: master
resolve reply via browse: name mxyzyz--0002c95ea5d8 type
_tms_cluster._tcp. domain local. addr 172.30.2.2 port 60102 ifindex 1
31072
Feb  1 10:57:07 switch SX[2785]: TID 1208106288: [7.746] [hwd.INFO]:
hwd_kernel_interrupt_sim: Entry
Feb  1 10:57:07 switch SX[2785]: TID 1208106288: [7.747] [hwd.INFO]:
hwd_kernel_interrupt_sim: err=0
Feb  1 10:57:07 switch mgmtd[2599]: [7.748] [mgmtd.INFO]: Handling
EVENT request (session 26)
Feb  1 10:57:07 switch mgmtd[2599]: [7.749] [mgmtd.INFO]: EVENT: /sys-
tem/chassis/events/hw-isr-event
Feb  1 10:57:07 switch mgmtd[2599]: [7.750] [mgmtd.INFO]: EVENT: [0]
mask = 0 (uint32)
Feb  1 10:57:07 switch health[2900]: TID 1208104656: [7.751]
[health.INFO]: Received ISR event with mask 0
Feb  1 10:57:07 switch mgmtd[2599]: [7.754] [mgmtd.INFO]: Sending
externally: type event session 36 id 1732128
Feb  1 10:57:07 switch mgmtd[2599]: [7.755] [mgmtd.INFO]: Event sent by
user i:2785-0-0 has been handled
switch (config) #
```

Related Commands

```
logging fields
logging files rotation
logging level
logging local
logging receive
logging <syslog IP address>
show logging
```

Note

2.7 Maintenance Tools

reload

reload [force | halt [noconfirm] | noconfirm]

Reboots or shuts down the system.

Syntax	Description
force	Forces an immediate reboot of the system even if the system is busy.
halt	Shuts down the system.
noconfirm	Reboots the system without asking about unsaved changes.

Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # reload Configuration has been modified; save first? [yes] yes Configuration changes saved. ... switch (config) #</pre>
Related Commands	reset factory
Note	

reset factory

reset factory [keep-all-config | keep-basic | only-config] [halt]

Clears the system and resets it entirely to its factory state.

Syntax Description	keep-all-cofig	Preserves everything in the running configuration file. The user will be prompted for confirmation before honoring this command, unless confirmation is disabled with the command: “no cli default prompt confirm-reset”.
	keep-basic	Preserves licenses in the running configuration file.
	only-config	Resets only configuration.
	halt	The system is halted after this process completes.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # reset factory Type 'YES' to confirm reset: YES Resetting and rebooting the system -- please wait... ...</pre>	
Related Commands	reload	
Note		

2.8 User management and AAA

2.8.1 User accounts

username

username <username> [capability <cap> | disable [login | password] | full-name <name> | nopassword | password [0 | 7] <password>]
no username <username> [capability | disable [login | password] | full-name]

Creates a user and sets its capabilities, password and name.
 The no form of the command deletes the user configuration.

Syntax Description	username	Specifies a username and creates a user account. New users are created initially with admin privileges but is disabled.
	cap	User capabilities: <ul style="list-style-type: none"> • admin - full administrative capabilities • monitor - read only capabilities and actions, can not change the running configuration
	disable [login password]	<ul style="list-style-type: none"> • Disable - disable this account • Disable login - disable all logins to this account • Disable password - disable login to this account using a local password
	name	Full name of the user.
	nopassword	The next login of the user will not require password.
	0 7	<ul style="list-style-type: none"> • 0: specifies a login password in cleartext • 7: specifies a login password in encrypted text
	password	Specifies a password for the user in string form. If [0 7] was not specified then the password is in cleartext.
Default	The following usernames are available by default: <ul style="list-style-type: none"> • admin • monitor • xmladmin • xmluser 	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example	<pre> switch (config) # username monitor full-name smith switch (config) # show usernames USERNAME FULL NAME CAPABILITY ACCOUNT STATUS USERID System Administrator admin Password set admin System Administrator admin Password set monitor smith monitor Password set xmladmin XML Admin User admin No password required xmluser XML Monitor User monitor No password required switch (config) # </pre>
Related Commands	<pre> show usernames show users </pre>
Note	<ul style="list-style-type: none"> • To enable a user account, just set a password on it (or use the "... nopassword" command to enable it with no password required for login) • Removing a user account does not terminate any current sessions that user has open; it just prevents new sessions from being established • Encrypted password is useful for the "show configuration" command, since the cleartext password cannot be recovered after it is set

show usernames

show usernames

Displays list of users and their capabilities.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.0000
Role	admin
Example	<pre> switch (config) # show usernames USERNAME FULL NAME CAPABILITY ACCOUNT STATUS USERID System Administrator admin Password set admin System Administrator admin Password set monitor smith monitor Password set xmladmin XML Admin User admin No password required xmluser XML Monitor User monitor No password required switch (config) # </pre>
Related Commands	<pre> username show users </pre>
Note	

show users

show users [history]

Displays logged in users and related information such as idle time and what host they have connected from.

Syntax Description	history	Displays current and historical sessions.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # show users USERNAME FULL NAME LINE HOST IDLE admin System Administrator pts/0 172.22.237.174 0d0h34m4s admin System Administrator pts/1 172.30.0.127 1d3h30m49s admin System Administrator pts/3 172.22.237.34 0d0h0m0s switch (config) #show users history admin pts/3 172.22.237.34 Wed Feb 1 11:56 still logged in admin pts/3 172.22.237.34 Wed Feb 1 11:42 - 11:46 (00:04) wtm begins Wed Feb 1 11:38:10 2012 switch (config) #</pre>	
Related Commands	username show usernames	
Note		

show whoami

show whoami

Displays username and capabilities of user currently logged in.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show whoami Current user: admin Capabilities: admin switch (config) #</pre>

Related Commands	username show usernames show users
-------------------------	--

Note

2.8.2 AAA methods

aaa accounting

aaa accounting changes default {<time-frame> | stop-only} tacacs+
no aaa accounting changes default {<time-frame> | stop-only} tacacs+

Enables logging of system changes to a AAA accounting server.
The no form of the command disables the accounting.

Syntax Description	stop-only	Sends a stop accounting notice at the end of requested user process.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # aaa accounting changes default stop-only tacacs+ switch (config) # show aaa AAA authorization: Default User: admin Map Order: local-only Authentication method(s): local radius tacacs+ ldap Accounting method(s): tacacs+ switch (config) #</pre>	
Related Commands	show aaa	
Note	<ul style="list-style-type: none"> TACACS+ is presently the only accounting service method supported Change accounting covers both configuration changes and system actions that are visible under audit logging, however this feature operates independently of audit logging, so it is unaffected by the “logging level audit mgmt” or “configuration audit” commands Configured TACACS+ servers are contacted in the order in which they appear in the configuration until one accepts the accounting data, or the server list is exhausted Despite the name of the “stop-only” keyword, which indicates that this feature logs a TACACS+ accounting “stop” message, and in contrast to configuration change accounting, which happens after configuration database changes, system actions are logged when the action is started, not when the action has completed 	

aaa authentication

aaa authentication login default [<auth method> [<auth method> [<auth method> [<auth method> [<auth method>]]]]
no aaa authentication login

Sets a sequence of authentication methods. Up to four methods can be configured. The no form of the command resets the configuration to its default.

Syntax Description	auth-method <ul style="list-style-type: none"> • local • radius • tacacs+ • ldap
Default	local
Modes/Context	Any Command Mode
History	3.1.0000
Role	admin
Example	<pre>switch (config) # aaa authentication login default local radius tacacs+ ldap switch (config) # show aaa AAA authorization: Default User: admin Map Order: local-only Authentication method(s): local radius tacacs+ ldap Accounting method(s): tacacs+ switch (config) #</pre>
Related Commands	show aaa
Note	The order in which the methods are specified is the order in which the authentication is attempted. It is required that “local” is one of the methods selected. It is recommended that “local” be listed first to avoid potential problems logging in to local accounts in the face of network or remote server issues.

aaa authorization

aaa authorization map [default-user <username> | order <policy>]

no aaa authorization map [default-user | order]

Sets the mapping permissions of a user in case a remote authentication is done.
The no form of the command resets the attributes to default.

Syntax Description	username	Specifies what local account the authenticated user will be logged on as when a user is authenticated (via RADIUS or TACACS+) and does not have a local account. If the username is local, this mapping is ignored.
	policy	<p>Sets the user mapping behavior when authenticating users via RADIUS or TACACS+ to one of three choices. The order determines how the remote user mapping behaves. If the authenticated username is valid locally, no mapping is performed. The setting has the following three possible behaviors:</p> <ul style="list-style-type: none"> • remote-first - If a local-user mapping attribute is returned and it is a valid local username, it maps the authenticated user to the local user specified in the attribute. Otherwise, it uses the user specified by the default-user command. • remote-only - Maps a remote authenticated user if the authentication server sends a local-user mapping attribute. If the attribute does not specify a valid local user, no further mapping is tried. • local-only - Maps all remote users to the user specified by the “aaa authorization map default-user <user name>” command. Any vendor attributes received by an authentication server are ignored.
Default	Default user - admin. Map order - remote-first.	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # aaa authorization map default-user admin switch (config) # show aaa AAA authorization: Default User: admin Map Order: remote-first Authentication method(s): local Accounting method(s): tacacs+ switch (config) #</pre>	

Related Commands	show aaa username
Note	If, for example, the user is locally defined to have admin permission, but in a remote server such as RADIUS the user is authenticated as monitor and the order is remote-first, then the user will be given monitor permissions.

show aaa

show aaa

Displays the AAA configuration.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show aaa AAA authorization: Default User: admin Map Order: remote-first Authentication method(s): local Accounting method(s): tacacs+ switch (config) #</pre>
Related Commands	aaa accounting aaa authentication aaa authorization show aaa show usernames username
Note	

2.8.3 RADIUS

radius-server

radius-server {key <secret> | retransmit <retries> | timeout <seconds>}
no radius-server {key | retransmit | timeout}

Sets global RADIUS server attributes.

The no form of the command resets the attributes to their default values.

Syntax Description	secret	Sets a secret key (shared hidden text string), known to the system and to the RADIUS server.
	retries	Number of retries (0-5) before exhausting from the authentication.
	seconds	Timeout in seconds between each retry (1-60).
Default	3 seconds, 1 retry	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) #radius-server retransmit 3 switch (config) # show radius RADIUS defaults: Key: 3333 Timeout: 3 Retransmit: 1 No RADIUS servers configured. switch (config) #</pre>	
Related Commands	aaa authorization radius-server host show radius	
Note	Each RADIUS server can override those global parameters using the command “radius-server host”.	

radius-server host

radius-server host <IP address> {enable | auth-port <port> | key <secret>|
retransmit <retries> | timeout <seconds>}
no radius-server host <IP address> {enable | auth-port }

Configures RADIUS server attributes.

The no form of the command resets the attributes to their default values and deletes the RADIUS server.

Syntax Description	IP address	RADIUS server IP address.
	enable	Administrative enable of the RADIUS server.
	port	RADIUS server UDP port number.
	secret	Sets a secret key (shared hidden text string), known to the system and to the RADIUS server.
	retries	Number of retries (0-5) before exhausting from the authentication.
	seconds	Timeout in seconds between each retry (1-60).
Default	3 seconds, 1 retry Default UDP port is 1812	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # radius-server host 40.40.40.40 switch (config) # show radius RADIUS defaults: Key: 3333 Timeout: 3 Retransmit: 1 RADIUS servers: 40.40.40.40:1812 Enabled: yes Key: 3333 (default) Timeout: 3 (default) Retransmit: 1 (default) switch (config) #</pre>	
Related Commands	<pre>aaa authorization radius-server show radius</pre>	
Note	<ul style="list-style-type: none"> • RADIUS servers are tried in the order they are configured • If you do not specify a parameter for this configured RADIUS server, the configuration will be taken from the global RADIUS server configuration. Refer to “radius-server” command. 	

show radius

show radius

Displays RADIUS configurations.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show radius RADIUS defaults: Key: 3333 Timeout: 3 Retransmit: 1 RADIUS servers: 40.40.40.40:1812 Enabled: yes Key: 3333 (default) Timeout: 3 (default) Retransmit: 1 (default) switch (config) #</pre>
Related Commands	<pre>aaa authorization radius-server radius-server host</pre>
Note	

2.8.4 TACACS+

tacacs-server

tacacs-server {key <secret> | retransmit <retries> | timeout <seconds>}
no tacacs-server {key | retransmit | timeout}

Sets global TACACS+ server attributes.
The no form of the command resets the attributes to default values.

Syntax Description	secret	Set a secret key (shared hidden text string), known to the system and to the TACACS+ server.
	retries	Number of retries (0-5) before exhausting from the authentication.
	seconds	Timeout in seconds between each retry (1-60).
Default	3 seconds, 1 retry	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) #tacacs-server retransmit 3 switch (config) # show tacacs TACACS+ defaults: Key: 3333 Timeout: 3 Retransmit: 1 No TACACS+ servers configured. switch (config) #</pre>	
Related Commands	<pre>aaa authorization show radius show tacacs tacacs-server host</pre>	
Note	Each TACACS+ server can override those global parameters using the command “tacacs-server host”.	

tacacs-server host

tacacs-server host <IP address> {enable | auth-port <port> | auth-type <type> | key <secret> | retransmit <retries> | timeout <seconds>}
no tacacs-server host <IP address> {enable | auth-port}

Configures TACACS+ server attributes.

The no form of the command resets the attributes to their default values and deletes the TACACS+ server.

Syntax Description	IP address	TACACS+ server IP address.
	enable	Administrative enable for the TACACS+ server.
	port	TACACS+ server UDP port number.
	type	Authentication type. Possible values are: <ul style="list-style-type: none"> • ASCII • PAP (Password Authentication Protocol)
	secret	Sets a secret key (shared hidden text string), known to the system and to the TACACS+ server.
	retries	Number of retries (0-5) before exhausting from the authentication.
	seconds	Timeout in seconds between each retry (1-60).
Default	3 seconds, 1 retry Default TCP port is 49 Default auth-type is PAP	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # tacacs-server host 40.40.40.40 switch (config) # show tacacs TACACS+ defaults: Key: 3333 Timeout: 3 Retransmit: 1 TACACS+ servers: 40.40.40.40:49 Enabled: yes Auth-type PAP Key: 3333 (default) Timeout: 3 (default) Retransmit: 1 (default) switch (config) #</pre>	
Related Commands	aaa authorization show tacacs tacacs-server	
Note	<ul style="list-style-type: none"> • TACACS+ servers are tried in the order they are configured • A PAP auth-type similar to an ASCII login, except that the username and password arrive at the network access server in a PAP protocol packet instead of being typed in by the user, so the user is not prompted • If the user does not specify a parameter for this configured TACACS+ server, the configuration will be taken from the global TACACS+ server configuration. Refer to “tacacs-server” command. 	

show tacacs

show tacacs

Displays TACACS+ configurations.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show tacacs TACACS+ defaults: Key: 3333 Timeout: 3 Retransmit: 1 TACACS+ servers: 40.40.40.40:49 Enabled: yes Auth-type PAP Key: 3333 (default) Timeout: 3 (default) Retransmit: 1 (default) switch (config) #</pre>
Related Commands	<pre>aaa authorization tacacs-server tacacs-server host</pre>
Note	

2.8.5 LDAP

ldap base-dn

ldap base-dn <string>

no ldap base-dn

Sets the base distinguished name (location) of the user information in the schema of the LDAP server.

The no form of the command resets the attribute to its default values.

Syntax Description	string	A case-sensitive string that specifies the location in the LDAP hierarchy where the server should begin searching when it receives an authorization request. For example: “ou=users,dc=example,dc=com”, with no spaces. when: ou - Organizational unit dc - Domain component cn - Common name sn - Surname
Default	ou=users,dc=example,dc=com	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # ldap base-dn ou=department,dc=example,dc=com switch (config) # show ldap User base DN : ou=department,dc=example,dc=com User search scope : subtree Login attribute : sAMAccountName Bind DN : Bind password : Group base DN : Group attribute : member LDAP version : 3 Referrals : yes Server port : 389 Search Timeout : 5 Bind Timeout : 5 SSL mode : none Server SSL port : 636 (not active) SSL cert verify : yes LDAP servers: 1: 10.10.10.10 2: 10.10.10.12 switch (config) #</pre>	
Related Commands	show ldap	
Note		

ldap bind-dn/bind-password

ldap {bind-dn | bind-password} <string>
no ldap {bind-dn | bind-password}

Gives the distinguished name or password to bind to on the LDAP server. This can be left empty for anonymous login (the default).

The no form of the command resets the attribute to its default values.

Syntax Description	string	A case-sensitive string that specifies distinguished name or password to bind to on the LDAP server.
Default	""	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # ldap bind-dn my-dn switch (config) # ldap bind-password my-password switch (config) # show ldap User base DN : ou=department,dc=example,dc=com User search scope : subtree Login attribute : sAMAccountName Bind DN : my-dn Bind password : my-password Group base DN : Group attribute : member LDAP version : 3 Referrals : yes Server port : 389 Search Timeout : 5 Bind Timeout : 5 SSL mode : none Server SSL port : 636 (not active) SSL cert verify : yes LDAP servers: 1: 10.10.10.10 2: 10.10.10.12 switch (config) # </pre>	
Related Commands	show ldap	
Note	For anonymous login, bind-dn and bind-password should be empty strings "".	

ldap group-attribute/group-dn

ldap {group-attribute {<group-att> | member | uniqueMember} | group-dn <group-dn>}

no ldap {group-attribute | group-dn}

Sets the distinguished name or attribute name of a group on the LDAP server. The no form of the command resets the attribute to its default values.

Syntax Description	group-att	Specifies a custom attribute name.
	member	groupOfNames or group membership attribute.
	uniqueMember	groupOfUniqueNames membership attribute.
	group-dn	DN of group required for authorization.
Default	group-att: member group-dn: ""	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # ldap group-attribute member switch (config) # ldap group-dn my-group-dn switch (config) # show ldap User base DN : ou=department,dc=example,dc=com User search scope : subtree Login attribute : sAMAccountName Bind DN : my-dn Bind password : my-password Group base DN : my-group-dn Group attribute : member LDAP version : 3 Referrals : yes Server port : 389 Search Timeout : 5 Bind Timeout : 5 SSL mode : none Server SSL port : 636 (not active) SSL cert verify : yes LDAP servers: 1: 10.10.10.10 2: 10.10.10.12 switch (config) # </pre>	
Related Commands	show ldap	
Note	<ul style="list-style-type: none"> The user's distinguished name must be listed as one of the values of this attribute, or the user will not be authorized to log in After login authentication, if the group-dn is set, a user must be a member of this group or the user will not be authorized to log in. If the group is not set ("" - the default) no authorization checks are done. 	

ldap host

ldap host <IP Address> [order <number> last]
no ldap host <IP Address>

Adds an LDAP server to the set of servers used for authentication.
 The no form of the command deletes the LDAP host.

Syntax Description	IP Address	IPv4 or IPv6 address.
	number	The order of the LDAP server.
	last	The LDAP server will be added in the last location.
Default	No hosts configured	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # ldap host 10.10.10.10 switch (config) # show ldap User base DN : ou=department,dc=example,dc=com User search scope : subtree Login attribute : sAMAccountName Bind DN : my-dn Bind password : my-password Group base DN : my-group-dn Group attribute : member LDAP version : 3 Referrals : yes Server port : 389 Search Timeout : 5 Bind Timeout : 5 SSL mode : none Server SSL port : 636 (not active) SSL cert verify : yes LDAP servers: 1: 10.10.10.10 2: 10.10.10.12 switch (config) # </pre>	
Related Commands	<pre> show aaa show ldap </pre>	
Note	<ul style="list-style-type: none"> The system will select the LDAP host to try according to its order New servers are by default added at the end of the list of servers 	

ldap login-attribute

ldap login-attribute {<string> | uid | sAMAccountName}
no ldap login-attribute

Sets the attribute name which contains the login name of the user.
 The no form of the command resets this attribute to its default.

Syntax Description	string	Custom attribute name.
	uid	LDAP login name is taken from the user login user-name.
	sAMAccountName	SAM Account name, active directory login name.
Default	sAMAccountName	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # ldap login-attribute uid switch (config) # show ldap User base DN : ou=department,dc=example,dc=com User search scope : subtree Login attribute : uid Bind DN : my-dn Bind password : my-password Group base DN : my-group-dn Group attribute : member LDAP version : 3 Referrals : yes Server port : 389 Search Timeout : 5 Bind Timeout : 5 SSL mode : none Server SSL port : 636 (not active) SSL cert verify : yes LDAP servers: 1: 10.10.10.10 2: 10.10.10.12 switch (config) # </pre>	
Related Commands	<pre> show aaa show ldap </pre>	
Note		

ldap port

ldap port <port>
no ldap port

Sets the TCP port on the LDAP server to connect to for authentication.
 The no form of the command resets this attribute to its default value.

Syntax Description	port	TCP port number.
Default	389	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # ldap port 1111 switch (config) # show ldap User base DN : ou=department,dc=example,dc=com User search scope : subtree Login attribute : uid Bind DN : my-dn Bind password : my-password Group base DN : my-group-dn Group attribute : member LDAP version : 3 Referrals : yes Server port : 1111 Search Timeout : 5 Bind Timeout : 5 SSL mode : none Server SSL port : 636 (not active) SSL cert verify : yes LDAP servers: 1: 10.10.10.10 2: 10.10.10.12 switch (config) # </pre>	
Related Commands	<pre> show aaa show ldap </pre>	
Note		

ldap referrals

ldap referrals no ldap referrals

Enables LDAP referrals.
The no form of the command disables LDAP referrals.

Syntax Description	N/A
Default	LDAP referrals are enabled
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre> switch (config) # no ldap referrals switch (config) # show ldap User base DN : ou=department,dc=example,dc=com User search scope : subtree Login attribute : uid Bind DN : my-dn Bind password : my-password Group base DN : my-group-dn Group attribute : member LDAP version : 3 Referrals : no Server port : 1111 Search Timeout : 5 Bind Timeout : 5 SSL mode : none Server SSL port : 636 (not active) SSL cert verify : yes LDAP servers: 1: 10.10.10.10 2: 10.10.10.12 switch (config) # </pre>
Related Commands	<pre> show aaa show ldap </pre>
Note	Referral is the process by which an LDAP server, instead of returning a result, will return a referral (a reference) to another LDAP server which may contain further information.

ldap scope

ldap scope <scope>

no ldap scope

Specifies the extent of the search in the LDAP hierarchy that the server should make when it receives an authorization request.

The no form of the command resets the attribute to its default value.

Syntax Description	scope <ul style="list-style-type: none"> • one-level - searches the immediate children of the base dn • subtree - searches at the base DN and all its children
Default	subtree
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre> switch (config) # ldap scope subtree switch (config) # show ldap User base DN : ou=department,dc=example,dc=com User search scope : subtree Login attribute : uid Bind DN : my-dn Bind password : my-password Group base DN : my-group-dn Group attribute : member LDAP version : 3 Referrals : no Server port : 1111 Search Timeout : 5 Bind Timeout : 5 SSL mode : none Server SSL port : 636 (not active) SSL cert verify : yes LDAP servers: 1: 10.10.10.10 2: 10.10.10.12 switch (config) # </pre>
Related Commands	show aaa show ldap
Note	

ldap ssl

ldap ssl {cert-verify | mode <mode>| port <port-number>}

no ldap ssl {cert-verify | mode | port}

Sets SSL parameter for LDAP.

The no form of the command resets the attribute to its default value.

Syntax Description	cert-verify	Enables verification of SSL/TLS server certificates. This may be required if the server's certificate is self-signed, or does not match the name of the server.
	mode	Sets the security mode for connections to the LDAP server. <ul style="list-style-type: none"> • none - requests no encryption for the LDAP connection • ssl - the SSL-port configuration is used, an SSL connection is made before LDAP requests are sent (LDAP over SSL) • tls - the normal LDAP port is used, an LDAP connection is initiated, and then TLS is started on this existing connection
	port-number	Sets the port on the LDAP server to connect to for authentication when the SSL security mode is enabled (LDAP over SSL).
Default	cert-verify is enabled mode is none (LDAP SSL is not activated) port-number is 636	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # ldap ssl mode ssl switch (config) # show ldap User base DN : ou=department,dc=example,dc=com User search scope : subtree Login attribute : uid Bind DN : my-dn Bind password : my-password Group base DN : my-group-dn Group attribute : member LDAP version : 3 Referrals : no Server port : 1111 Search Timeout : 5 Bind Timeout : 5 SSL mode : ssl Server SSL port : 636 SSL cert verify : yes LDAP servers: 1: 10.10.10.10 2: 10.10.10.12 switch (config) #</pre>	

Related Commands	show aaa show ldap
Note	<ul style="list-style-type: none"> • If available, the TLS mode is recommended, as it is standardized, and may also be of higher security • The port number is used only for SSL mode. In case the mode is TLS, the LDAP port number will be used.

ldap timeout

ldap {timeout-bind | timeout-search} <seconds>
no ldap {timeout-bind | timeout-search}

Sets a global communication timeout in seconds for all LDAP servers to specify the extent of the search in the LDAP hierarchy that the server should make when it receives an authorization request.

The no form of the command resets the attribute to its default value.

Syntax Description	timeout-bind	Sets the global LDAP bind timeout for all LDAP servers.
	timeout-search	Sets the global LDAP search timeout for all LDAP servers.
	seconds	1-60 seconds.
Default	5 seconds	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # ldap timeout-bind 10 switch (config) # show ldap User base DN : ou=department,dc=example,dc=com User search scope : subtree Login attribute : uid Bind DN : my-dn Bind password : my-password Group base DN : my-group-dn Group attribute : member LDAP version : 3 Referrals : no Server port : 1111 Search Timeout : 5 Bind Timeout : 10 SSL mode : none Server SSL port : 636 (not active) SSL cert verify : yes LDAP servers: 1: 10.10.10.10 2: 10.10.10.12 switch (config) # </pre>	

Related Commands	show aaa show ldap
-------------------------	-----------------------

Note

ldap version

ldap version <version>
no ldap version

Sets the LDAP version.
 The no form of the command resets the attribute to its default value.

Syntax Description	version	Sets the LDAP version. Possible values are 2 and 3.
Default	3	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # ldap version 3 switch (config) # show ldap User base DN : ou=department,dc=example,dc=com User search scope : subtree Login attribute : uid Bind DN : my-dn Bind password : my-password Group base DN : my-group-dn Group attribute : member LDAP version : 3 Referrals : no Server port : 1111 Search Timeout : 5 Bind Timeout : 10 SSL mode : none Server SSL port : 636 (not active) SSL cert verify : yes LDAP servers: 1: 10.10.10.10 2: 10.10.10.12 switch (config) #</pre>	

Related Commands	show aaa show ldap
-------------------------	-----------------------

Note

show ldap

show ldap

Displays LDAP configurations.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.0000
Role	admin
Example	<pre> switch (config) # show ldap User base DN : ou=department,dc=example,dc=com User search scope : subtree Login attribute : uid Bind DN : my-dn Bind password : my-password Group base DN : my-group-dn Group attribute : member LDAP version : 3 Referrals : no Server port : 1111 Search Timeout : 5 Bind Timeout : 10 SSL mode : none Server SSL port : 636 (not active) SSL cert verify : yes LDAP servers: 1: 10.10.10.10 2: 10.10.10.12 switch (config) # </pre>
Related Commands	<pre> show aaa show ldap </pre>
Note	

2.9 CLI Session

This chapter displays all the relevant commands used to manage CLI session terminal.

cli clear-history

cli clear-history

Clears the command history of the current user.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	switch (config) # cli clear-history switch (config) #
Related Commands	N/A
Note	

cli default

cli default {auto-logout <minutes> | paging enable | prefix-modes {enable | show-config} | progress enable | prompt {confirm-reload | confirm-reset | confirm-unsaved | empty-password}

no cli default {auto-logout | paging enable | prefix-modes {enable | show-config} | progress enable prompt {confirm-reload | confirm-reset | confirm-unsaved | empty-password}

Configures default CLI options for all future sessions.

The no form of the command deletes or disables the default CLI options.

Syntax Description	minutes	Configures keyboard inactivity timeout for automatic logout. Range is 0-35791 minutes. Setting the value to 0 or using the no form of the command disables the auto-logout.
	paging enable	Enables text viewing one screen at a time.
	prefix-modes {enable show-config}	Configures the prefix modes feature of CLI. <ul style="list-style-type: none"> “prefix-modes enable” enables prefix modes for current and all future sessions “prefix-modes show-config” uses prefix modes in “show configuration” output for current and all future sessions
	progress enable	Enables progress updates.
	prompt confirm-reload	Prompts for confirmation before rebooting.
	prompt confirm-reset	Prompts for confirmation before resetting to factory state.
	prompt confirm-unsaved	Confirms whether or not to save unsaved changes before rebooting.
	prompt empty-password	Prompts for a password if none is specified in a pseudo-URL for SCP.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # cli default prefix-modes enable switch (config) # show cli CLI current session settings: Maximum line size: 8192 Terminal width: 171 columns Terminal length: 38 rows Terminal type: xterm X display setting: (none) Auto-logout: disabled Paging: enabled Progress tracking: enabled Prefix modes: disabled CLI defaults for future sessions: Auto-logout: disabled Paging: enabled Progress tracking: enabled Prefix modes: enabled (and use in 'show configuration') Settings for both this session and future ones: Show hidden config: yes Confirm losing changes: yes Confirm reboot/shutdown: no Confirm factory reset: yes Prompt on empty password: yes switch (config) # </pre>	

Related Commands	show cli
-------------------------	----------

Note

cli session

cli session {auto-logout <minutes> | paging enable | prefix-modes {enable | show-config} | progress enable | terminal {length <size> | resize | type <terminal-type> | width} | x-display full <display>}
no cli session {auto-logout | paging enable | prefix-modes {enable | show-config} | progress enable | terminal type | x-display}

Configures default CLI options for all future sessions.
The no form of the command deletes or disables the CLI sessions.

Syntax Description		
	minutes	Configures keyboard inactivity timeout for automatic logout. Range is 0-35791 minutes. Setting the value to 0 or using the no form of the command disables the auto logout.
	paging enable	Enables text viewing one screen at a time.
	prefix-modes enable show-config	Configures the prefix modes feature of CLI. <ul style="list-style-type: none"> “prefix-modes enable” enables prefix modes for current and all future sessions “prefix-modes show-config” uses prefix modes in “show configuration” output for current and all future sessions
	progress enable	Enables progress updates.
	terminal length	Sets the number of lines for the current terminal. Valid range is 5-999.
	terminal resize	Resizes the CLI terminal settings (to match the actual terminal window).
	terminal-type	Sets the terminal type. Valid options are: <ul style="list-style-type: none"> ansi console dumb linux unknown vt52 vt100 vt102 vt220 vt320 xterm
	terminal width	Sets the width of the terminal in characters. Valid range is 34-999.
	x-display full <display>	Specifies the display as a raw string, e.g localhost:0.0.

Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	switch (config) # cli session auto-logout switch (config) #
Related Commands	show terminal
Note	

show cli

show cli

Displays the CLI configuration and status.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre> switch (config) # show cli CLI current session settings: Maximum line size: 8192 Terminal width: 171 columns Terminal length: 38 rows Terminal type: xterm X display setting: (none) Auto-logout: disabled Paging: enabled Progress tracking: enabled Prefix modes: disabled CLI defaults for future sessions: Auto-logout: disabled Paging: enabled Progress tracking: enabled Prefix modes: enabled (and use in 'show configuration') Settings for both this session and future ones: Show hidden config: yes Confirm losing changes: yes Confirm reboot/shutdown: no Confirm factory reset: yes Prompt on empty password: yes switch (config) # </pre>

Related Commands	cli default
-------------------------	-------------

Note

2.10 Banner

banner login

banner login <string>
no banner login

Sets the CLI welcome banner message.
 The no form of the command resets the system login banner to its default.

Syntax Description	string	Text string.
Default	“Mellanox MLNX-OS Switch Management”	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # banner login example switch (config) # show banner Banners: MOTD: Mellanox Switch Login: example switch (config) #</pre>	
Related Commands	show banner	
Note		

banner motd

banner motd <string>
no banner motd

Sets the contents of the /etc/motd file.
 The no form of the command resets the system Message of the Day banner.

Syntax Description	string	Text string.
---------------------------	--------	--------------

Default	“Mellanox Switch”
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # banner motd Testing switch (config) # show banner Banners: MOTD: Testing Login: Mellanox MLNX-OS Switch Management switch (config) #</pre>
Related Commands	show banner
Note	If more then one word is used (there is a space) quotation marks should be added (i.e. "xxxx xxxx").

show banner

show banner

Displays configured banners.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	unpriv/monitor/admin
Example	<pre>switch (config) # show banner Banners: MOTD: Testing Login: Mellanox MLNX-OS Switch Management switch (config) #</pre>
Related Commands	banner login banner motd
Note	

2.11 SSH

ssh server enable

	ssh server enable no ssh server enable
	Enables the SSH server. The no form of the command disables the SSH server.
Syntax Description	N/A
Default	SSH server is enabled
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre> switch (config) # ssh server enable switch (config) # show ssh server SSH server configuration: SSH server enabled: yes Minimum protocol version: 2 X11 forwarding enabled: no SSH server ports: 22 Interface listen enabled: yes No Listen Interfaces. Host Key Finger Prints: RSA v1 host key: a0:63:db:96:e2:95:5a:5a:fd:a8:d0:f4:ab:e3:5f:f8 RSA v2 host key: 1e:b7:8b:ec:ab:35:98:be:6b:d6:12:c2:18:72:12:d6 DSA v2 host key: 7c:4a:f7:72:51:67:b5:0b:cd:a2:d2:b9:f3:be:3e:68 switch (config) # </pre>
Related Commands	show ssh server
Note	Disabling SSH server does not terminate existing SSH sessions, it only prevents new ones from being established.

ssh server host-key

ssh server host-key {<key type> {private-key <private-key>| public-key <public-key>} | generate}

Manipulates host keys for SSH.

Syntax Description	key type	<ul style="list-style-type: none"> • rsa1 - RSAv1 • rsa2 - RSAv2 • dsa2 - DSAv2
	private-key	Sets new private-key for the host keys of the specified type.
	public-key	Sets new public-key for the host keys of the specified type.
	generate	Generates new RSA and DSA host keys for SSH.
Default	SSH keys are locally generated	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # ssh server host-key dsa2 private-key Key: ***** Confirm: ***** switch (config) # show ssh server host-keys SSH server configuration: SSH server enabled: yes Minimum protocol version: 2 X11 forwarding enabled: no SSH server ports: 22 Interface listen enabled: yes No Listen Interfaces. Host Key Finger Prints: RSA v1 host key: a0:63:db:96:e2:95:5a:5a:fd:a8:d0:f4:ab:e3:5f:f8 RSA v2 host key: 1e:b7:8b:ec:ab:35:98:be:6b:d6:12:c2:18:72:12:d6 DSA v2 host key: 7c:4a:f7:72:51:67:b5:0b:cd:a2:d2:b9:f3:be:3e:68 Host Keys: RSA v1 host key: "switch-5ea5d8 1024 35 12457497995374010105491416867919987976776882016984375942831915584962796 99375406596085804272219042450456598705866658144854493132172365068789517 13570509420864336951833046700451354269467758379288848962624165330724512 16091899983038691571036219385577978596282214644533444813712105628654158 3022982220576029771297093" RSA v2 host key: "switch-5ea5d8 ssh-rsa AAAAB3NzaC1yc2EAAAABIwAAAIEArB9i5OnukAHNUOkwpCmEl0m88kJgBzL22+F5tfaSn+S OpVYxrceZeyuzXsoZlVtFTk2Fydwy0YvMS0Kcv2PuCrPZV/ GYd3lQEnn22rEmrlPrKCrMl1XlUy6DFlr3OgwWmlbaobmDlG/gSziWz/ gc4Jgqf2CyXFq4pzaR1jarlVk=" DSA v2 host key: "switch-5ea5d8 ssh-dss AAAAB3NzaC1kc3MAAACBAMeJ3S+nyaHhRbwv3tJqlWttDC35RZVC5iG4ZEvMMHp28VL94Oc yyuGh39VCdM9pEvaI7hzZrsgHrNqakb/YLD/ 7anGH3wpl9Fx8lfe0RH3bloJzG+mJ6R5momdoPCrKwEKiKABKE00jLzlVznpP0IHxjwF+Tb R3dK5HwVzQYw/ bAAAAFQCBODPqBZZa+2KylKlzUsbZ2pKhgQAAAIAJK+StiQdtORw1B5UCMzTrTef5L07DSf VreMEYtTRnBBtgVSNqQFWpSQIYbVDHQr9T6qCM4VO39DuHUGQ1TMDIX7t+9mfbB87YyUu5a /ndbf3GhNhXHWwbzlr9hgLL7FSHA7DYH7bVOZRLqxH64eQKGZqy1ps/ F4E31lyn7GC4EQAAAIA/2osHipXf+NRjplgfmHROVvf/mGE9Vzc9/ AMUxlJJn5VhvEJ5CZW9cI+LxMOJoJhOj3YW3B1czGxRObDA9vUbKXTNc8bkgoUrxysAH1rH N0PqJgeT4L009AItSp3mlmxHqdS7jixfTvtOTEKWXrgpczlmTB8+zjhUah/YuuB12H g==" switch (config) # </pre>	

Related Commands	show ssh server
-------------------------	-----------------

Note

ssh server listen

ssh server listen {enable | interface <inf>}
no ssh server listen {enable | interface <inf>}

Enables the listen interface restricted list for SSH. If enabled, and at least one non-DHCP interface is specified in the list, the SSH connections are only accepted on those specified interfaces.

The no form of the command disables the listen interface restricted list for SSH. When disabled, SSH connections are not accepted on any interface.

Syntax Description	enable	Enables SSH interface restrictions on access to this system.
	interface <inf>	Adds interface to SSH server access restriction list. Possible interfaces are “lo”, and “mgmt0”.
Default	SSH listen is enabled	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # ssh server listen enable switch (config) # show ssh server SSH server configuration: SSH server enabled: yes Minimum protocol version: 2 X11 forwarding enabled: no SSH server ports: 22 Interface listen enabled: yes No Listen Interfaces. Host Key Finger Prints: RSA v1 host key: a0:63:db:96:e2:95:5a:5a:fd:a8:d0:f4:ab:e3:5f:f8 RSA v2 host key: 1e:b7:8b:ec:ab:35:98:be:6b:d6:12:c2:18:72:12:d6 DSA v2 host key: 7c:4a:f7:72:51:67:b5:0b:cd:a2:d2:b9:f3:be:3e:68 switch (config) #</pre>	

Related Commands	show ssh server
-------------------------	-----------------

Note

ssh server min-version

ssh server min-version <version>

no ssh server min-version

Sets the minimum version of the SSH protocol that the server supports.
The no form of the command resets the minimum version of SSH protocol supported.

Syntax Description	version	Possible versions are 1 and 2.
Default	2	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # ssh server min-version 2 switch (config) # show ssh server SSH server configuration: SSH server enabled: yes Minimum protocol version: 2 X11 forwarding enabled: no SSH server ports: 22 Interface listen enabled: yes No Listen Interfaces. Host Key Finger Prints: RSA v1 host key: a0:63:db:96:e2:95:5a:5a:fd:a8:d0:f4:ab:e3:5f:f8 RSA v2 host key: 1e:b7:8b:ec:ab:35:98:be:6b:d6:12:c2:18:72:12:d6 DSA v2 host key: 7c:4a:f7:72:51:67:b5:0b:cd:a2:d2:b9:f3:be:3e:68 switch (config) #</pre>	
Related Commands	show ssh server	
Note		

ssh server ports

ssh server ports {<port1> [<port2>...]}

Specifies which ports the SSH server listens on.

Syntax Description	port	Port number in [1...65535].
Default	22.	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```

switch (config) # ssh server ports 22
switch (config) # show ssh server
SSH server configuration:
  SSH server enabled:      yes
  Minimum protocol version: 2
  X11 forwarding enabled:  no
  SSH server ports:       22

  Interface listen enabled: yes
  No Listen Interfaces.

Host Key Finger Prints:
  RSA v1 host key: a0:63:db:96:e2:95:5a:5a:fd:a8:d0:f4:ab:e3:5f:f8
  RSA v2 host key: 1e:b7:8b:ec:ab:35:98:be:6b:d6:12:c2:18:72:12:d6
  DSA v2 host key: 7c:4a:f7:72:51:67:b5:0b:cd:a2:d2:b9:f3:be:3e:68
switch (config) #

```

Related Commands

```
show ssh server
```

Note

- Multiple ports can be specified by repeating the <port> parameter
- The command will remove any previous ports if not listed in the command

ssh server x11-forwarding

ssh server x11-forwarding enable
no ssh server x11-forwarding enable

Enables X11 forwarding on the SSH server.
 The no form of the command disables X11 forwarding.

Syntax Description	N/A
Default	X11-forwarding is disabled.
Modes/Context	Config
History	3.1.0000
Role	admin

Example

```

switch (config) # ssh server x11-forwarding enable
switch (config) # show ssh server
SSH server configuration:
  SSH server enabled:      yes
  Minimum protocol version: 2
  X11 forwarding enabled:  yes
  SSH server ports:       22

  Interface listen enabled: yes
  No Listen Interfaces.

Host Key Finger Prints:
  RSA v1 host key: a0:63:db:96:e2:95:5a:5a:fd:a8:d0:f4:ab:e3:5f:f8
  RSA v2 host key: 1e:b7:8b:ec:ab:35:98:be:6b:d6:12:c2:18:72:12:d6
  DSA v2 host key: 7c:4a:f7:72:51:67:b5:0b:cd:a2:d2:b9:f3:be:3e:68
switch (config) #

```


Related Commands	N/A
-------------------------	-----

Note

ssh client global

ssh client global {host-key-check <policy>} | known-host <known-host-entry>}
no ssh client global {host-key-check | known-host localhost}

Configures global SSH client settings.
 The no form of the command negates global SSH client settings.

Syntax Description	host-key-check <policy>	Sets SSH client configuration to control how host key checking is performed. This parameter may be set in 3 ways. <ul style="list-style-type: none"> • If set to “no” it always permits connection, and accepts any new or changed host keys without checking • If set to “ask” it prompts user to accept new host keys, but does not permit a connection if there was already a known host entry that does not match the one presented by the host • If set to “yes” it only permits connection if a matching host key is already in the known hosts file
	known-host	Adds an entry to the global known-hosts configuration file.
	known-host-entry	Adds/removes an entry to/from the global known-hosts configuration file. The entry consist of “<IP> <key-type> <key>”.
Default	host-key-check - ask, no keys are configured by default	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```

switch (config) # ssh client global host-key-check no
switch (config) # ssh client global known-host "72.30.2.2 ssh-rsa
AAAAB3NzaC1yc2EAAAABIwAAAIEArB9i5OnukAHNUOkwpCmEl0m88kJgBzL22+F5tfaSn+S
0pVYxrceZeyuzXsoZ1VtFTk2FydwY0YvMS0Kcv2PuCrPZV/
GYd3lQEnn22rEmrlPrKCrMl1XlUy6DFlr3OgwWmlbaobmDlG/gSziWz/
gc4Jgqf2CyXFq4pzaR1jarlVk="

switch (config) # show ssh client
SSH client Strict Hostkey Checking: ask

SSH Global Known Hosts:
  Entry 1: 72.30.2.2
           Finger Print: 1e:b7:8b:ec:ab:35:98:be:6b:d6:12:c2:18:72:12:d6

No SSH user identities configured.

No SSH authorized keys configured.

switch (config) #

```

Related Commands

```
show ssh client
```

Note**ssh client user**

```

ssh client user <username> {authorized-key sshv2 <public key> | identity <key
type> {generate | private-key [<private key>] | public-key [<public key>}} |
known-host <known host> remove}
no ssh client user admin {authorized-key sshv2 <public key ID> | identity <key
type>}

```

Adds an entry to the global known-hosts configuration file, either by generating new key, or by adding manually a public or private key.
The no form of the command removes a public key from the specified user's authorized key list, or changes the key type.

Syntax Description	username	The specified user must be a valid account on the system. Possible values for this parameter are “admin”, “monitor”, “xmladmin”, and “xmluser”.
	authorized-key sshv2 <public key>	Adds the specified key to the list of authorized SSHv2 RSA or DSA public keys for this user account. These keys can be used to log into the user's account.
	identity <key type>	Sets certain SSH client identity settings for a user, dsa2 or rsa2.
	generate	Generates SSH client identity keys for specified user.
	private-key	Sets private key SSH client identity settings for the user.
	public-key	Sets public key SSH client identity settings for the user.
	known-host <known host> remove	Removes host from user's known host file.
Default	No keys are created by default	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # ssh client user admin known-host 172.30.1.116 remove switch (config) #</pre>	
Related Commands	show ssh client	
Note	If a key is being pasted from a cut buffer and was displayed with a paging program, it is likely that newline characters have been inserted, even if the output was not long enough to require paging. One can specify “no cli session paging enable” before running the “show” command to prevent the newlines from being inserted.	

slogin

slogin [<slogin options>] <hostname>

Invokes the SSH client. The user is returned to the CLI when SSH finishes.

Syntax Description	slogin options	usage: slogin [-1246AaCfGkNnqsTtVvXxY] [-b bind_address] [-c cipher_spec] [-D port] [-e escape_char] [-F configfile] [-i identity_file] [-L port:host:hostport] [-l login_name] [-m mac_spec] [-o option] [-p port] [-R port:host:hostport] [user@]host-name [command]
Default	N/A	
Modes/Context	Config	

History	3.1.0000
Role	monitor/admin
Example	<pre>switch (config) # slogin 192.168.10.70 The authenticity of host '192.168.10.70 (192.168.10.70)' can't be estab- lished. RSA key fingerprint is 2e:ad:2d:23:45:4e:47:e0:2c:ae:8c:34:f0:1a:88:cb. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added '192.168.10.70' (RSA) to the list of known hosts. Mellanox MLNX-OS Switch Management Last login: Sat Feb 28 22:55:17 2009 from 10.208.0.121 Mellanox Switch switch (config) #</pre>
Related Commands	N/A
Note	

show ssh client

show ssh client

Displays the client configuration of the SSH server.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show ssh client SSH client Strict Hostkey Checking: ask SSH Global Known Hosts: Entry 1: 72.30.2.2 Finger Print: 1e:b7:8b:ec:ab:35:98:be:6b:d6:12:c2:18:72:12:d6 No SSH user identities configured. No SSH authorized keys configured. switch (config) #</pre>
Related Commands	N/A
Note	

show ssh server

show ssh server

Displays SSH server configuration.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show ssh server SSH server configuration: SSH server enabled: yes Minimum protocol version: 2 X11 forwarding enabled: no SSH server ports: 22 Interface listen enabled: yes No Listen Interfaces. Host Key Finger Prints: RSA v1 host key: a0:63:db:96:e2:95:5a:5a:fd:a8:d0:f4:ab:e3:5f:f8 RSA v2 host key: 1e:b7:8b:ec:ab:35:98:be:6b:d6:12:c2:18:72:12:d6 DSA v2 host key: 7c:4a:f7:72:51:67:b5:0b:cd:a2:d2:b9:f3:be:3e:68 switch (config) #</pre>
Related Commands	ssh server
Note	

2.12 Remote Login

telnet-server enable

telnet-server enable no telnet-server enable

Enables the telnet server.
The no form of the command disables the telnet server.

Syntax Description	N/A
Default	Telnet server is disabled
Modes/Context	Config

History	3.1.0000
Role	admin
Example	switch (config) # telnet-server enable switch (config) # show telnet-server Telnet server enabled: yes
Related Commands	show telnet-server
Note	

show telnet-server

	show telnet-server
	Displays telnet server settings.
Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	switch (config) # show telnet-server Telnet server enabled: yes switch (config) #
Related Commands	telnet-server enable
Note	

2.13 XML Gateway

xml-gw enable

	xml-gw enable no xml-gw enable
	Enables the XML gateway. The no form of the command disables the XML gateway.
Syntax Description	N/A

Default	XML Gateway is enabled
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # xml-gw enable switch (config) # show xml-gw XML Gateway enabled: yes switch (config) #</pre>
Related Commands	show xml-gw
Note	

show xml-gw

show xml-gw

Displays the XML gateway setting.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show xml-gw XML Gateway enabled: yes switch (config) #</pre>
Related Commands	xml-gw enable
Note	

2.14 Web Server

web auto-logout

web auto-logout <number of minutes>
no web auto-logout <number of minutes>

Configures length of user inactivity before auto-logout of a web session.
 The no form of the command disables the web auto-logout (web sessions will never logged out due to inactivity).

Syntax Description	number of minutes	The length of user inactivity in minutes. 0 will disable the inactivity timer (same as a “no web auto-logout” command).
Default	60 minutes	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # web auto-logout 60 switch (config) # show web Web-based management console enabled: yes HTTP enabled: yes HTTP port: 80 HTTP redirect to HTTPS: no HTTPS enabled: yes HTTPS port: 443 Listen enabled: yes No Listen Interfaces. Inactivity timeout: 1 hr Session timeout: 2 hr 30 min Session renewal: 30 min Web proxy enabled: yes Proxy address: 10.10.10.10 Proxy port: 1080 Authentication type: basic Basic auth username: web-user Basic auth password: web-password switch (config) #</pre>	
Related Commands	show web	
Note	The no form of the command does not automatically log users out due to inactivity.	

web enable

web enable
no web enable

Enables the web-based management console.
 The no form of the command disables the web-based management console.

Syntax Description	N/A
Default	enable
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre> switch (config) # web enable switch (config) # show web Web-based management console enabled: yes HTTP enabled: yes HTTP port: 80 HTTP redirect to HTTPS: no HTTPS enabled: yes HTTPS port: 443 Listen enabled: yes No Listen Interfaces. Inactivity timeout: 1 hr Session timeout: 2 hr 30 min Session renewal: 30 min Web proxy enabled: yes Proxy address: 10.10.10.10 Proxy port: 1080 Authentication type: basic Basic auth username: web-user Basic auth password: web-password switch (config) # </pre>
Related Commands	show web
Note	

web http

web http {enable | port <port number> | redirect}

no web http {enable | port | redirect}

Configures HTTP access to the web-based management console.

The no form of the command negates HTTP settings for the web-based management console.

Syntax Description	enable	Enables HTTP access to the web-based management console.
	port number	Sets a port for HTTP access.
	redirect	Enables redirection to HTTPS. If HTTP access is enabled, this specifies whether a redirect from the HTTP port to the HTTPS port should be issued to mandate secure HTTPS access.
Default	HTTP is enabled HTTP TCP port is 80 HTTP redirect to HTTPS is disabled	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # web http enable switch (config) # show web Web-based management console enabled: yes HTTP enabled: yes HTTP port: 80 HTTP redirect to HTTPS: no HTTPS enabled: yes HTTPS port: 443 Listen enabled: yes No Listen Interfaces. Inactivity timeout: 1 hr Session timeout: 2 hr 30 min Session renewal: 30 min Web proxy enabled: yes Proxy address: 10.10.10.10 Proxy port: 1080 Authentication type: basic Basic auth username: web-user Basic auth password: web-password switch (config) # </pre>	

Related Commands	show web web enable
Note	Enabling HTTP is meaningful if the WebUI as a whole is enabled.

web httpd

web httpd listen {enable | interface <ifName> }
no web httpd listen {enable | interface <ifName> }

Enables the listen interface restricted list for HTTP and HTTPS.
The no form of the command disables the HTTP server listen ability.

Syntax Description	enable	Enables Web interface restrictions on access to this system.
	interface <ifName>	Adds interface to Web server access restriction list (i.e. mgmt0, mgmt1)
Default	Listening is enabled. all interfaces are permitted.	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # web httpd enable switch (config) # show web Web-based management console enabled: yes HTTP enabled: yes HTTP port: 80 HTTP redirect to HTTPS: no HTTPS enabled: yes HTTPS port: 443 Listen enabled: yes No Listen Interfaces. Inactivity timeout: 1 hr Session timeout: 2 hr 30 min Session renewal: 30 min Web proxy enabled: yes Proxy address: 10.10.10.10 Proxy port: 1080 Authentication type: basic Basic auth username: web-user Basic auth password: web-password switch (config) #</pre>	

Related Commands	N/A
Note	If enabled, and if at least one of the interfaces listed is eligible to be a listen interface, then HTTP/HTTPS requests will only be accepted on those interfaces. Otherwise, HTTP/HTTPS requests are accepted on any interface.

web https

web https {certificate regenerate | enable | port <port number>}
no web https {enable | port <port number>}

Configures HTTPS access to the web-based management console.
The no form of the command negates HTTPS settings for the web-based management console.

Syntax Description	certificate regenerate	Re-generates certificate to use for HTTPS connections.
	enable	Enables HTTPS access to the web-based management console.
	port	Sets a TCP port for HTTPS access.
Default	HTTPS is enabled Default port is 443	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # web https enable switch (config) # show web Web-based management console enabled: yes HTTP enabled: yes HTTP port: 80 HTTP redirect to HTTPS: no HTTPS enabled: yes HTTPS port: 443 Listen enabled: yes No Listen Interfaces. Inactivity timeout: 1 hr Session timeout: 2 hr 30 min Session renewal: 30 min Web proxy enabled: yes Proxy address: 10.10.10.10 Proxy port: 1080 Authentication type: basic Basic auth username: web-user Basic auth password: web-password switch (config) # </pre>	

Related Commands	show web web enable
Note	Enabling HTTPS is meaningful if the WebUI as a whole is enabled.

web session

web session {renewal <minutes> | timeout <minutes>}
no web session {renewal | timeout}

Configures session settings.
The no form of the command resets session settings to default.

Syntax Description	renewal <minutes>	Configures time before expiration to renew a session.
	timeout <minutes>	Configures time after which a session expires.
Default	timeout - 2.5 hours renewal - 30 min	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # web session renewal 60 switch (config) # show web Web-based management console enabled: yes HTTP enabled: yes HTTP port: 80 HTTP redirect to HTTPS: no HTTPS enabled: yes HTTPS port: 443 Listen enabled: yes No Listen Interfaces. Inactivity timeout: 1 hr Session timeout: 2 hr 30 min Session renewal: 60 min Web proxy enabled: yes Proxy address: 10.10.10.10 Proxy port: 1080 Authentication type: basic Basic auth username: web-user Basic auth password: web-password switch (config) #</pre>	
Related Commands	N/A	
Note		

web proxy auth

web proxy auth {authtype <type>| basic [password <password> | username <username>]}

no web proxy auth {authtype | basic {password | username } }

Configures authentication settings for web proxy authentication.
The no form of the command resets the attributes to their default values.

Syntax Description	type	Configures the type of authentication to use with web proxy. The possible values are: <ul style="list-style-type: none"> • basic - HTTP basic authentication • none - No authentication
	basic	Configures HTTP basic authentication settings for proxy.
	password	A password used for HTTP basic authentication with the web proxy.
	username	A username used for HTTP basic authentication with the web proxy.
Default	Web proxy is disabled.	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # web proxy auth authtype basic switch (config) # web proxy auth basic username web-user switch (config) # web proxy auth basic password web-password switch (config) # show web Web-based management console enabled: yes HTTP enabled: yes HTTP port: 80 HTTP redirect to HTTPS: no HTTPS enabled: yes HTTPS port: 443 Listen enabled: yes No Listen Interfaces. Inactivity timeout: 1 hr Session timeout: 2 hr 30 min Session renewal: 30 min Web proxy enabled: yes Proxy address: 10.10.10.11 Proxy port: 40 Authentication type: basic Basic auth username: web-user Basic auth password: web-password switch (config) # </pre>	

Related Commands	show web web proxy host
-------------------------	----------------------------

Note

web proxy host

web proxy host <IP address> [port <port number>]
no web proxy

Adds and enables a proxy to be used for any HTTP or FTP downloads.
 The no form of the command disables the web proxy.

Syntax Description	IP address	IPv4 or IPv6 address.
	port number	Sets the web proxy default port.
Default	1080	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # web proxy host 10.10.10.10 port 1080 switch (config) # show web Web-based management console enabled: yes HTTP enabled: yes HTTP port: 80 HTTP redirect to HTTPS: no HTTPS enabled: yes HTTPS port: 443 Listen enabled: yes No Listen Interfaces. Inactivity timeout: 1 hr Session timeout: 2 hr 30 min Session renewal: 30 min Web proxy enabled: yes Proxy address: 10.10.10.10 Proxy port: 1080 Authentication type: basic Basic auth username: web-user Basic auth password: web-password switch (config) #</pre>	
Related Commands	web proxy auth	
Note		

show web

show web

Displays the web configuration.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show web Web-based management console enabled: yes HTTP enabled: yes HTTP port: 80 HTTP redirect to HTTPS: no HTTPS enabled: yes HTTPS port: 443 Listen enabled: yes No Listen Interfaces. Inactivity timeout: 1 hr Session timeout: 2 hr 30 min Session renewal: 30 min Web proxy enabled: yes Proxy address: 10.10.10.10 Proxy port: 1080 Authentication type: basic Basic auth username: web-user Basic auth password: web-password switch (config) #</pre>
Related Commands	<pre>show web web proxy auth</pre>
Note	

2.15 SNMP

The commands in this section are used to manage the SNMP server.

snmp-server community

snmp-server community <community> [ro | rw]

no snmp-server community <community>

Sets a community name for either read-only or read-write SNMP requests.
The no form of the command sets the community string to default.

Syntax Description	community	Community name.
	ro	Sets the read-only community string.
	rw	Sets the read-write community string.
Default	Read-only community: "public" Read-write community: ""	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch(config) # snmp-server community private rw switch (config) # show snmp SNMP enabled: yes SNMP port: 161 System contact: System location: Read-only community: public Read-write community: private Interface listen enabled: yes No Listen Interfaces. Traps enabled: yes Default trap community: public Default trap port: 162 No trap sinks configured. switch(config) # </pre>	
Related Commands	show snmp	
Note	<ul style="list-style-type: none"> If neither the "ro" or the "rw" parameters are specified, the read-only community is set as the default community If the read-only community is specified, only queries can be performed If the read-write community is specified, both queries and sets can be performed 	

snmp-server contact

snmp-server contact <contact name>
no snmp-server contact

Sets a value for the sysContact variable in MIB-II.
 The no form of the command resets the parameter to its default value.

Syntax Description	contact name	Contact name.
Default	""	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # snmp-server contact my-name switch (config) # show snmp SNMP enabled: yes SNMP port: 161 System contact: my-name System location: Read-only community: public Read-write community: private Interface listen enabled: yes No Listen Interfaces. Traps enabled: yes Default trap community: public Default trap port: 162 No trap sinks configured. switch (config) #</pre>	
Related Commands	show snmp	
Note		

snmp-server enable

snmp-server enable [communities | mult-communities | traps]
no snmp-server enable [communities | mult-communities | traps]

Enables SNMP-related functionality.
 The no form of the command disables the SNMP server.

Syntax Description	enable	Enables SNMP-related functionality: <ul style="list-style-type: none"> • SNMP engine • SNMP traps
	communities	Enables community-based authentication on this system.
	mult-communities	Enables multiple communities to be configured.
	traps	Enables sending of SNMP traps from this system.
Default	SNMP is enabled by default SNMP server communities are enabled by default SNMP traps are enabled by default SNMP server multi-communities are disabled by default	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # snmp-server enable switch (config) # show snmp SNMP enabled: yes SNMP port: 161 System contact: my-name System location: Read-only community: public Read-write community: private Interface listen enabled: yes No Listen Interfaces. Traps enabled: yes Default trap community: public Default trap port: 162 No trap sinks configured. switch (config) # </pre>	
Related Commands	show snmp	
Note	SNMP traps are only sent if there are trap sinks configured with the “snmp-server host...” command, and if these trap sinks are themselves enabled.	

snmp-server host

snmp-server host <IP address> {disable | traps [<community> | <port> | version <snmp version>]}

no snmp-server host <IPv4 or IPv6 address> {disable | traps [<community> | <port>]}

Configures hosts to which to send SNMP traps.

The no form of the commands removes a host from which SNMP traps should be sent.

Syntax Description	IP address	IPv4 or IPv6 address.
	disable	Temporarily disables sending of traps to this host.
	community	Specifies trap community string.
	port	Overrides default UDP port for this trap sink.
	snmp version	Specifies the SNMP version of traps to send to this host.
Default	No hosts are configured Default community is “public” Default UDP port is 162 Default SNMP version is 2c	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```

switch (config) # snmp-server host 10.10.10.10 traps version 1
switch (config) # show snmp
SNMP enabled:          yes
SNMP port:             161
System contact:
System location:

Read-only communities:
    public

Read-write communities:
    (none)

Interface listen enabled: yes
No Listen Interfaces.

Traps enabled:          yes
Default trap community: public
Default trap port:      162

Trap sinks:
    10.10.10.10
        Enabled: yes
        Type: traps version 1
        Port: 162 (default)
        Community: public (default)
switch (config) #

```

Related Commands

```

show snmp
snmp-server enable

```

Note

This setting is only meaningful if traps are enabled, though the list of hosts may still be edited if traps are disabled. Refer to “snmp-server enable” command.

snmp-server listen

```

snmp-server listen {enable | interface <ifName>}
no snmp-server listen {enable | interface <ifName> }

```

Configures SNMP server interface access restrictions.
The no form of the command disables the listen interface restricted list for SNMP server.

Syntax Description	enable	Enables SNMP interface restrictions on access to this system.
	ifName	Adds an interface to the “listen” list for SNMP server. For example: “mgmt0”, “mgmt1”.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```

switch (config) # snmp listen enable
switch (config) # show snmp
SNMP enabled:          yes
SNMP port:             161
System contact:
System location:
Read-only community:   public
Read-write community:  private

Interface listen enabled: yes
No Listen Interfaces.

Traps enabled:          yes
Default trap community: public
Default trap port:      162

Trap sinks:
  10.10.10.10
    Enabled: yes
    Type: traps version 1
    Port: 3
    Community: public (default)
switch (config) #

```

Related Commands

```
show snmp
```

Note

If enabled, and if at least one of the interfaces listed is eligible to be a listen interface, then SNMP requests will only be accepted on those interfaces. Otherwise, SNMP requests are accepted on any interface.

snmp-server location

snmp-server location <system location>

no snmp-server location

Sets a value for the sysLocation variable in MIB-II.

The no form of the command clears the contents of the sysLocation variable.

Syntax Description	system location	String.
Default	""	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```

switch (config) # snmp-server location lab
switch (config) # show snmp
SNMP enabled:          yes
SNMP port:             161
System contact:        my-name
System location:       lab
Read-only community:   public
Read-write community:  private

Interface listen enabled: yes
No Listen Interfaces.

Traps enabled:         yes
Default trap community: public
Default trap port:     162

No trap sinks configured.
switch (config) #

```

Related Commands

```
show snmp
```

Note**snmp-server port**

```
snmp-server port <port>
```

```
no snmp-server port
```

Sets the UDP listening port for the SNMP agent.

The no form of the command resets the parameter to its default value.

Syntax Description	port	UDP port.
Default	161	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```

switch (config) # snmp-server port 1000
switch (config) # show snmp
SNMP enabled:          yes
SNMP port:             1000
System contact:        my-name
System location:       lab
Read-only community:   public
Read-write community:  private

Interface listen enabled: yes
No Listen Interfaces.

Traps enabled:          yes
Default trap community: public
Default trap port:      162

No trap sinks configured.
switch (config) #

```

Related Commands

```
show snmp
```

Note**snmp-server traps**

```

snmp-server traps {community <community> | event <event name> | port
<port> | send-test}
no snmp-server traps {community | event <event name> | port}

```

Configures hosts to which to send SNMP traps.
The no form of the commands removes a host from which SNMP traps should be sent.

Syntax Description	community	Sets the default community for traps sent to hosts which do not have a custom community string set.
	event	Specifies which events will be sent as traps.
	port	Sets the default port to which traps are sent.
	send-test	Sends a test trap.
Default	Community: public All traps are enabled Port: 162	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```

switch (config) # snmp-server community public
switch (config) # show snmp
SNMP enabled:          yes
SNMP port:             1000
System contact:        my-name
System location:       lab
Read-only community:   public
Read-write community:  private

Interface listen enabled: yes
No Listen Interfaces.

Traps enabled:         yes
Default trap community: public
Default trap port:     162

No trap sinks configured.
switch (config) #

```

Related Commands

```

show snmp
show snmp events

```

Note

- This setting is only meaningful if traps are enabled, though the list of hosts may still be edited if traps are disabled
- Refer to Mellanox MIB file for the list of supported traps

snmp-server user

```

snmp-server user {admin | <username> } v3 {[encrypted] auth <hash-type>
<password> [priv <privacy-type> [<password>]] | capability <cap> | enable
<sets> | prompt auth <hash-type> [priv <privacy-type>]}
no snmp-server user {admin | <username> } v3 {[encrypted] auth <hash-type>
<password> [priv <privacy-type> [<password>]] | capability <cap> | enable
<sets> | prompt auth <hash-type> [priv <privacy-type>]}

```

Specifies an existing username, or a new one to be added.
The no form of the command disables access via SNMP v3 for the specified user.

Syntax Description	v3	Configures SNMP v3 users.
	auth	Configures SNMP v3 security parameters, specifying passwords in plaintext on the command line (note: passwords are always stored encrypted).
	capability	Sets capability level for SET requests.
	enable	Enables SNMP v3 access for this user.
	encrypted	Configures SNMP v3 security parameters, specifying passwords in encrypted form.
	prompt	Configures SNMP v3 security parameters, specifying passwords securely in follow-up prompts, rather than on the command line.

Default	No SNMP v3 users defined
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # snmp-server user admin v3 enable switch (config) # show snmp user User name: admin Enabled overall: yes Authentication type: sha Privacy type: aes-128 Authentication password: (NOT SET; user disabled) Privacy password: (NOT SET; user disabled) SET access: Enabled: yes Capability level: admin switch (config) #</pre>
Related Commands	show snmp user
Note	

show snmp

show snmp [engineID | events | user]

Displays SNMP-server configuration and status.

Syntax Description	engineID	SNMP Engine ID.
	events	SNMP events.
	user	SNMP users.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```
switch (config) # show snmp
SNMP enabled:      yes
SNMP port:         161
System contact:
System location:
Read-only community: public
Read-write community: private

Interface listen enabled: yes
No Listen Interfaces.

Traps enabled:      yes
Default trap community: public
Default trap port:  162

No trap sinks configured.
switch(config) #
```

Related Commands

```
show snmp
```

Note

2.16 Scheduled Jobs

Use the commands in this section to manage and schedule the execution of jobs.

job

```
job <job ID>
no job <job ID>
```

Creates a job.
The no form of the command deletes the job.

Syntax Description	job ID	An integer.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # job 100 switch (config job 100) #</pre>	
Related Commands	show jobs	
Note	Job state is lost on reboot.	

command

command <sequence #> | <command>
no command <sequence #>

Adds a CLI command to the job.
 The no form of the command deletes the command from the job.

Syntax Description	sequence #	An integer that controls the order the command is executed relative to other commands in this job. The commands are executed in an ascending order.
	command	A CLI command.
Default	N/A	
Modes/Context	Config job	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config)# job 100 switch (config job 100) # command 10 "show power" switch (config job 100) #</pre>	
Related Commands	show jobs	
Note	<ul style="list-style-type: none"> The command must be defined with inverted commas (“”) The command must be added as it was executed from the “config” mode. For example, in order to change the interface description you need to add the command: “interface <type> <number> description my-description”. 	

comment

comment <comment>
no comment

Adds a comment to the job.
 The no form of the command deletes the comment.

Syntax Description	comment	The comment to be added (string).
Default	“”	
Modes/Context	Config job	
History	3.1.0000	
Role	admin	

Example	<pre>switch (config)# job 100 switch (config job 100) # comment Job_for_example switch (config job 100) #</pre>
Related Commands	show jobs
Note	

enable

	enable no enable
	<p>Enables the specified job.</p> <p>The no form of the command disables the specified job.</p>
Syntax Description	N/A
Default	N/A
Modes/Context	Config job
History	3.1.0000
Role	admin
Example	<pre>switch (config)# job 100 switch (config job 100) # enable switch (config job 100) #</pre>
Related Commands	show jobs
Note	If a job is disabled, it will not be executed automatically according to its schedule; nor can it be executed manually.

execute

	execute
	<p>Forces an immediate execution of the job.</p>
Syntax Description	N/A
Default	N/A
Modes/Context	Config job
History	3.1.0000
Role	admin

Example	<pre>switch (config)# job 100 switch (config job 100) # execute switch (config job 100) #</pre>
Related Commands	show jobs
Note	<ul style="list-style-type: none"> • The job timer (if set) is not canceled and the job state is not changed: i.e. the time of the next automatic execution is not affected • The job will not be run if not currently enabled

fail-continue

fail-continue
no fail-continue

Continues the job execution regardless of any job failures.
The no form of the command returns fail-continue to its default.

Syntax Description	N/A
Default	A job will halt execution as soon as any of its commands fails
Modes/Context	Config job
History	3.1.0000
Role	admin
Example	<pre>switch (config)# job 100 switch (config job 100) # fail-continue switch (config job 100) #</pre>
Related Commands	show jobs
Note	

name

name <job name>
no name

Configures a name for this job.
The no form of the command resets the name to its default.

Syntax Description	name	Specifies a name for the job (string).
Default	""	
Modes/Context	Config job	
History	3.1.0000	

Role	admin
Example	<pre>switch (config)# job 100 switch (config job 100) # name my-job switch (config job 100) #</pre>
Related Commands	show jobs
Note	

schedule type

schedule type <recurrence type>
no schedule type

Sets the type of schedule the job will automatically execute on.
The no form of the command resets the schedule type to its default.

Syntax Description	recurrence type	<p>The available schedule types are:</p> <ul style="list-style-type: none"> • daily - the job is executed every day at a specified time • weekly - the job is executed on a weekly basis • monthly - the job is executed every month on a specified day of the month • once - the job is executed once at a single specified date and time • periodic - the job is executed on a specified fixed time interval, starting from a fixed point in time.
Default	once	
Modes/Context	Config job	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config)# job 100 switch (config job 100) # schedule type once switch (config job 100) #</pre>	
Related Commands	show jobs	
Note	A schedule type is essentially a structure for specifying one or more future dates and times for a job to execute.	

schedule <recurrence type>

schedule <recurrence type> <interval and date>

no schedule

Sets the type of schedule the job will automatically execute on.
The no form of the command resets the schedule type to its default.

Syntax Description	recurrence type	<p>The available schedule types are:</p> <ul style="list-style-type: none"> • daily - the job is executed every day at a specified time • weekly - the job is executed on a weekly basis • monthly - the job is executed every month on a specified day of the month • once - the job is executed once at a single specified date and time • periodic - the job is executed on a specified fixed time interval, starting from a fixed point in time.
	interval and date	Interval and date, per recurrence type.
Default	once	
Modes/Context	Config job	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config)# job 100 switch (config job 100) # schedule monthly interval 10 switch (config job 100) #</pre>	
Related Commands	show jobs	
Note	A schedule type is essentially a structure for specifying one or more future dates and times for a job to execute.	

show jobs

show jobs [<job-id>]

Displays configuration and state (including results of last execution, if any exist) of all jobs, or of one job if a job ID is specified.

Syntax Description	job-id	Job ID.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```

switch (config) # show jobs 10
Job 10:
  Status:                inactive
  Enabled:                yes
  Continue on failure:   no
  Schedule Type:         once
  Time and date:          1970/01/01 00:00:00 +0000
  Last Exec Time:        Thu 2012/04/05 13:11:42 +0000
  Next Exec Time:        N/A
  Commands:
    Command 10: show power
  Last Output:
=====
Module           Status
=====
PS1              OK
PS2              NOT PRESENT

switch (config) #

```

Related Commands

```
show jobs
```

Note

2.17 Event Notification

email autosupport

email autosupport {enable | event <event name>}
no email autosupport enable

Enables the support of the email notification and specifies which events will be sent as email notifications.
 The no form of the command disables sending of email notifications globally or per event.

Syntax Description	enable	Enables the sending of email to vendor autosupport when certain failures occur.
	event <event name>	Specifies events for which to send autosupport notification emails.
Default	Email autosupport is disabled	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # email autosupport enable switch (config) # </pre>	

Related Commands	show email
Note	Refer to “show email event” command for full event list.

email dead-letter

email dead-letter {cleanup max-age <duration> | enable}
no email dead-letter

Configures settings for saving undeliverable emails.
The no form of the command disables sending of emails to vendor auto-support upon certain failures.

Syntax Description	duration	Example: “5d4h3m2s” for 5 days, 4 hours, 3 minutes, 2 seconds.
	enable	Saves dead-letter files for undeliverable emails.
Default	Save dead letter is enabled The default duration is 14 days	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	switch (config) # email dead-letter enable switch (config) #	
Related Commands	show email	
Note		

email domain

email domain <hostname or IP address>
no email domain

Sets the domain name from which the emails will appear to come from (provided that the return address is not already fully-qualified). This is used in conjunction with the system hostname to form the full name of the host from which the email appears to come.
The no form of the command clears email domain override.

Syntax Description	hostname or IP address	IP address.
Default	No email domain	

Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # email domain mellanox switch (config) # show email Mail hub: 10.0.8.11 Mail hub port: 125 Domain: mellanox Return address: do-not-reply Include hostname in return address: yes ... switch (config) #</pre>
Related Commands	show emails
Note	

email mailhub

email mailhub <hostname or IP address>

no email mailhub

Sets the mail relay to be used to send notification emails.

The no form of the command clears the mail relay to be used to send notification emails.

Syntax Description	hostname or IP address	Hostname or IP address.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # email mailhub 10.0.8.11 switch (config) # show email Mail hub: 10.0.8.11 Mail hub port: 25 Domain: (not specified) Return address: do-not-reply Include hostname in return address: yes ... switch (config) #</pre>	
Related Commands	show email [events]	
Note		

email mailhub-port

email mailhub-port <hostname or IP address>

no email mailhub-port

Sets the mail relay port to be used to send notification emails.
The no form of the command resets the port to its default.

Syntax Description	hostname or IP address	hostname or IP address.
Default	25	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # email mailhub-port 125 switch (config) # show email Mail hub: 10.0.8.11 Mail hub port: 125 Domain: (system domain name) Return address: do-not-reply Include hostname in return address: yes ... switch (config) #</pre>	
Related Commands	show email	
Note		

email notify event

email notify event <event name>

no email notify event <event name>

Enables sending email notifications for the specified event type.
The no form of the command disables sending email notifications for the specified event type.

Syntax Description	event name	Example event names would include “process-crash” and “cpu-util-high”.
Default	No events are enabled	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```

switch (config) # email notify event process-crash
switch (config) # show email events
Failure events for which emails will be sent:
process-crash: A process in the system has crashed
unexpected-shutdown: Unexpected system shutdown

Informational events for which emails will be sent:
liveness-failure: A process in the system was detected as hung
process-exit: A process in the system unexpectedly exited
cpu-util-ok: CPU utilization has fallen back to normal levels
cpu-util-high: CPU utilization has risen too high
disk-io-ok: Disk I/O per second has fallen back to acceptable levels
...
temperature-too-high: Temperature has risen too high

All events for which autosupport emails will be sent:
process-crash: A process in the system has crashed
liveness-failure: A process in the system was detected as hung
switch (config) #
switch (config) #

```

Related Commands

show email

Note

This does not affect auto-support emails. Auto-support can be disabled overall, but if it is enabled, all auto-support events are sent as emails.

email notify recipient

email notify recipient <email addr> [class {info | failure} | detail]

no email notify recipient <email addr> [class {info | failure} | detail]

Adds an email address from the list of addresses to which to send email notifications of events.

The no form of the command removes an email address from the list of addresses to which to send email notifications of events.

Syntax Description	email addr	Email address of intended recipient.
	class	Specifies which types of events are sent to this recipient.
	info	Sends informational events to this recipient.
	failure	Sends failure events to this recipient.
	detail	Sends detailed event emails to this recipient.
Default	No recipients are added	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```
switch (config) # email notify recipient user2@autosupport.mellanox.com
switch (config) # show email
Mail hub:
Mail hub port: 25
Domain: (not specified)
Return address: user1
Include hostname in return address: no
Dead letter settings:
Save dead.letter files: yes
Dead letter max age: (none)
Email notification recipients:
user2@autosupport.mellanox.com (all events, in detail)
Autosupport emails
Enabled: no
Recipient: autosupport@autosupport.mellanox.com
Mail hub: autosupport.mellanox.com
switch (config) #
```

Related Commands

show email

Note

email return-addr

email return-addr <username>
no email domain

Sets the username or fully-qualified return address from which email notifications are sent.

- If the string provided contains an “@” character, it is considered to be fully-qualified and used as-is.
- Otherwise, it is considered to be just the username, and we append “@<host-name>.<domain>”. The default is “do-not-reply”, but this can be changed to “admin” or whatnot in case something along the line does not like fictitious addresses.

The no form of the command resets this attribute to its default.

Syntax Description	username	Username.
Default	do-not-reply	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # email return-addr user1 switch (config) # show email Mail hub: Mail hub port: 25 Domain: (not specified) Return address: user1 Include hostname in return address: yes ... switch (config) #</pre>	

Related Commands	show email
-------------------------	------------

Note	
-------------	--

email return-host

email return-host
no email return-host

Includes the hostname in the return address for emails.
 The no form of the command does not include the hostname in the return address for emails.

Syntax Description	N/A
Default	No return host
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # no email return-host switch (config) # show email Mail hub: Mail hub port: 25 Domain: (system domain name) Return address: my-address Include hostname in return address: no Current reply address: host@localdomain Dead letter settings: Save dead.letter files: yes Dead letter max age: 5 days No recipients configured. Autosupport emails Enabled: no Recipient: autosupport@autosupport.mellanox.com Mail hub: autosupport.mellanox.com switch (config) #</pre>
Related Commands	show email
Note	This only takes effect if the return address does not contain an “@” character.

email send-test

email send-test

Sends test-email to all configured event and failure recipients.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	switch (config) # email autosupport enable switch (config) #
Related Commands	show email [events]
Note	

show email

show email [events]

Shows email configuration or events for which email should be sent upon.

Syntax Description	events	show event list
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.0000	
Role	admin	

Example

```

switch (config) # show email
Mail hub:
Mail hub port:    25
Domain:          (system domain name)
Return address:  my-address
Include hostname in return address: no

Current reply address: host@localdomain

Dead letter settings:
  Save dead.letter files: yes
  Dead letter max age:    5 days

No recipients configured.

Autosupport emails
  Enabled:    no
  Recipient:  autosupport@autosupport.mellanox.com
  Mail hub:   autosupport.mellanox.com
switch (config) #

```

Related Commands

show email

Note

2.18 Statistics and Alarms

stats alarm <alarm-id> clear

stats alarm <alarm ID> clear

Clears alarm state.

Syntax Description	alarm ID	Alarms supported by the system, for example: <ul style="list-style-type: none"> cpu_util_indiv - Average CPU utilization too high: percent utilization disk_io - Operating System Disk I/O per second too high: kilobytes per second fs_mnt - Free filesystem space too low: percent of disk space free intf_util - Network utilization too high: bytes per second memory_pct_used - Too much memory in use: percent of physical memory used paging - Paging activity too high: page faults temperature - Temperature is too high: degrees
Default	N/A	
Modes/Context	Config	
History	3.1.0000	

Role	admin
Example	switch (config) # stats alarm cpu_util_indiv clear switch (config) #
Related Commands	show stats alarm
Note	

stats alarm <alarm-id> enable

stats alarm <alarm-id> enable
no stats alarm <alarm-id> enable

Enables the alarm.
The no form of the command disables the alarm, notifications will not be received.

Syntax Description	alarm ID	Alarms supported by the system, for example: <ul style="list-style-type: none"> • cpu_util_indiv - Average CPU utilization too high: percent utilization • disk_io - Operating System Disk I/O per second too high: kilobytes per second • fs_mnt - Free filesystem space too low: percent of disk space free • intf_util - Network utilization too high: bytes per second • memory_pct_used - Too much memory in use: percent of physical memory used • paging - Paging activity too high: page faults • temperature - Temperature is too high: degrees
Default	The default is different per alarm-id	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	switch (config) # stats alarm cpu_util_indiv enable switch (config) #	
Related Commands	show stats alarm	
Note		

stats alarm <alarm-id> event-repeat

stats alarm <alarm ID> event-repeat {single | while-not-cleared}

no stats alarm <alarm ID> event-repeat

Configures repetition of events from this alarm.

Syntax Description	alarm ID	Alarms supported by the system, for example: <ul style="list-style-type: none"> • cpu_util_indiv - Average CPU utilization too high: percent utilization • disk_io - Operating System Disk I/O per second too high: kilobytes per second • fs_mnt - Free filesystem space too low: percent of disk space free • intf_util - Network utilization too high: bytes per second • memory_pct_used - Too much memory in use: percent of physical memory used • paging - Paging activity too high: page faults • temperature - Temperature is too high: degrees
	single	Does not repeat events: only sends one event whenever the alarm changes state.
	while-not-cleared	Repeats error events until the alarm clears.
Default	single	
Modes/Context	Config	
History	3.1.0000	
Role	monitor/admin	
Example	<pre>switch (config) # stats alarm cpu_util_indiv event-repeat single switch (config) #</pre>	
Related Commands	show stats alarm	
Note		

stats alarm <alarm-id> {rising | falling}

stats alarm <alarm ID> {rising | falling} {clear-threshold | error-threshold} <threshold-value>

Configure alarms thresholds.

Syntax Description	alarm ID	Alarms supported by the system, for example: <ul style="list-style-type: none"> cpu_util_indiv - Average CPU utilization too high: percent utilization disk_io - Operating System Disk I/O per second too high: kilobytes per second fs_mnt - Free filesystem space too low: percent of disk space free intf_util - Network utilization too high: bytes per second memory_pct_used - Too much memory in use: percent of physical memory used paging - Paging activity too high: page faults temperature - Temperature is too high: degrees
	falling	Configures alarm for when the statistic falls too low.
	rising	Configures alarm for when the statistic rises too high.
	error-threshold	Sets threshold to trigger falling or rising alarm.
	clear-threshold	Sets threshold to clear falling or rising alarm.
	threshold-value	The desired threshold value, different per alarm.
Default	Default is different per alarm-id	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # stats alarm cpu_util_indiv falling clear-threshold 10 switch (config) #</pre>	
Related Commands	show stats alarm	
Note	Not all alarms support all four thresholds.	

stats alarm <alarm-id> rate-limit

stats alarm <alarm ID> rate-limit {count <count-type> <count> | reset | window <window-type> <duration>}

Configures alarms rate limit.

Syntax Description	alarm ID	Alarms supported by the system, for example: <ul style="list-style-type: none"> • cpu_util_indiv - Average CPU utilization too high: percent utilization • disk_io - Operating System Disk I/O per second too high: kilobytes per second • fs_mnt - Free filesystem space too low: percent of disk space free • intf_util - Network utilization too high: bytes per second • memory_pct_used - Too much memory in use: percent of physical memory used • paging - Paging activity too high: page faults • temperature - Temperature is too high: degrees
	count-type	Long medium, or short count (number of alarms).
	reset	Set the count and window durations to default values for this alarm.
	window-type	Long medium, or short count, in seconds.
Default	Short window: 5 alarms in 1 hour Medium window: 20 alarms in 1 day Long window: 50 alarms in 7 days	
Modes/Context	Config	
History	3.1.0000	
Role	monitor/admin	
Example	<pre>switch (config) # stats alarm paging rate-limit window long 2000 switch (config) #</pre>	
Related Commands	show stats alarm	
Note		

stats chd <chd-id> clear

stats chd <CHD ID> clear

Clears CHD counters.

Syntax Description	CHD ID	CHD supported by the system, for example: <ul style="list-style-type: none"> • cpu_util - CPU utilization: percentage of time spent • cpu_util_ave - CPU utilization average: percentage of time spent • cpu_util_day - CPU utilization average: percentage of time spent • disk_device_io_hour - Storage device I/O read/write statistics for the last hour: bytes • disk_io - Operating system aggregate disk I/O average: KB/sec • eth_day • eth_hour • fs_mnt_day - Filesystem system usage average: bytes • fs_mnt_month - Filesystem system usage average: bytes • fs_mnt_week - Filesystem system usage average: bytes • ib_day • ib_hour • intf_day - Network interface statistics aggregation: bytes • intf_hour - Network interface statistics (same as “interface” sample) • intf_util - Aggregate network utilization across all interfaces • memory_day - Average physical memory usage: bytes • memory_pct - Average physical memory usage • paging - Paging activity: page faults • paging_day - Paging activity: page faults
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # stats chd memory_day clear switch (config) #</pre>	
Related Commands	show stats chd	
Note		

stats chd <chd-id> enable

stats chd <chd-id> enable
no stats chd <chd-id> enable

Enables the CHD.
 The no form of the command disables the CHD.

Syntax Description	chd-id	<p>CHD supported by the system, for example:</p> <ul style="list-style-type: none"> • cpu_util - CPU utilization: percentage of time spent • cpu_util_ave - CPU utilization average: percentage of time spent • cpu_util_day - CPU utilization average: percentage of time spent • disk_device_io_hour - Storage device I/O read/write statistics for the last hour: bytes • disk_io - Operating system aggregate disk I/O average: KB/sec • eth_day • eth_hour • fs_mnt_day - Filesystem system usage average: bytes • fs_mnt_month - Filesystem system usage average: bytes • fs_mnt_week - Filesystem system usage average: bytes • ib_day • ib_hour • intf_day - Network interface statistics aggregation: bytes • intf_hour - Network interface statistics (same as “interface” sample) • intf_util - Aggregate network utilization across all interfaces • memory_day - Average physical memory usage: bytes • memory_pct - Average physical memory usage • paging - Paging activity: page faults • paging_day - Paging activity: page faults
Default	Enabled	
Modes/Context	Config	
History	3.1.0000	
Role	monitor/admin	
Example	<pre>switch (config) # stats chd memory_day enable switch (config) #</pre>	
Related Commands	show stats chd	
Note		

stats chd <chd-id> compute time

stats chd <CHD ID> compute time {interval | range} <number of seconds>

Sets parameters for when this CHD is computed.

Syntax Description	CHD ID	Possible IDs:
		<ul style="list-style-type: none"> • cpu_util - CPU utilization: percentage of time spent • cpu_util_ave - CPU utilization average: percentage of time spent • cpu_util_day - CPU utilization average: percentage of time spent • disk_device_io_hour - Storage device I/O read/write statistics for the last hour: bytes • disk_io - Operating system aggregate disk I/O average: KB/sec • eth_day • eth_hour • fs_mnt_day - Filesystem system usage average: bytes • fs_mnt_month - Filesystem system usage average: bytes • fs_mnt_week - Filesystem system usage average: bytes • ib_day • ib_hour • intf_day - Network interface statistics aggregation: bytes • intf_hour - Network interface statistics (same as “interface” sample) • intf_util - Aggregate network utilization across all interfaces • memory_day - Average physical memory usage: bytes • memory_pct - Average physical memory usage • paging - Paging activity: page faults • paging_day - Paging activity: page faults
	interval	Specifies calculation interval (how often to do a new calculation) in number of seconds.
	range	Specifies calculation range, in number of seconds.
	number of seconds	Number of seconds.
Default	Different per CHD	
Modes/Context	Config	
History	3.1.0000	
Role	monitor/admin	
Example	<pre>switch (config) # stats chd memory_day compute time interval 120 switch (config) # show stats chd memory_day CHD "memory_day" (Average physical memory usage: bytes): Source dataset: sample "memory" Computation basis: time Interval: 120 second(s) Range: 1800 second(s) switch (config) #</pre>	

Related Commands	show stats chd
-------------------------	----------------

Note

stats sample <sample-id> clear

stats sample <sample ID> clear

Clears sample history.

Syntax Description	sample ID	Possible sample IDs are: <ul style="list-style-type: none"> • congested • cpu_util - CPU utilization: milliseconds of time spent • disk_device_io - Storage device I/O statistics • disk_io - Operating system aggregate disk I/O: KB/sec • eth • fan - Fan speed • fs_mnt_bytes - Filesystem usage: bytes • fs_mnt_inodes - Filesystem usage: inodes • ib • interface - Network interface statistics • intf_util - Network interface utilization: bytes • memory - System memory utilization: bytes • paging - Paging activity: page faults • power - Power supply usage • power-consumption • temperature - Modules temperature
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # stats sample temperature clear switch (config) #</pre>	
Related Commands	show stats sample	
Note		

stats sample <sample-id> enable

stats sample <sample-id> enable
no stats sample <sample-id> enable

Enables the sample.
 The no form of the command disables the sample.

Syntax Description	sample-id	Possible sample IDs are: <ul style="list-style-type: none"> • congested • cpu_util - CPU utilization: milliseconds of time spent • disk_device_io - Storage device I/O statistics • disk_io - Operating system aggregate disk I/O: KB/sec • eth • fan - Fan speed • fs_mnt_bytes - Filesystem usage: bytes • fs_mnt_inodes - Filesystem usage: inodes • ib • interface - Network interface statistics • intf_util - Network interface utilization: bytes • memory - System memory utilization: bytes • paging - Paging activity: page faults • power - Power supply usage • power-consumption • temperature - Modules temperature
Default	Enabled	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # stats sample temperature enable switch (config) #</pre>	
Related Commands	show stats sample	
Note		

stats sample <sample-id> interval

stats sample <sample ID> interval <number of seconds>

Sets the amount of time between samples for the specified group of sample data.

Syntax Description	sample ID	Possible sample IDs are: <ul style="list-style-type: none"> • congested • cpu_util - CPU utilization: milliseconds of time spent • disk_device_io - Storage device I/O statistics • disk_io - Operating system aggregate disk I/O: KB/sec • eth • fan - Fan speed • fs_mnt_bytes - Filesystem usage: bytes • fs_mnt_inodes - Filesystem usage: inodes • ib • interface - Network interface statistics • intf_util - Network interface utilization: bytes • memory - System memory utilization: bytes • paging - Paging activity: page faults • power - Power supply usage • power-consumption • temperature - Modules temperature
	number of seconds	Interval in seconds.
Default	Different per sample	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # stats sample temperature interval 1 switch (config) # show stats sample temperature Sample "temperature" (Modules temperature): Enabled: yes Sampling interval: 1 second switch (config) #</pre>	
Related Commands	show stats sample	
Note		

stats clear-all

stats clear all

Clears data for all samples, CHDs, and status for all alarms.

Syntax Description	N/A
---------------------------	-----

Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	switch (config) # stats clear-all switch (config) #
Related Commands	N/A
Note	

stats export

stats export <format> <report name> [{after | before} <yyyy/mm/dd>
<hh:mm:ss>] [filename <filename>]

Exports statistics to a file.

Syntax Description	format	Currently the only supported value for <format> is “csv” (comma-separated value).
	report name	Determines dataset to be exported. Possible report names are: <ul style="list-style-type: none"> memory - Memory utilization paging - Paging I/O cpu_util - CPU utilization
	after before	Only includes stats collected after or before a specific time.
	yyyy/mm/dd	Date: It must be between 1970/01/01 and 2038/01/19.
	hh:mm:ss	Time: It must be between 00:00:00 and 03:14:07 UTC and is treated as local time.
	filename	Specifies filename to give new report. If a filename is specified, the stats will be exported to a file of that name; otherwise a name will be chosen automatically and will contain the name of the report and the time and date of the export. Any automatically-chosen name will be given a .csv extension.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example	<pre>switch (config) # stats export csv memory filename mellanoxexample before 2000/08/14 15:59:50 after 2000/08/14 15:01:50 Generated report file: mellanoxexample.csv switch (config) # show files stats mellanoxexample.csv switch (config) #</pre>
Related Commands	show files stats
Note	

show stats alarm

show stats alarm [<Alarm ID> [rate-limit]]

Displays status of all alarms or the specified alarm.

Syntax Description	Alarm ID	May be: <ul style="list-style-type: none"> • <code>cpu_util_indiv</code> - Average CPU utilization too high: percent utilization • <code>disk_io</code> - Operating System Disk I/O per second too high: kilobytes per second • <code>fs_mnt</code> - Free filesystem space too low: percent of disk space free • <code>intf_util</code> - Network utilization too high: bytes per second • <code>memory_pct_used</code> - Too much memory in use: percent of physical memory used • <code>paging</code> - Paging activity too high: page faults • <code>temperature</code> - Temperature is too high: degrees
	rate-limit	Displays rate limit parameters.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # show stats alarm Alarm cpu_util_indiv (Average CPU utilization too high): ok Alarm disk_io (Operating System Disk I/O per second too high): (dis- abled) Alarm fs_mnt (Free filesystem space too low): ok Alarm intf_util (Network utilization too high): (disabled) Alarm memory_pct_used (Too much memory in use): (disabled) Alarm paging (Paging activity too high): ok Alarm temperature (Temperature is too high): ok switch (config) #</pre>	
Related Commands	stats alarm	
Note		

show stats chd

show stats chd [<CHD ID>]

Displays configuration of all statistics CHDs.

Syntax Description	CHD ID	May be: <ul style="list-style-type: none"> • <code>cpu_util_indiv</code> - Average CPU utilization too high: percent utilization • <code>disk_io</code> - Operating System Disk I/O per second too high: kilobytes per second • <code>fs_mnt</code> - Free filesystem space too low: percent of disk space free • <code>intf_util</code> - Network utilization too high: bytes per second • <code>memory_pct_used</code> - Too much memory in use: percent of physical memory used • <code>paging</code> - Paging activity too high: page faults • <code>temperature</code> - Temperature is too high: degrees
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # show stats chd disk_device_io_hour CHD "disk_device_io_hour" (Storage device I/O read/write statistics for the last hour: bytes): Enabled: yes Source dataset: sample "disk_device_io" Computation basis: data points Interval: 1 data point(s) Range: 1 data point(s) switch (config) #</pre>	
Related Commands	stats chd	
Note		

show stats cpu

show stats cpu

Displays some basic stats about CPU utilization:

- the current level
- the peak over the past hour
- the average over the past hour

Syntax Description	N/A
---------------------------	-----

Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show stats cpu CPU 0 Utilization: 6% Peak Utilization Last Hour: 16% at 2012/02/28 08:47:32 Avg. Utilization Last Hour: 8% switch (config) #</pre>
Related Commands	N/A
Note	

show stats sample

show stats sample [<sample ID>]

Displays sampling interval for all samples, or the specified one.

Syntax Description	sample ID	Possible sample IDs are: <ul style="list-style-type: none"> • congested • cpu_util - CPU utilization: milliseconds of time spent • disk_device_io - Storage device I/O statistics • disk_io - Operating system aggregate disk I/O: KB/sec • eth • fan - Fan speed • fs_mnt_bytes - Filesystem usage: bytes • fs_mnt_inodes - Filesystem usage: inodes • ib • interface - Network interface statistics • intf_util - Network interface utilization: bytes • memory - System memory utilization: bytes • paging - Paging activity: page faults • power - Power supply usage • power-consumption • temperature - Modules temperature
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```
switch (config) # show stats sample fan
Sample "fan" (Fan speed):
  Enabled:          yes
  Sampling interval: 1 minute 11 seconds
switch (config) #
```

Related Commands

N/A

Note

2.19 Chassis Management

health

health {max-report-len <length> | re-notif-cntr <counter> | report-clear}

Configures health daemon settings.

Syntax Description	max-report-len <length>	Sets the length of the health report - number of line entries. Possible values: 10-2048.
	re-notif-cntr <counter>	Health control changes notification counter, in seconds. Possible values: 120-7200 seconds.
	report-clear	Clears the health report.
Default	max-report-len: 50 re-notif-cntr:	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	switch (config) # health re-notif-cntr 125 switch (config) #	
Related Commands	show health-report	
Note		

power enable

power enable <module name>
no power enable <module name>

Powers on the module.
 The no form of the command shuts down the module.

Syntax Description	module name	Enables power for selected module.
Default	Power is enabled on all modules.	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # power enable L01 switch (config) #</pre>	
Related Commands	<pre>show power show power consumers</pre>	
Note	This command is not applicable for 1U systems.	

usb eject

usb eject

Gracefully turns off the USB interface.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # usb eject switch (config) #</pre>
Related Commands	N/A
Note	Applicable only for systems with USB interface.

system profile

system profile <profile> [force]

Sets the profile of the system to either InfiniBand or Ethernet.

Syntax Description	profile	<ul style="list-style-type: none"> eth-single-switch ib-single-switch
	force	Force operation, without the need for user confirmation.
Default	The default system profile depends on the system. SX6XXX systems will have “ib-single-switch” as default, while SX1XXX will have “eth-single-switch” as default.	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # system profile eth-single-switch switch (config) #</pre>	
Related Commands	show system profile	
Note	<ul style="list-style-type: none"> This command requires a license This command will delete all switch configuration (keeping IP connectivity) and reset the system Refer to the “Licensing” chapter in the <i>MLNX-OS SwitchX User Manual</i> 	

show fan

show fan

Displays fans status.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin

Example

```

switch (config) # show fan
switch (config) # show fan
=====
Module           Device           Fan  Speed      Status
                        (RPM)
=====
FAN              FAN              F1   5340.00    OK
FAN              FAN              F2   5340.00    OK
FAN              FAN              F3   5640.00    OK
FAN              FAN              F4   5640.00    OK
PS1              FAN              F1   5730.00    OK
PS2              FAN              -    -          NOT PRESENT
switch (config) #

```

Related Commands

N/A

Note

show version

show version [concise]

Displays version information for the currently running system image.

Syntax Description	concise	The concise variant fits the description onto one line.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre> switch (config) # show version Product name: SX_PPC_M460EX Product release: 3.0.0000-dev-HA Build ID: #1-dev Build date: 2012-02-26 08:47:51 Target arch: ppc Target hw: m460ex Built by: root@r-fit16 Uptime: 1d 3h 32m 24.656s Product model: ppc Host ID: 0002c911a15e System memory: 110 MB used / 1917 MB free / 2027 MB total Swap: 0 MB used / 0 MB free / 0 MB total Number of CPUs: 1 CPU load averages: 0.18 / 0.19 / 0.16 switch (config) # </pre>	
Related Commands	N/A	
Note		

show inventory

show inventory

Displays system inventory.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show inventory ===== Module Type Part number Serial Number ===== CHASSIS SX6036 MSX6036F-1BFR MT1140X00300 MGMT SX6036 MSX6036F-1BFR MT1140X00300 FAN SXX0XX_FAN MSX60-FF MT1143X05136 PS1 SXX0XX_PS MSX60-PF MT1144X11656 CPU CPU SA000203-B MT1140X00188 switch (config) #</pre>
Related Commands	N/A
Note	

show module

show module

Displays modules status.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin

Example

```
switch (config) # show module
```

```
=====
Module                Type                Present      Power
=====
MGMT                  SX6036                1            N/A
FAN                   SXX0XX_FAN            1            N/A
PS1                   SXX0XX_PS              1            N/A
PS2                   SXX0XX_PS              0            N/A
CPU                   CPU                    1            N/A
switch (config) #
```

Related Commands

N/A

Note

show memory

show memory

Displays memory status.

Syntax Description

N/A

Default

N/A

Modes/Context

Config

History

3.1.0000

Role

admin

Example

```
switch (config) # show memory
Total      Used      Free      Used+B/C  Free-B/C
Physical  2027 MB    761 MB    1266 MB   1214 MB    813 MB
Swap        0 MB      0 MB      0 MB
Physical Memory Borrowed for System Buffers and Cache:
  Buffers:                0 MB
  Cache:                   452 MB
  Total Buffers/Cache:     452 MB
switch (config) #
```

Related Commands

N/A

Note

show asic-version

show asic-version

Displays firmware ASIC version.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show asic-version ===== SX module Version ===== SX 9.1.1260 switch (config) #</pre>
Related Commands	N/A
Note	

show power

show power

Displays power supplies and power usage.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin

Example

```

switch (config) # show power
=====
Module           Power      Voltage  Current  Capacity  Grid   Status
                (Watts)             (Amp)    (Watts)  Group
=====
PS1              0.00      47.11    0.00     1008      A      OK
PS2             248.82     48.05    5.18     1008      A      OK
PS3              0.00      46.88    0.00     1008      A      OK
PS4              -          -         -         NOT PRESENT
PS5             46.72     47.82    0.98     1008      A      OK
PS6              -          -         -         NOT PRESENT
PS7              -          -         -         NOT PRESENT
PS8              -          -         -         NOT PRESENT
PS9              -          -         -         NOT PRESENT
PS10             -          -         -         NOT PRESENT

Total power used : 295.54 W
Total power capacity : 4032.00 W
Total power budget : 4032.00 W
Total power available : 3736.46 W
Redundancy mode: combined
Redundancy status: OK
switch (config) #

```

Related Commands	N/A
-------------------------	-----

Note**show power consumers****show power consumers**

Displays power consumers.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin

Example

```

switch (config) # show power consumers
=====
Module           Power      Voltage  Current  Status
                (Watts)             (Amp)
=====
MGMT              17.47      48.00    0.36     OK
S01               33.26      48.00    0.69     OK
S02               33.50      48.00    0.70     OK
L01               31.73      48.00    0.66     OK
L02               29.76      48.00    0.62     OK
L30               28.61      48.00    0.60     OK
FAN5              14.91      48.00    0.31     OK
FAN2              13.70      48.00    0.29     OK
FAN1              14.21      48.00    0.30     OK
FAN6              15.10      48.00    0.31     OK
FAN4              14.53      48.00    0.30     OK
FAN7              15.04      48.00    0.31     OK
FAN3              15.17      48.00    0.32     OK
FAN8              14.98      48.00    0.31     OK

Total power used : 291.97 W
Max power : 1636.00 W
switch (config) #

```

Related Commands	N/A
-------------------------	-----

Note

show temperature

show temperature

Displays the system's temperature sensors status.

Syntax Description	N/A
---------------------------	-----

Default	N/A
----------------	-----

Modes/Context	Config
----------------------	--------

History	3.1.0000
----------------	----------

Role	admin
-------------	-------

Example

```

switch (config) # show temperature
=====
Module  Sensor                CurTemp  Status
                (Celsius)
=====
MGMT    SX                    32.00    OK
MGMT    QSFP_TEMP1              22.50    OK
MGMT    QSFP_TEMP2              25.50    OK
MGMT    QSFP_TEMP3              24.50    OK
MGMT    BOARD_MONITOR           28.00    OK
MGMT    CPU_BOARD_MONITOR       31.00    OK
switch (config) #

```


Related Commands	N/A
-------------------------	-----

Note

show voltage

show voltage

Displays power supplies voltage level.

Syntax Description	N/A
---------------------------	-----

Default	N/A
----------------	-----

Modes/Context	Config
----------------------	--------

History	3.1.0000
----------------	----------

Role	admin
-------------	-------

Example	switch (config) # show voltage
----------------	--------------------------------

```
=====
Module   Power Meter           Reg Expected Actual   Status High   Low
              Voltage   Voltage              Range   Range
=====
MGMT     BOARD_MONITOR          V1   5.00    5.15    OK      5.55   4.45
MGMT     BOARD_MONITOR          V2   2.27    2.11    OK      2.55   1.99
MGMT     BOARD_MONITOR          V3   1.80    1.79    OK      2.03   1.57
MGMT     BOARD_MONITOR          V4   3.30    3.28    OK      3.68   2.92
MGMT     BOARD_MONITOR          V5   0.90    0.93    OK      1.04   0.76
MGMT     BOARD_MONITOR          V6   1.20    1.19    OK      1.37   1.03
MGMT     CPU_BOARD_MONITOR      V1  12.00   11.67   OK     13.25  10.75
MGMT     CPU_BOARD_MONITOR      V2   2.50    2.46    OK      2.80   2.20
MGMT     CPU_BOARD_MONITOR      V3   3.30    3.26    OK      3.68   2.92
MGMT     CPU_BOARD_MONITOR      V4   3.30    3.24    OK      3.68   2.92
MGMT     CPU_BOARD_MONITOR      V5   1.80    1.79    OK      2.03   1.57
MGMT     CPU_BOARD_MONITOR      V6   1.20    1.24    OK      1.37   1.03
switch (config) #
```

Related Commands	N/A
-------------------------	-----

Note

show health-report

show health-report

Displays health report.

Syntax Description	N/A
---------------------------	-----

Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show health-report HEALTH DAEMON REPORT ===== switch (config) #</pre>
Related Commands	N/A
Note	

show resources

show resources

Displays system resources.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show resources Total Used Free Physical 2027 MB 761 MB 1266 MB Swap 0 MB 0 MB 0 MB Number of CPUs: 1 CPU load averages: 0.11 / 0.23 / 0.23 CPU 1 Utilization: 5% Peak Utilization Last Hour: 19% at 2012/02/15 13:26:19 Avg. Utilization Last Hour: 7% switch (config) #</pre>
Related Commands	N/A
Note	

show system profile

show system profile

Displays system profile.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.2.0000
Role	admin
Example	switch (config) # show system profile eth-single-switch switch (config) #
Related Commands	system profile
Note	

show system capabilities

show system capabilities

Displays system capabilities.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	switch (config) # show system capabilities IB: Supported Ethernet: Supported, Full L2 Max number of GW ports: 0 Max SM nodes: 648 IB Max licensed speed: FDR Ethernet Max licensed speed: 56Gb switch (config) #

Related Commands	show system profile
-------------------------	---------------------

Note

show system mac

show system mac

Displays system MAC address.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show system mac 00:02:C9:5E:AF:18 switch (config) #</pre>
Related Commands	N/A
Note	

3 Ethernet Switching

3.1 Interface

interface ethernet

interface ethernet <slot number>/<port number>

Enters the Ethernet interface configuration mode.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # interface ethernet 1/1 switch (config interface ethernet 1/1) #</pre>
Related Commands	show interface ethernet
Note	

flowcontrol

flowcontrol {receive | send} {off | on}

Enables or disables IEEE 802.3x link-level flow control per direction for the specified interface.

Syntax Description	receive send	receive - ingresses direction send - egresses direction
	off on	on - enables IEEE 802.3x link-level flow control for the specified interface on receive or send. off - disables IEEE 802.3x link-level flow control for the specified interface on receive or send
Default	receive off, send off	
Modes/Context	Config interface ethernet Config Interface Port Channel	
History	3.1.0000	
Role	admin	

Example	switch (config interface ethernet 1/1) # flowcontrol receive off switch (config interface ethernet 1/1) #
Related Commands	show interface ethernet
Note	N/A

mtu

mtu <frame-size>

Configures the Maximum Transmission Unit (MTU) frame size for the interface.

Syntax Description	frame-size	This value may be 1518-9216 bytes.
Default	1522 bytes	
Modes/Context	Config interface ethernet Config Interface Port Channel	
History	3.1.0000	
Role	admin	
Example	switch (config interface ethernet 1/1) # mtu 9216 switch (config interface ethernet 1/1) #	
Related Commands	show interface ethernet	
Note		

shutdown

shutdown **no shutdown**

Disables the interface.
The no form of the command enables the interface.

Syntax Description	N/A
Default	The interface is enabled.
Modes/Context	Config interface ethernet Config Interface Port Channel
History	3.1.0000

Role	admin
Example	switch (config interface ethernet 1/1) # shutdown switch (config interface ethernet 1/1) #
Related Commands	show interface ethernet
Note	N/A

description

description <string>

no description

Sets an interface description.

The no form of the command returns the interface description to its default value.

Syntax Description	string	40 bytes
Default	""	
Modes/Context	Config interface ethernet Config Interface Port Channel	
History	3.1.0000	
Role	admin	
Example	switch (config interface ethernet 1/1) # description my-interface switch (config interface ethernet 1/1) #	
Related Commands	show interface ethernet	
Note		

speed

speed <port speed> [force]

no speed

Sets the speed of the interface.

The no form of the command sets the speed of the interface to its default value.

Syntax Description	port speed	1000 - 1Gbps 10000 - 10Gbps 40000 - 40Gbps 56000 - 56Gbps
	force	force changing the speed.
Default	Depends on the port module type, see “Notes” section below.	
Modes/Context	Config interface ethernet	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config interface ethernet 1/1) # speed 40000 switch (config interface ethernet 1/1) #</pre>	
Related Commands	show interface ethernet	
Note	<ul style="list-style-type: none"> • 56Gbps port speed requires a license (LIC-6036F-56GE) • The default speed depends on the interface capabilities, interface capable with 40Gbps will have 40Gbps speed by default • Not all interfaces support all speed options 	

clear counters

clear counters

Clears the interface counters.

Syntax Description	N/A
Default	N/A
Modes/Context	Config interface ethernet Config Interface Port Channel
History	3.1.0000
Role	admin
Example	<pre>switch (config interface ethernet 1/1) # clear counters switch (config interface ethernet 1/1) #</pre>

Related Commands	show interface ethernet
-------------------------	-------------------------

Note

show interfaces ethernet

show interfaces ethernet <inf> [counters [priority]]

Displays the configuration and status for the interface.

Syntax Description	inf	Interface number: <slot>/<port>.
	counters	Displays interface extended counters.
	priority	Displays interface extended counters, per priority (0-7).
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # show interfaces ethernet 1/5 Eth1/5 Admin state: Enabled Operational state: Down Description: N/A Mac address: 00:02:c9:5d:e0:26 MTU: 1522 bytes Flow-control: receive off send off Actual speed: 40 Gbps Switchport mode: access Rx 0 frames 0 unicast frames 0 multicast frames 0 broadcast frames 0 octets 0 error frames 0 discard frames Tx 0 frames 0 unicast frames 0 multicast frames 0 broadcast frames 0 octets 0 discard frames switch (config) #</pre>	

Related Commands

Note

show interfaces ethernet [<inf>] capabilities

show interfaces ethernet [<inf>] capabilities

Displays the interface capabilities.

Syntax Description	inf	shows only one interface capabilities. Interface number: <slot>/<port>.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # show interfaces ethernet 1/1 capabilities Eth1/1 Speed : 10000,40000 FlowControl : Send, Receive switch (config) #</pre>	

Related Commands

Note

show interfaces ethernet [<inf>] description

show interfaces ethernet [<inf>] description

Displays the admin status and protocol status for the specified interface.

Syntax Description	inf	Interface number: <slot>/<port>.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.0000	
Role	admin	

Example

```
switch (config) # show interfaces ethernet 0/1 description
Interface      Status      Protocol
-----
Ethernet 1/1 Enables up
switch (config) #
```

Related Commands**Note****show interfaces ethernet [<inf>] status****show interfaces ethernet [<inf>] status**

Displays the status, speed and negotiation mode of the specified interface.

Syntax Description	infInterface number: <slot>/<port>.																							
Default	N/A																							
Modes/Context	Any Command Mode																							
History	3.1.0000																							
Role	admin																							
Example	<pre>switch (config) # show interfaces ethernet status</pre> <table><thead><tr><th>Port</th><th>Operational state</th><th>Speed</th><th>Negotiation</th></tr></thead><tbody><tr><td>Eth1/1</td><td>Up</td><td>40 Gbps</td><td>No-Negotiation</td></tr><tr><td>Eth1/2</td><td>Up</td><td>10 Gbps</td><td>No-Negotiation</td></tr><tr><td>Eth1/3</td><td>Up</td><td>40 Gbps</td><td>No-Negotiation</td></tr><tr><td>...</td><td></td><td></td><td></td></tr></tbody></table> <pre>switch (config) #</pre>				Port	Operational state	Speed	Negotiation	Eth1/1	Up	40 Gbps	No-Negotiation	Eth1/2	Up	10 Gbps	No-Negotiation	Eth1/3	Up	40 Gbps	No-Negotiation	...			
Port	Operational state	Speed	Negotiation																					
Eth1/1	Up	40 Gbps	No-Negotiation																					
Eth1/2	Up	10 Gbps	No-Negotiation																					
Eth1/3	Up	40 Gbps	No-Negotiation																					
...																								
Related Commands																								
Note																								

show interfaces ethernet [<inf>] transceiver**show interfaces ethernet [<inf>] transceiver**

Displays the transceiver info.

Syntax Description	inf	interface number: <slot>/<port>
Default	N/A	

Modes/Context	Any Command Mode
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show interfaces ethernet 1/1 transceiver Port 1/1 state identifier : QSFP+ cable/ module type : Optical cable/ module ethernet speed and type: 40GBASE - SR4 vendor : Mellanox cable_length : 50 m part number : MC2210411-SR4 revision : A1 serial number : TT1151-00006 switch (config) #</pre>
Related Commands	
Note	

3.1.1 Brake-out cables

module-type

module-type <type> [force]

Splits or un-splits the interface, as desired.

Syntax Description	type	qsfp - Port runs at 40000/56000Mbps. qsfp-split-2 - Port is split and runs at 2X10000Mbps. qsfp-split-4 - Port is split and runs at 4X10000Mbps.
	force	force the split operation without asking for user confirmation.
Default	interface module type is qsfp (if the interface supports 40Gbps speed)	
Modes/Context	Config interface ethernet	
History	3.1.1400	
Role	admin	
Example	<pre>switch (config interface ethernet 1/4) # module-type qsfp-split-4 the following interfaces will be unmapped: 1/4 1/1 Type 'yes' to confirm split: yes switch (config interface ethernet 1/4) #</pre>	

Related Commands	switchport mode switchport [trunk hybrid] allowed-vlan show vlan
Note	<ul style="list-style-type: none"> • The affected interfaces should be disabled prior to the operation • in order to un-split the interface - used the command with “qsfp”, the speed is set to 40Gbps “module-type qsfp”. • This command is applicable only on 40Gbps Ethernet ports

3.2 Link Aggregation Group (LAG) and LACP

interface port-channel

interface port-channel <1-4096>
no interface port-channel <1-4096>

Creates a port channel and enters the port-channel configuration mode.
The no form of the command deletes the port-channel.

Syntax Description	1-4096	Port channel number.
Default	Port channels are not created by default.	
Modes/Context	Config	
History	3.1.1400	
Role	admin	
Example	<pre>switch (config)# interface port-channel 1 switch (config interface port-channel 1) #</pre>	
Related Commands		
Note		

lacp

lacp
no lacp

Enables LACP in the switch.
The no form of the command disables LACP in the switch.

Syntax Description	N/A
Default	LACP is disabled.
Modes/Context	Config
History	3.1.1400
Role	admin
Example	switch (config)# lacp switch (config)#
Related Commands	
Note	

lacp system-priority

lacp system-priority <1-65535>
no lacp system-priority

Configures the LACP system priority.
The no form of the command sets the LACP system-priority to default.

Syntax Description	1-65535	LACP system-priority.
Default	32768	
Modes/Context	Config	
History	3.1.1400	
Role	admin	
Example	switch (config)# lacp system-priority 1 switch (config)# show lacp interfaces port-channel Port-channel Module Admin Status is enabled Port-channel System Identifier is 00:02:c9:5c:61:70 LACP System Priority: 3 switch (config)#	

Related Commands

Note

lacp (interface)

lacp {rate fast | port-priority <1-65535>}

no lacp {rate fast | port-priority}

Configures the LACP interface parameters.

The no form of the command sets the LACP interface configuration to default.

Syntax Description	rate fast	Sets LACP PDUs on the port to be in fast (1 second) or slow rate. (30 seconds).														
	1-65535	LACP port-priority.														
Default	rate - slow (30 seconds) port-priority 32768															
Modes/Context	Config															
History	3.1.1400															
Role	admin															
Example	<pre>switch (config)# lacp rate fast switch (config)# show lacp interfaces ethernet 1/7 Port : 1/7 ----- Port State = Down Channel Group : 1 Pseudo port-channel = Po1 LACP port-priority = 32768 LACP Rate = Slow LACP Activity : Passive LACP Timeout : Short Aggregation State : Aggregation, Defaulted,</pre> <table><tr><th>Port</th><th>State</th><th>LACP Port Priority</th><th>Admin Key</th><th>Oper Key</th><th>Port Number</th><th>Port State</th></tr><tr><td>1/7</td><td>Down</td><td>128</td><td>1</td><td>1</td><td>0x7</td><td>0x0</td></tr></table> <pre>switch (config)#</pre>		Port	State	LACP Port Priority	Admin Key	Oper Key	Port Number	Port State	1/7	Down	128	1	1	0x7	0x0
Port	State	LACP Port Priority	Admin Key	Oper Key	Port Number	Port State										
1/7	Down	128	1	1	0x7	0x0										

Related Commands

Note

Configuring LACP rate (fast or slow) will configure the peer port to send (fast or slow), it does not make any affect on the local port LACP rate.

port-channel load-balance

lacp port-channel load-balance <method>
no lacp port-channel load-balance <method>

Configures the port channel load balancing distribution function method.
 The no form of the command sets the distribution function method to default.

Syntax Description	method	Possible load balance methods: <ul style="list-style-type: none"> • destination-ip • destination-mac • destination-port • source-destination-ip • source-destination-mac • source-destination-port • source-ip • source-mac • source-port
Default	source-destination-mac	
Modes/Context	Config	
History	3.1.1400	
Role	admin	
Example	<pre>switch (config)# port-channel load-balance ethernet destination-ip source-port source-mac switch (config)# show interfaces port-channel load-balance destination-ip,source-mac,source-port switch (config)#</pre>	
Related Commands		
Note	Several load balance methods can be configured (refer to the example)	

channel-group

channel-group <1-4096> [mode {on | active | passive}]
no channel-group

Assigns and configures a physical interface to a port channel.
 The no form of the command removes a physical interface from the port-channel.

Syntax Description	1-4096	The port channel number.
	mode on	Static assignment the port to LAG. LACP will not be enabled on this port.
	mode active/passive	Dynamic assignment of the port to LAG. LACP will be enabled in either passive or active mode.
Default	N/A	
Modes/Context	Config interface ethernet	
History	3.1.1400	
Role	admin	
Example	<pre>switch (config interface 1/7)# channel-group 1 mode active switch (config interface 1/7)# show interfaces port-channel summary Flags: D- Down P - Up in port-channel (members) I - Individual H - Hot-standby (LACP only) s - Suspended r - Module-removed U - Up (port-channel) ----- Group Port- Type Member Ports Channel ----- 1 Po1 (D) LACP Eth1/7 (D) switch (config interface 1/7)#</pre>	
Related Commands	<pre>show interfaces port-channel summary show interfaces port-channel compatibility-parameters show lacp interfaces ethernet</pre>	
Note	<ul style="list-style-type: none"> Setting the mode to active/passive is possible only in LACP is enabled. The first port in the LAG decide if the LAG will be static (“on”) or LACP (“active”, “pasive”). All the ports in the LAG must have the same configuration, determines by the first port added to the LAG. The port with a different configuration will be rejected, for the list of dependencies refer to ‘show interfaces port-channel compatibility-parameters’ 	

show lacp system-identifier

show lacp system-identifier

Displays the system identifier of LACP.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode

History	3.1.1400
Role	admin
Example	switch (config)# show lacp system-identifier 00:02:c9:5c:61:70 switch (config)#
Related Commands	show lacp interface port-channel
Note	

show lacp counters

show lacp counters

Displays the LACP PDUs counters.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.1400
Role	admin
Example	<pre>switch (config)# show lacp counters LACPDU Marker Marker Response LACPDU Port Sent Recv Sent Recv Sent Recv Illegal Unknown ----- Port-channel: 1 ----- 1/7 0 0 0 0 0 0 0 0 switch (config) # switch (config)#</pre>
Related Commands	
Note	

show lacp interface ethernet

show lacp interface ethernet <inf>

Displays the LACP interface configuration and status.

Syntax Description	inf	Interface number, for example “1/1”.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.1400	
Role	admin	
Example	<pre>switch (config) # show lacp interfaces ethernet 1/4 Port : 1/4 ----- Port State = Down Channel Group : 1 Pseudo port-channel = Po1 LACP port-priority = 128 LACP Rate = Slow LACP Activity : Passive LACP Timeout : Short Aggregation State : Aggregation, Defaulted, Port State LACP Port Admin Oper Port Port State Priority Key Key Number State ----- 1/4 Down 128 1 1 0x4 0x0 switch (config) #</pre>	
Related Commands		
Note		

show lacp interface neighbor

show lacp interface neighbor

Displays the LACP interface neighbor status.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode

History	3.1.1400
Role	admin
Example	<pre> switch (config) # show lacp interfaces neighbor Flags: A - Device is in Active mode P - Device is in Passive mode Channel group 1 neighbors Port 1/4 ----- Partner System ID : 00:00:00:00:00:00 Flags : A LACP Partner Port Priority : 0 LACP Partner Oper Key : 0 LACP Partner Port State : 0x0 Port State Flags Decode ----- Activity : Active Aggregation State : Aggregation, Sync, Collecting, Distributing, Expired, Defaulted, switch (config) # </pre>
Related Commands	
Note	

show lacp interfaces port-channel

show lacp interfaces port-channel

Displays the LACP global parameters.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.1400
Role	admin
Example	<pre> switch (config) # show lacp interfaces port-channel Port-channel Module Admin Status is enabled Port-channel System Identifier is 00:01:02:03:04:05 LACP System Priority: 32768 switch (config) # </pre>

Related Commands

Note

3.3 VLANs

vlan

vlan {<vlan-id> | <vlan-range>}
no vlan {<vlan-id> | <vlan-range>}

Creates a VLAN or range of VLANs, and enters a VLAN context.
 The no form of the command deletes the VLAN or VLAN range.

Syntax Description	vlan-id	1-4094.									
	vlan-range	Any range of VLANs.									
Default	VLAN 1 is enabled by default.										
Modes/Context	Config										
History	3.1.1400										
Role	admin										
Example	<pre>switch (config) # vlan 10 switch (config vlan 10) # show vlan</pre> <table> <thead> <tr> <th>VLAN</th><th>Name</th><th>Ports</th></tr> </thead> <tbody> <tr> <td>1</td><td>default</td><td>Eth1/2, Eth1/3, Eth1/4/1, Eth1/4/2 ...</td></tr> <tr> <td>10</td><td></td><td></td></tr> </tbody> </table> <pre>switch (config vlan 10) #</pre>		VLAN	Name	Ports	1	default	Eth1/2, Eth1/3, Eth1/4/1, Eth1/4/2 ...	10		
VLAN	Name	Ports									
1	default	Eth1/2, Eth1/3, Eth1/4/1, Eth1/4/2 ...									
10											
Related Commands	show vlan switchport mode switchport [trunk hybrid] allowed-vlan										
Note	Interfaces are not added automatically to VLAN unless configured with trunk or hybrid mode with “all” option turned on.										

name

name <vlan-name>

no name

Adds VLAN name.

The no form of the command deletes the VLAN name.

Syntax Description	vlan-name	40-character long string.																											
Default	No name available.																												
Modes/Context	Config Vlan																												
History	3.1.1400																												
Role	admin																												
Example	<pre>switch (config) # vlan 10 switch (config vlan 10) # name my-vlan-name switch (config vlan 10) # show vlan</pre> <table> <thead> <tr> <th>VLAN</th><th>Name</th><th>Ports</th></tr> </thead> <tbody> <tr> <td>1</td><td>default</td><td>Eth1/2, Eth1/3, Eth1/4/1, Eth1/4/2, Eth1/5,</td></tr> <tr> <td></td><td></td><td>Eth1/6, Eth1/7, Eth1/8, Eth1/9, Eth1/10, Eth1/11, Eth1/12, Eth1/13, Eth1/14, Eth1/15,</td></tr> <tr> <td></td><td></td><td>Eth1/16, Eth1/17, Eth1/18, Eth1/19, Eth1/20,</td></tr> <tr> <td></td><td></td><td>Eth1/21, Eth1/22, Eth1/23, Eth1/24, Eth1/25,</td></tr> <tr> <td></td><td></td><td>Eth1/26, Eth1/27, Eth1/28, Eth1/29, Eth1/30,</td></tr> <tr> <td></td><td></td><td>Eth1/31, Eth1/32, Eth1/33, Eth1/34, Eth1/35,</td></tr> <tr> <td></td><td></td><td>Eth1/36, Po34, Po4096</td></tr> <tr> <td>10</td><td>my-vlan-name</td><td></td></tr> </tbody> </table>		VLAN	Name	Ports	1	default	Eth1/2, Eth1/3, Eth1/4/1, Eth1/4/2, Eth1/5,			Eth1/6, Eth1/7, Eth1/8, Eth1/9, Eth1/10, Eth1/11, Eth1/12, Eth1/13, Eth1/14, Eth1/15,			Eth1/16, Eth1/17, Eth1/18, Eth1/19, Eth1/20,			Eth1/21, Eth1/22, Eth1/23, Eth1/24, Eth1/25,			Eth1/26, Eth1/27, Eth1/28, Eth1/29, Eth1/30,			Eth1/31, Eth1/32, Eth1/33, Eth1/34, Eth1/35,			Eth1/36, Po34, Po4096	10	my-vlan-name	
VLAN	Name	Ports																											
1	default	Eth1/2, Eth1/3, Eth1/4/1, Eth1/4/2, Eth1/5,																											
		Eth1/6, Eth1/7, Eth1/8, Eth1/9, Eth1/10, Eth1/11, Eth1/12, Eth1/13, Eth1/14, Eth1/15,																											
		Eth1/16, Eth1/17, Eth1/18, Eth1/19, Eth1/20,																											
		Eth1/21, Eth1/22, Eth1/23, Eth1/24, Eth1/25,																											
		Eth1/26, Eth1/27, Eth1/28, Eth1/29, Eth1/30,																											
		Eth1/31, Eth1/32, Eth1/33, Eth1/34, Eth1/35,																											
		Eth1/36, Po34, Po4096																											
10	my-vlan-name																												
Related Commands	<pre>show vlan switchport mode switchport [trunk hybrid] allowed-vlan</pre>																												
Note	Name can not be added to a range of VLANs.																												

show vlan

show vlan [id <vlan-id>]

Displays the VLAN table.

Syntax Description	vlan-id	1-4094.
---------------------------	---------	---------

Default	N/A											
Modes/Context	Any Command Mode											
History	3.1.1400											
Role	admin											
Example	<pre>switch (config vlan 10) # show vlan</pre> <table><thead><tr><th>VLAN</th><th>Name</th><th>Ports</th></tr></thead><tbody><tr><td>1</td><td>default</td><td>Eth1/2, Eth1/3, Eth1/4/1, Eth1/4/2 ...</td></tr><tr><td>10</td><td>my-vlan-name</td><td></td></tr></tbody></table>			VLAN	Name	Ports	1	default	Eth1/2, Eth1/3, Eth1/4/1, Eth1/4/2 ...	10	my-vlan-name	
VLAN	Name	Ports										
1	default	Eth1/2, Eth1/3, Eth1/4/1, Eth1/4/2 ...										
10	my-vlan-name											
Related Commands	<pre>show vlan switchport mode switchport [trunk hybrid] allowed-vlan vlan</pre>											
Note												

switchport mode

switchport mode {access | trunk | hybrid | access-dcb}

no switchport mode

Sets the switch port mode.

The no form of the command sets the switch port mode to access.

Syntax Description	access	Un-tagged port. 802.1q tagged traffic will be filtered. egress traffic is un-tagged.
	trunk	802.1q tagged port, un-tagged traffic will be filtered.
	hybrid	Both 802.1q tagged and un-tagged traffic is allowed on the port.
	access-dcb	Un-tagged port, egress traffic is priority tagged.
Default	access.	
Modes/Context	Config interface ethernet Config Interface Port Channel	
History	3.1.1400	
Role	admin	

Example

```

switch (config) # interface ethernet 1/7
switch (config interface ethernet 1/7) # switchport mode access
switch (config interface ethernet 1/7) # show interfaces switchport
Interface |      Mode      | Access vlan |      Allowed vlans
-----|-----|-----|-----
Eth1/2      access      1
Eth1/3      access      1
Eth1/4/1    access      1
Eth1/4/2    access      1
Eth1/5      access      1
Eth1/6      access      1
....
Po34        access      1
Po4096      access      1
switch (config interface ethernet 1/7) #

```

Related Commands

```

show vlan
show interfaces switchport
switchport access vlan
switchport [trunk | hybrid] allowed-vlan
vlan

```

Note

switchport access

switchport access vlan <vlan-id>**no switchport access vlan**

Sets the port access VLAN.

The no form of the command sets the port access VLAN to 1.

Syntax Description	vlan-id	1-4094.
Default	1	
Modes/Context	Config interface ethernet Config Interface Port Channel	
History	3.1.1400	Initial version
	3.2.0500	Format change (removed hybrid and access-dcb options). Previous command format was: “switchport {hybrid access-dcb access} vlan <vlan-id>”
Role	admin	

Example

```

switch (config) # interface ethernet 1/7
switch (config interface ethernet 1/7) # switchport access vlan 10
switch (config interface ethernet 1/7) # show interfaces switchport
Interface |      Mode      | Access vlan |      Allowed vlans
-----|-----|-----|-----
Eth1/2     access      1
Eth1/3     access      1
Eth1/4/1   access      1
Eth1/4/2   access      1
Eth1/5     access      1
Eth1/6     access      1
Eth1/7     access     10
....
Po4096     access      1
switch (config interface ethernet 1/7) #

```

Related Commands

```

show vlan
show interfaces switchport
switchport mode
switchport [trunk | hybrid] allowed-vlan
vlan

```

Note

This command is not applicable for interfaces with port mode trunk.
only one option (“access”, “access-dcb” or “hybrid”) is applicable to configure on the port, depends on the switchport mode of the port.

switchport {hybrid, trunk} allowed vlan

switchport {hybrid, trunk} allowed vlan {<vlan> | add <vlan> | remove <vlan> all | except <vlan> | none}

Sets the port allowed VLANs.

Syntax Description	vlan	VLAN ID (1-4094) or VLAN range.
	add	Add VLAN or range of VLANs.
	remove	Remove VLANs or range of VLANs.
	all	Add all VLANs in available in the VLAN table. New vlans that will be added to the vlan table will be added automatically.
	except	Add all VLANs expect this VLAN or VLAN range.
	none	Remove all VLANs.
Default	N/A	
Modes/Context	Config interface ethernet Config Interface Port Channel	
History	3.1.1400	

Role	admin
Example	<pre> switch (config) # interface ethernet 1/7 switch (config interface ethernet 1/7) # switchport hybrid allowed-vlan all switch (config interface ethernet 1/7) #show interfaces switchport Interface Mode Access vlan Allowed vlans ----- ----- ----- ----- Eth1/2 access 1 Eth1/3 access 1 Eth1/4/1 access 1 Eth1/4/2 access 1 Eth1/5 access 1 Eth1/6 access 1 Eth1/7 hybrid 1 1, 10 Po34 access 1 Po4096 access 1 switch (config interface ethernet 1/7) # </pre>
Related Commands	<pre> show vlan show interfaces switchport switchport access vlan switchport mode vlan </pre>
Note	This command is not applicable for interfaces with port mode access or access-dcb.

show interface switchport

show interface switchport

Displays all interface switch port configurations.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.1400
Role	admin

Example

```
switch (config) #show interfaces switchport
Interface | Mode | Access vlan | Allowed vlans
-----|-----|-----|-----
Eth1/2    access    1
Eth1/3    access    1
Eth1/4/1  access    1
Eth1/4/2  access    1
Eth1/5    access    1
Eth1/6    access    1
Eth1/7    hybrid    1      1, 10
....
Po34      access    1
Po4096    access    1
switch (config)#
```

Related Commands

```
show vlan
switchport access vlan
switchport mode
vlan
```

Note

3.4 MAC Address Table

mac-address-table aging-time

mac-address-table aging-time <age>

no mac-address-table aging-time

Sets the maximum age of a dynamically learnt entry in the MAC address table. The no form of the command resets the aging time of the MAC address table to its default.

Syntax Description	age	10-1000000 seconds.
Default	300	
Modes/Context	Config	
History	3.1.0600	
Role	admin	
Example	<pre>switch (config) # mac-address-table aging-time 50 switch (config) # show mac-address-table aging-time Mac Address Aging Time: 50 switch (config) #</pre>	

Related Commands	show mac-address-table show mac-address-table aging time
-------------------------	---

Note

mac-address-table static

mac-address-table static <mac address> vlan <vlan> interface <if-type> <if-number>
no mac-address-table static <mac address> vlan <vlan> interface <if-type> <if-number>

Configures a static MAC address in the forwarding database.
The no form of the command deletes a configured static MAC address from the forwarding database.

Syntax Description	mac address	Destination MAC address.
	vlan	VLAN ID or VLAN range.
	if-type	Ethernet or port-channel interface type.
	if-number	The interface number (i.e. 1/1, 3).
Default	No static MAC addresses available in default.	
Modes/Context	Config	
History	3.1.0600	
Role	admin	
Example	<pre>switch (config) # mac-address-table static aa:aa:aa:aa:aa:aa vlan 1 interface ethernet 1/7 switch (config) # show mac-address-table Switch ethernet-default Vlan Mac Address Type Interface ---- - 1 aa:aa:aa:aa:aa:aa static Eth1/7 Number of unicast: 1 Number of multicast: 0 switch (config) #</pre>	
Related Commands	show mac-address-table mac-address-table aging time	
Note	The no form of the command will not clear a dynamic MAC address. Dynamic MAC addresses are cleared using the “clear mac-address-table dynamic” command.	

clear mac-address-table dynamic

clear mac-address-table dynamic

Clear the dynamic entries in the MAC address table.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0600
Role	admin
Example	<pre>switch (config) # clear mac-address-table dynamic switch (config) #</pre>
Related Commands	mac-address-table aging-time mac-address-table static show mac-address-table
Note	This command does not clear the MAC addresses learned on the mgmt0 port. Static entries are deleted using the “no mac-address-table static” command.

show mac-address-table

show mac-address-table [address <mac-address> | interface ethernet <if-number> | vlan [<vlan> | range <range>] | unicast | multicast]

Displays the static and dynamic unicast and multicast MAC addresses for the switch. Various of filter options available.

Syntax Description	mac-address	Filter the table to a specific MAC address.
	if-number	Filter the table to a specific interface.
	vlan	Filter the table to a specific VLAN number (1-4094).
	range	Filter the table to a range of VLANs.
	unicast	Filter the table to a unicast addresses only.
	multicast	Filter the table to a multicast addresses only.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.0600	

Role	admin																								
Example	<pre>switch (config) # show mac-address-table</pre> <pre>Switch ethernet-default</pre> <table><thead><tr><th>Vlan</th><th>Mac Address</th><th>Type</th><th>Interface</th></tr><tr><th>----</th><th>-----</th><th>----</th><th>-----</th></tr></thead><tbody><tr><td>1</td><td>00:02:c9:06:97:36</td><td>dynamic</td><td>Eth1/36</td></tr><tr><td>1</td><td>00:02:c9:10:d7:c0</td><td>static</td><td>Eth1/35</td></tr><tr><td colspan="2">Number of unicast:</td><td>2</td><td></td></tr><tr><td colspan="2">Number of multicast:</td><td>0</td><td></td></tr></tbody></table> <pre>switch (config) #</pre>	Vlan	Mac Address	Type	Interface	----	-----	----	-----	1	00:02:c9:06:97:36	dynamic	Eth1/36	1	00:02:c9:10:d7:c0	static	Eth1/35	Number of unicast:		2		Number of multicast:		0	
Vlan	Mac Address	Type	Interface																						
----	-----	----	-----																						
1	00:02:c9:06:97:36	dynamic	Eth1/36																						
1	00:02:c9:10:d7:c0	static	Eth1/35																						
Number of unicast:		2																							
Number of multicast:		0																							
Related Commands	<pre>mac-address-table static</pre> <pre>clear mac-address-table</pre>																								
Note																									

show mac-address-table aging-time

show mac-address-table aging-time

Displays the MAC address table aging time.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.0600
Role	admin
Example	<pre>switch (config) # mac-address-table aging-time 300</pre> <pre>switch (config) # show mac-address-table aging-time</pre> <pre>Mac Address Aging Time: 300</pre> <pre>switch (config) #</pre>
Related Commands	<pre>mac-address-table aging-time</pre> <pre>mac-address-table static</pre> <pre>clear mac-address-table</pre>
Note	MAC addresses learned on the mgmt0 is not shown by this command.

3.5 Spanning Tree

spanning-tree

spanning-tree
no spanning-tree

Globally enables the spanning tree feature.
 The no form disables the spanning tree feature.

Syntax Description	N/A
Default	Spanning tree is enabled.
Modes/Context	Config
History	3.1.0000
Role	admin
Example	switch (config) # no spanning-tree switch (config) #
Related Commands	show spanning-tree
Note	

spanning-tree (timers)

spanning-tree [forward-time <time in secs> | hello-time <time in secs> | max-age <time in secs>]
no spanning-tree [forward-time | hello-time | max-age]

Sets the spanning tree timers.
 The no form of the command sets the timer to default.

Syntax Description	forward-time	Controls how fast a port changes its spanning tree state from Blocking state to Forwarding state. Parameter range: 4-30 seconds.
	hello-time	Determines how often the switch broadcasts its hello message to other switches when it is the root of the spanning tree. Parameter range: 1-2 seconds.
	max-age	Sets the maximum age allowed for the Spanning Tree Protocol information learnt from the network on any port before it is discarded. Parameter range: 6-40 seconds.

Default	forward-time: 15 seconds hello-time:2 seconds max-age: 20 seconds
Modes/Context	Config
History	3.1.0000
Role	admin
Example	switch (config) # spanning-tree forward-time switch (config) #
Related Commands	show spanning-tree
Note	The following formula applies on the spanning tree timers: $2 * (\text{ForwardTime} - 1) \geq \text{MaxAgeTime} \geq 2 * (\text{Hello Time} + 1)$

spanning-tree port type (default global)

spanning-tree port type <port-type> default
no spanning-tree port type default

Configures all switch interfaces as edge/network/normal ports. These ports can be connected to any type of device.
The no form of the command disables the spanning tree operation.

Syntax Description	port-type	<ul style="list-style-type: none"> • Edge - Assumes all ports are connected to hosts/servers. • Network - Assumes all ports are connected to switches and bridges. • Normal - the port type (Edge or Network) determines according to the spanning tree operational mode.
Default	Normal	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	switch (config) # spanning-tree port type edge default switch (config) #	
Related Commands	show spanning-tree	
Note		

spanning-tree priority

spanning-tree priority <bridge-priority>
no spanning-tree priority

Sets the spanning tree bridge priority.
 The no form of the command sets the bridge priority to default.

Syntax Description	bridge-priority	Sets the bridge priority for the spanning tree. Its value must be in steps of 4096, starting from 0. Only the following values are applicable: 0, 4096, 8192, 12288, 16384, 20480, 24576, 28672, 32768, 36864, 40960, 45056, 49152, 53248, 57344, 61440.
Default	32786	
Modes/Context	Config	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # spanning-tree priority 4096 switch (config) #</pre>	
Related Commands	show spanning-tree	
Note		

spanning-tree port-priority

spanning-tree port-priority <priority>
no spanning-tree port-priority

Configures the spanning-tree interface priority.
 The no form of the command returns configuration to its default.

Syntax Description	priority	Spanning tree interface priority. The possible values are: 0, 16, 32,48, 64, 80, 96, 112, 128,144, 160, 176, 192, 208, 224, 240.
Default	128	
Modes/Context	Config interface ethernet	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # interface ethernet 1/1 switch (config interface ethernet 1/1) # spanning-tree port-priority 16 switch (config interface ethernet 1/1) #</pre>	

Related Commands	show spanning-tree
-------------------------	--------------------

Note

spanning-tree cost

spanning-tree cost <port cost>

no spanning-tree cost

Configures the interface cost of the spanning tree.

The no form of the command returns configuration to its default.

Syntax Description	port cost	Sets the spanning tree cost of an interface. Value range is 0-2000000000.
Default	The default cost is derived from the speed. 1Gbps 20000 10Gbps 2000 40Gbps 500 56Gbps 357	
Modes/Context	Config interface ethernet	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # interface ethernet 1/1 switch (config interface ethernet 1/1) # spanning-tree cost 1000 switch (config interface ethernet 1/1) #</pre>	
Related Commands	show spanning-tree	
Note	<ul style="list-style-type: none"> LAG default cost is calculated by dividing the port speed by the number of active links in UP state. For example: if there were 4 links in the LAG out of which only two are in UP state, assuming the port speed is 10Gbps, the LAG cost will be $2000/2 = 1000$. When configuring the cost for a LAG, the cost will be fixed to this configuration, no matter what the number of active links (UIP state) in the LAG is Unstable network may cause the LAG cost to change dynamically assuming the cost parameter is not configured for anything else other than default 	

spanning-tree port type

spanning-tree port type <port type>

no spanning-tree port type

Configures spanning-tree port type

The no form of the command returns configuration to default.

Syntax Description	port type	Sets the spanning-tree port type. The port type parameter has four options: <ul style="list-style-type: none"> • Default (globally defined) • Edge • Normal • Network In case there is no change of this parameter, the configuration will be taken from the global default port type.
Default	Globally defined by the command “spanning-tree port type <port-type> default”	
Modes/Context	Config interface ethernet	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # interface ethernet 1/1 switch (config interface ethernet 1/1) # spanning-tree port type edge switch (config interface ethernet 1/1) #</pre>	
Related Commands	show spanning-tree	
Note		

spanning-tree guard

spanning-tree guard {loop | root}

no spanning-tree guard {loop | root}

Configures spanning-tree guard.

The no form of the command returns configuration to default.

Syntax Description	loop	Enables loop-guard on the interface. If the loop-guard is enabled, upon a situation where the interface fails to receive BPDUs the switch will not egress data traffic on this interface.
	root	Enables root-guard on the interface. If root-guard is enabled on the interface, the interface will never be selected as root port.
Default	loop-guard and loop-guard are disabled.	

Modes/Context	Config interface ethernet
History	3.1.0000
Role	admin
Example	<pre>switch (config) # interface ethernet 1/1 switch (config interface ethernet 1/1) # spanning-tree guard root switch (config interface ethernet 1/1) #</pre>
Related Commands	show spanning-tree
Note	

spanning-tree bpdudfilter

spanning tree bpdudfilter {disable | enable}
no spanning tree bpdudfilter

Configures spanning-tree BPDU filter on the interface. The interface will ignore any BPDU that it receives and will not send PDUs, The STP state on the port will move to the forwarding state.

The no form of the command returns the configuration to default.

Syntax Description	disable	Disables the BPDU filter on this port.
	enable	Enables the BPDU filter on this port.
Default	BPDU filter is disabled.	
Modes/Context	Config interface ethernet	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config) # interface ethernet 1/1 switch (config interface ethernet 1/1) # spanning-tree bpdudfilter enable switch (config interface ethernet 1/1) #</pre>	
Related Commands	show spanning-tree	
Note	This command can be used when the switch is connected to hosts.	

clear spanning-tree counters

clear spanning-tree counters

Clears the spanning-tree counters.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # clear panning-tree counters switch (config) #</pre>
Related Commands	show spanning tree
Note	

show spanning-tree

show spanning-tree [detail | interface <type> <number>]

Displays spanning tree information.

Syntax Description	detail	Displays detailed spanning-tree configuration and statistics.
	interface <type> <number>	Displays the running state for a specific interface. Options for “type”: ethernet or port-channel. Options for “number”: <slot/port> or <number>.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.0000	
Role	admin	

Example

```

switch (config) # show spanning-tree

Switch ethernet-default

Spanning tree protocol is enabled rstp

Spanning tree force version:2
Root ID
    Priority 32768
    Address 00:02:c9:5c:61:70
    This bridge is the root
    Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
Bridge ID
    Priority 32768
    Address 00:02:c9:5c:61:70
    Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Interface      Role      Sts      Cost      Prio      Type
----          -
switch (config) #

```

Related Commands

```

clear spanning-tree counters
spanning-tree

```

Note

3.6 IGMP Snooping

ip igmp snooping (admin)

```

ip igmp snooping
no ip igmp snooping

```

Enables IGMP snooping globally or per VLAN.
The no form of the command disables IGMP snooping globally or per VLAN.

Syntax Description	N/A
Default	IGMP snooping is disabled, globally and per VLAN.
Modes/Context	Config Config Vlan
History	3.1.1400
Role	admin

Example

```

switch (config) # ip igmp snooping
switch (config) # vlan 10
switch (config vlan 10) # ip igmp snooping
switch (config vlan 10) # exit
switch (config) # show ip igmp snooping

IGMP snooping global configuration:

IGMP snooping globally enabled
IGMP snooping operationally enabled
Proxy-reporting globally disabled
Last member query interval is 1 seconds
Mrouter timeout is 125 seconds
Port purge timeout is 260 seconds
Report suppression interval is 5 seconds

switch (config vlan 10) # show ip igmp snooping vlan 10

Vlan 10 configuration parameters:
  IGMP snooping is enabled
  IGMP version is V2
  Snooping switch is acting as Non-Querier
  mrouter static port list: none
  mrouter dynamic port list: none
switch (config vlan 10) # vlan 10
switch (config vlan 10) #

```

Related Commands

```
show ip igmp snooping
```

Note

IGMP snooping has global admin state, and per VLAN admin state. Both states need to be enabled in order to enable the IGMP snooping on a specific VLAN.

ip igmp snooping (config)

**ip igmp snooping {last-member-query-interval <1-25> | proxy reporting
mrouter-timeout <60-600> | port-purge-timeout <130-1225> | report-suppression-interval <1-25>}**

no ip igmp snooping {last-member-query-interval | proxy reporting | mrouter-timeout | report-suppression-interval}

Configures IGMP global parameters.

The no form of the command resets the IGMP global parameters to default.

Syntax Description

last-member-query-interval <1-25>

Sets the time period (in seconds) with which the general queries are sent by the IGMP querier. After timeout expiration the port will be removed from the multicast group.

proxy reporting

Enables proxy reporting

	mrouters-timeout <60-600> Sets the IGMP snooping router port purge time-out after which the port gets deleted if no IGMP router control packets are received. The default value is 125 seconds.
	port-purge-timeout <130-1225> Sets the IGMP snooping port purge time interval after which the port gets deleted if no IGMP reports are received.
	report-suppression-interval <1-25> Sets the IGMP snooping report-suppression time interval for which the IGMPv2 report messages for the same group will not get forwarded onto the router ports. The default value is 5 seconds.
Default	last-member-query-interval - 1 second. proxy-reporting is disabled mrouters-timeout - 125 port-purge-timeout - 260 seconds report-suppression-interval - 5 seconds.
Modes/Context	Config
History	3.1.1400
Role	admin
Example	<pre>switch (config) # ip igmp snooping report-suppression-interval 3 switch (config) # show ip igmp snooping</pre> <p>IGMP snooping global configuration:</p> <pre>IGMP snooping globally enabled IGMP snooping operationally enabled Proxy-reporting globally disabled Last member query interval is 1 seconds Mrouter timeout is 125 seconds Port purge timeout is 260 seconds Report suppression interval is 3 seconds</pre> <pre>switch (config) #</pre>
Related Commands	ip igmp snooping (admin) show ip igmp snooping
Note	

ip igmp snooping fast-leave

ip igmp snooping fast-leave
no ip igmp snooping fast-leave

Enables fast leave processing on a specific interface.
 The no form of the command disables fast leave processing on a specific interface.

Syntax Description N/A

Default	Normal-leave is enabled.
Modes/Context	Config interface ethernet Config Interface Port Channel
History	3.1.1400
Role	admin
Example	<pre>switch (config interface ethernet 1/1) # ip igmp snooping fast-leave switch (config interface ethernet 1/1) # show ip igmp snooping inter- faces interface leave-mode ----- - Eth1/1 Fast Eth1/2 Normal Eth1/3 Normal ... switch (config interface ethernet 1/1) #</pre>
Related Commands	show ip igmp snooping interfaces
Note	

ip igmp snooping static-group

ip igmp snooping static-group <IP address> interface <type> <number>
no ip igmp snooping static-group <IP address> interface <type> <number>

Creates a static multicast group and attaches a port to a specified group.
The no form of the command deletes the interface from the multicast group.

Syntax Description	Ip address	Multicast IP address <224.x.x.x - 239.255.255.255>
	interface <type> <number>	Attach the group to a specific interface. type - ethernet or port-channel
Default	No static groups are configured.	
Modes/Context	Config Vlan	
History	3.1.1400	
Role	admin	
Example	<pre>switch (config)# vlan 1 switch (config vlan 1) # ip igmp snooping static-group 230.0.0.1 interface ethernet 1/1 switch (config vlan 1) # show ip igmp snooping groups Vlan ID Group St/Dyn Ports ----- - 1 230.0.0.1 St Eth1/1 Total Num of Dynamic Group Addresses 0 Total Num of Static Group Addresses 1 switch (config vlan 1) #</pre>	

Related Commands	show ip igmp snooping groups
Note	If the deleted interface is the last port, it deletes the entire multicast group.

ip igmp snooping mrouter

ip igmp snooping mrouter interface <type> <number>
no ip igmp snooping mrouter interface <type> <number>

Creates a static multicast router port on a specific VLAN, on a specific interface.
The no form of the command removes the static multicast router port from a specific VLAN.

Syntax Description	interface <type> <number> type - ethernet or port-channel.
Default	No static mrouters are configured.
Modes/Context	Config Vlan
History	3.1.1400
Role	admin
Example	<pre>switch (config)# vlan 1 switch (config vlan 1) # ip igmp snooping mrouter interface ethernet 1/1 switch (config vlan 1) # show ip igmp snooping mrouter Vlan Ports ----- 1 Eth1/1(static) switch (config vlan 1) #</pre>
Related Commands	show ip igmp snooping mrouter
Note	The multicast router port can be created only if IGMP snooping is enabled both globally and on the VLAN.

ip igmp snooping unregistered multicast

ip igmp snooping unregistered multicast <options>
no ip igmp snooping unregistered multicast

Sets the behavior of the snooping switch for unregistered multicast traffic.
The no form of the command sets it default.

Syntax Description	options	<ul style="list-style-type: none"> flood forward-to-mrouter-ports
---------------------------	---------	---

Default	flood
Modes/Context	Config
History	3.2.0500
Role	admin
Example	<pre>switch (config) # ip igmp snooping unregistered multicast flood switch (config) # show ip igmp snooping IGMP snooping global configuration: IGMP snooping globally enabled IGMP snooping operationally enabled Proxy-reporting globally disabled Last member query interval is 1 seconds Mrouter timeout is 125 seconds Port purge timeout is 260 seconds Report suppression interval is 5 seconds IGMP snooping unregistered multicast: flood switch (config) #</pre>
Related Commands	show ip igmp snooping
Note	

show ip igmp snooping

show ip igmp snooping

Displays IGMP snooping information for all VLANs or a specific VLAN.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.1400
Role	admin

Example

```
switch (config) # show ip igmp snooping

IGMP snooping global configuration:

IGMP snooping globally enabled
IGMP snooping operationally enabled
Proxy-reporting globally disabled
Last member query interval is 1 seconds
Mrouter timeout is 125 seconds
Port purge timeout is 260 seconds
Report suppression interval is 3 seconds
IGMP snooping unregistered multicast: flood

switch (config) #
```

Related Commands**Note****show ip igmp snooping groups****show ip igmp snooping groups**

Displays per VLAN the list of multicast groups attached (static or dynamic allocated) per port.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.1.1400
Role	admin
Example	<pre>switch (config) # show ip igmp snooping groups Vlan ID Group St/Dyn Ports ----- 1 230.0.0.1 St Eth1/1 Total Num of Dynamic Group Addresses 0 Total Num of Static Group Addresses 1 switch (config) #</pre>

Related Commands**Note**

show ip igmp snooping vlan

show ip igmp snooping vlan {<vlan/vlan-range> | all}

Displays IGMP configuration per VLAN or VLAN range.

Syntax Description	<div> <div>vlan/vlan range</div> <div>Displays IGMP VLAN configuration per specific VLAN or VLAN range.</div> </div> <div> <div>all</div> <div>Display IGMP VLAN configuration on all VLAN.</div> </div>
Default	N/A
Modes/Context	Any Command Mode
History	3.1.1400
Role	admin
Example	<pre>switch (config) # show ip igmp vlan 1 Vlan 1 configuration parameters: IGMP snooping is enabled IGMP version is V2 Snooping switch is acting as Non-Querier mrouter static port list: Eth1/1 mrouter dynamic port list: none switch (config) #</pre>
Related Commands	
Note	

show ip igmp snooping mrouter

show ip igmp snooping mrouter

Displays IGMP snooping multicast router information.

Syntax Description	
Default	N/A
Modes/Context	Any Command Mode
History	3.1.1400
Role	admin

Example

```
switch (config) # show ip igmp snooping mrouter
Vlan            Ports
-----
1               Eth1/1(static)
switch (config) #
```

Related Commands**Note****show ip igmp snooping interfaces**

show ip igmp snooping interfaces

Displays IGMP snooping interface information.

Syntax Description

Default N/A

Modes/Context Any Command Mode

History 3.1.1400

Role admin

Example

```
switch (config) # show ip igmp snooping interfaces
interface        leave-mode
-----
1/1              Normal
1/2              Normal
1/3              Normal
1/4              Fast
...
switch (config) #
```

Related Commands**Note****show ip igmp snooping statistics**

show ip igmp snooping statistics

Displays IGMP snooping statistical counters.

Syntax Description N/A

Default	N/A
Modes/Context	Any Command Mode
History	3.1.1400
Role	admin
Example	<pre>switch (config) # show ip igmp snooping statistics Snooping Statistics for VLAN 1 General queries received : 0 Group specific queries received : 0 V1/V2 reports received : 0 V1/V2 reports transmitted : 0 Leave messages received : 0 Group specific queries transmitted: 0 Leave messages transmitted: 0 Unsuccessful joins received count Per Vlan: 0 Active/Successful joins received count Per Vlan: 0 Active Groups count: 0 Packets dropped: 0 switch (config) #</pre>
Related Commands	
Note	

3.7 Link Layer Discovery Protocol (LLDP)

lldp

lldp
no lldp

Enables LLDP globally.
The no form of the command disables the LLDP.

Syntax Description	N/A
Default	Disabled
Modes/Context	Config
History	3.2.0300
Role	admin
Example	<pre>switch (config)# lldp switch (config)#</pre>

Related Commands	show lldp local
-------------------------	-----------------

Note

lldp reinit

lldp reinit <seconds>
no lldp reinit

Sets the delay in seconds from enabling the LLDP on the port until re-initialization will be attempted.
 The no form of the command sets the parameter to default.

Syntax Description	seconds	1-10
Default	2	
Modes/Context	Config	
History	3.2.0300	
Role	admin	
Example	switch (config)# lldp reinit 10 switch (config)#	
Related Commands	show lldp timers	
Note		

lldp timer

lldp timer <seconds>
no lldp timer

Sets the LLDP interval at which LLDP frames are transmitted. (lldpMessageTxInterval)
 The no form of the command sets the parameter to default.

Syntax Description	seconds	5-32768
Default	30	
Modes/Context	Config	
History	3.2.0300	
Role	admin	

Example	switch (config)# lldp timer 10 switch (config)#
Related Commands	show lldp timers
Note	

lldp tx-delay

lldp tx-delay <seconds>
no lldp tx-delay

Indicates the delay in seconds between successive LLDP frame transmissions
The no form of the command sets the parameter to default.

Syntax Description	seconds	1-8192
Default	2	
Modes/Context	Config	
History	3.2.0300	
Role	admin	
Example	switch (config)# lldp tx-delay 10 switch (config)#	
Related Commands	show lldp timers	
Note	The recommended value for the tx-delay is set by the following formula: $1 \leq \text{lldp tx-delay} \leq (0.25 * \text{lldp timer})$	

lldp tx-hold-multiplier

lldp tx-hold-multiplier <seconds>
no lldp tx-hold-multiplier

The time-to-live value expressed as a multiple of the lldpMessageTxInterval object.
The no form of the command sets the parameter to default.

Syntax Description	seconds	1-8192
Default	2	
Modes/Context	Config	
History	3.2.0300	
Role	admin	

Example	switch (config)# lldp tx-hold-multiplier 10 switch (config)#
Related Commands	show lldp timers
Note	The actual time-to-live value used in LLDP frames, can be expressed by the following formula: $TTL = \min(65535, (lldpMessageTxInterval * lldpMessageTxHoldMultiplier))$ For example, if the value of lldpMessageTxInterval is '30', and the value of lldpMessageTxHoldMultiplier is '4', then the value '120' is encoded in the TTL field in the LLDP header.

lldp {receive | transmit}

lldp {receive | transmit}
no lldp {receive | transmit}

Enables LLDP to be received or transmitted on this port.
The no form of the command disables the LLDP to be received or transmitted on this port.

Syntax Description	N/A
Default	Enabled for receive and Transmit.
Modes/Context	Config interface ethernet
History	3.2.0300
Role	admin
Example	switch (config interface ethernet 1/1)# lldp receive switch (config interface ethernet 1/1)# lldp transmit switch (config interface ethernet 1/1)#
Related Commands	show lldp interface
Note	The LLDP is disabled by default (globally)

lldp tlv-select

lldp tlv-select { [port-description] [sys-name] [sys-description] [sys-capabilities] [management-address] all}

Sets the LLDP basic TLVs to be transmitted on this port.

Syntax Description	port-description	LLDP port description TLV
	sys-name	LLDP system name TLV
	sys-description	LLDP system description TLV
	sys-capabilities	LLDP system capabilities TLV
	management-address	LLDP management address TLV
	all	all above TLVs
Default	all	
Modes/Context	Config interface ethernet	
History	3.2.0300	
Role	admin	
Example	<pre>switch (config interface ethernet 1/1)# lldp tlv-select port-descrip- tion sys-name switch (config interface ethernet 1/1)#</pre>	
Related Commands	show lldp interface	
Note		

show lldp local

show lldp local

Shows LLDP local information.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.2.0300
Role	admin
Example	<pre>switch (config)# show lldp local LLDP is Enabled Local global configuration Chassis sub type: macAddress (4) Chassis id: 0002C9030046AF00 System Name: my-switch System Description: SX1036 Supported capabilities: B,R Supported capabilities enabled: B switch (config)#</pre>

Related Commands

Note

show lldp interface

show lldp interface [ethernet <inf>]

Shows LLDP local interface table information.

Syntax Description	inf	Interface number, for example 1/1.								
Default	N/A									
Modes/Context	Any Command Mode									
History	3.2.0300									
Role	admin									
Example	<pre>switch (config)# show lldp interface ethernet 1/1</pre> <p>TLV flags: PD: port-description, SN: sys-name, SD: sys-description, SC: sys-capabilities, MA: management-address</p> <table><tr><th>Interface</th><th>Receive</th><th>Transmit</th><th>TLVs</th></tr><tr><td>Eth1/1</td><td>Enabled</td><td>Enabled</td><td>PD,SN,SD,SC,MA</td></tr></table> <pre>switch (config)#</pre>		Interface	Receive	Transmit	TLVs	Eth1/1	Enabled	Enabled	PD,SN,SD,SC,MA
Interface	Receive	Transmit	TLVs							
Eth1/1	Enabled	Enabled	PD,SN,SD,SC,MA							

Related Commands

Note

show lldp interface ethernet <inf> remote

show lldp interface ethernet <inf> remote

Shows LLDP remote interface table information.

Syntax Description	inf	local interface number, for example 1/1.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.2.0300	
Role	admin	

Example

```
switch (config)# show lldp interface ethernet 1/1

Ethernet 1/1

Remote Index:1
Remote chassis id: 0002C903005C8DB0 ; chassis id subtype: Local(7)
Remote port-id: Eth1/1 ; port id subtype: ifName(5)
Remote port description: Ethernet 1/1
Remote system name: remote-system-name
Remote system description: remote-system-description
Remote system capabilities supported: B; enabled B

switch (config)#
```

Related Commands**Note**

show lldp timers

show lldp timers

Shows LLDP timers configuration

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.2.0300
Role	admin
Example	<pre>switch (config)# show lldp timers msg-tx-interval:30 tx-delay:2 tx-hold:4 tx-reinit-delay:2 switch (config)#</pre>
Related Commands	
Note	

show lldp statistics global

show lldp statistics global

Shows LLDP global statistics

Syntax Description	N/A
---------------------------	-----

Default	N/A
Modes/Context	Any Command Mode
History	3.2.0300
Role	admin
Example	<pre>switch (config)# show lldp timers Remote Table Last Change Time : 10300 Remote Table Inserts : 5 Remote Table Deletes : 0 Remote Table Drops : 0 Remote Table Ageouts : 0 switch (config)#</pre>
Related Commands	
Note	

show lldp statistics [interface ethernet <inf>]

show lldp statistics [interface ethernet <inf>]

Shows LLDP interface statistics

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.2.0300
Role	admin
Example	<pre>switch (config)# show lldp statistics ethernet 1/1 Interface Frames In In TLVs TLVs Ageout Out Discarded Errors Total Discarded Unrecognize Frames ----- Eth 1/1 0 0 10 0 0 0 0 switch (config)#</pre>
Related Commands	
Note	

3.8 Quality of Service

3.8.1 Enhanced Transmission Selection (ETS)

dcb ets enable

dcb ets enable
no dcb ets enable

Sets the switch egress scheduling mode to be weighted round robin.
 The no form of the command sets the switch egress scheduling mode to be strict priority.

Syntax Description	N/A
Default	ETS is enabled.
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config)# dcb ets enable switch (config)# show dcb ets</pre> <p>ETS enabled</p> <pre>TC Bandwidth ----- 0 25% 1 25% 2 25% 3 25%</pre> <p>Number of Traffic Class: 4</p> <pre>switch (config) #</pre>
Related Commands	show dcb ets
Note	

dcb ets tc bandwidth

dcb ets tc bandwidth <tc-0> <tc-1> <tc-2> <tc-3>
no dcb ets tc bandwidth

Configures the bandwidth limit of the traffic class.
 The no form of the command sets the bandwidths per traffic class back to its default.

Syntax Description	tc-i 0-100.
Default	25% per traffic class.
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config)# dcb ets tc bandwidth 20 20 30 30 switch (config) # show dcb ets</pre> <p>ETS enabled</p> <pre>TC Bandwidth ----- 0 20% 1 20% 2 30% 3 30%</pre> <p>Number of Traffic Class: 4</p> <pre>switch (config) #</pre>
Related Commands	show dcb ets
Note	The sum of all traffic class bandwidth must be equal to 100.

vlan map-priority

vlan map priority <priority> traffic-class <tc>
no vlan map priority <priority>

Maps an VLAN user priority to a traffic class.
 The no form of the command sets the mapping back to default.

Syntax Description	N/A
Default	Priority 0,1 mapped to tc 0. Priority 2,3 mapped to tc 1. Priority 4,5 mapped to tc 2. Priority 6,7 mapped to tc 3.

Modes/Context	Config interface ethernet
History	3.1.0000
Role	admin
Example	switch (config interface ethernet 1/1) # vlan map-priority 1 traffic-class 2 switch (config interface ethernet 1/1) #
Related Commands	show dcb ets interface
Note	

show dcb ets

show dcb ets

Displays ETS configuration and operational data.

Syntax Description													
Default	ETS is enabled.												
Modes/Context	Any Command Mode												
History	3.1.0000												
Role	admin												
Example	switch (config)# show dcb ets ETS enabled <table> <tr> <th>TC</th><th>Bandwidth</th></tr> <tr> <td colspan="2">-----</td></tr> <tr> <td>0</td><td>25%</td></tr> <tr> <td>1</td><td>25%</td></tr> <tr> <td>2</td><td>25%</td></tr> <tr> <td>3</td><td>25%</td></tr> </table> Number of Traffic Class: 4 switch (config) #	TC	Bandwidth	-----		0	25%	1	25%	2	25%	3	25%
TC	Bandwidth												

0	25%												
1	25%												
2	25%												
3	25%												
Related Commands													
Note													

show dcb ets interface

show dcb ets interface <type> <number>

Displays ETS configuration and operational data, per interface.

Syntax Description	type	ethernet or port-channel
	number	interface number, i.e. 1/1
Default	ETS is enabled.	
Modes/Context	Any Command Mode	
History	3.1.0000	
Role	admin	

Example

```
switch (config)# show dcb ets interface ethernet 1/1
```

```
ETS Port Mode           :ON MODE
ETS Oper State          :INIT STATE
ETS State Machine Type  :Assymetric
```

```
-----
ETS Local Port Info
-----
```

```
TC bandwidth table
-----
```

TC	Bandwidth	RecomBandwidth
0	25%	25%
1	25%	25%
2	25%	25%
3	25%	25%

```
-----
priority assignment table
-----
```

Priority	TC
0	0
1	0
2	1
3	1
4	2
5	2
6	3
7	3

```
-----
Number of Traffic Class: 4
-----
```

```
Willing Status: Disable
-----
```

```
ETS Admin Port Info
-----
```

TC	Bandwidth	RecomBandwidth
0	30%	30%
1	30%	30%
2	30%	30%
3	10%	10%

```
-----
ETS Remote Port Info
-----
```

```
No Remote Entry is Present
-----
```

```
switch (config) #
```

Related Commands**Note**

3.8.2 Priority Flow Control (PFC)

dcb priority-flow-control enable

dcb priority-flow-control enable
no dcb priority-flow-control enable

Enables PFC globally on the switch.
 The no form of the command globally disables PFC on the switch.

Syntax Description	N/A																																	
Default	PFC is disabled.																																	
Modes/Context	Config																																	
History	3.1.0000																																	
Role	admin																																	
Example	<pre>switch (config)# dcb priority-flow-control enable switch (config)# show dcb priority-flow-control</pre> <p>PFC enabled Priority Enabled List : Priority Disabled List :0 1 2 3 4 5 6 7</p> <table><tr><td>TC</td><td>Lossless</td></tr><tr><td>---</td><td>-----</td></tr><tr><td>0</td><td>N</td></tr><tr><td>1</td><td>Y</td></tr><tr><td>2</td><td>Y</td></tr><tr><td>3</td><td>N</td></tr></table> <table><tr><td>Interface</td><td>PFC admin</td><td>PFC oper</td></tr><tr><td>-----</td><td>-----</td><td>-----</td></tr><tr><td>1/1</td><td>Disabled</td><td>Disabled</td></tr><tr><td>1/2</td><td>Disabled</td><td>Disabled</td></tr><tr><td>1/3</td><td>Disabled</td><td>Disabled</td></tr><tr><td>1/4</td><td>Disabled</td><td>Disabled</td></tr><tr><td>...</td><td></td><td></td></tr></table> <pre>switch (config) #</pre>	TC	Lossless	---	-----	0	N	1	Y	2	Y	3	N	Interface	PFC admin	PFC oper	-----	-----	-----	1/1	Disabled	Disabled	1/2	Disabled	Disabled	1/3	Disabled	Disabled	1/4	Disabled	Disabled	...		
TC	Lossless																																	
---	-----																																	
0	N																																	
1	Y																																	
2	Y																																	
3	N																																	
Interface	PFC admin	PFC oper																																
-----	-----	-----																																
1/1	Disabled	Disabled																																
1/2	Disabled	Disabled																																
1/3	Disabled	Disabled																																
1/4	Disabled	Disabled																																
...																																		
Related Commands	show dcb priority-flow-control																																	
Note																																		

dcb priority-flow-control priority

dcb priority-flow-control priority <prio> enable
no dcb priority-flow-control priority <prio> enable

Enables PFC per priority on the switch.
 The no form of the command disables PFC per priority on the switch.

Syntax Description	prio0-7.																																	
Default	PFC is disabled for all priorities.																																	
Modes/Context	Config																																	
History	3.1.0000																																	
Role	admin																																	
Example	<pre>switch (config)# dcb priority-flow-control priority 0 enable switch (config)# show dcb priority-flow-control</pre> <p>PFC enabled Priority Enabled List : 0 Priority Disabled List : 1 2 3 4 5 6 7</p> <table><tr><td>TC</td><td>Lossless</td></tr><tr><td>---</td><td>-----</td></tr><tr><td>0</td><td>N</td></tr><tr><td>1</td><td>Y</td></tr><tr><td>2</td><td>Y</td></tr><tr><td>3</td><td>N</td></tr></table> <table><tr><td>Interface</td><td>PFC admin</td><td>PFC oper</td></tr><tr><td>-----</td><td>-----</td><td>-----</td></tr><tr><td>1/1</td><td>Disabled</td><td>Disabled</td></tr><tr><td>1/2</td><td>Disabled</td><td>Disabled</td></tr><tr><td>1/3</td><td>Disabled</td><td>Disabled</td></tr><tr><td>1/4</td><td>Disabled</td><td>Disabled</td></tr><tr><td>...</td><td></td><td></td></tr></table> <pre>switch (config) #</pre>	TC	Lossless	---	-----	0	N	1	Y	2	Y	3	N	Interface	PFC admin	PFC oper	-----	-----	-----	1/1	Disabled	Disabled	1/2	Disabled	Disabled	1/3	Disabled	Disabled	1/4	Disabled	Disabled	...		
TC	Lossless																																	
---	-----																																	
0	N																																	
1	Y																																	
2	Y																																	
3	N																																	
Interface	PFC admin	PFC oper																																
-----	-----	-----																																
1/1	Disabled	Disabled																																
1/2	Disabled	Disabled																																
1/3	Disabled	Disabled																																
1/4	Disabled	Disabled																																
...																																		
Related Commands	show dcb priority-flow-control																																	
Note																																		

dcb priority-flow-control mode on

dcb priority-flow-control mode on
no dcb priority-flow-control mode

Enables PFC per interface.
 The no form of the command disables PFC per interface.

Syntax Description	N/A																																	
Default	PFC is disabled for all interfaces.																																	
Modes/Context	Config interface ethernet Config Interface Port Channel																																	
History	3.1.0000																																	
Role	admin																																	
Example	<pre>switch (config interface ethernet 1/1) # dcb priority-flow-control mode on switch (config interface ethernet 1/1) # show dcb priority-flow-control</pre> <p>PFC enabled Priority Enabled List : 0 Priority Disabled List : 1 2 3 4 5 6 7</p> <table><tr><th>TC</th><th>Lossless</th></tr><tr><td>---</td><td>-----</td></tr><tr><td>0</td><td>N</td></tr><tr><td>1</td><td>Y</td></tr><tr><td>2</td><td>Y</td></tr><tr><td>3</td><td>N</td></tr></table> <table><tr><th>Interface</th><th>PFC admin</th><th>PFC oper</th></tr><tr><td>-----</td><td>-----</td><td>-----</td></tr><tr><td>1/1</td><td>On</td><td>Enabled</td></tr><tr><td>1/2</td><td>Disabled</td><td>Disabled</td></tr><tr><td>1/3</td><td>Disabled</td><td>Disabled</td></tr><tr><td>1/4</td><td>Disabled</td><td>Disabled</td></tr><tr><td>...</td><td></td><td></td></tr></table> <pre>switch (config) #</pre>	TC	Lossless	---	-----	0	N	1	Y	2	Y	3	N	Interface	PFC admin	PFC oper	-----	-----	-----	1/1	On	Enabled	1/2	Disabled	Disabled	1/3	Disabled	Disabled	1/4	Disabled	Disabled	...		
TC	Lossless																																	
---	-----																																	
0	N																																	
1	Y																																	
2	Y																																	
3	N																																	
Interface	PFC admin	PFC oper																																
-----	-----	-----																																
1/1	On	Enabled																																
1/2	Disabled	Disabled																																
1/3	Disabled	Disabled																																
1/4	Disabled	Disabled																																
...																																		
Related Commands	show dcb priority-flow-control																																	
Note																																		

show dcb priority-flow-control

show dcb priority-flow-control [interface <type> <inf>] [detail]

Displays DCB priority flow control configuration and status.

Syntax Description	type	<ul style="list-style-type: none"> ethernet port-channel
	inf	The interface number.
	detail	Adds details information to the show output.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.0000	
Role	admin	
Example	<pre>switch (config interface ethernet 1/1) # show dcb priority-flow-control PFC enabled Priority Enabled List : 0 Priority Disabled List : 1 2 3 4 5 6 7 TC Lossless --- - 0 N 1 Y 2 Y 3 N Interface PFC admin PFC oper ----- 1/1 On Enabled 1/2 Disabled Disabled 1/3 Disabled Disabled 1/4 Disabled Disabled ... switch (config) #</pre>	

Related Commands

Note

3.9 Access Control List

ipv4/mac access-list

{ipv4 | mac} access-list <acl-name>
no {ipv4 | mac} access-list <acl-name>

Creates a MAC or IPv4 ACL and enter the ACL configuration mode.
 The no form of the command deletes the ACL.

Syntax Description	ipv4 mac	IPv4 or MAC - access list.
	acl-name	User defined string for the ACL.
Default	No ACL available by default.	
Modes/Context	Config	
History	3.1.1400	
Role	admin	
Example	<pre>switch (config)# mac access-list my-mac-list switch (config mac access-list my-mac-list)#</pre>	
Related Commands	ipv4/port access-group	
Note		

ipv4/mac port access-group

{ipv4 | mac} port access-list <acl-name>
no {ipv4 | mac} port access-list <acl-name>

Binds an ACL to the interface.
 The no form of the command unbinds the ACL from the interface.

Syntax Description	ipv4 mac	IPv4 or MAC - access list.
	acl-name	ACL name.
Default	No ACL is bind by default.	
Modes/Context	Config interface ethernet Config Interface Port Channel	
History	3.1.1400	
Role	admin	

Example	switch (config interface ethernet 1/1) # mac port access-group my-list switch (config interface ethernet 1/1) #
Related Commands	ipv4/mac access-list
Note	The access control list should be defined prior to the binding action.

deny/permit (MAC ACL rule)

**[seq-number <sequence-number>] {deny|permit} {any | <source-mac> [mask <mac>]} {any | <destination-mac> [mask <mac>]} [protocol <protocol>] [cos <cos-value>] [vlan <vlan-id>] [action <action-id>]
no <sequence-number>**

Creates a rule for MAC ACL.

The no form of the command deletes a rule from the MAC ACL.

Syntax Description	sequence-number	Optional parameter to set a specific sequence number for the rule. The range is:1-500.
	deny permit	Determines the type of the rule, denies or permits action.
	{any <source-mac> [mask <mac>]}	Sets source MAC and optionally sets a mask for that MAC. The “any” option will cause the rule not to check the source MAC.
	{any <destination-mac> [mask <mac>]}	Sets destination MAC and optionally sets a mask for that MAC. The “any” option will cause the rule not to check the destination MAC.
	protocol	Sets the Ethertype field value from the MAC address. Possible range is: 0x0000-0xffff.
	cos-value	Sets the COS (priority bits) field, possible range is: 0-7.
	vlan-id	Sets the VLAN ID field, possible range is 0-4095.
Default	No rule is added by default to access control list. Default sequence number is in multiple of 10.	
Modes/Context	Config MAC ACL	
History	3.1.1400	
Role	admin	
Example	switch (config mac access-list my-list) # seq-number 10 deny 0a:0a:0a:0a:0a:0a mask ff:ff:ff:ff:ff:ff any vlan 6 cos 2 protocol 80 switch (config mac access-list my-list) #	

Related Commands	ipv4/mac access-list ipv4/mac port access-group
-------------------------	--

Note

deny/permit (IPv4 ACL rule)

```
[seq-number <sequence-number>] {permit | deny} ip {<source-ip> [mask <ip>] |
[any]} {<dest-ip> [mask <ip>] | [any]} [action <action-id>]
no <sequence-number>
```

Creates a rule for IPv4 ACL.
The no form of the command deletes a rule from the IPv4 ACL.

Syntax Description	sequence-number	Optional parameter to set a specific sequence number for the rule. The range is:1-500.
	deny permit	Determines the type of the rule, deny or permit action.
	{any <source-ip> [mask <ip>]}	Sets source IP and optionally sets a mask for that IP address. The “any” option will cause the rule not to check the source IP.
	{any <destination-ip> [mask <ip>]}	Sets destination IP and optionally sets a mask for that MAC. The “any” option will cause the rule not to check the destination MAC.
Default	No rule is added by default to access control list. Default sequence number is in multiple of 10.	
Modes/Context	Config IPv4 ACL	
History	3.1.1400	
Role	admin	
Example	switch (config ipv4 access-list my-list) # seq-number 10 deny ip any any switch (config ipv4 access-list my-list) #	
Related Commands	ipv4/mac access-list ipv4/mac port access-group	
Note		

deny/permit (IPv4 TCP/UDP ACL rule)

```
[seq-number <sequence-number>] {permit | deny} {tcp | udp} {<source-ip>
[mask <ip>] | [any]} {<dest-ip> [mask <ip>] | [any]} [eq-source <port-number>]
[eq-destination <port-number>] [action <action-id>]
no <sequence-number>
```

Creates a rule for IPv4 UDP/TCP ACL.

The no form of the command deletes a rule from the ACL.

Syntax Description	sequence-number	Optional parameter to set a specific sequence number for the rule. The range is:1-500.
	deny permit	Determines the type of the rule, deny or permit action.
	tcp udp	UDP or TCP rule transport type.
	{any <source-ip> [mask <ip>]}	Sets source IP and optionally sets a mask for that IP address. The “any” option will cause the rule not to check the source IP.
	{any <destination-ip> [mask <ip>]}	Sets destination IP and optionally sets a mask for that MAC. The “any” option will cause the rule not to check the destination MAC.
	[eq-source <port-number>]	TCP/UDP source port number. Range is 0-65535.
	[eq-destination <port-number>]	TCP/UDP destination port number. Range is 0-65535.
Default	No rule is added by default to access control list. Default sequence number is in multiple of 10.	
Modes/Context	Config IPv4 ACL	
History	3.1.1400	
Role	admin	
Example	<pre>switch (config ipv4 access-list my-list) # seq-number 10 deny tcp any any eq-source 1200 switch (config ipv4 access-list my-list) #</pre>	
Related Commands	<pre>ipv4/mac access-list ipv4/mac port access-group</pre>	
Note		

access-list action

access-list action <action-profile-name>
no access-list action <action-profile-name>

Creates access-list action profile and entering the action profile configuration mode.
 The no form of the command deletes the action profile.

Syntax Description	action-profile-name	given name for the profile.
Default	N/A	
Modes/Context	Config	
History	3.2.0230	
Role	admin	
Example	<pre>switch (config)# access-list action my-action switch (config access-list action my-action)# show access-list action my-action Access-list Action my-action Mapped_Vlan_ID Mapped_port Counter_set Policer_ID ===== N/A N/A N/A N/A switch (config access-list action my-action)#</pre>	
Related Commands		
Note		

vlan-map

vlan-map <vlan-id>
no vlan-map

Adds action to map a new VLAN to the packet (in the ingress port or VLAN).
 The no form of the command removes the action to map a new VLAN.

Syntax Description	vlan-is	1-4096.
Default	N/A	
Modes/Context	Config	
History	3.2.0230	
Role	admin	

Example

```
switch (config access-list action my-action)# vlan-map 10
switch (config access-list action my-action)# show access-list action
my-action
Access-list Action my-action
Mapped_Vlan_ID |Mapped_port |Counter_set |Policer_ID |
=====
10              |N/A          |N/A          |N/A          |
switch (config access-list action my-action)#
```

Related Commands**Note****show access-list action**

show access-list action {<action-profile-name> | summary}

Displays the access-list action profiles summary.

Syntax Description	action-profile-name	Filter the table according to the action profile name.
	summary	Display summary of the action list.
Default	N/A	
Modes/Context	Config	
History	3.2.0230	
Role	admin	
Example	<pre>switch (config access-list action my-action)# show access-list action my-action Access-list Action my-action Mapped_Vlan_ID Mapped_port Counter_set Policer_ID ===== 10 N/A N/A N/A switch (config access-list action my-action)#</pre>	

Related Commands**Note**

show mac/ipv4 access-lists

show [mac |ipv4 |] access-lists <access-list-name>

Displays the list of rules for the MAC/IPv4 ACL.

Syntax Description	ipv4 mac	IPv4 or MAC - access list.
	access-list-name	ACL name.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.1400	
Role	admin	
Example	<pre>switch (config mac access-list my-list) # show mac access-lists my-list mac access-list my-list seq-number p/d smac dmac protocol cos vlan ===== 10 deny any any 0800 3 3 20 deny any any 80 2 6 switch (config mac access-list my-list) #</pre>	
Related Commands	deny/permit (MAC ACL rule) deny/permit (IPv4 ACL rule) deny/permit (IPv4 TCP/UDP ACL rule) ipv4/mac access-list ipv4/mac port access-group	
Note		

show mac/ipv4 access-lists summary

show [mac |ipv4 |] access-lists summary

Displays the summary of number of rules per ACL, and the interfaces attached.

Syntax Description	ipv4 mac	IPv4 or MAC - Access list
	access-list-name	ACL name
Default	N/A	
Modes/Context	Any Command Mode	
History	3.1.1400	
Role	admin	

Example

```
switch (config) # show mac access-lists summary
mac access-list my-list
  Total ACEs Configured: 2
  Configured on interfaces:
    Ethernet 1/1
    Ethernet 1/2
switch (config) #
```

Related Commands

deny/permit (MAC ACL rule)
deny/permit (IPv4 ACL rule)
deny/permit (IPv4 TCP/UDP ACL rule)
ipv4/mac access-list
ipv4/mac port access-group

Note

4 IP Routing

4.1 General

ip routing

ip routing
no ip routing

Enables L3 capabilities: IP router interfaces, static routing and routing protocols. The no form of the command disables L3 capabilities, however does not delete the L3 configuration.

Syntax Description	N/A
Default	IP routing is disabled
Modes/Context	Config
History	3.2.0230
Role	admin
Example	switch (config) # ip routing switch (config) #
Related Commands	interface vlan show ip routing
Note	<ul style="list-style-type: none"> This command requires L3 license (i.e.LIC-1036-L3) Disabling the command does not remove the feature configuration

show ip routing

show ip routing

Displays IP routing admin state.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.2.0230
Role	admin
Example	switch (config) # show ip routing IP routing: enabled switch (config) #

Related Commands	ip routing
-------------------------	------------

Note	
-------------	--

4.2 IP Interface

interface vlan

interface vlan <vlan-id>
no interface vlan <vlan-id>

Creates a VLAN interface and enters the interface VLAN configuration mode.
 The no form of the command deletes the VLAN interface.

Syntax Description	<div> <div>vlan-id</div> <div>A numeric range of 1-4094</div> </div>
Default	N/A
Modes/Context	Config
History	3.2.0230
Role	admin
Example	<pre>switch (config) # interface vlan 10 switch (config interface vlan 10) # show interfaces vlan 10 Vlan 10 Admin state: Enabled Operational state: Down (no up member port) Mac Address: 00:02:c9:5d:e0:f0 Internet Address: 0.0.0.0/0 Broadcast address: 255.255.255.255 MTU: 1522 bytes Description: N/A switch (config interface vlan 10) #</pre>
Related Commands	ip routing vlan <vlan-id> switchport mode switchport access show interfaces vlan
Note	<ul style="list-style-type: none"> Make sure the VLAN was created, using the command “vlan <vlan-id>” in the global configuration mode The VLAN must be assigned to one of the L2 interfaces. To do so, run the command “switchport ...” At least one interface belong to that VLAN must be in UP state

ip address

ip address <ip-address> <mask>
no ip address <ip-address> <mask>

Enters user-defined description for the interface.

Syntax Description	ip-address	IPv4 address
	mask	There are two possible ways to the mask: <ul style="list-style-type: none"> • /length (i.e. /24) • Network address (i.e. 255.255.255.0)
Default	0.0.0.0/0	
Modes/Context	Config vlan interface	
History	3.2.0230	
Role	admin	
Example	<pre>switch (config interface vlan 10) # ip address 10.10.10.10 /24 switch (config interface vlan 10) # show interfaces vlan 10 Vlan 10 Admin state: Enabled Operational state: Down (no up member port) Mac Address: 00:02:c9:5d:e0:f0 Internet Address: 10.10.10.10/24 Broadcast address: 10.10.10.255 MTU: 1522 bytes Description: my-ip-interface switch (config) #</pre>	
Related Commands	interface vlan	
Note		

counters

counters
no counters

Enables counters gathering on the IP interface.
The no form of the command disables counters gathering on the IP interface.

Syntax Description	N/A
Default	counters are disabled.
Modes/Context	Config vlan interface
History	3.2.0230

Role	admin
Example	<pre> switch (config) # interface vlan 10 switch (config interface vlan 10) # counters switch (config interface vlan 10) # show interfaces vlan 10 Vlan 10 Admin state: Enabled Operational state: Down (no up member port) Mac Address: 00:02:c9:5d:e0:f0 Internet Address: 0.0.0.0/0 Broadcast address: 255.255.255.255 MTU: 1522 bytes Description: N/A RX 0 Unicast frames 0 Multicast frames 0 Unicast octets 0 Multicast octets 0 Error frames 0 Error octets TX 0 Unicast frames 0 Multicast frames 0 Unicast octets 0 Multicast octets switch (config) # </pre>
Related Commands	interface vlan
Note	<ul style="list-style-type: none"> Enabling counters for the router interface adds delay to the traffic stream There are maximum of 16 counter sets

description

description <string>
no description

Enters a description for the interface.
The no form of the command sets the description to default.

Syntax Description	string	user defined string
Default	""	
Modes/Context	Config vlan interface	
History	3.2.0230	
Role	admin	

Example

```
switch (config interface vlan 10) #description my-ip-interface
switch (config interface vlan 10) #show interfaces vlan 10

Vlan 10
  Admin state: Enabled
  Operational state: Down (no up member port)
  Mac Address: 00:02:c9:5d:e0:f0
  Internet Address: 0.0.0.0/0
  Broadcast address: 255.255.255.255
  MTU: 1522 bytes
  Description: my-ip-interface

switch (config) #
```

Related Commands

interface vlan

Note**mtu**

mtu <size>
no mtu

Sets the MTU for the interface.
 The no form of the command sets the MTU to default.

Syntax Description	size	1518-9216
Default	1522	
Modes/Context	Config vlan interface	
History	3.2.0230	
Role	admin	
Example	<pre>switch (config interface vlan 10)# mtu 9216 switch (config interface vlan 10 # show interfaces vlan 10 Vlan 10 Admin state: Enabled Operational state: Down (no up member port) Mac Address: 00:02:c9:5d:e0:f0 Internet Address: 10.10.10.10/24 Broadcast address: 10.10.10.255 MTU: 9216 bytes Description: my-ip-interface switch (config interface vlan 10)#</pre>	
Related Commands	interface vlan	
Note		

shutdown

shutdown
no shutdown

Disables the interface.
 The no form of the command enables the interface.

Syntax Description	N/A
Default	The interface is enabled.
Modes/Context	Config vlan interface
History	3.1.0000
Role	admin
Example	<pre>switch (config interface vlan 20) # shutdown switch (config interface vlan 20) # show interfaces vlan 20 Vlan 20 Admin state: Disabled Operational state: Down (admin down) Mac Address: 00:02:c9:5d:e0:f0 Internet Address: 0.0.0.0/0 Broadcast address: 255.255.255.255 MTU: 1522 bytes Description: N/A switch (config interface vlan 20) #</pre>
Related Commands	interface vlan
Note	

clear counters

clear counters

Clears the interface counters.

Syntax Description	N/A
Default	N/A
Modes/Context	Config vlan interface
History	3.2.0230
Role	admin
Example	<pre>switch (config interface vlan 10) # clear counters switch (config interface vlan 10) #</pre>

Related Commands	interface vlan counters
-------------------------	----------------------------

Note

show interfaces vlan

show interfaces vlan [<vlan-ID> | status]

Displays the interface VLAN configuration and status per VLAN or as a summarized list.

Syntax Description	vlan-id	A numeric range of 1-4094
	status	Displays a summarized status table.
Default	N/A	
Modes/Context	Any Command Mode	
History	3.2.0230	
Role	admin	
Example	switch (config) # show interfaces vlan status	

Related Commands	interface vlan
Note	Byte counters count octets starting from the IP header field, it doesn't count the L2 header (MAC, VLAN) and FCS length.

4.3 Routing and ECMP

ip route

ip route <IP prefix> <netmask> <next hop IP address>
no ip route <IP prefix> <netmask> <next hop IP address>

Sets a static route.

The no form of the command deletes the static route

Syntax Description	IP address	IPv4 address
	netmask	There are two possible ways to the mask: <ul style="list-style-type: none"> • /length (i.e. /24) • Network address (i.e. 255.255.255.0)
	next hope IP address	IPv4 address of the next hop.
Default	N/A	
Modes/Context	Config	
History	3.1.0000	
Role	admin	

Example

```
switch (config) # ip route 10.10.10.0 /24 172.28.2.4
switch (config) # show ip route
Destination      Mask           Gateway        Interface      Source
default          0.0.0.0        172.28.0.1     mgmt0          DHCP
10.10.10.0       255.255.255.0  172.28.2.4     mgmt0          static
172.28.0.0       255.255.0.0    0.0.0.0        mgmt0          direct
1.0.0.0          255.255.255.0  0.0.0.0        Vlan11         direct
2.0.0.0          255.255.255.0  0.0.0.0        Vlan12         direct
3.0.0.0          255.255.255.0  0.0.0.0        Vlan13         direct
4.0.0.0          255.255.255.0  0.0.0.0        Vlan14         direct
8.8.8.0          255.255.255.0  0.0.0.0        Vlan1          direct
7.7.7.0          255.255.255.0  1.0.0.2        Vlan11         static
                  2.0.0.2        Vlan12         static
                  4.0.0.2        Vlan14         static
                  3.0.0.2        Vlan13         static

switch (config) #
```

Related Commands	interface vlan ip load sharing show ip route
Note	The IP prefix and the network mask must be aligned in the LSB mask, (for example 192.168.0.0 /16 or 192.168.10.0 /24, or 192.168.10.10 /32)

ip load-sharing

ip load-sharing <type>
no ip load-sharing

This command sets the ECMP load sharing mode.
The no form of the command sets the load-sharing to default.

Syntax Description	type <ul style="list-style-type: none"> • source-ip-port • destination-ip-port • source-destination-ip-port • traffic-class • all
Default	all
Modes/Context	Config
History	3.2.0230
Role	admin
Example	switch (config) # ip load-sharing all switch (config) # show ip load-sharing Load sharing: all switch (config)
Related Commands	ip route
Note	

show ip route

show ip route

Displays the route table.

Syntax Description	N/A
---------------------------	-----

Default	N/A
Modes/Context	Any Command Mode
History	3.1.0000
Role	admin
Example	<pre>switch (config) # show ip route Destination Mask Gateway Interface Source default 0.0.0.0 172.28.0.1 mgmt0 DHCP 10.10.10.0 255.255.255.0 172.28.2.4 mgmt0 static 172.28.0.0 255.255.0.0 0.0.0.0 mgmt0 direct 1.0.0.0 255.255.255.0 0.0.0.0 Vlan11 direct 2.0.0.0 255.255.255.0 0.0.0.0 Vlan12 direct 3.0.0.0 255.255.255.0 0.0.0.0 Vlan13 direct 4.0.0.0 255.255.255.0 0.0.0.0 Vlan14 direct 8.8.8.0 255.255.255.0 0.0.0.0 Vlan1 direct 7.7.7.0 255.255.255.0 1.0.0.2 Vlan11 static 2.0.0.2 2.0.0.2 Vlan12 static 4.0.0.2 4.0.0.2 Vlan14 static 3.0.0.2 3.0.0.2 Vlan13 static switch (config) #</pre>
Related Commands	ip route
Note	ECMP routes are displayed in an aggregated manner.

show ip load-sharing

show ip load-sharing

Displays ECMP hash attribute.

Syntax Description	N/A
Default	N/A
Modes/Context	Any Command Mode
History	3.2.0230
Role	admin
Example	<pre>switch (config) # show ip load-sharing Load sharing: all switch (config) #</pre>
Related Commands	ip load-sharing
Note	

4.4 Network to Media Resolution (ARP)

ip arp

ip arp <ip-address> <MAC-address>

no ip arp <ip-address>

Adds static ARP entry for the defined interface.

The no form of the command deletes the static ARP entry from the interface.

Syntax Description	IP address	IPv4 Address
	Mac-address	Mac address (format XX:XX:XX:XX:XX:XX)
Default	No static ARP entries	
Modes/Context	Config vlan interface	
History	3.2.0230	
Role	admin	
Example	<pre>switch (config interface vlan 11) # ip arp 1.0.0.3 00:11:22:33:44:55 switch (config interface vlan 11) # show ip arp ARP Timeout: 2000 Total number of entries: 55 IP Address MAC Address Interface 1.0.0.2 00:02:c9:5c:30:40 Vlan11 1.0.0.3 00:11:22:33:44:55 Vlan11 2.0.0.2 00:02:c9:5c:30:40 Vlan12 3.0.0.2 00:02:c9:5c:30:40 Vlan13 4.0.0.2 00:02:c9:5c:30:40 Vlan14 switch (config interface vlan 11) #</pre>	
Related Commands	show ip arp	
Note		

ip arp timeout

ip arp timeout <timeout-value>

no ip arp timeout

Sets the dynamic arp cache timeout.

The no form of the command sets the timeout to default.

Syntax Description	timeout-value	Time (in seconds) that an entry remains in the ARP cache. Valid values are from 60 to 28800.
Default	1500 seconds	

Modes/Context	Config
History	3.2.0230
Role	admin
Example	<pre>switch (config) # ip arp timeout 2000 switch (config) # show ip arp ARP Timeout: 2000 Total number of entries: 55 IP Address MAC Address Interface 1.0.0.2 00:02:c9:5c:30:40 Vlan11 1.0.0.3 00:11:22:33:44:55 Vlan11 2.0.0.2 00:02:c9:5c:30:40 Vlan12 3.0.0.2 00:02:c9:5c:30:40 Vlan13 4.0.0.2 00:02:c9:5c:30:40 Vlan14 switch (config) #</pre>
Related Commands	<pre>ip arp show ip arp</pre>
Note	

clear ip arp

clear ip arp {[vlan <vlan-id>] | [<IP-address>]}

Clears dynamic arp entries from the ARP table with possible filters.

Syntax Description	vlan-id	Clears dynamic ARP entries only for a specific VLAN, range 1-4094
	IP address	Clears dynamic ARP entries for a specific IP address.
Default	N/A	
Modes/Context	Config	
History	3.2.0230	
Role	admin	
Example	<pre>switch (config) # clear ip arp switch (config) #</pre>	
Related Commands	ip arp	
Note		

show ip arp

show ip arp [count]

Displays the ARP table.

Syntax Description	count	show ARP table size (inband and out or band)		
Default	N/A			
Modes/Context	Any Command Mode			
History	3.2.0230			
Role	admin			
Example	<pre>switch (config) # show ip arp ARP Timeout: 1500 Total number of entries: 9 Address Type MAC Address Interface 10.209.1.105 Dynamic 00:02:C9:5E:0B:56 mgmt0 10.209.1.168 Dynamic 00:02:C9:5E:C3:28 mgmt0 10.209.0.1 Dynamic 00:00:5E:00:01:01 mgmt0 10.209.1.226 Dynamic 00:02:C9:62:6A:54 mgmt0 1.1.1.1 Static 00:00:00:00:00:01 Vlan1 1.1.2.1 Static 00:00:00:00:00:02 Vlan1 1.1.3.1 Static 00:00:00:00:00:03 Vlan1 1.1.4.1 Static 00:00:00:00:00:04 Vlan1 1.1.5.1 Static 00:00:00:00:00:05 Vlan1 ARP Timeout: 1500 switch (config) # show ip arp count ARP Table size: 9 (inband:5, out of band:4) switch (config) #</pre>			
Related Commands	<pre>ip arp ip arp timeout</pre>			
Note				

4.5 IP Diagnostic Tools

ping

ping [-LRUbdnqrvVaA] [-c count] [-i interval] [-w deadline] [-p pattern] [-s packetsize] [-t ttl] [-I interface or address] [-M mtu discovery hint] [-S sndbuf] [-T timestamp option] [-Q tos] [hop1 ...] destination

Sends ICMP echo requests to a specified host.

Syntax Description	Linux Ping options
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # ping 172.30.2.2 PING 172.30.2.2 (172.30.2.2) 56(84) bytes of data. 64 bytes from 172.30.2.2: icmp_seq=1 ttl=64 time=0.703 ms 64 bytes from 172.30.2.2: icmp_seq=2 ttl=64 time=0.187 ms 64 bytes from 172.30.2.2: icmp_seq=3 ttl=64 time=0.166 ms 64 bytes from 172.30.2.2: icmp_seq=4 ttl=64 time=0.161 ms 64 bytes from 172.30.2.2: icmp_seq=5 ttl=64 time=0.153 ms 64 bytes from 172.30.2.2: icmp_seq=6 ttl=64 time=0.144 ms ^C --- 172.30.2.2 ping statistics --- 6 packets transmitted, 6 received, 0% packet loss, time 5004ms rtt min/avg/max/mdev = 0.144/0.252/0.703/0.202 ms switch (config) #</pre>
Related Commands	traceroute
Note	<ul style="list-style-type: none"> • Ping to IPv6 address is not supported. • When using -I option use the interface name + interface number, for example “ping -I vlan10”

traceroute

traceroute [-46dFITUnrAV] [-f first_ttl] [-g gate,...] [-i device] [-m max_ttl] [-N squeries] [-p port] [-t tos] [-l flow_label] [-w waittime] [-q nqueries] [-s src_addr] [-z sendwait] host [packetlen]

Traces the route packets take to a destination.

Syntax Description	<code>-4</code>	Uses IPv4.
	<code>-6</code>	Uses IPv6
	<code>-d</code>	Enables socket level debugging.
	<code>-F</code>	Sets DF (don't fragment bit) on.
	<code>-I</code>	Uses ICMP ECHO for tracerouting.
	<code>-T</code>	Uses TCP SYN for tracerouting.
	<code>-U</code>	Uses UDP datagram (default) for tracerouting.
	<code>-n</code>	Does not resolve IP addresses to their domain names.
	<code>-r</code>	Bypasses the normal routing and send directly to a host on an attached network.
	<code>-A</code>	Performs AS path lookups in routing registries and print results directly after the corresponding addresses.
	<code>-V</code>	Prints version info and exit.
	<code>-f</code>	Starts from the <code>first_ttl</code> hop (instead from 1).
	<code>-g</code>	Routes packets throw the specified gateway (maximum 8 for IPv4 and 127 for IPv6).
	<code>-i</code>	Specifies a network interface to operate with.
	<code>-m</code>	Sets the max number of hops (max TTL to be reached). Default is 30.
	<code>-N</code>	Sets the number of probes to be tried simultaneously (default is 16).
	<code>-p</code>	Uses destination port. It is an initial value for the UDP destination port (incremented by each probe, default is 33434), for the ICMP seq number (incremented as well, default from 1), and the constant destination port for TCP tries (default is 80).
	<code>-t</code>	Sets the TOS (IPv4 type of service) or TC (IPv6 traffic class) value for outgoing packets.
	<code>-l</code>	Uses specified <code>flow_label</code> for IPv6 packets.
	<code>-w</code>	Sets the number of seconds to wait for response to a probe (default is 5.0). Non-integer (float point) values allowed too.
	<code>-q</code>	Sets the number of probes per each hop. Default is 3.
	<code>-s</code>	Uses source <code>src_addr</code> for outgoing packets.
	<code>-z</code>	Sets minimal time interval between probes (default is 0). If the value is more than 10, then it specifies a number in milliseconds, else it is a number of seconds (float point values allowed too).

Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin
Example	<pre>switch (config) # traceroute 192.168.10.70 traceroute to 192.168.10.70 (192.168.10.70), 30 hops max, 40 byte packets 1 172.30.0.1 (172.30.0.1) 3.632 ms 2.849 ms 3.544 ms 2 10.222.128.46 (10.222.128.46) 3.176 ms 3.289 ms 3.656 ms 3 10.158.128.30 (10.158.128.30) 15.331 ms 15.819 ms 16.388 ms 4 10.158.128.65 (10.158.128.65) 20.468 ms 7.893 ms 12.27 ms 5 10.7.34.115 (10.7.34.115) 16.405 ms 11.985 ms 12.264 ms 6 192.168.10.70 (192.168.10.70) 16.377 ms 16.091 ms 20.475 ms switch (config) #</pre>
Related Commands	
Note	<ul style="list-style-type: none"> • Traceroute for IPv6 is not supported • The following flags are not supported: -6, -l, -A • When using -i option use the interface name + interface number, for example “traceroute -i vlan10”

tcpdump

```
tcpdump [-aAdefILnNOPqRStuUvxX] [-c count] [-C file_size]
        [-E algo:secret] [-F file] [-i interface] [-M secret]
        [-r file] [-s snaplen] [-T type] [-w file]
        [-W filecount] [-y datalinktype] [-Z user]
        [ expression ]
```

Invokes standard binary, passing command line parameters straight through. Runs in foreground, printing packets as they arrive, until the user hits Ctrl+C.

Syntax Description	N/A
Default	N/A
Modes/Context	Config
History	3.1.0000
Role	admin

Example

```
switch (config) # tcpdump
.....
09:37:38.678812 IP 192.168.10.7.ssh > 192.168.10.1.54155: P
1494624:1494800(176) ack 625 win 90
<nop,nop,timestamp 5842763 858672398>
09:37:38.678860 IP 192.168.10.7.ssh > 192.168.10.1.54155: P
1494800:1495104(304) ack 625 win 90
<nop,nop,timestamp 5842763 858672398>
...
9141 packets captured
9142 packets received by filter
0 packets dropped by kernel
switch (config) #
```

Related Commands

N/A

Note

When using `-i` option use the interface name + interface number, for example “`tcpdump -i vlan10`”