



# Differences between ONTAP Mediator and MetroCluster Tiebreaker

## ONTAP MetroCluster

netapp-martyh  
May 14, 2021

# Table of Contents

- Differences between ONTAP Mediator and MetroCluster Tiebreaker ..... 1
  - Interoperability of ONTAP Mediator with other applications and appliances ..... 1
  - How the ONTAP Mediator supports automatic unplanned switchover. .... 1

# Differences between ONTAP Mediator and MetroCluster Tiebreaker

Starting with ONTAP 9.7, you can use either the ONTAP Mediator-assisted automatic unplanned switchover (MAUSO) in the MetroCluster IP configuration or you can use the MetroCluster Tiebreaker software. Only one of the two services can be used with the MetroCluster IP configuration.

The different MetroCluster configurations perform automatic switchover under different circumstances:

- **MetroCluster FC configurations using the AUSO capability (not present in MetroCluster IP configurations)**

In these configurations, AUSO is initiated if controllers fail but the storage (and bridges, if present) remain operational.

- **MetroCluster IP configurations using the ONTAP Mediator service (ONTAP 9.7 and later)**

In these configurations, MAUSO is initiated in the same circumstances as AUSO, as described above, and also after a complete site failure (controllers, storage, and switches).



MAUSO is initiated only if nonvolatile cache mirroring (*DR mirroring*) and SyncMirror plex mirroring is in sync at the time of the failure.

- **MetroCluster IP or FC configurations using the Tiebreaker software in active mode**

In these configurations, the Tiebreaker initiates unplanned switchover after a complete site failure.

Before using the Tiebreaker software, review the [MetroCluster Tiebreaker Software Installation and Configuration Guide](#)

## Interoperability of ONTAP Mediator with other applications and appliances

You cannot use any third-party applications or appliances that can trigger a switchover in combination with ONTAP Mediator. In addition, monitoring a MetroCluster configuration with MetroCluster Tiebreaker software is not supported when using ONTAP Mediator.

## How the ONTAP Mediator supports automatic unplanned switchover

The ONTAP Mediator stores state information about the MetroCluster nodes in mailboxes located on the Mediator host. The MetroCluster nodes can use this information to monitor the state of their DR partners and implement a Mediator-assisted automatic unplanned switchover (MAUSO) in the case of a disaster.

When a node detects a site failure requiring a switchover, it takes steps to confirm that the switchover is appropriate and, if so, performs the switchover.

MAUSO is only initiated if both SyncMirror mirroring and DR mirroring of each node's nonvolatile cache is

operating and the caches and mirrors are synchronized at the time of the failure.

## Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.