



# **Changing ISL properties, ISL ports, or the IOD/OOD configuration on a Brocade switch**

## **ONTAP MetroCluster**

netapp-ivanad, ntap-bmegan  
April 21, 2021

This PDF was generated from [https://docs.netapp.com/us-en/ontap-metrocluster/maintain/task\\_change\\_isl\\_properties\\_isl\\_ports\\_or\\_the\\_iod\\_ood\\_configuration\\_on\\_a\\_brocade\\_switch.html](https://docs.netapp.com/us-en/ontap-metrocluster/maintain/task_change_isl_properties_isl_ports_or_the_iod_ood_configuration_on_a_brocade_switch.html) on May 31, 2021. Always check docs.netapp.com for the latest.

# Table of Contents

Changing ISL properties, ISL ports, or the IOD/OOD configuration on a Brocade switch . . . . . 1

# Changing ISL properties, ISL ports, or the IOD/OOD configuration on a Brocade switch

You might need to add ISLs to a switch if you are adding or upgrading hardware such as additional or faster controllers or switches.

Ensure that the system is properly configured, that all fabric switches are operational, and that no errors exist.

If the equipment on the ISL link changes and the new link configuration no longer supports the current configuration----trunking and ordered delivery----then the fabric needs to be reconfigured for the correct routing policy: either in-order-deliver (IOD) or out-of-order-delivery (OOD).



To make changes to OOD from ONTAP software, use the following steps: [Configuring in-order delivery or out-of-order delivery of frames on ONTAP software](#)

1. Disable the FCVI and storage HBA ports:

**`portcfgpersistentdisable port number`**

By default the first 8 ports (ports 0 through 7) are used for FCVI and Storage HBA. The ports must be persistently disabled so that the ports remain disabled in the event of a switch reboot.

The following example shows ISL ports 0—7 being disabled on both switches:

```
Switch_A_1:admin> portcfgpersistentdisable 0-7
Switch_B_1:admin> portcfgpersistentdisable 0-7
```

2. Change the ISL ports as required.

Option	Step
To change the speed of an ISL port...	<p>Use the <code>portcfgspeed port number port speed</code> command on both switches on the fabric.</p> <p>In the following example, you change the ISL port speed from 40 Gbps to 16 Gbps:</p> <pre>brocade_switch_A_1:admin&gt; portcfgspeed 40 16</pre> <p>You can verify that the speed has changed using the <code>switchshow</code> command:</p> <pre>brocade_switch_A_1:admin&gt; switchshow</pre> <p>You should see the following output:</p> <pre> . . .       40  40    062800    id 16G      No_Sync      FC  Disabled . . . </pre>
To change the distance of an ISL port...	Use the <code>portcfglongdistance port number port distance</code> command on both switches in the fabric.
To remove an ISL...	Disconnect the link <code>\(cable\)</code> .
To add an ISL...	Insert SFPs into the ports you are adding as ISL ports. Ensure that these ports are listed in the <b>Fabric-attached MetroCluster Installation and Configuration Guide</b> for the switch you are adding them to and cable them according to this guide.
To relocate an ISL...	Relocating an ISL is the same as removing and then adding an ISL. First, remove the ISL by disconnecting the link and then insert SFPs into the ports you are adding as ISL ports.

### 3. Reconfigure for out-of-order delivery `\(OOD\)` or in-order-delivery `(IOD)`.



If the routing policies remain the same, you do not need to reconfigure and this step can be ignored. The ONTAP configuration needs to match the fabric configuration. If the fabric is configured for OOD, then ONTAP must also be configured for OOD. The same applies for IOD.

This step should be executed in the following scenarios:

- More than one ISL formed a trunk before the change, but after the change, trunking is no longer supported. In this case, you must configure the fabric for OOD.
- There is one ISL before the change and multiple ISLs after the change.
- If multiple ISLs form a trunk, configure the fabric for IOD.
- If multiple ISLs **cannot** form a trunk, configure the fabric for OOD.
  - a. Persistently disable the switches using the **switchcfgpersistentdisable** command as shown in the following example:

```
Switch_A_1:admin> switchcfgpersistentdisable
Switch_B_1:admin> switchcfgpersistentdisable
```

- b. Configure the trunking mode for each ISL **portcfgtrunkport port number** as shown in the following table:

Scenario	Steps
Configure the ISL for trunking \ (IOD\)	Set the <b>portcfgtrunkport port number</b> to 1: <pre>FC_switch_A_1:admin&gt; portcfgtrunkport 20 1 FC_switch_A_1:admin&gt; portcfgtrunkport 21 1 FC_switch_B_1:admin&gt; portcfgtrunkport 20 1 FC_switch_B_1:admin&gt; portcfgtrunkport 21 1</pre>
Configure the ISL for trunking \ (OOD\)	Set the <b>portcfgtrunkport port number</b> to 0: <pre>FC_switch_A_1:admin&gt; portcfgtrunkport 20 0 FC_switch_A_1:admin&gt; portcfgtrunkport 21 0 FC_switch_B_1:admin&gt; portcfgtrunkport 20 0 FC_switch_B_1:admin&gt; portcfgtrunkport 21 0 ...</pre>

- c. Configure the fabric for IOD or OOD as required.

Scenario	Steps
Configure the fabric for IOD	<p>Set the three settings of IOD, APT, and DLS using the <b>iodset</b>, <b>aptpolicy</b>, and <b>dlsreset</b> commands as shown in the following example:</p> <pre> Switch_A_1:admin&gt; iodset Switch_A_1:admin&gt; aptpolicy 1 Policy updated successfully. Switch_A_1:admin&gt; dlsreset FC_switch_A_1:admin&gt;portcfgtru nkport 40 1 FC_switch_A_1:admin&gt;portcfgtru nkport 41 1 </pre> <pre> Switch_B_1:admin&gt; iodset Switch_B_1:admin&gt; aptpolicy 1 Policy updated successfully. Switch_B_1:admin&gt; dlsreset FC_switch_B_1:admin&gt;portcfgtru nkport 20 1 FC_switch_B_1:admin&gt;portcfgtru nkport 21 1 </pre>

Configure the fabric for OOD

Set the three settings of IOD, APT, and DLS using the **iodreset**, **aptpolicy**, and **dlset** commands as shown in the following example:

```
Switch_A_1:admin> iodreset
Switch_A_1:admin> aptpolicy 3
Policy updated successfully.
Switch_A_1:admin> dlset
FC_switch_A_1:admin>
portcfgtrunkport 40 0
FC_switch_A_1:admin>
portcfgtrunkport 41 0
```

```
Switch_B_1:admin> iodreset
Switch_B_1:admin> aptpolicy 3
Policy updated successfully.
Switch_B_1:admin> dlset
FC_switch_B_1:admin>
portcfgtrunkport 40 0
FC_switch_B_1:admin>
portcfgtrunkport 41 0
```

- d. Enable the switches persistently using the **switchcfgpersistentenable** command.

```
switch_A_1:admin>switchcfgpersistentenable
switch_B_1:admin>switchcfgpersistentenable
```

If this command does not exist, use the **switchenable** command as shown in the following example:

```
brocade_switch_A_1:admin>
switchenable
```

- e. Verify the OOD settings using the **iodshow**, **aptpolicy**, and **dlsshow** commands as shown in the following example:

```
switch_A_1:admin> iodshow
IOD is not set

switch_A_1:admin> aptpolicy

Current Policy: 3 0(ap)

3 0(ap) : Default Policy
1: Port Based Routing Policy
3: Exchange Based Routing Policy
    0: AP Shared Link Policy
    1: AP Dedicated Link Policy
command aptpolicy completed

switch_A_1:admin> dlsshow
DLS is set by default with current routing policy
```



You must run these commands on both switches.

- f. Verify the IOD settings using the **iodshow**, **aptpolicy**, and **dlsshow** commands as shown in the following example:

```
switch_A_1:admin> iodshow
IOD is set

switch_A_1:admin> aptpolicy

Current Policy: 1 0(ap)

3 0(ap) : Default Policy
1: Port Based Routing Policy
3: Exchange Based Routing Policy
    0: AP Shared Link Policy
    1: AP Dedicated Link Policy
command aptpolicy completed

switch_A_1:admin> dlsshow
DLS is not set
```



You must run these commands on both switches.

4. Verify that the ISLs are online and trunked (if the linking equipment supports trunking) using the **islshow** and **trunkshow** commands.





If FEC is enabled, the deskew value of the last online port of the trunk group might show a difference of up to 36 although the cables are all of the same length.

Are ISLs trunked?	You see the following system output...
Yes	<p>If the ISLs are trunked, only a single ISL appears in the output for the <b>islshow</b> command. Either port 40 or 41 can appear depending on which is the trunk master. The output of <b>trunkshow</b> should one trunk with ID '1' listing both the physical ISLs on ports 40 and 41. In the following example the ports 40 and 41 are configured for use as an ISL:</p> <pre>switch_A_1:admin&gt; islshow 1: 40-&gt; 40 10:00:00:05:33:88:9c:68 2 switch_B_1 sp: 16.000G bw: 32.000G TRUNK CR_RECOV FEC switch_A_1:admin&gt; trunkshow 1: 40-&gt; 40 10:00:00:05:33:88:9c:68 2 deskew 51 MASTER 41-&gt; 41 10:00:00:05:33:88:9c:68 2 deskew 15</pre>

Are ISLs trunked?	You see the following system output...
No	<p>If the ISLs are not trunked, both ISLs appear separately in the outputs for <b>islshow</b> and <b>trunkshow</b>. Both commands list the ISLs with their ID of '1' and '2'. In the following example, the ports 40 and 41 are configured for use as an ISL:</p> <pre data-bbox="844 363 1484 1066">switch_A_1:admin&gt; islshow 1: 40-&gt; 40 10:00:00:05:33:88:9c:68 2 switch_B_1 sp: 16.000G bw: 16.000G TRUNK CR_RECOV FEC 2: 41-&gt; 41 10:00:00:05:33:88:9c:68 2 switch_B_1 sp: 16.000G bw: 16.000G TRUNK CR_RECOV FEC switch_A_1:admin&gt; trunkshow 1: 40-&gt; 40 10:00:00:05:33:88:9c:68 2 deskew 51 MASTER 2: 41-&gt; 41 10:00:00:05:33:88:9c:68 2 deskew 48 MASTER</pre>

5. Run the **spinfab** command on both switches to verify that the ISLs are healthy:

```
switch_A_1:admin> spinfab -ports 0/40 - 0/41
```

6. Enable the ports that were disabled in step 1:

**portenable port number**

The following example shows ISL ports 0—7 being enabled:

```
brocade_switch_A_1:admin> portenable 0-7
```

## Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

## Trademark Information

NETAPP, the NETAPP logo, and the marks listed at <http://www.netapp.com/TM> are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.