

# Raspberry Pi - Install Ubuntu

Official OS on Raspberry Pi is a Debian distro which is lightweight and more stable but slowly updated. Running Ubuntu on Raspberry Pi gives user a richer user experience and up-to-date software. Moreover, Ubuntu is the main OS that ROS natively supports.

[#rasberry-pi](#) [#linux](#)

---

Last update: 2021-08-10 16:50:49

# Table of Content

1. Ubuntu
2. Supported boards
3. Flash image to a MicroSD Card
4. Wi-Fi setup
  - 4.1. Setup priority
5. Install Desktop Environment

# 1. Ubuntu

Ubuntu Desktop comes with a rich desktop environment which consumes a bit high system resource and performance. Therefore, other lightweight version of Ubuntu will be chosen.

In December 2019, Canonical published a support roadmap for the latest Raspberry Pi 4 single-board computer on their Ubuntu Server operating system and pledged to fully support Ubuntu on all Raspberry Pi boards.

Ubuntu currently supports Raspberry Pi 2, Raspberry Pi 3, and Raspberry Pi 4 models, and images are available for the latest version of Ubuntu LTS (Long-Term Support) at <https://ubuntu.com/download/raspberry-pi>.

## Old-releases archived images

Visit <https://old-releases.ubuntu.com/releases/> see the list of prebuilt images for older versions.

# 2. Supported boards

Ubuntu supports :

- Raspberry Pi 2
- Raspberry Pi 3
- Raspberry Pi 4
- Raspberry Pi 400
- Raspberry Pi CM4







All boards have 2 version: **64-bit** and **32-bit** , except Raspberry Pi 2 which has only 32-bit version.

## 64-bit version

This version is built for 64-bit mode of the CPU used in Raspberry Pi boards. It has **arm4** tag in the image name.

## 32-bit version

This version is built for 32-bit mode of the CPU used in Raspberry Pi boards. It has **armhf** tag in the image name.

	<a href="#">ubuntu-18.04.4-preinstalled-server-arm64+raspi3.img.xz</a>	2020-02-03 18:43 477M
	<a href="#">ubuntu-18.04.4-preinstalled-server-arm64+raspi3.img.xz.zsync</a>	2020-02-12 13:37 954K
	<a href="#">ubuntu-18.04.4-preinstalled-server-arm64+raspi3.manifest</a>	2020-02-03 18:43 14K
	<a href="#">ubuntu-18.04.4-preinstalled-server-arm64+raspi4.img.xz</a>	2020-02-03 18:43 477M
	<a href="#">ubuntu-18.04.4-preinstalled-server-arm64+raspi4.img.xz.zsync</a>	2020-02-12 13:37 954K
	<a href="#">ubuntu-18.04.4-preinstalled-server-arm64+raspi4.manifest</a>	2020-02-03 18:43 14K
	<a href="#">ubuntu-18.04.4-preinstalled-server-armhf+raspi2.img.xz</a>	2020-02-03 18:40 472M
	<a href="#">ubuntu-18.04.4-preinstalled-server-armhf+raspi2.img.xz.zsync</a>	2020-02-12 13:38 943K
	<a href="#">ubuntu-18.04.4-preinstalled-server-armhf+raspi2.manifest</a>	2020-02-03 18:40 14K
	<a href="#">ubuntu-18.04.4-preinstalled-server-armhf+raspi3.img.xz</a>	2020-02-03 18:40 472M
	<a href="#">ubuntu-18.04.4-preinstalled-server-armhf+raspi3.img.xz.zsync</a>	2020-02-12 13:38 943K
	<a href="#">ubuntu-18.04.4-preinstalled-server-armhf+raspi3.manifest</a>	2020-02-03 18:40 14K
	<a href="#">ubuntu-18.04.4-preinstalled-server-armhf+raspi4.img.xz</a>	2020-02-03 18:40 472M
	<a href="#">ubuntu-18.04.4-preinstalled-server-armhf+raspi4.img.xz.zsync</a>	2020-02-12 13:38 943K
	<a href="#">ubuntu-18.04.4-preinstalled-server-armhf+raspi4.manifest</a>	2020-02-03 18:40 14K

64-bit version

32-bit version

*Choose an OS version*

### 3. Flash image to a MicroSD Card

Follow the instruction of using [Etcher](#) to flash the image.

Launch Etcher and select the image file and the target SD card. The process will take a few minutes, so be patient. When Etcher is done, follow the [headless mode setup](#) if needed as the installed Ubuntu version is for server.

#### Boot up

Login with the default user:

- Login: **ubuntu**
- Password: **ubuntu**

Right after the first time logging in, default password have to be changed.

### 4. Wi-Fi setup

Starting from Ubuntu 18.04 LTS, Ubuntu uses [Netplan](#) to configure network interfaces by default. Netplan is a utility for configuring network interfaces on Linux. Netplan uses YAML files for

configuring network interfaces. YAML configuration file format is really simple. It has clear and easy to understand syntax.

Edit the Netplan YAML configuration file `/etc/netplan/50-cloud-init.yaml` with the following command:

```
sudo nano /etc/netplan/50-cloud-init.yaml
```

Add the Wi-Fi access information. Make sure not to use tab for space, use the spaces to create the blank.

```
# This file is generated from information provided by
# the datasource. Changes to it will not persist across an instance.
# To disable cloud-init's network configuration capabilities, write a file
# /etc/cloud/cloud.cfg.d/99-disable-network-config.cfg with the following:
# network: {config: disabled}
network:
  version: 2
  ethernets:
    eth0:
      optional: true
      dhcp4: true
  # add wifi setup information here ...
  wifis:
    wlan0:
      optional: true
      access-points:
        "YOUR-SSID-NAME":
          password: "NETWORK-PASSWORD"
      dhcp4: true
```

Change the `SSID-NAME` and the `NETWORK-PASSWORD` with the Wi-Fi AP information. Close and save the file using `Ctrl + X` and press yes.

Now, check whether there's any error in the configuration file with the following command:

```
sudo netplan --debug try
```

If any error encounters then check with this command for detailed error information:

```
sudo netplan --debug generate
```

Apply the configuration file with the following command:

```
sudo netplan --debug apply
```

## 4.1. Setup priority

By default, Ethernet has higher priority to route network packets through it.

Run:

```
route -n
```

This will show the **metric** value for **eth0** is 100 and that value of **wlan0** is 600. Lower value has higher priority.

Destination	Gateway	Genmask	Flags	Metric	Ref	Use	Iface
0.0.0.0	192.168.0.1	0.0.0.0	UG	100	0	0	eth0
0.0.0.0	192.168.1.1	0.0.0.0	UG	600	0	0	wlan0
192.168.0.0	0.0.0.0	255.255.255.0	U	0	0	0	eth0
192.168.0.1	0.0.0.0	255.255.255.255	UH	100	0	0	eth0
192.168.1.0	0.0.0.0	255.255.255.0	U	0	0	0	wlan0
192.168.1.1	0.0.0.0	255.255.255.255	UH	600	0	0	wlan0

To make Wi-Fi has higher priority, add a config line in Netplan configuration file:

```
sudo nano /etc/netplan/50-cloud-init.yaml
```

```
wifis:
wlan0:
  access-points:
    "SSID":
      password: "password"
  dhcp4: true
  dhcp4-overrides:
    route-metric: 50
  optional: true
```

Then regenerate network configs and apply them:

```
sudo netplan --debug generate && \
sudo netplan --debug apply
```

Run again:

```
route -n
```

to see the **metric** for **wlan0** is now set to 50:

Kernel IP routing table							
Destination	Gateway	Genmask	Flags	Metric	Ref	Use	Iface
0.0.0.0	192.168.1.1	0.0.0.0	UG	50	0	0	wlan0
0.0.0.0	192.168.0.1	0.0.0.0	UG	100	0	0	eth0
192.168.0.0	0.0.0.0	255.255.255.0	U	0	0	0	eth0
192.168.0.1	0.0.0.0	255.255.255.255	UH	100	0	0	eth0
192.168.1.0	0.0.0.0	255.255.255.0	U	0	0	0	wlan0
192.168.1.1	0.0.0.0	255.255.255.255	UH	50	0	0	wlan0

**i Netplan configuration**

Refer to <https://netplan.io/reference/>

## 5. Install Desktop Environment

The installed Ubuntu version is for server which is designed to use minimal resources. To install a very lightweight desktop environment run bellow command:

```
To install a very lightweight desktop environment run bellow command
```

or

```
sudo apt-get install lubuntu-desktop
```

**i Lubuntu vs Xubuntu**

If you are looking for the most lightweight, Lubuntu is the choice to go. It uses the least system resources and comes with the fewest installed applications, unlike Xubuntu which packs some punch in polish and features meaning a lot more resource use. Xubuntu is relatively lightweight, as in, it's lighter than Ubuntu and Kubuntu but **Lubuntu is actually lightweight**.

### Ubuntu Mate

This is an alternative Ubuntu version using MATE desktop environment. The latest version is available at <https://ubuntu-mate.org/download/>, while old releases are listed in <https://releases.ubuntu-mate.org/archived>.