

RALINK TECHNOLOGY, CORP.

RT3X5X/5350 LINUX STATION RELEASE NOTES AND USER'S GUIDE

Copyright © 2010 Ralink Technology, Corp.

All Rights Reserved.

This document is property of Ralink Technology Corporation. Transmittal, receipt, or possession of this document does not express, license, or imply any rights to use, sell, design, or manufacture from this information or the software documented herein. No reproduction, publication, or disclosure of this information, in whole or in part, shall be allowed, unless the prior written consent of Ralink Technology Corporation is obtained.

NOTE: THIS DOCUMENT CONTAINS SENSITIVE INFORMATION AND HAS RESTRICTED DISTRIBUTION.

**for stevej@cradlepoint.com
And Company Use Only**

Proprietary Notice and Liability Disclaimer

The confidential Information, technology or any Intellectual Property embodied therein, including without limitation, specifications, product features, data, source code, object code, computer programs, drawings, schematics, know-how, notes, models, reports, contracts, schedules and samples, constitute the Proprietary Information of Ralink (hereinafter "Proprietary Information")

All the Proprietary Information is provided "AS IS". No Warranty of any kind, whether express or implied, is given hereunder with regards to any Proprietary Information or the use, performance or function thereof. Ralink hereby disclaims any warranties, including but not limited warranties of non-infringement, merchantability, completeness, accuracy, fitness for any particular purpose, functionality and any warranty related to course of performance or dealing of Proprietary Information. In no event shall Ralink be liable for any special, indirect or consequential damages associated with or arising from use of the Proprietary Information in any way, including any loss of use, data or profits.

Ralink retains all right, title or interest in any Proprietary Information or any Intellectual Property embodied therein. The Proprietary Information shall not in whole or in part be reversed, decompiled or disassembled, nor reproduced or sublicensed or disclosed to any third party without Ralink's prior written consent.

Ralink reserves the right, at its own discretion, to update or revise the Proprietary Information from time to time, of which Ralink is not obligated to inform or send notice. Please check back if you have any question. Information or items marked as "not yet supported" shall not be relied on, nor taken as any warranty or permission of use.

Ralink Technology Corporation (Taiwan)

5F, No.5, Tai-Yuen Street,
ChuPei City
HsinChu Hsien 302, Taiwan, ROC
Tel +886-3-560-0868
Fax +886-3-560-0818

Sales Taiwan: Sales@ralinktech.com.tw
Technical Support Taiwan: FAE@ralinktech.com.tw

<http://www.ralinktech.com/>

Contents

Contents		3	2.2.15	DefaultKeyID	15
1.1	RT 305X Version History	6	2.2.16	WEP KeyType	15
1.1.1	Version 2.5.0.0	6	2.2.17	WEP Hex Key	16
1.1.2	Version 2.4.1.0	6	2.2.18	WEP Key String	16
1.1.3	Version 2.3.0.0	7	2.2.19	WPAPSK	16
1.1.4	Version 2.2.0.0	7	2.2.20	WmmCapable	16
1.1.5	Version 2.0.0.0	7	2.2.21	IEEE80211H	16
1.1.6	Version 1.9.0.0	7	2.2.22	PSMode	16
1.1.7	Version 1.8.0.0	8	2.2.23	FastRoaming	17
1.1.8	Version 1.7.0.0	8	2.2.24	RoamThreshold	17
1.1.9	Version 1.6.0.0	8	2.2.25	TGnWifiTest	17
1.1.10	Version 1.5.0.0	9	2.2.26	WirelessEvent	17
1.1.11	Version 1.4.0.0	9	2.2.27	CarrierDetect	17
1.1.12	Version 1.3.0.0	9	2.2.28	HT_RDG	17
1.1.13	Version 1.2.0.0	10	2.2.29	HT_EXTCHA	17
1.1.14	Version 1.1.0.0	10	2.2.30	HT_OpMode	17
1.1.15	Version 1.0.0.0:	10	2.2.31	HT_MpduDensity	18
1.2	RT 3352 Version History	10	2.2.32	HT_BW	18
1.2.1	Version 2.5.0.0	10	2.2.33	HT_AutoBA	18
1.3	RT535X Version History	11	2.2.34	HT_AMSDU	18
1.3.1	Version 2.5.0.0	11	2.2.35	HT_BAWinSize	18
2	Configuration	11	2.2.36	HT_GI	18
2.1	Configuration File		2.2.37	HT_MCS	18
RT2860STA.dat		11	2.2.38	HT_MIMOPSEnable	18
2.2	Configuration file use	13	2.2.39	HT_MIMOPSMODE	19
2.2.1	CountryRegion	13	2.2.40	HT_DisallowTKIP	19
2.2.2	CountryRegionForABand	13	2.2.41	HT_RxStream	19
2.2.3	SSID	14	2.2.42	HT_TxStream	19
2.2.4	WirelessMode	14	2.2.43	HT_LinkAdapt	19
2.2.5	Channel	14	2.2.44	HT_HTC	19
2.2.6	BGProtection	14	2.2.45	HT_DisableReordering	20
2.2.7	TxPreamble	14	2.2.46	BeaconLostTime	20
2.2.8	RTSThreshold	14	2.2.47	AutoRoaming	20
2.2.9	FragThreshold	15	2.2.48	MacAddress	20
2.2.10	TxBurst	15	2.2.49	TDLSCapable	20
2.2.11	PktAggregate	15	2.2.50	AutoConnect	20
2.2.12	NetworkType	15	2.2.51	HT_40MHZ_INTOLERANT	
2.2.13	AuthMode	15	20		
2.2.14	EncrypType	15	2.2.52	AntGain	21
			2.2.53	BandedgeDelta	21
			2.2.54	HwAntDiversity=Value	
			(RT5350 only)		21
3	Wireless Tools	21	3	Wireless Tools	21
3.1	Iwpriv ra0 set use	21	3.1	Iwpriv ra0 set use	21
3.1.1	DriverVersion	21	3.1.1	DriverVersion	21

3.1.2	CountryRegion	22	3.1.56	HwAntDiv=Value (RT5350 only)	31
3.1.3	CountryRegionABand	22			
3.1.4	SSID	22	3.2	lwpriv ra0 show use.....	31
3.1.5	WirelessMode.....	23			
3.1.6	TxBurst:.....	23	3.2.1	connStatus	31
3.1.7	PktAggregate:	23	3.2.2	driverVer	31
3.1.8	TxPreamble:.....	23	3.2.3	bainfo	31
3.1.9	TxPower:.....	24	3.2.4	rxbulk	31
3.1.10	Channel.....	24	3.2.5	txbulk	31
3.1.11	BGProtection:	24	3.2.6	AutoReconnect	31
3.1.12	RTSThreshold:.....	24	3.2.7	WPAPSK	32
3.1.13	FragThreshold:.....	24	3.2.8	PMK.....	32
3.1.14	NetworkType:	24			
3.1.15	AuthMode:	24	3.3	lwpriv ra0 use	33
3.1.16	EncrypType:	24			
3.1.17	DefaultKeyID:.....	25	3.3.1	radio_off	33
3.1.18	Key1	25	3.3.2	radio_on.....	33
3.1.19	Key2	25			
3.1.20	Key3	25	3.4	lwpriv Examples.....	34
3.1.21	Key4	25			
3.1.22	WPAPSK	25	3.4.1	Infrastructure	34
3.1.23	WmmCapable	26	3.4.2	Ad-Hoc	35
3.1.24	IEEE80211H.....	26	3.4.3	Get site survey	35
3.1.25	PSMode	26	3.4.4	Get Statistics	35
3.1.26	ResetCounter.....	26	3.4.5	ANY SSID	35
3.1.27	Debug	26			
3.1.28	CarrierDetect	26	3.5	iwlist	35
3.1.29	HtRdg.....	27	3.6	iwconfig	35
3.1.30	HtExtcha	27			
3.1.31	HtOpMode.....	27	4	WPS – Wi-Fi Protected Setup	37
3.1.32	HtMpduDensity	27			
3.1.33	HtBw	27	4.1	lwpriv use	37
3.1.34	HtAutoBa	27			
3.1.35	HtAmsdu.....	27	4.1.1	wsc_conf_mode.....	37
3.1.36	HtBaWinSize	28	4.1.2	wsc_mode.....	37
3.1.37	HtGi.....	28	4.1.3	wsc_pin	38
3.1.38	HtMcs	28	4.1.4	wsc_ssid	38
3.1.39	HtProtect	28	4.1.5	wsc_bssid	38
3.1.40	HtMimoPs.....	28	4.1.6	wsc_start.....	38
3.1.41	FixedTxMode	28	4.1.7	wsc_stop	38
3.1.42	LongRetry.....	29	4.1.8	wsc_gen_pincode	38
3.1.43	ShortRetry.....	29	4.1.9	wsc_cred_count.....	38
3.1.44	HtTxStream=value	29	4.1.10	wsc_cred_ssid.....	38
3.1.45	HtRxStream=value	29	4.1.11	wsc_cred_auth.....	39
3.1.46	HtDisallowTKIP=value....	29	4.1.12	wsc_cred_encr.....	39
3.1.47	HtBaDecline	29	4.1.13	wsc_cred_keyidx.....	39
3.1.48	BeaconLostTime=value..	29	4.1.14	wsc_cred_key	39
3.1.49	AutoRoaming=value	30	4.1.15	wsc_cred_mac	40
3.1.50	SiteSurvey=value	30	4.1.16	wsc_conn_by_idx.....	40
3.1.51	TdlsCapable=value	30	4.1.17	wsc_auto_conn.....	40
3.1.52	TdlsSetup=value	30	4.1.18	wsc_ap_band	40
3.1.53	AutoReconnect=value ...	30	4.1.19	Wsc4digitPinCode	40
3.1.54	AdhocN=value	30			
3.1.55	AntGain.....	31			

4.2	WPS STA as an Enrollee or Registrar	41	5.2	Tx Mode, MCS, BW and GI Selection Table	52
4.2.1	Enrollee Mode	41	5.2.1	MODE = 0, Legacy CCK ...	52
4.2.2	Registrar Mode	41	5.2.2	MODE = 1, Legacy OFDM	52
4.3	WPS IOCTL use	42	5.2.3	MODE = 2, HT Mixed Mode	52
4.3.1	iwpriv commands without argument	43	5.2.4	MODE = 3, HT Greenfield	52
4.3.2	iwpriv commands with one INT argument	43	5.3	Examples	53
4.3.3	iwpriv commands with string argument	43	5.3.1	Check EVM & Power	53
4.4	WPS IOCTL Sample Program ...	45	5.3.2	Check Carrier	54
5	ATE Test Command Format	47	5.3.3	Check spectrum mask	54
5.1	iwpriv ra0 set [parameters]=[val]	48	5.3.4	Frequency offset tuning.	54
5.1.1	ATE	48	5.3.5	Rx	54
5.1.2	ATEDA	48	5.3.6	Show all ate parameters	55
5.1.3	ATESA	48	5.3.7	Online help	55
5.1.4	ATEBSSID	48	5.3.8	Display Rx Packet Count and RSSI	55
5.1.5	ATECHANNEL	48	5.3.9	Internal ALC calibration (For RT5350 only)	56
5.1.6	ATETXPOW0	49	5.3.10	Internal ALC function testing in ATE mode (For RT5350 only)	56
5.1.7	ATETXPOW1	49	5.4	iwpriv ra0 bbp [parameters]=[Value]	57
5.1.8	ATETFREQOFFSET	49	5.4.1	BBPID	57
5.1.9	ATETXLEN	49	5.4.2	BBPID=Value	57
5.1.10	ATETXCNT	49	5.5	iwpriv ra0 mac [parameters]=[val]	57
5.1.11	ATETXMODE (Refer to TxMode)	49	5.5.1	MAC_OFFSET	57
5.1.12	ATETXBW (Refer to TxMode)	50	5.5.2	MAC_OFFSET=Value	57
5.1.13	ATETXGI (Refer to TxMode)	50	5.6	iwpriv ra0 e2p [parameters]=[val]	57
5.1.14	ATETXMCS (Refer to TxMode)	50	5.6.1	EEP_ADDR	58
5.1.15	ATETXANT	50	5.6.2	EEP_ADDR=Value	58
5.1.16	ATERXANT	50	5.7	Example	58
5.1.17	ATERXFER	50	5.7.1	Hardware access	58
5.1.18	ATESHOW	51	5.7.2	Statistic counter operation	58
5.1.19	ATEHELP	51	5.7.3	Suggestion	58
5.1.20	ResetCounter	51	5.8	ated	60
5.1.21	ATERRF	51	5.8.1	Introduction	60
5.1.22	ATELDE2P	51	5.8.2	Environment setup	60
5.1.23	ATETSSICBAEX (For RT5350 only)	51			
5.1.24	ATEIPG	51			
5.1.25	ATEPAYLOAD	52			
5.1.26	ATETSSICBA	52			

5.8.3	How to use ated for ATE purpose	60	7.1.4	GET scan table:.....	89
6	IOCTL.....	61	7.1.5	GET station's MAC:	89
6.1	Parameters for iwconfig.....	61	7.1.6	GET station connection status:	90
6.2	Parameters for iwpriv	68	7.1.7	GET AP's BSSID	90
6.2.1	Set Data, Parameters is Same as iwpriv	68	7.1.8	GET SSID	90
6.2.2	Get Data, Parameters is Same as iwpriv	69	7.1.9	GET station's last TX related information:.....	90
6.2.3	Set Raw Data with Flags	70	7.1.10	GET station's last RX related information:.....	90
6.2.4	Get Raw Data with Flags	78	7.1.11	GET station's wireless mode:	90
6.2.5	Set Raw Data with Flags	87	7.1.12	GET Bss type:.....	91
7	IOCTL instructions	89	7.1.13	GET Authentication Mode:	91
7.1	Get Data	89	7.1.14	GET Encryption Type:.....	92
7.1.1	GET station connection status:	89	7.1.15	GET RSSI 0 (unit: db)	92
7.1.2	GET station statistics information:	89	7.1.16	GET RSSI 1 (unit: db)	92
7.1.3	GET AP list table:	89	7.1.17	GET RSSI 2 (unit: db)	92
			7.1.18	GET Driver wireless extension version	92
			7.2	How to display rate, BW:.....	94

1.1 RT 305X Version History

1.1.1 Version 2.5.0.0

1. Add mac80211 iw utility other commands support.
2. WMM ACM: see history of acm_comm.c.
3. Fix issue: interrupt() issue in fedora core 7.
4. Fix issue in 64bit CPU:
5. CFG80211: Patch for Linux 2.6.32.
6. Add an ATE command for AUTOALC.
7. Add an ATE command for interpacket GAP.
8. Add an ATE command for ATE payload pattern.
9. Fix issue: UAPSD SP can not be closed correctly for mix-mode power save.
10. Fixe issue: The extended rate of probe-req is disappeared in AP-Client mode.
11. Fix issue: kernel panic when forward VLAN bc/mc packet to wireless LAN.
12. Fix issue: get wrong VLAN priority from VLAN tag in RTMPCheckEtherType().
13. Fix issue: no 11b basic rate in beacon when change WirelessMode to 2.4G, then 5G, then 2.4G.
14. Fix issue: no 11b-only mode can be set in AP mode.
15. MBSS: add function to set different phy mode for different BSS.
16. QLOAD: Fix issue for big endian or value of QLOAD element in beacon will be wrong.
17. TX Block: Fix no packet can be sent when TX Fail count > a threshold for non-WDS interface.
18. Fix issue: WPS process failed with WPS Client that sends dis-assoc close to WSC_DONE.

1.1.2 Version 2.4.1.0

1. Fix issue: Radio On/Off can not work.

1.1.3 Version 2.3.0.0

1. WMM ACM AP/STA support. (Pass WiFi Test Plan v0.30)
2. Add HAS_STATS_COUNT compile option.
3. Provide some 802.1x parameter support(Quiet-period, idle-timeout, NAD-ID).
4. Fix issue : The Tx data rate can't be fixed in B/G PHY mode.
5. QLOAD: Add status information display function. "qload show" & QloadClr.
6. QLOAD: Add channel busy alarm and a command thread in PCI/USB driver.
7. It supports the MAC assignment from configuration file(.dat).
8. Fix issue : No packet is delivered from AP when PsMode from PS to ACTIVE.
9. Fast Power Save : Use Null frame with PM=0 to get buffered packet, not PS-Poll.
10. miniupnpd supported.
11. AP-Client and WDS support fixed rate.
12. Support GreenAP.
13. Support Single SKU.
14. Fix issue: RT3062/RT3562 can't enable/disable Radio.
15. Discard IgmpSn enable setting per BSSID and change it to as global setting.

1.1.4 Version 2.2.0.0

1. New generation schema for multiple OS porting
2. New chip support for RT3572
3. New chip support for RT3062/RT3562.
4. Restrict the encryption type in HT mode..
5. Support 802.1x reauthentication mechanism.
6. Limit the STA connection count per BSS.
7. Some variables support MBSS setting.
8. Support WDS entry life check function
9. Support Dot11K RRM for all testing cases of voice-enterprise testing event.

1.1.5 Version 2.0.0.0

1. Added Global Country Domain supported.
2. Fix bug: suspend/resume error when ra0 down, rax up
3. Add new UAPSD SP counting mechanism.
4. Fix bug: Ikanos WDS, AP Client, Mess interface get problem.
5. Add new WSC hardware push button function for PCI & USB.
6. Added a function allow user to sepcific Tx rate for Mcast packets.
7. Migrate Mesh supporting to Draft-2.0.
8. Support WAPI functionality
9. Modify the priority of BAR transmission to solve the connection issue with Intel 4965 11n STA.

1.1.6 Version 1.9.0.0

1. Replace iwpriv cmd "AccessControlList" by "ACLAddEntry" and "ACLClearAll"
2. Fixed the wrong usage of AtoH ().
3. Support new Windows ATE GUI.
4. Add a command "iwpriv ra0 set ATERE2P=1" to display all EEPROM content.
5. Correct the limitation of the length of fragment
6. Fix bug: Fail to transmit packets through AMPDU way except the case that AP to STA.
7. Wrong Hareware packet length calculation of Mesh packet if it has been fragmented.
8. Support SIGMA 8622/8624 platform.
9. Add WPS PBC Session Overlap Detecting.
10. Add WPS 4-PinCode Support.
11. Fixed WPS enable PSP can not associate AP when AP security set to WPA-PSK.

12. If 11n station operated in power save mode, the AP should transmit none AMPDU nor AMSDU to the station for the Ps-Poll.
13. 20/40 overlapping BSS scan mechanism and bandwidth adjustment.
14. Support 802.11n draft 4.0

1.1.7 Version 1.8.0.0

1. Show Tx/Rx statistics per MBSS.
2. 802.1x supports failover mechanism.
3. Add watchdog to prevent MAC/BBP into the deadlock condition.
4. Support pure 11n with 5G band.
5. Update Timer Functions
6. In multiple cards application, the interface name is changed to raxx_k, where xx means card ID (0 ~ 31) and k means the BSS number (0 ~ 7)
7. Support individual MCS per BSS.
8. Add IKANOS Vx160 and Vx180.
9. Add station keep alive detection function in AP mode.
10. The SIFS of CCK is changed to 16 micro seconds to fix the connection problem with INTEL 2200bg cards.
11. QBSS Load Element is added to provide channel utilization information to all STAs.
12. Fix bug : After AP re-key, the ping connection from client to AP would be time-out within several seconds.
13. Support Mesh function.
14. Support SNMP function.
15. Big-endian ATE supported.

1.1.8 Version 1.7.0.0

1. Support IDS notification mechanism.
2. Change IRQ LOCK to SEM LOCK.
3. Fix bug : When QoS(non-BE) and fragment packets are received, AP would calculate wrong MIC in TKIP mode.
4. Support Non-GPL MD5.
5. Update Group rekey mechanism.
6. Fix BA time-out issue for Intel wireless card 4965AGN with version 11.5.0.32.
7. Add command "iwpriv ra0 set ATLEDE2P=1" to overwrite all EEPROM contents from "/etc/Wireless/RT2860(/70)AP(/STA)/e2p.bin".
8. Fix RTS threshold issue in 5G-band.
9. Add DLS Function.
10. IPV6 MLDv2 support.
11. Fix VLAN ID >= 256 can not be used.
12. Added PCIE MSI supporting for RT2890.
13. Added new channel list builder that create channel list according to country-code and channel Geography (in/out door).

1.1.9 Version 1.6.0.0

1. Fix bug: Before AP shutdown, AP doesn't notify those associated STA through dis-association.
2. Fix bug: The Atheros wireless STA card built in MacBook can't work normally when HT mode and the encryption is WEP or TKIP.
3. The support region in A band synchronizes with EEPROM.
4. It supports to initialize current wireless MAC address from E2PROM or module parameter.
5. Support maximum 8 MBSS and each beacon maximum length is 512 bytes.
6. Support 5-GHz band ATE.
7. Send DisAssoc frame to timeout STA.
8. Workaround for Atheros STA on AES mode.

9. Tx RTS/CTS when AP setup BA.
10. Driver sends IAPP L2 frame instead of Daemon.
11. Correct some timeout values of WPS.
12. Fix bug: The 802.1x daemon (rt2860apd) has some problem for parsing multiple parameters in MBSS.
13. Fix bug: The AP site survey signal isn't correct.
14. Provide some 11n statistics variables.
15. Fix bug: RT2561 module can not be removed after RT2860 module is inserted.
16. Added DEO (100 ~ 140) channel list for Germany.
17. Support wds phy mode and security setting for each wds link.
18. Fix bug: The Atheros legacy USB STA card can't connect to our AP in WPA-TKIP.
19. Modify rate adaptation for fast ramp-up tuning.
20. Fix WPS IOT issue with Atheros external registrar. Need Sync the user space daemon "wscd" to version 0.1.0
21. Fix bug: The BlackBerry/HTC can't connect to our AP.
22. Correct the default values of those WMM EDCA parameters.

1.1.10 Version 1.5.0.0

1. Added McastPhyMode and McastMcs iwpriv commands let user to specify the rate for Multicast packets transmission.
2. Added two configurations of McastPhyMode and McastMcs.
3. Re-organize the WPA state machine in order to the consistency between AP and AP-Client.
4. Added DFS support.
5. Added Carrier-Sense support.
6. Fixed a bug about dissection issue about ';' in profile.
7. Fixed CountryRegion and channel map, when profile's channel have not on channel list.
8. Fixed 802.1x Authentication problem with 1x-WEP/WPA(2)-Enterprise when WPS is enabled.
9. Fix bug: Once the radio is off and on, the beacon frames disappear.

1.1.11 Version 1.4.0.0

1. Wireless IGMP snooping support for multimedia streaming.
2. Access control list support
3. Re-organize the Rx data path.
4. AP client WPS support.
5. Fix the Auto-selecting channel issue.
6. Add CountryString ioctl command function.
7. Bug fix for Atheros WPS STA can not config WPS AP when Atheros JumpStart STA is external Registrar.
8. Merge for WCN test modify to WPS functions.
9. Patch for 11n requirement, if HT mode is set and BW is 40MHz in A-band, the supported Channel number must be the multiple of 2.
10. Fix bug: If STA card operated with zero-config, the group rekey negotiation of WPA2(PSK)-AES always fails.
11. Add Tx & Rx Stream functionality.
12. Support QA user interface for ATE function.

1.1.12 Version 1.3.0.0

1. Add vlan tag support for each BSS.
2. Add support for 32bit/64bit Linux.
3. Merge in plugfest code.
4. Support Ap-Client function.
5. Add new parameter "bWiFiTest" for WPA & WMM WiFi-Test.
6. Add the setting of Japan filter coefficients for ATE.
7. Fix bug for channel have not update when auto channel select was true.

8. Add protect for RTMP_IRQ_LOCK to avoid in spin_lock_irqsave call spin_lock_bh cause kernel warning messages.

1.1.13 Version 1.2.0.0

1. Fix bug for counterMeasures in WiFi test.
2. Write TXWI in ATE's way and disable any protection mechanism when ATE is running.
3. Disable ATE RSSI statistics when ATE is not running.
4. Select DAC according to HT or Legacy mode.
5. Support WPA2 Pre-authentication.
6. Fix WDS panic bug.
7. Shift skb control block used by driver to offset 10 to avoid dirty cb[] from protocol stack.
8. Fix issue - 802.1X daemon may cause throughput reduction.
9. Support Wireless event log mechanism.
10. Add a 200ms-timer to enqueue EAPoL-Start for WPAPSK, not RTMPusecDelay.
11. Auto-selecting channel check.

1.1.14 Version 1.1.0.0

1. Add fast rate switch.
2. Modify fast rate switch timer from periodic to trigger by condition.
3. Fix UAPSD bugs for null frame was drop.
4. Fix management queue pass qos null frame ...
5. Code freeze for Wifi.
6. Merge code from Plugfest #6.
7. Add "iwpriv ra0 show driverinfo" to show the driver version.

1.1.15 Version 1.0.0.0:

1. Interface support and bugs fix for WMM (Under testing).
2. DFS support.
3. Support WPA over WDS.
4. Bug fix for two WPAPSK-STAs causes the AP to crash.
5. Bug fix for BG-STAs will link up with B-only-AP.
6. Fix compatibility issue in 802.11d.

1.2 RT 3352 Version History

1.2.1 Version 2.5.0.0

1. Fix issue: The start address of HeaderBuf must be aligned by 4 when
2. VENDOR_FEATURE1_SUPPORT is enabled.
3. WMM ACM: see history of acm_comm.c.
4. Add an ATE command for AUTOALC.
5. Add an ATE command for interpacket GAP.
6. Add an ATE command for ATE payload pattern.
7. Fix issue: UAPSD SP can not be closed correctly for mix-mode power save. UAPSD + legacy PS.
8. [Bug fixed] The extended rate of probe-req is disappeared in AP-Client mode
9. Fix issue: kernel panic when we forward VLAN bc/mc packet to wireless LAN.
10. Fix issue: some reports from Prevent software analysis tool.
11. Fix issue: get wrong VLAN priority from VLAN tag in RTMPCheckEtherType().
12. Fix issue: no 11b basic rate in beacon when we change WirelessMode to 2.4G, then 5G, then 2.4G
13. Fix issue: no 11b-only mode can be set in AP mode.
14. MBSS: add function to set different phy mode for different BSS.

15. Phy Mode: add check if the chip supports 5G band when WirelessMode is 5G band for command WirelessMode and MBSSWirelessMode.
16. QLOAD: Fix issue for big endian. Or value of QLOAD element in beacon will be wrong.
17. Station: Add new rate switch algorithm (AGS) for 1*1, 2*2, 3*3.
18. AP: Fix power save problem when station is in power-save mode and send (re)associate frame again we will think the station is still in PS mode, but the station is in ACTIVE mode.
19. TX Block: Fix no packet can be sent when TX Fail count > a threshold for non-WDS interface in RTMPDeQueuePacket().
20. Fix WPS issue: WPS process failed with some WPS Client that sends dis-assoc close to WSC_DONE.

1.3 RT535X Version History

1.3.1 Version 2.5.0.0

1. RT5350 init version.
2. AP/STA pass TGN and WPS QA pre test.
3. Feature Support: 16 Multiple SSID support.
4. New multiple BSSID (use MAC address Byte0 to distinguish different BSSID).
5. Hardware WAPI support.
6. Hardware Antenna Diversity support.
7. Internal TSSI support.
8. Software to config BBP diversity directly and skip the calibration in EEPROM.

2 CONFIGURATION

STA driver can be configured via following interfaces, i.e.

1. configuration file
2. "iwconfig" command
3. "iwpriv" command

Note:

- 1) modify configuration file "RT2860STA.dat" in /etc/Wireless/RT2860STA/RT2860STA.dat.
- 2) iwconfig/iwpriv comes with kernel.
- 3) iwpriv use, please refer to below sections for details.

2.1 Configuration File RT2860STA.dat

```
# Copy this file to /etc/Wireless/RT2860STA/RT2860STA.dat
# This file will be read on loading driver module.
#
# Use "vi RT2860STA.dat" to modify settings according to your need.
#
#
#The word of "Default" must not be removed
Default
CountryRegion=5
CountryRegionABand=7
CountryCode=
ChannelGeography=1
SSID=11n-AP
NetworkType=Infra
WirelessMode=5
```

Channel=0
BeaconPeriod=100
TxPower=100
BGProtection=0
TxPreamble=0
RTSThreshold=2347
FragThreshold=2346
TxBurst=1
PktAggregate=0
WmmCapable=1
AckPolicy=0;0;0;0
AuthMode=OPEN
EncryptType=NONE
WPAPSK=
DefaultKeyID=1
Key1Type=0
Key1Str=
Key2Type=0
Key2Str=
Key3Type=0
Key3Str=
Key4Type=0
Key4Str=
PSMode=CAM
AutoRoaming=0
RoamThreshold=70
APSDCapable=0
APSDAC=0;0;0;0
HT_RDG=1
HT_EXTCHA=0
HT_OpMode=1
HT_MpduDensity=4
HT_BW=1
HT_BADecline=0
HT_AutoBA=1
HT_BADecline=0
HT_AMSDU=0
HT_BAWinSize=64
HT_GI=1
HT_MCS=33
HT_MIMOPSMODE=3
HT_DisallowTKIP=1
IEEE80211H=0
TGnWifiTest=0
WirelessEvent=0
CarrierDetect=0
AntDiversity=0
BeaconLostTime=4
FtSupport=1

NOTE:

WMM parameters
WmmCapable
AckPolicy1~4

Set it as 1 to turn on WMM Qos support
Ack policy which support normal Ack or no Ack

(AC_BK, AC_BE, AC_VI, AC_VO)

All WMM parameters do not support iwpriv command but 'WmmCapable', please store all parameter to RT2870STA.dat, and restart driver.

2.2 Configuration file use

Syntax is 'Param'='Value' and describes below.

SectionNumber	Param Value
	...
	...
	...

2.2.1 CountryRegion

Value

Region	Channels
0	1-11
1	1-13
2	10-11
3	10-13
4	14
5	1-14
6	3-9
7	5-13
31	1-14
32	1-11 active scan, 12 and 13 passive scan
33	1-14 all active scan, 14 b mode only

2.2.2 CountryRegionForABand

Value

Region	Channels
0	36, 40, 44, 48, 52, 56, 60, 64, 149, 153, 157, 161, 165
1	36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140
2	36, 40, 44, 48, 52, 56, 60, 64
3	52, 56, 60, 64, 149, 153, 157, 161
4	149, 153, 157, 161, 165
5	149, 153, 157, 161
6	36, 40, 44, 48
7	36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140, 149, 153, 157, 161, 165

8	52, 56, 60, 64
9	36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 132, 136, 140, 149, 153, 157, 161, 165
10	36, 40, 44, 48, 149, 153, 157, 161, 165
11	36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 149, 153, 157, 161

2.2.3 SSID

value

0~z, 1~32 ascii characters.

2.2.4 WirelessMode

value

- 0: legacy 11b/g mixed
- 1: legacy 11B only
- 2: legacy 11A only
- 3: legacy 11a/b/g mixed
- 4: legacy 11G only
- 5: 11ABGN mixed
- 6: 11N only
- 7: 11GN mixed
- 8: 11AN mixed
- 9: 11BGN mixed
- 10: 11AGN mixed
- 11: 11N only in 5G band only

2.2.5 Channel

value

depends on CountryRegion or CountryRegionForABand

2.2.6 BGProtection

value

- 0: Auto
- 1: Always on
- 2: Always off

2.2.7 TxPreamble

value

- 0:Preamble Long
- 1:Preamble Short
- 2:Auto

2.2.8 RTSThreshold

value

1~2347

2.2.9 FragThreshold

value
256~2346

2.2.10 TxBurst

value
0: Disable
1: Enable

2.2.11 PktAggregate

value
0: Disable
1: Enable

2.2.12 NetworkType

value
Infra: infrastructure mode
Adhoc: adhoc mode

2.2.13 AuthMode

value
OPEN For open system
SHARED For shared key system
WEPAUTO Auto switch between OPEN and SHARED
WPAPSK For WPA pre-shared key (Infra)
WPA2PSK For WPA2 pre-shared key (Infra)
WPANONE For WPA pre-shared key (Adhoc)
WPA
WPA2

2.2.14 EncryptType

value
NONE For AuthMode=OPEN
WEP For AuthMode=OPEN or AuthMode=SHARED
TKIP For AuthMode=WPAPSK or WPA2PSK
AES For AuthMode=WPAPSK or WPA2PSK

2.2.15 DefaultKeyID

value
1~4

2.2.16 WEP KeyType

Key1Type=vaule

Key2Type=value
Key3Type=vaule
Key4Type=vaule
value
0 hexadecimal type
1 assic type
(use: reading profile only)

2.2.17 WEP Hex Key

Key1=value
Key2=value
Key3=value
Key4=value
value
10 or 26 hexadecimal characters eg: 012345678
5 or 13 ascii characters eg: passwd
(use: "iwpriv" only)

2.2.18 WEP Key String

Key1Str=value
Key2Str=value
Key3Str=vaule
Key4Str=vaule
value
10 or 26 characters (key type=0)
5 or 13 characters (key type=1)
(use: reading profile only)

2.2.19 WPAPSK

value
8~63 ASCII or
64 HEX characters

2.2.20 WmmCapable

value
0: Disable WMM
1: Enable WMM

2.2.21 IEEE80211H

Enabel IEEE802.11h support
Value:
0:Disable
1:Enable

2.2.22 PSMode

value

CAM
Max_PSP
Fast_PSP
Legacy_PSP

Constantly Awake Mode
Max Power Saving
Fast Power Saving
Legacy Power Saving

2.2.23 FastRoaming

value
0: Disabled
1: Enabled

2.2.24 RoamThreshold

value
0 ~ 255

2.2.25 TGnWifiTest

value
0: Disabled
1: Enabled

2.2.26 WirelessEvent

value
0: Disabled
1: Enabled (send custom wireless event)

2.2.27 CarrierDetect

value
0: Disabled
1: Enabled

2.2.28 HT_RDG

value
0: Disabled
1: Enabled

2.2.29 HT_EXTCHA

value
0: Below
1: Above

2.2.30 HT_OpMode

value
0: HT mixed format
1: HT greenfield format

(Note) If you want to do TGN WIFI green field item, please set HT_OpMode=1

2.2.31 HT_MpduDensity

value
0 ~ 7

2.2.32 HT_BW

value
0: 20MHz
1: 40MHz

2.2.33 HT_AutoBA

value
0: Disabled
1: Enabled

2.2.34 HT_AMSDU

value
0: Disabled
1: Enabled

2.2.35 HT_BAWinSize

value
1 ~ 64

2.2.36 HT_GI

value
0: long GI
1: short GI

2.2.37 HT_MCS

value
0 ~ 15
33: auto

2.2.38 HT_MIMOPSEnable

Enable/Disable the 802.11n SM power save function.

Value:

0: Disable
1: Enable (Default)

2.2.39 HT_MIMOPSMODE

value

- 0: Static SM Power Save Mode
- 2: Reserved
- 1: Dynamic SM Power Save Mode
- 3: SM enabled
(not fully support yet)

2.2.40 HT_DisallowTKIP

Enable/Disable N rate with 11N ap when cipher is WEP or TKIP.

Value:

- 0: FALSE
- 1: TRUE

Default setting is disable.

2.2.41 HT_RxStream

Set the number of spatial streams for reception

Value:

- 1: 1 Rx stream
- 2: 2 Rx stream

2.2.42 HT_TxStream

Set the number of spatial streams for transmission

Value:

- 1: 1 Tx stream
- 2: 2 Tx stream

2.2.43 HT_LinkAdapt

Enable/Disable HT Link Adaptation Control

Value:

- 0: Disable (Default)
- 1: Enable

2.2.44 HT_HTC

Enable/disable HTC field of data frames send with 802.11n data rates

Value:

- 0: Disable (Default)
- 1: Enable

2.2.45 HT_DisableReordering

Disable AMPDU re-ordering handling mechanism

Value:

0:Disable (Default)

1:Enable

2.2.46 BeaconLostTime

Change Beacon Lost Time

Value:

1 ~ 60 seconds

Default value is 4 seconds

2.2.47 AutoRoaming

Enable/disable auto roaming mechanism

Value:

0: disable (Default)

1: enable

2.2.48 MacAddress

MacAddress=value

Value: XX:XX:XX:XX:XX:XX

2.2.49 TDLSCapable

Enable/disable TDLSCapable function

Value:

0: disable

1: enable

2.2.50 AutoConnect

Enable/Disable driver connect to ANY AP when SSID is null.

Value:

0: disable (default)

1: enable

2.2.51 HT_40MHZ_INTOLERANT

Enable/Disable 40MHz channel bandwidth operation and also indicate other 20/40BSS Coex

Value:

0:Disable (default)

1:Enable

2.2.52 AntGain

Define peak antenna gain (dBi) for Single SKU setting.

Value:

0: Disable Single SKU TxPower Adjustment.

1~255: Enable Single SKU TxPower Adjustment.

2.2.53 BandedgeDelta

Define delta conducted power value which can pass bandedge of FCC certification at Ch1 and Ch11 (dBm) within HT_40 Bandwidth for Single SKU setting.

Value:

1~255: Delta value between HT_20 and HT_40 power value.

2.2.54 HwAntDiversity=Value (RT5350 only)

Description:

Use this command to enable HW Antenna Diversity.

Value:

0: Disable

1: Enable

3 WIRELESS TOOLS

3.1 Iwpriv ra0 set use

This section describes parameters set using iwpriv. Please refer to the Readme section for more general data.

`iwpriv ra0 set [parameters]=[Value]`

Note: Execute one iwpriv/set command at a time.

3.1.1 DriverVersion

Check driver version by issue iwpriv set command.

Range:

Any value

Value:

0

3.1.2 CountryRegion

Set country region.

Range:

{0~7}

Value:

Region	Channels
0	1-11
1	1-13
2	10-11
3	10-13
4	14
5	1-14
6	3-9
7	5-13
31	1-14
32	1-11 active scan, 12 and 13 passive scan
33	1-14 all active scan, 14 b mode only

3.1.3 CountryRegionABand

Set country region for A band.

Range:

{0~9}

Value:

Region	Channels
0	36, 40, 44, 48, 52, 56, 60, 64, 149, 153, 157, 161, 165
1	36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140
2	36, 40, 44, 48, 52, 56, 60, 64
3	52, 56, 60, 64, 149, 153, 157, 161
4	149, 153, 157, 161, 165
5	149, 153, 157, 161
6	36, 40, 44, 48
7	36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140, 149, 153, 157, 161, 165
8	52, 56, 60, 64
9	36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 132, 136, 140, 149, 153, 157, 161, 165
10	36, 40, 44, 48, 149, 153, 157, 161, 165
11	36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 149, 153, 157, 161

3.1.4 SSID

Set AP SSID

Range:

{0~z, 1~32 ascii characters}

Value:

3.1.5 WirelessMode

Set Wireless Mode

Range:

{0~10}

Value:

- 0: legacy 11b/g mixed
- 1: legacy 11B only
- 2: legacy 11A only
- 3: legacy 11a/b/g mixed
- 4: legacy 11G only
- 5: 11ABGN mixed
- 6: 11N only
- 7: 11GN mixed
- 8: 11AN mixed
- 9: 11BGN mixed
- 10: 11AGN mixed
- 11: 11N only in 5G band only

3.1.6 TxBurst:

Set TxBurst Enable or Disable

Range:

{0,1}

Value:

- 0:Disable,
- 1:Enable

3.1.7 PktAggregate:

Set Tx Aggregate Enable or Disable

Range:

{0,1}

Value:

- 0:Disable,
- 1:Enable

3.1.8 TxPreamble:

Set TxPreamble

Range:

{0~2}

Value:

- 0:Preamble Long,
- 1:Preamble Short,
- 2:Auto

3.1.9 TxPower:

Set Tx power in percentage
Range:
{0~100}
Value:

3.1.10 Channel

Set Channel, depends on CountryRegion or CountryRegionABand

3.1.11 BGProtection:

Set 11B/11G Protection
Range:
{0~2}
Value:
0:Auto,
1:Always on,
2:Always off

3.1.12 RTSThreshold:

Set RTS Threshold
Range:
{1~2347}
Value:

3.1.13 FragThreshold:

Set Fragment Threshold
Range:
{256~2346}
Value:

3.1.14 NetworkType:

Set Network type
Range:
{Infra,Adhoc}
Value:

3.1.15 AuthMode:

Set Authentication Mode
Range:
{OPEN,SHARED,WEPAUTO,WPAPSK,WPA2PSK,WPANONE}
Value:

3.1.16 EncryptType:

Set Encryption Type

Range:

{NONE,WEP,TKIP,AES}

Value:

3.1.17 DefaultKeyID:

Set Default Key ID

Range:

{1~4}

Value:

3.1.18 Key1

Set Key1 String

Range:

{5 ascii characters or 10 hex number or
13 ascii characters or 26 hex numbers}

Value:

3.1.19 Key2

Set Key2 String

Range:

{5 ascii characters or 10 hex number or
13 ascii characters or 26 hex numbers}

Value:

3.1.20 Key3

Set Key3 String

Range:

{5 ascii characters or 10 hex number or
13 ascii characters or 26 hex numbers}

Value:

3.1.21 Key4

Set Key4 String

Range:

{5 ascii characters or 10 hex number or
13 ascii characters or 26 hex numbers}

Value:

3.1.22 WPAPSK

WPA Pre-Shared Key

Range:

{8~63 ascii or 64 hex characters}

Value:

3.1.23 WmmCapable

Set WMM Capable

Range:

{0,1}

Value:

0:Disable WMM,
1:Enable WMM

3.1.24 IEEE80211H

Enabel IEEE802.11h support

Range:

{0,1}

Value:

0:Disable
1:Enable

3.1.25 PSMode

Set Power Saving Mode

Range:

{CAM, MAX_PSP, FAST_PSP}

Value:

3.1.26 ResetCounter

Reset statistics counter

Range:

Any vlaue

Value:

0

3.1.27 Debug

Set on debug level

Range:

{0 ~ 5}

Value:

0: OFF no debug message display
1: ERROR display error message
2: WARN display warning message
3: TRACE display trace message, usually used.
4: INFO display informatic message
5: LOUD display all message

3.1.28 CarrierDetect

value

0: Disabled
1: Enabled

3.1.29 HtRdg

Enable HT Reverse Direction Grant.

value

- 0: Disabled
- 1: Enabled

3.1.30 HtExtcha

To locate the 40MHz channel in combination with the control.

value

- 0: Below
- 1: Above

3.1.31 HtOpMode

Change HT operation mode.

value

- 0: HT mixed format
- 1: HT greenfield format

3.1.32 HtMpduDensity

Minimum separation of MPDUs in an A-MPDU.

value

0 ~ 7

- 0: no restriction
- 1: 1/4 μ s
- 2: 1/2 μ s
- 3: 1 μ s
- 4: 2 μ s
- 5: 4 μ s
- 6: 8 μ s
- 7: 16 μ s

3.1.33 HtBw

Support channel width.

value

- 0: 20MHz
- 1: 40MHz

3.1.34 HtAutoBa

Enable auto block acknowledgment (Block Ack).

value

- 0: Disabled
- 1: Enabled

3.1.35 HtAmsdu

Enable aggregation of multiple MSDUs in one MPDU.

value

0: Disabled
1: Enabled

3.1.36 HtBaWinSize

Set BA WinSize.

value

1 ~ 64

3.1.37 HtGi

Support Short/Long GI.

value

0: long GI
1: short GI

3.1.38 HtMcs

MCS rate selection.

value

0 ~ 15
33: auto

3.1.39 HtProtect

Enable HT protection for legacy device.

value

0: Disable
1: Enable

3.1.40 HtMimoPs

MIMO power save.

value

0: Disable
1: Enable

3.1.41 FixedTxMode

Set Fixed Tx Mode for fixed rate setting

value

Mode = CCK

MCS= 0	=> 1Mbps
MCS= 1	=> 2Mbps
MCS= 2	=> 5.5 Mbps
MCS= 3	=> 11 Mbps

Mode = OFDM

MCS= 0	=> 6Mbps
MCS= 1	=> 9Mbps
MCS= 2	=> 12Mbps
MCS= 3	=> 18Mbps

MCS= 4	=> 24Mbps
MCS= 5	=> 36Mbps
MCS= 6	=> 48Mbps
MCS= 7	=> 54Mbps

3.1.42 LongRetry

USE:
iwpriv ra0 set LongRetry=value
value:
0~255

3.1.43 ShortRetry

USE:
iwpriv ra0 set ShortRetry=value
value:
0~255

3.1.44 HtTxStream=value

Value:
1: Support 1-Tx Stream for MCS0 ~ MCS7
2: Support 2-Tx Stream for MCS0 ~ MCS15

3.1.45 HtRxStream=value

Value:
1: Support 1-Rx Stream for MCS0 ~ MCS7
2: Support 2-Rx Stream for MCS0 ~ MCS15

3.1.46 HtDisallowTKIP=value

Enable/Disable N rate with 11N ap when cipher is WEP or TKIP.

Value:
0: FALSE (Default)
1: TRUE

3.1.47 HtBaDecline

Reject all Recipient's BA requests.

Value:
0: Disable (Default)
1: Enable

3.1.48 BeaconLostTime=value

Change Beacon Lost Time

Value:

1 ~ 60 seconds

Default value is 4 seconds

3.1.49 AutoRoaming=value

Enable/disable auto roaming mechanism

Value:

0: disable (Default)

1: enable

3.1.50 SiteSurvey=value

Scan with specific SSID after link up

Value:

0~z, 1~32 ascii characters

3.1.51 TdlsCapable=value

Enable/disable TDLS capable

Value:

0: disable

1: enable

Example: iwpriv ra0 set TdlsCapable=0

3.1.52 TdlsSetup=value

Manually add TDLS link

Value: MAC address

Example: iwpriv ra0 set TdlsSetup=00:11:22:33:44:55

3.1.53 AutoReconnect=value

Description: Enable/Disable driver auto reconnect functionality

Valid Range: 0-1

Default Value: 1

0: Disable, 1: Enable

3.1.54 AdhocN=value

Description: Enable/Disable Adhoc to support N or not

Valid Range: 0-1

Default Value: 1

0: Disable, 1: Enable

3.1.55 AntGain

Define peak antenna gain (dBi) for Single SKU setting.

Value:

- 0: Disable Single SKU TxPower Adjustment.
- 1~255: Enable Single SKU TxPower Adjustment.

3.1.56 HwAntDiv=Value (RT5350 only)

Description:

Use this command to enable HW Antenna Diversity.

Value:

- 0: Disable
- 1: Enable

3.2 iwpriv ra0 show use

This section describes parameters set using iwpriv. Please refer to the Readme section for more general data.

A detailed explanation of each parameter for iwpriv is shown subsequently. Refer to the Readme before using this section. `iwpriv ra0 show [parameters]`

3.2.1 connStatus

Show STA connection Status

3.2.2 driverVer

Show STA current driver version

3.2.3 bainfo

Show STA current BA information

3.2.4 rxbulk

Show STA current rxbulk information

3.2.5 txbulk

Show STA current txbulk information

3.2.6 AutoReconnect

Show bAutoReconnect flag

3.2.7 WPAPSK

Show WPA Passphrase

3.2.8 PMK

Show PMK key

Ralink Website document

**for stevej@cradlepoint.com
And Company Use Only**

3.3 iwpriv ra0 use

This section describes parameters set using iwpriv. Please refer to the Readme section for more general data.

```
iwpriv ra0 show [parameters]
```

3.3.1 radio_off

Turn STA radio off

3.3.2 radio_on

Turn STA radio on

Ralink Website document

**for stevej@cradlepoint.com
And Company Use Only**

3.4 Iwpriv Examples

3.4.1 Infrastructure

1.1.1.1 OPEN/NONE

Config STA to link with AP which is OPEN/NONE(Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Infra
2. iwpriv ra0 set AuthMode=OPEN
3. iwpriv ra0 set EncrypType=NONE
4. iwpriv ra0 set SSID="AP's SSID"

1.1.1.2 SHARED/WEP

Config STA to link with AP which is SHARED/WEP(Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Infra
2. iwpriv ra0 set AuthMode=SHARED
3. iwpriv ra0 set EncrypType=WEP
4. iwpriv ra0 set DefaultKeyID=1
5. iwpriv ra0 set Key1="AP's wep key"
6. iwpriv ra0 set SSID="AP's SSID"

1.1.1.3 WPAPSK/TKIP

Config STA to link with AP which is WPAPSK/TKIP(Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Infra
2. iwpriv ra0 set AuthMode=WPAPSK
3. iwpriv ra0 set EncrypType=TKIP
4. iwpriv ra0 set SSID="AP's SSID"
5. iwpriv ra0 set WPAPSK="AP's wpa-preshared key"
6. iwpriv ra0 set SSID="AP's SSID"

1.1.1.4 WPAPSK/AES

Config STA to link with AP which is WPAPSK/AES(Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Infra
2. iwpriv ra0 set AuthMode=WPAPSK
3. iwpriv ra0 set EncrypType=AES
4. iwpriv ra0 set SSID="AP's SSID"
5. iwpriv ra0 set WPAPSK="AP's wpa-preshared key"
6. iwpriv ra0 set SSID="AP's SSID"

1.1.1.5 WPA2PSK/TKIP

Config STA to link with AP which is WPA2PSK/TKIP(Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Infra
2. iwpriv ra0 set AuthMode=WPA2PSK
3. iwpriv ra0 set EncrypType=TKIP
4. iwpriv ra0 set SSID="AP's SSID"
5. iwpriv ra0 set WPAPSK=12345678
6. iwpriv ra0 set SSID="AP's SSID"

3.4.2 Ad-Hoc

1.1.1.6 OPEN/NONE

Config STA to create/link as adhoc mode, which is OPEN/NONE(Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Adhoc
2. iwpriv ra0 set AuthMode=OPEN
3. iwpriv ra0 set EncrypType=NONE
4. iwpriv ra0 set SSID="Adhoc's SSID"

1.1.1.7 WPANONE/TKIP

Config STA to create/link as adhoc mode, which is WPANONE/TKIP(Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Adhoc
2. iwpriv ra0 set AuthMode=WPANONE
3. iwpriv ra0 set EncrypType=TKIP
4. iwpriv ra0 set SSID="AP's SSID"
5. iwpriv ra0 set WPAPSK=12345678
6. iwpriv ra0 set SSID="AP's SSID"

3.4.3 Get site survey

use:

```
iwpriv ra0 get_site_survey
```

3.4.4 Get Statistics

use:

```
iwpriv ra0 stat ; read statistic counter
iwpriv ra0 set ResetCounter=0 ; reset statistic counter
```

3.4.5 ANY SSID

Link with an AP which is the largest strength, set ANY SSID (ssidLen=0)

use:

```
iwconfig ra0 essid ""
or
iwpriv ra0 set SSID=""
```

3.5 iwlist

This section describes parameters set using iwlist. Please refer to the Readme section for more general data.

iwlist ra0 scanning - list the results after scanning(manual rescan)

3.6 iwconfig

The subsequent settings are used in the standard iwconfig configuration

- 1) iwconfig ra0 essid {NN|on|off} ; set essid

- | | | |
|-----|--|---|
| 2) | <code>iwconfig ra0 mode {managed ad-hoc ...}</code> | <code>; set wireless mode</code> |
| 3) | <code>iwconfig ra0 freq N.NNNN[k M G]</code> | <code>; set frequency</code> |
| 4) | <code>iwconfig ra0 channel N</code> | <code>; set channel</code> |
| 5) | <code>iwconfig ra0 ap {N off auto}</code> | <code>; set AP address</code> |
| 6) | <code>iwconfig ra0 nick N</code> | <code>; set nickname</code> |
| 7) | <code>iwconfig ra0 rate {N auto fixed}</code> | <code>; set rate</code> |
| 8) | <code>iwconfig ra0 rts {N auto fixed off}</code> | <code>; set RTS threshold</code> |
| 9) | <code>iwconfig ra0 frag {N auto fixed off}</code> | <code>; set Fragment threshold</code> |
| 10) | <code>iwconfig ra0 enc {NNNN-NNNN off}</code> | <code>; set encryption type</code> |
| 11) | <code>iwconfig ra0 power {period N timeout N}</code> | <code>; set power management modes</code> |

Note: Refer to the 'iwconfig', 'iwlist' and 'iwpriv' sections for wireless extension instructions.

Ralink Website document

**for stevej@cradlepoint.com
And Company Use Only**

4 WPS – WI-FI PROTECTED SETUP

Simple Config Architectural Overview

This section presents a high-level description of the Simple Config architecture. Much of the material is taken directly from the Simple Config specification.

Figure 1 depicts the major components and their interfaces as defined by Wi-Fi Simple Config Spec. There are three logical components involved: the Registrar, the access point (AP), and the Enrollee.

- The **Enrollee** is a device seeking to join a WLAN domain. Once an Enrollee obtains a valid credential, it becomes a member.
- A **Registrar** is an entity with the authority to issue and revoke domain credentials. A registrar can be integrated into an AP.
- The **AP** can be either a WLAN AP or a wireless router.




Figure 1. Components and Interfaces

Registration initiation is ordinarily accomplished by a user action such as powering up the Enrollee and, optionally, running a setup wizard on the Registrar (PC).

4.1 Iwpriv use

This section describes parameters set using iwpriv. Please refer to the Readme section for more general data.

`iwpriv ra0 [commands]=[Value]`

Note: Wireless extension private handlers.

4.1.1 wsc_conf_mode

Set WPS conf mode.

Range:

{0, 1, 2}

Value:

0: WPS Disabled

1: Enrollee

2: Registrar

4.1.2 wsc_mode

Set WPS mode, PIN or PBC.

Range:

{1, 2}

Value:

1: PIN

2: PBC

4.1.3 wsc_pin

Set Enrollee's PIN Code.

Range:

{00000000 ~ 99999999}

Value:

4.1.4 wsc_ssid

Set WPS AP SSID.

Range:

{0~z, 1~32 ascii characters}

Value:

4.1.5 wsc_bssid

BSSID of WSC AP that STA wants to do WPS with

Value:

xx:xx:xx:xx:xx:xx

4.1.6 wsc_start

Trigger RT3572 STA driver to do WPS process.

Range:

NULL

Value:

4.1.7 wsc_stop

Stop WPS process and don't wait upon two-minute timeout.

Range:

NULL

Value:

4.1.8 wsc_gen_pincode

Generate new PIN code.

Range:

NULL

Value:

4.1.9 wsc_cred_count

Set count of WPS credential, only support one credential for M8 in Registrar mode.

Range:

{1 ~ 8}

Value:

4.1.10 wsc_cred_ssid

Set SSID into credtentail[idx].

Range:
{"idx ssid_str"}
Value:
idx: 0 ~ 7
ssid_str: 0~z, 1~32 ascii characters
Example:
iwpriv ra0 wsc_cred_ssid "0 wps_ap1"

4.1.11 wsc_cred_auth

Set AuthMode into credtentail[idx].
Range:
{"idx auth_str"}
Value:
idx: 0 ~ 7
auth_str: OPEN, WPAPSK, WPA2PSK, SHARED, WPA, WPA2
Example:
iwpriv ra0 wsc_cred_auth "0 WPAPSK"

4.1.12 wsc_cred_encr

Set EncryptType into credtentail[idx].
Range:
{"idx encr_str"}
Value:
idx: 0 ~ 7
encr_str: NONE, WEP, TKIP, AES
Example:
iwpriv ra0 wsc_cred_encr "0 TKIP"

4.1.13 wsc_cred_keyIdx

Set Key Index into credtentail[idx].
Range:
{"idx key_index"}
Value:
idx: 0 ~ 7
key_index: 1 ~ 4
Example:
iwpriv ra0 wsc_cred_keyIdx "0 1"

4.1.14 wsc_cred_key

Set Key into credtentail[idx].
Range:
{"idx key"}
Value:
idx: 0 ~ 7
key: ASCII string (wep_key_len(=5,13), passphrase_len(=8~63))
OR
Hex string (wep_key_len(=10,26), passphrase_len(=64))
Example:

```
iwpriv ra0 wsc_cred_key "0 12345678" ;; Passphrase
iwpriv ra0 wsc_cred_key "0 abcd" ;; WEP Key
```

4.1.15 wsc_cred_mac

Set AP's MAC into credtentail[idx].

Range:

{"idx mac_str"}

Value:

idx: 0 ~ 7

mac_str: xx:xx:xx:xx:xx:xx

Example:

```
iwpriv ra0 wsc_cred_mac "0 00:11:22:33:44:55"
```

4.1.16 wsc_conn_by_idx

Connect AP by credential index.

Range:

{0 ~ 7}

Value:

idx: 0 ~ 7

4.1.17 wsc_auto_conn

If the registration is successful, driver will re-connect to AP or not.

Range:

{0, 1}

Value:

0: Disabled, driver won't re-connect to AP with new configurations.

1: Enabled, driver will re-connect to AP with new configurations.

4.1.18 wsc_ap_band

Setting prefer band to do WPS with dual band WPS AP.

Range:

{0, 1, 2}

Value:

0: prefer 2.4G

1: prefer 5G

2: auto

Default value is auto (2)

4.1.19 Wsc4digitPinCode

Generate WPS 4-digits PIN

Value:

0: Disable

1: Enable

4.2 WPS STA as an Enrollee or Registrar

Build WPS function. Please set the "HAS_WSC" parameter value to "y".

4.2.1 Enrollee Mode

1.1.1.8 PIN mode

Running Scenarios (case 'a' and 'b')

- a. Adding an Enrollee to AP+Registrar (EAP)
[AP+Registrar]<----EAP-->[Enrollee Client]
- b. Adding an Enrollee with external Registrar (UPnP/EAP)
[External Registrar]<----UPnP-->[AP_Proxy]<---EAP-->[Enrollee Client]

Note:

'EAP' indicates to use wireless medium and 'UPnP' indicates to use wired or wireless medium.

- (i) [Registrar] or [AP+Registrar]
Enter the Enrollee PinCode on the Registrar and start WPS on the Registrar.
Note:
How to get the Enrollee PinCode? Use 'iwpriv ra0 stat' on the Enrollee.
- (ii) [RT3572 Linux WPS STA]
iwpriv ra0 wsc_conf_mode 1 ;; Enrollee
iwpriv ra0 wsc_mode 1 ;; PIN
iwpriv ra0 wsc_ssid "AP's SSID"
iwpriv ra0 wsc_start
- (iii) If the registration is successful, the Enrollee will be re-configured with the new parameters, and will connect to the AP with these new parameters.

1.1.1.9 PBC mode

Running Scenarios (case 'a' only)

- a. Adding an Enrollee to AP+Registrar (EAP)
[AP+Registrar]<----EAP-->[Client]
- (i) [AP+Registrar]
Start PBC on the Registrar.
- (ii) [RT3572 Linux WPS STA]
iwpriv ra0 wsc_conf_mode 1 ;; Enrollee
iwpriv ra0 wsc_mode 2 ;; PBC
iwpriv ra0 wsc_start
- (iii) If the registration is successful, the Enrollee will be re-configured with the new parameters, and will connect to the AP with these new parameters.

4.2.2 Registrar Mode

1.1.1.10 PIN mode

Running Scenarios (case 'a' and 'b')

- a. Configure the un-configured AP
[Unconfigured AP]<---EAP--->[Registrar]
- b. Configure the configured AP
Configured AP]<---EAP--->[Registrar]
- (i) [AP]
Start PIN on the Enrollee WPS AP.
- (ii) [RT3572 Linux WPS STA]
iwpriv ra0 wsc_conf_mode 2 ;; Registrar
iwpriv ra0 wsc_mode 1 ;; PIN
iwpriv ra0 wsc_pin xxxxxxxx ;; AP's PIN Code
iwpriv ra0 wsc_ssid "AP's SSID"
iwpriv ra0 wsc_start
- (iii) If the registration is successful;

in case 'a':

The Registrar will be re-configured with the new parameters, and will connect to the AP with these new parameters;

in case 'b':

The Registrar will be re-configured with AP's configurations, and will connect to the AP with these new parameters.

1.1.1.11 PBC mode

Running Scenarios (case 'a' and 'b')

- a. Configure the un-configured AP
[Unconfigured AP]<---EAP--->[Registrar]
- b. Configure the configured AP
Configured AP]<---EAP--->[Registrar]
- (i) [AP]
Start PBC on the Enrollee WPS AP.
- (ii) [RT3572 Linux WPS STA]
iwpriv ra0 wsc_conf_mode 2 ;; Registrar
iwpriv ra0 wsc_mode 2 ;; PBC
iwpriv ra0 wsc_start
- (iii) If the registration is successful;

in case 'a':

The Registrar will be re-configured with the new parameters, and will connect to the AP with these new parameters;

in case 'b':

The Registrar will be re-configured with AP's configurations, and will connect to the AP with these new parameters.

4.3 WPS IOCTL use

This section describes specific parameters and arguments. Please refer to the previous section for more general data.

4.3.1 iwpriv commands without argument

1. iwpriv ra0 wsc_start
2. iwpriv ra0 wsc_stop
3. iwpriv ra0 wsc_gen_pincode

Example:

```
memset(&lwreq, 0, sizeof(lwreq));
sprintf(lwreq.ifr_name, "ra0", 3);
lwreq.u.mode = WSC_STOP;

/* Perform the private ioctl */
if(ioctl(skfd, RTPRIV_IOCTL_SET_WSC_PROFILE_U32_ITEM, &lwreq) < 0)
{
    fprintf(stderr, "Interface doesn't accept private ioctl...\n");
    return -1;
}
```

4.3.2 iwpriv commands with one INT argument

1. iwpriv ra0 wsc_cred_count 1
2. iwpriv ra0 wsc_conn_by_idx 1
3. iwpriv ra0 wsc_auto_conn 1
4. iwpriv ra0 wsc_conf_mode 1
5. iwpriv ra0 wsc_mode 1
6. iwpriv ra0 wsc_pin 12345678

Example:

```
memset(&lwreq, 0, sizeof(lwreq));
lwreq.u.data.length = 1;
cred_count = 1;
((int *) buffer)[i] = (int) cred_count;
offset = sizeof(int);

sprintf(lwreq.ifr_name, "ra0", 3);
lwreq.u.mode = WSC_CREDENTIAL_COUNT;
memcpy(lwreq.u.name + offset, buffer, IFNAMSIZ - offset);

/* Perform the private ioctl */
if(ioctl(skfd, RTPRIV_IOCTL_SET_WSC_PROFILE_U32_ITEM, &lwreq) < 0)
{
    fprintf(stderr, "Interface doesn't accept private ioctl...\n");
    return -1;
}
```

4.3.3 iwpriv commands with string argument

1. iwpriv ra0 wsc_ssid "0 xxxxx"
2. iwpriv ra0 wsc_cred_ssid "0 xxxxx"
3. iwpriv ra0 wsc_cred_auth "0 WPAPSK"
4. iwpriv ra0 wsc_cred_encr "0 TKIP"

5. iwpriv ra0 wsc_cred_keyIdx "0 1"
6. iwpriv ra0 wsc_cred_key "0 12345"
7. iwpriv ra0 wsc_cred_mac "0 00:11:22:33:44:55"

Example:

```
memset(&lwreq, 0, sizeof(lwreq));
memset(buffer, 0, 2048);
sprintf(lwreq.ifr_name, "ra0", 3);
sprintf(buffer, "0 wps_ssid_1");
lwreq.u.data.length = strlen(buffer) + 1;
lwreq.u.data.pointer = (caddr_t) buffer;
lwreq.u.data.flags = WSC_CREDENTIAL_SSID;

/* Perform the private ioctl */
if(ioctl(skfd, RTPRIV_IOCTL_SET_WSC_PROFILE_STRING_ITEM, &lwreq) < 0)
{
    fprintf(stderr, "Interface doesn't accept private ioctl...\n");
    return -1;
}
```

Ralink Website document

**for stevej@cradlepoint.com
And Company Use Only**

4.4 WPS IOCTL Sample Program

```
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
#include <assert.h>
#include <netinet/in.h> /* for sockaddr_in */
#include <fcntl.h>
#include <time.h>
#include <sys/times.h>
#include <unistd.h>
#include <sys/socket.h> /* for connect and socket*/
#include <sys/stat.h>
#include <err.h>
#include <errno.h>
#include <asm/types.h>
#include </usr/include/linux/wireless.h>
#include <sys/ioctl.h>

#define IFNAMSIZ 16

#define RTPRIV_IOCTL_SET_WSC_PROFILE_U32_ITEM (SIOCWFIRSTPRIV + 0x14)
#define RTPRIV_IOCTL_SET_WSC_PROFILE_STRING_ITEM (SIOCWFIRSTPRIV + 0x16)

enum {
    WSC_CREDENTIAL_COUNT = 1,
    WSC_CREDENTIAL_SSID = 2,
    WSC_CREDENTIAL_AUTH_MODE = 3,
    WSC_CREDENTIAL_ENCR_TYPE = 4,
    WSC_CREDENTIAL_KEY_INDEX = 5,
    WSC_CREDENTIAL_KEY = 6,
    WSC_CREDENTIAL_MAC = 7,
    WSC_SET_DRIVER_CONNECT_BY_CREDENTIAL_IDX = 8,
    WSC_SET_DRIVER_AUTO_CONNECT = 9,
    WSC_SET_CONF_MODE = 10, // Enrollee or Registrar
    WSC_SET_MODE = 11, // PIN or PBC
    WSC_SET_PIN = 12,
    WSC_SET_SSID = 13,
    WSC_START = 14,
    WSC_STOP = 15,
    WSC_GEN_PIN_CODE = 16,
};

int main()
{
    struct iwreq lwreq;
    char buffer[2048] = {0};
    int cred_count;
    int offset = 0; /* Space for sub-ioct index */
    int skfd, i = 0; /* generic raw socket desc. */

    skfd = socket(AF_INET, SOCK_DGRAM, 0);
    if (skfd < 0)
        return -1;

    //////////// WSC_STOP ////////////
    memset(&lwreq, 0, sizeof(lwreq));
    sprintf(lwreq.ifr_name, "ra0", 3);
    lwreq.u.mode = WSC_STOP;

    /* Perform the private ioctl */
    if(ioctl(skfd, RTPRIV_IOCTL_SET_WSC_PROFILE_U32_ITEM, &lwreq) < 0)
    {
        fprintf(stderr, "Interface doesn't accept private ioctl...\n");
        return -1;
    }
}
```

```
////////////////////////////////////

//////// WSC_CREDENTIAL_COUNT //////////
memset(&lwreq, 0, sizeof(lwreq));
lwreq.u.data.length = 1;
cred_count = 1;
((int *) buffer)[i] = (int) cred_count;
offset = sizeof(int);

sprintf(lwreq.ifr_name, "ra0", 3);
lwreq.u.mode = WSC_CREDENTIAL_COUNT;
memcpy(lwreq.u.name + offset, buffer, IFNAMSIZ - offset);

/* Perform the private ioctl */
if(ioctl(skfd, RTPRIV_IOCTL_SET_WSC_PROFILE_U32_ITEM, &lwreq) < 0)
{
    fprintf(stderr, "Interface doesn't accept private ioctl...\n");
    return -1;
}
////////////////////////////////////

//////// WSC_CREDENTIAL_SSID //////////
memset(&lwreq, 0, sizeof(lwreq));
memset(buffer, 0, 2048);
sprintf(lwreq.ifr_name, "ra0", 3);
sprintf(buffer, "0 wps_ssid_1");
lwreq.u.data.length = strlen(buffer) + 1;
lwreq.u.data.pointer = (caddr_t) buffer;
lwreq.u.data.flags = WSC_CREDENTIAL_SSID;


/* Perform the private ioctl */
if(ioctl(skfd, RTPRIV_IOCTL_SET_WSC_PROFILE_STRING_ITEM, &lwreq) < 0)
{
    fprintf(stderr, "Interface doesn't accept private ioctl...\n");
    return -1;
}
////////////////////////////////////

close(skfd);
return 0;
}
```

5 ATE TEST COMMAND FORMAT

IF YOU ARE NOT FAMILIAR WITH HARDWARE, IT IS RECOMMENDED NOT TO MODIFY HARDWARE
DEFAULT VALUE.

Ralink ATE Operation Flow



Note:

- Channel setting would take effect on next ATE command.
- TxPower would take effect after frame transmit start.
TxPower can be changed dynamically on any ATE command operating.
- Any ATE parameters have to be included into ATE_INFO structure.
- Enter ATE mode by set ATE command "ATESTART".
 - Abort all TX rings
 - AsicDisableSync → Stop Beacon.
 - Stop REKEYTimer
 - Stop CounterMeasureTimer
 - MacTableReset
- Use TXCONT to check transmit power mask.
- Use TXCARR to check frequency lock (under 25ppm).

5.1 iwpriv ra0 set [parameters]=[val]

Syntax:	Example
Section# parameters	11.1.5 ATECHANNEL
Explanation	Set ATE channel.
Value:	Value:
0: ...	1:
1: ...	2:
..::

5.1.1 ATE

Description:
Set ATE actions.

Value:

ATESTART: Enter/Reset ATE mode and set Tx/Rx Idle.

ATESTOP: Leave ATE mode.

TXCARR: Send out single carrier wave at channel frequency from hardware for frequency calibration.

TXCONT: Send out frames without time gap from hardware for power mask.

TXFRAME: Send out WIFI frames from driver, Transmit frame, for EVM.

RXFRAME: Receive all frames from MAC block, Continuous RX, for PER/FER.

TXSTOP: MAC TX disable, ONLY for QA GUI.

RXSTOP: MAC RX disable, ONLY for QA GUI.

5.1.2 ATEDA

Description:
Set ATE frame header addr1.

Value:

xx:xx:xx:xx:xx:xx ; hex

5.1.3 ATESA

Description:
Set ATE frame header addr2.

Value:

xx:xx:xx:xx:xx:xx ; hex

5.1.4 ATEBSSID

Description:
Set ATE frame header addr3.

Value:

xx:xx:xx:xx:xx:xx ; hex

5.1.5 ATECHANNEL

Description:

Set ATE Channel, decimal.

Value:

802.11b/g: 1 ~ 14 depends on CountryRegion setting

5.1.6 ATETXPOW0

Description:

Set ATE Tx power for Antenna 1.

Value:

0 ~ 31 ; 2.4GHz, 5-bits only, decimal
-7 ~ 15 ; 5GHz, 5-bits only, decimal

5.1.7 ATETXPOW1

Description:

Set ATE Tx power for Antenna 2.

Value:

0 ~ 31 ; 5-bits only, decimal
-7 ~ 15 ; 5GHz, 5-bits only, decimal

5.1.8 ATETXFREQOFFSET

Description:

Set ATE RF frequency offset.

Value:

0 ~ 63 ; unit: 2KHz, decimal

5.1.9 ATETXLLEN

Description:

Set ATE frame length.

Value:

24 ~ 1500 ; decimal

5.1.10 ATETXCNT

Description:

Set ATE frame Tx count.

Value:

1 ~ ; 32-bit, decimal

5.1.11 ATETXMODE (Refer to TxMode)

Description:

Set ATE Tx Mode.

Value:

0:	CCK	802.11b
1:	OFDM	802.11g
2:	HT_MIX	802.11b/g/n

5.1.12 ATETXBW (Refer to TxMode)

Description:

Set ATE Tx and Rx Bandwidth.

Value:

- 0: 20MHz
- 1: 40MHz

5.1.13 ATETXGI (Refer to TxMode)

Description:

Set ATE Tx Guard Interval.

Value:

- 0: Long
- 1: Short

5.1.14 ATETXMCS (Refer to TxMode)

Description:

Set ATE Tx MCS type.

Value:

- 0 ~ 15

5.1.15 ATETXANT

Description:

Set ATE TX antenna.

Value:

- 0: All
- 1: Antenna one
- 2: Antenna two

5.1.16 ATERXANT

Description:

Set ATE RX antenna.

Value:

- 0: All
- 1: Antenna one
- 2: Antenna two
- 3: Antenna three

5.1.17 ATERXFER

Description:

Set ATE to periodically reset and show up RxCount (per-second) and RxTotalCount.

Value:

- 0: Disable counter visibility
- 1: Enable counter visibility

5.1.18 ATESHOW

Description:

Show all parameters of ATE.

Value:

1

5.1.19 ATEHELP

Description:

List all commands of ATE.

Value:

1

5.1.20 ResetCounter

Description:

Reset statistic counter.

Value:

0

5.1.21 ATERRF

Description:

Read all of the RF registers.

Value:

1

5.1.22 ATELDE2P

Description:

Overwrite all EEPROM contents from "/etc/Wireless/RT2860/(70)AP(/STA)/e2p.bin".

Value:

1

E.g.

iwpriv ra0 set ATELDE2P=1

5.1.23 ATETSSICBAEX (For RT5350 only)

Description:

Write the temperature compensation reference value into EEPROM relation field (0x6E).

Value:

1

E.g.

iwpriv ra0 set ATETSSICBAEX=1

5.1.24 ATEIPG

Description:

Set ATE Tx frame Interpacket gap.

Value:

200 ; decimal

5.1.25 ATEPAYLOAD

Description:

Set ATE payload pattern for TxFrame.

Value:

x ; only one octet acceptable

5.1.26 ATETSSICBA

Description:

Calibrate TSSI power delta per channel and write them into EEPROM for normal driver

Value:

xx ;8-bit, decimal,get it from e2p 0x52);
1 ;for RT5350

5.2 Tx Mode, MCS, BW and GI Selection Table

5.2.1 MODE = 0, Legacy CCK	
MCS = 0	Long Preamble CCK 1Mbps
MCS = 1	Long Preamble CCK 2Mbps
MCS = 2	Long Preamble CCK 5.5Mbps
MCS = 3	Long Preamble CCK 11Mbps
MCS = 8	Short Preamble CCK 1Mbps, * illegal rate
MCS = 9	Short Preamble CCK 2Mbps
MCS = 10	Short Preamble 5.5Mbps
MCS = 11	Short Preamble 11Mbps
Notes:	
<ol style="list-style-type: none"> Other MCS codes are reserved in legacy CCK mode. BW, SGI and STBC are reserved in legacy CCK mode. 	
5.2.2 MODE = 1, Legacy OFDM	
MCS = 0	6Mbps
MCS = 1	9Mbps
MCS = 2	12Mbps
MCS = 3	18Mbps
MCS = 4	24Mbps
MCS = 5	36Mbps
MCS = 6	48Mbps
MCS = 7	54Mbps
Notes:	
<ol style="list-style-type: none"> Other MCS code in legacy CCK mode are reserved. When BW = 1, duplicate legacy OFDM is sent. SGI, STBC are reserved in legacy OFDM mode. 	
5.2.3 MODE = 2, HT Mixed Mode	
5.2.4 MODE = 3, HT Greenfield	

MCS = 0 (1S)	(BW=0, SGI=0) 6.5Mbps
MCS = 1	(BW=0, SGI=0) 13Mbps
MCS = 2	(BW=0, SGI=0) 19.5Mbps
MCS = 3	(BW=0, SGI=0) 26Mbps
MCS = 4	(BW=0, SGI=0) 39Mbps
MCS = 5	(BW=0, SGI=0) 52Mbps
MCS = 6	(BW=0, SGI=0) 58.5Mbps
MCS = 7	(BW=0, SGI=0) 65Mbps
MCS = 8 (2S)	(BW=0, SGI=0) 13Mbps
MCS = 9	(BW=0, SGI=0) 26Mbps
MCS = 10	(BW=0, SGI=0) 39Mbps
MCS = 11	(BW=0, SGI=0) 52Mbps
MCS = 12	(BW=0, SGI=0) 78Mbps
MCS = 13	(BW=0, SGI=0) 104Mbps
MCS = 14	(BW=0, SGI=0) 117Mbps
MCS = 15	(BW=0, SGI=0) 130Mbps
MCS = 32	(BW=1, SGI=0) HT duplicate 6Mbps

Notes:

1. When BW=1, PHY_RATE = PHY_RATE * 2
2. When SGI=1, PHY_RATE = PHY_RATE * 10/9
3. The effects of BW and SGI are accumulative.
4. When MCS=0~7(1S, One Tx Stream), STBC option is supported. SGI option is supported. BW option is supported.
5. When MCS=8~15(2S, Two Tx Stream), STBC option is NOT supported. SGI option is supported. BW option is supported.
6. When MCS=32, only SGI option is supported. BW and STBC option are not supported. (BW =1, STBC=0)
7. Other MCS code in HT mode are reserved.
8. When STBC is supported. Only STBC = 1 is allowed. STBC will extend the transmission range but will not increase transmission rate.

5.3 Examples

5.3.1 Check EVM & Power

```
iwpriv ra0 set ATE=ATESTART
iwpriv ra0 set ATEDA=00:11:22:33:44:55
iwpriv ra0 set ATESA=00:aa:bb:cc:dd:ee
iwpriv ra0 set ATEBSSID=00:11:22:33:44:55
iwpriv ra0 set ATECHANNEL=1 ; set Channel
iwpriv ra0 set ATETXMODE=1 ; set TX-Mode.
iwpriv ra0 set ATETXMCS=7 ; set MCS type.
iwpriv ra0 set ATETXBW=0 ; set Bandwidth
iwpriv ra0 set ATETXGI=0 ; set Long GI.
iwpriv ra0 set ATETXLEN=1024 ; set packet length.
iwpriv ra0 set ATETXPOW0=18
iwpriv ra0 set ATETXPOW1=18
iwpriv ra0 set ATETXCNT=100000
iwpriv ra0 set ATE=TXFRAME
...
iwpriv ra0 set ATETXPOW0=19
...
iwpriv ra0 set ATETXPOW0=20
...
iwpriv ra0 set ATE=ATESTART
```

5.3.2 Check Carrier

```

iwpriv ra0 set ATE=AESTART
iwpriv ra0 set ATECHANNEL=1           ; set Channel
iwpriv ra0 set ATETXMODE=1           ; set TX-Mode.
iwpriv ra0 set ATETXMCS=7             ; set MCS type.
iwpriv ra0 set ATETXBW=0             ; set Bandwidth
iwpriv ra0 set ATETXCNT=200          ; Tx frame count(decimal)
iwpriv ra0 set ATE=TXFRAME           ; Start Tx Frame(inform BBP to change, modulation mode)
iwpriv ra0 set ATE=TXCARR             ; Start Tx carrier, Measure carrier with instrument
iwpriv ra0 set ATETXPOW0=05
iwpriv ra0 set ATETXPOW1=05
iwpriv ra0 set ATETXFREQOFFSET=19
iwpriv ra0 set ATE=AESTART

```

5.3.3 Check spectrum mask

```

iwpriv ra0 set ATE=AESTART
iwpriv ra0 set ATECHANNEL=1           ; set Channel
iwpriv ra0 set ATETXMODE=1           ; set TX-Mode.
iwpriv ra0 set ATETXMCS=7             ; set MCS type.
iwpriv ra0 set ATETXBW=0             ; set Bandwidth
iwpriv ra0 set ATETXCNT=200          ; Tx frame count(decimal)
iwpriv ra0 set ATE=TXFRAME           ; Start Tx Frame(inform BBP to change, modulation mode)
iwpriv ra0 set ATE=TXCONT            ; Start continuous TX, Measure spectrum mask with instrument
iwpriv ra0 set ATETXPOW0=5
iwpriv ra0 set ATETXPOW1=5
iwpriv ra0 set ATE=AESTART

```

5.3.4 Frequency offset tuning

```

iwpriv ra0 set ATE=AESTART
iwpriv ra0 set ATECHANNEL=1           ; set Channel
iwpriv ra0 set ATETXMODE=1           ; set TX-Mode.
iwpriv ra0 set ATETXMCS=7             ; set MCS type.
iwpriv ra0 set ATETXCNT=200          ; Tx frame count(decimal)
iwpriv ra0 set ATETXFREQOFFSET=0      ; Set frequency offset 0(decimal)
iwpriv ra0 set ATE=TXFRAME           ; Start Tx Frame
iwpriv ra0 set ATE=TXCARR             ; Start Tx carrier, Measure carrier frequency with instrument
iwpriv ra0 set ATETXFREQOFFSET=10     ; Dynamic turning frequency offset, 10(decimal)
iwpriv ra0 set ATETXFREQOFFSET=20     ; Dynamic turning frequency offset, 20(decimal)
iwpriv ra0 set ATE=AESTART           ; Stop, Store the tuning result to EEPROM

```

5.3.5 Rx

```

iwpriv ra0 set ATE=AESTART
iwpriv ra0 set ATECHANNEL=1           ; set Channel
iwpriv ra0 set ResetCounter=0         ; Reset statistic counter
iwpriv ra0 set ATETXMODE=1           ; set TX-Mode.
iwpriv ra0 set ATETXMCS=7             ; set MCS type.
iwpriv ra0 set ATETXBW=0             ; set Bandwidth
iwpriv ra0 set ATE=RXFRAME           ; Start Rx,
iwpriv ra0 set ATERXFER=1             ; show RxCnt and RSSI/per-antenna, Transmit test packets
iwpriv ra0 set ATE=AESTART           ; Stop
iwpriv ra0 stat                      ; get statistics counter
iwpriv ra0 set ATERXFER=1
iwpriv ra0 set ATERXANT=1

iwpriv ra0 set ATE=AESTART
iwpriv ra0 set ATERXANT=0
iwpriv ra0 set ATE=RXFRAME

```

5.3.6 Show all ate parameters

iwpriv ra0 set ATESHOW=1

Mode=4
TxPower0=0
TxPower1=0
TxAntennaSel=0
RxAntennaSel=0
BBPCurrentBW=0
GI=0
MCS=7
TxMode=1
Addr1=00:11:22:aa:bb:cc
Addr2=00:11:22:aa:bb:cc
Addr3=00:11:22:aa:bb:cc
Channel=1
TxLength=1024
TxCount=40000
TxRate=11
RFFreqOffset=0

5.3.7 Online help

iwpriv ra0 set ATEHELP=1

ATE=ATESTART, ATESTOP, TXCONT, TXCARR, TXFRAME, RXFRAME
ATEDA
ATESA
ATEBSSID
ATECHANNEL, range:0~14
ATETXPOW0, set power level of antenna 1.
ATETXPOW1, set power level of antenna 2.
ATETXANT, set TX antenna. 0:all, 1:antenna one, 2:antenna two.
ATERXANT, set RX antenna.0:all, 1:antenna one, 2:antenna two, 3:antenna three.
ATETXFREQOFFSET, set frequency offset, range 0~63
ATETXBW, set BandWidth, 0:20MHz, 1:40MHz
ATETXLEN, set Frame length, range 24~1500
ATETXCNT, set how many frame going to transmit.
ATETXRATE, set rate, reference to rate table.
ATETXMCS, set MCS, reference to rate table.
ATETXMODE, set Mode 0:CCK, 1:OFDM, 2:HT-Mix, 3:GreenField, reference to rate table.
ATETXGI, set GI interval, 0:Long, 1:Short
ATERXFER, 0:disable Rx Frame error rate. 1:enable Rx Frame error rate.
ATESHOW, display all parameters of ATE.
ATEHELP, online help.

5.3.8 Display Rx Packet Count and RSSI

iwpriv ra0 set ATE=RXFRAME → Start Rx

iwpriv ra0 set ATERXANT=0 → Enable All Three Rx Antennas

iwpriv ra0 set ATERXFER=1 → Enable Rx Frame Error Rate: RxCnt/RxTotal

MlmePeriodicExec: Rx packet cnt = 2/4
MlmePeriodicExec: Rx AvgRssi0=-88, AvgRssi1=-80, AvgRssi2=-91

MlmePeriodicExec: Rx packet cnt = 2/6
MlmePeriodicExec: Rx AvgRssi0=-86, AvgRssi1=-77, AvgRssi2=-89...

...

iwpriv ra0 set ATE=RXFRAME → Start Rx

iwpriv ra0 set ATERXANT=1
iwpriv ra0 set ATERXFER=1

→ Enable Three Rx Antenna-1
→ Enable Rx Frame Error Rate: RxCnt/RxTotal

MlmePeriodicExec: Rx packet cnt = 0/7
MlmePeriodicExec: Rx AvgRssi=-87

MlmePeriodicExec: Rx packet cnt = 7/14
MlmePeriodicExec: Rx AvgRssi=-90

5.3.9 Internal ALC calibration (For RT5350 only)

iwpriv ra0 set ATE=ATESTART
iwpriv ra0 set ATETSSICBA=DAC@CH1

(Note : DAC@CH1 is referred to the value of channel 1 TX0 power, stored in EEPROM 0x52 b7~b0. When user is finish this procedure, the EEPROM 0x6E will be stuffed the reference value for internal ALC function)

5.3.10 Internal ALC function testing in ATE mode (For RT5350 only)

iwpriv ra0 set ATE=ATESTART
iwpriv ra0 set ATEDA=00:11:22:33:44:55
iwpriv ra0 set ATESA=00:aa:bb:cc:dd:ee
iwpriv ra0 set ATEBSSID=00:11:22:33:44:55
iwpriv ra0 set ATECHANNEL=1
iwpriv ra0 set ATETXMODE=1
iwpriv ra0 set ATETXMCS=7
iwpriv ra0 set ATETXBW=0
iwpriv ra0 set ATETXGI=0
iwpriv ra0 set ATETXLEN=1024
iwpriv ra0 set ATETXPOW=12
iwpriv ra0 set ATETXCNT=10000000
iwpriv ra0 set ATE TXFRAME
iwpriv ra0 set ATEAUTOALC=1 (Note:Enable temperature compensation)

Below is recommend testing flow :

Make sure the device is calibrated already.

Record the channel 1 power DAC value such as #iwpriv ra0 e2p 52 which is 0x0C

Run below command for temperature compensation process:

#iwpriv ra0 set ATE=ATE ATESTART

iwpriv ra0 set ATETSSICBA=12 (Note : 12 is the decimal value of 0x0C)

Measure the Tx power status in room temperature. (The output power should be +/- 1dBm)

If the output power is normal, please change the temperature and check the Tx power status.

iwpriv ra0 set ATE=ATESTART

iwpriv ra0 set ATEDA=00:11:22:33:44:55

iwpriv ra0 set ATESA=00:aa:bb:cc:dd:ee

iwpriv ra0 set ATEBSSID=00:11:22:33:44:55

iwpriv ra0 set ATECHANNEL=1

iwpriv ra0 set ATETXMODE=1

iwpriv ra0 set ATETXMCS=7

iwpriv ra0 set ATETXBW=0

iwpriv ra0 set ATETXGI=0

iwpriv ra0 set ATETXLEN=1024

iwpriv ra0 set ATETXPOW=12

iwpriv ra0 set ATETXCNT=10000000

iwpriv ra0 set ATE TXFRAME

iwpriv ra0 set ATEAUTOALC=1 (Note:Enable temperature compensation)

5.4 iwpriv ra0 bbp [parameters]=[Value]

Read/Write BBP register by ID number.

5.4.1 BBPID

Read BBP register, BBPID only, no "=" symbol.

BBPID:

0 ~ xx ; decimal, 8-bit

5.4.2 BBPID=Value

Write BBP register.

BBPID:

0 ~ xx ; decimal, 8-bit

Value:

00 ~ FF ; hexadecimal, 8-bit

5.5 iwpriv ra0 mac [parameters]=[val]

Read/Write MAC register by offset.

5.5.1 MAC_OFFSET

Read MAC register, MAC_OFFSET only, no "=" symbol.

MAC_OFFSET:

0000 ~ FFFF ; hexadecimal, 16-bit

5.5.2 MAC_OFFSET=Value

Write MAC register.

MAC_OFFSET:

0000 ~ FFFF ; hexadecimal, 16-bit

Value:

0000 ~ FFFF ; hexadecimal, 32-bit

5.6 iwpriv ra0 e2p [parameters]=[val]

Read/Write EEPROM content by address.

5.6.1 EEP_ADDR

Read EEPROM content, EEP_ADDR only, no "=" symbol.

EEP_ADDR:

00 ~ FF ; hexadecimal, 16-bit alignment (0, 2, 4, 6, 8, A, C, ...)

5.6.2 EEP_ADDR=Value

Write EEPROM content.

EEP_ADDR:

00 ~ FF ; hexadecimal, 16-bit alignment (0, 2, 4, 6, 8, A, C, ...)

Value:

0000 ~FFFF ; hexadecimal, 16-bit

5.7 Example

5.7.1 Hardware access

```
iwpriv ra0 bbp 0 # read BBP register 0
iwpriv ra0 bbp 0=12 # write BBP register 0 as 0x12
iwpriv ra0 mac 0 # read MAC register 0
iwpriv ra0 mac 0=1234abcd # write MAC register 0 as 0x1234abcd
iwpriv ra0 e2p 0 # read E2PROM 0
iwpriv ra0 e2p c=12ab # write E2PROM 0xc as 0x12ab
```

5.7.2 Statistic counter operation

```
iwpriv ra0 stat # read statistic counter
iwpriv ra0 set ResetCounter=0 # reset statistic counter
```

5.7.3 Suggestion:

1. To turn on ATE functionality, you have to add compile flag "RALINK_ATE" to Makefile
2. Before doing ATE testing, please stop AP function
3. If you want to test another ATE action, prefer to stop AP & ATE function
4. All ATE function settings will lose efficacy after reboot.
5. Before hardware register access, please reference hardware spec.

Note.

In ATE mode, the channel must set via "ATECHANNEL"

Ralink Website document

**for stevej@cradlepoint.com
And Company Use Only**

5.8 ated

- ated - user space ATE agent program for RT3572 linux driver, Ralink Tech. Corp.
- RT3572 ATE daemon - ated, comes with RT3572 Linux driver.

The section describes the use of the Linux driver, Windows QA GUI and RT3572 ATE daemon.

5.8.1 Introduction

The ated is an optional user space component for the RT3572 linux driver. AP immediately starts working in ATE mode when "ated" starts (i.e. ATESTART). It behaves as a proxy between Windows QA GUI and RT3572 linux driver when ATE process proceeds.

ATED AUTOMATICALLY STOPS WHEN THE WINDOWS QA GUI IS CLOSED.

Ated can be stopped manually (key in '\$killall ated'). The RT3572 linux driver will stop working in ATE mode when ated is stopped or the QA GUI is closed.

5.8.2 Environment setup

1. Connect the platform you want to test directly with a Windows host by ether network line.
2. In the Windows host, run WinPcap_4_0.exe for the QA GUI.

5.8.3 How to use ated for ATE purpose

1. First you should set **both "HAS_ATE=y" and "HAS_28XX_QA=y"** in the file `~/Module/os/linux/config.mk` and compile the driver.
2. Modify the Makefile according to our target "PLATFORM".
3. Change the path of "CROSS_COMPILE" if needed.
4. Remove "-I\$(INCLUDE)" about in line 39 if your target "PLATFORM" is not "PC".
5. Then type 'make' command to compile the source code of the daemon.
6. After the driver interface "ra0" has started up, attach both of "ra0" and the ethernet interface to the bridge interface "br0".
7. Manually start ated, type '\$ated -bbrX -iraX'. (For further use of options, type \$ated -h)
8. In the Windows host, run RT2870QA_ATE.exe.
9. Select the wired network adapter.
10. Choose 2870_ATE, then press OK.

Note:

The names of WLAN interface(default is "ra0") and Bridge interface(default is "br0") must be specified manually (for example: '\$ated -b br1 -ira2') if your WLAN interface or Bridge interface is not "ra0" or "br0" respectively !

6 IOCTL

6.1 Parameters for iwconfig

Access	Description	ID	Parameters
Get	BSSID, MAC Address	SIOCGIFHWADDR	wrq->u.name, (length = 6)
	WLAN Name	SIOCGIWNAME	wrq->u.name = "RT3572Wireless", length = strlen(wrq->u.name)
	SSID	SIOCGIWESSID	<pre> erq = &wrq->u.essid; if(OPSTATUS_TEST_FLAG(pAd,fOP_STATUS_MEDIA_STATE_CONNECTED)) { erq->flags=1; erq->length = pAd-> CommonCfg.SsidLen; Status = copy_to_user(erq->pointer, pAd-> CommonCfg.Ssid, erq->length); } else { erq->flags=0; erq->length=0; } </pre>
	Channel / Frequency (Hz)	SIOCGIWFREQ	<pre> wrq->u.freq.m = pAd-> CommonCfg.Channel; wrq->u.freq.e = 0; wrq->u.freq.i = 0; </pre>
	Node name / Nickname	SIOCGIWNICKN	<pre> erq = &wrq->u.data; erq->length = strlen(pAd->nickn); Status = copy_to_user(erq->pointer, pAd->nickn, erq->length); </pre>
	Bit Rate (bps)	SIOCGIWRATE	<pre> wrq->u.bitrate.value = RateIdTo500Kbps[pAd-> CommonCfg.TxRate] * 500000; wrq->u.bitrate.disabled = 0; </pre>
	RTS/CTS threshold	SIOCGIWRTS	<pre> wrq->u.rts.value = (INT) pAd-> CommonCfg.RtsThreshold; wrq->u.rts.disabled = (wrq->u.rts.value == MAX_RTS_THRESHOLD); wrq->u.rts.fixed = 1; </pre>
	Fragmentation threshold	SIOCGIWFRAG	<pre> wrq->u.frag.value = (INT) pAd-> CommonCfg.FragmentThreshold; </pre>

(bytes)		<pre> wrq->u.frag.disabled = (wrq->u.frag.value >= MAX_FRAG_THRESHOLD); wrq->u.frag.fixed = 1; </pre>
Encoding token & mode	SIOCGIWENCODE	<pre> index = (wrq->u.encoding.flags & IW_ENCODE_INDEX) - 1; if ((index < 0) (index >= NR_WEP_KEYS)) index = pAd->CommonCfg.DefaultKeyId; // Default key for tx (shared key) if (pAd->CommonCfg.AuthMode == Ndis802_11AuthModeOpen) wrq->u.encoding.flags = IW_ENCODE_OPEN; else if (pAd->CommonCfg.AuthMode == Ndis802_11AuthModeShared) wrq->u.encoding.flags = IW_ENCODE_RESTRICTED; if (pAd->CommonCfg.WepStatus == Ndis802_11WEPDisabled) wrq->u.encoding.flags = IW_ENCODE_DISABLED; else { if(wrq->u.encoding.pointer) { wrq->u.encoding.length = pAd->SharedKey[index].KeyLen; Status = copy_to_user(wrq->u.encoding.pointer, pAd->SharedKey[index].Key, pAd->SharedKey[index].KeyLen); wrq->u.encoding.flags = (index + 1); } } </pre>
AP's MAC address	SIOCGIWAP	<pre> wrq->u.ap_addr.sa_family = ARPHRD_ETHER; memcpy(wrq->u.ap_addr.sa_data, &pAd->CommonCfg.Bssid, ETH_ALEN); </pre>
Operation Mode	SIOCGIWMODE	<pre> if (ADHOC_ON(pAd)) { BssType = Ndis802_11IBSS; wrq->u.mode = IW_MODE_ADHOC; } else if (INFRA_ON(pAd)) { BssType = Ndis802_11Infrastructure; } </pre>

			<pre> wrq->u.mode = IW_MODE_INFRA; } else { BssType = Ndis802_11AutoUnknown; wrq->u.mode = IW_MODE_AUTO; } </pre>
Access	Description	ID	Parameters
Set	SSID	SIOCSIWESSID	<pre> erq = &wrq->u.essid; memset(&Ssid, 0x00, sizeof(NDIS_802_11_SSID)); if (erq->flags) { if (erq->length > IW_ESSID_MAX_SIZE) { Status = -E2BIG; break; } Status = copy_from_user(Ssid.Ssid, erq->pointer, (erq->length - 1)); Ssid.SsidLength = erq->length - 1; //minus null character. } else { Ssid.SsidLength = 0; // ANY ssid memcpy(pSsid->Ssid, "", 0); pAd->CommonCfg.BssType = BSS_INFRA; pAd->CommonCfg.AuthMode = Ndis802_11AuthModeOpen; pAd->CommonCfg.WepStatus = Ndis802_11EncryptionDisabled; } pSsid = &Ssid; if (pAd->Mlme.CntlMachine.CurrState != CNTL_IDLE) { </pre>

			<pre> MlmeRestartStateMachine(pAd); } pAd->MlmeAux.CurrReqIsFromNdis = FALSE; MlmeEnqueue(pAd, MLME_CNTL_STATE_MACHINE, OID_802_11_SSID, sizeof(NDIS_802_11_SSID), (VOID *)pSsid); Status = NDIS_STATUS_SUCCESS; StateMachineTouched = TRUE; </pre>
Channel / Frequency (Hz)	SIOCSIWFREQ		<pre> frq = &wrq->u.freq; if((frq->e == 0) && (frq->m <= 1000)) chan = frq->m; // Setting by channel number else MAP_KHZ_TO_CHANNEL_ID((frq->m / 100) , chan); pAd->CommonCfg.Channel = chan; </pre>
node name/nickname	SIOCSIWNICKN		<pre> erq = &wrq->u.data; if (erq->flags) { if (erq->length <= IW_ESSID_MAX_SIZE) Status = copy_from_user(pAd->nickn, erq->pointer, erq->length); else Status = -E2BIG; } </pre>
Bit Rate (bps)	SIOCSIWRATE		<pre> RTMPSetDesiredRates(pAd, wrq->u.bitrate.value); </pre>
RTS/CTS threshold	SIOCSIWRTS		<pre> RtsThresh = wrq->u.rts.value; if (wrq->u.rts.disabled) RtsThresh = MAX_RTS_THRESHOLD; if((RtsThresh > 0) && (RtsThresh <= MAX_RTS_THRESHOLD)) pAd->CommonCfg.RtsThreshold = (USHORT)RtsThresh; else if (RtsThresh == 0) pAd->CommonCfg.RtsThreshold = MAX_RTS_THRESHOLD; </pre>

Fragmentation threshold (bytes)	SIOCSIWFRAG	<pre> FragThresh = wrq->u.frag.value; if (wrq->u.rts.disabled) FragThresh = MAX_FRAG_THRESHOLD; if ((FragThresh >= MIN_FRAG_THRESHOLD) && (FragThresh <= MAX_FRAG_THRESHOLD)) pAd->CommonCfg.FragmentThreshold = (USHORT)FragThresh; else if (FragThresh == 0) pAd->CommonCfg.FragmentThreshold = MAX_FRAG_THRESHOLD; if (pAd->CommonCfg.FragmentThreshold == MAX_FRAG_THRESHOLD) pAd->CommonCfg.bFragmentZeroDisable = TRUE; else pAd->CommonCfg.bFragmentZeroDisable = FALSE; </pre>
Encoding token & mode	SIOCSIWENCODE	<pre> index = (wrq->u.encoding.flags & IW_ENCODE_INDEX) - 1; if((index < 0) (index >= NR_WEP_KEYS)) index = pAd->CommonCfg.DefaultKeyId; // Default key for tx (shared key) if(wrq->u.encoding.pointer) { len = wrq->u.encoding.length; if(len > WEP_LARGE_KEY_LEN) len = WEP_LARGE_KEY_LEN; memset(pAd->SharedKey[index].Key, 0x00, MAX_LEN_OF_KEY); Status = copy_from_user(pAd->SharedKey[index].Key, wrq->u.encoding.pointer, len); pAd->SharedKey[index].KeyLen = len <= WEP_SMALL_KEY_LEN ? WEP_SMALL_KEY_LEN : WEP_LARGE_KEY_LEN; } pAd->CommonCfg.DefaultKeyId = (UCHAR) index; if (wrq->u.encoding.flags & IW_ENCODE_DISABLED) pAd->CommonCfg.WepStatus = Ndis802_11WEPDisabled; else pAd->CommonCfg.WepStatus = Ndis802_11WEPEnabled; </pre>

			<pre> if (wrq->u.encoding.flags & IW_ENCODE_RESTRICTED) pAd->CommonCfg.AuthMode = Ndis802_11AuthModeShared; else pAd->CommonCfg.AuthMode = Ndis802_11AuthModeOpen; if(pAd->CommonCfg.WepStatus == Ndis802_11WEPDisabled) pAd->CommonCfg.AuthMode = Ndis802_11AuthModeOpen; </pre>
AP's MAC address	SIOCSIWAP		<pre> Status = copy_from_user(&Bssid, &wrq->u.ap_addr.sa_data, sizeof(NDIS_802_11_MAC_ADDRESS)); if (pAd->Mlme.CntlMachine.CurrState != CNTL_IDLE) { MlmeRestartStateMachine(pAd); } pAd->MlmeAux.CurrReqIsFromNdis = FALSE; MlmeEnqueue(pAd, MLME_CNTL_STATE_MACHINE, OID_802_11_BSSID, sizeof(NDIS_802_11_MAC_ADDRESS), (VOID *)&Bssid); Status = NDIS_STATUS_SUCCESS; StateMachineTouched = TRUE; </pre>
Operation Mode	SIOCSIWMODE		<pre> if(wrq->u.mode == IW_MODE_ADHOC) { if (pAd->CommonCfg.BssType != BSS_ADHOC) { pAd->bConfigChanged = TRUE; } pAd->CommonCfg.BssType = BSS_ADHOC; } else if (wrq->u.mode == IW_MODE_INFRA) { if (pAd->CommonCfg.BssType != BSS_INFRA) { </pre>

			<pre>pAd->bConfigChanged = TRUE; } pAd->CommonCfg.BssType = BSS_INFRA; } else { Status = -EINVAL; } pAd->CommonCfg.WpaState = SS_NOTUSE;</pre>
--	--	--	---

Ralink Website document

**for stevej@cradlepoint.com
And Company Use Only**

6.2 Parameters for iwpriv

Please refer section 3 to have iwpriv parameters and values.

Parameters:

```
int      socket_id;

char     name[25];           // interface name

char     data[255];         // command string

struct   iwreq wrq;
```

Default setting:

```
wrq.ifr_name = name = "ra0";           // interface name

wrq.u.data.pointer = data;             // data buffer of command string

wrq.u.data.length = strlen(data);     // length of command string

wrq.u.data.flags = 0;
```

Data Structure:

Please refer to `./include/oid.h` for update and detail definition.

6.2.1 Set Data, Parameters is Same as iwpriv

Command and IOCTL Function		
Set Data		
Function Type	Command	IOCTL
RTPRIV_IOCTL_SET	iwpriv ra0 set SSID=RT3572AP	<pre>printf(name, "ra0"); strcpy(data, "SSID=RT3572AP"); strcpy(wrq.ifr_name, name); wrq.u.data.length = strlen(data); wrq.u.data.pointer = data; wrq.u.data.flags = 0; ioctl(socket_id, RTPRIV_IOCTL_SET, &wrq);</pre>

6.2.2 Get Data, Parameters is Same as iwpriv

Command and IOCTL Function		
Get Data		
Function Type	Command	IOCTL
RTPRIV_IOCTL_STATISTICS	lwpriv ra0 stat	<pre> sprintf(name, "ra0"); strcpy(data, "stat"); strcpy(wrq.ifr_name, name); wrq.u.data.length = strlen(data); wrq.u.data.pointer = data; wrq.u.data.flags = 0; ioctl(socket_id, RTPRIV_IOCTL_STATISTICS, &wrq); </pre>
RTPRIV_IOCTL_GSITESURVEY	lwpriv ra0 get_site_survey	<pre> sprintf(name, "ra0"); strcpy(data, "get_site_survey"); strcpy(wrq.ifr_name, name); wrq.u.data.length = strlen(data); wrq.u.data.pointer = data; wrq.u.data.flags = 0; ioctl(socket_id, RTPRIV_IOCTL_GSITESURVEY, &wrq); </pre>

6.2.3 Set Raw Data with Flags

IOCTL Function	
Set Raw Data by I/O Control Interface with Flags	
Function Type	IOCTL
RT_OID_802_11_COUNTRY_REGION	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(UCHAR)); wrq.u.data.length = sizeof(UCHAR); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_COUNTRY_REGION; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_BSSID_LIST_SCAN	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); wrq.u.data.length = 0; wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_BSSID_LIST_SCAN; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_SSID	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_SSID)); wrq.u.data.length = sizeof(NDIS_802_11_SSID); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_SSID; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_BSSID	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_MAC_ADDRESS)); wrq.u.data.length = sizeof(NDIS_802_11_MAC_ADDRESS); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_BSSID; </pre>

	ioctl(socket_id, RT_PRIV_IOCTL , &wrq);
RT_OID_802_11_RADIO	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(BOOLEAN)); wrq.u.data.length = sizeof(BOOLEAN); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_RADIO; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_PHY_MODE	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RT_802_11_PHY_MODE)); wrq.u.data.length = sizeof(RT_802_11_PHY_MODE); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_PHY_MODE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_STA_CONFIG	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RT_802_11_STA_CONFIG)); wrq.u.data.length = sizeof(RT_802_11_STA_CONFIG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_STA_CONFIG; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_DESIRED_RATES	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_RATES)); wrq.u.data.length = sizeof(NDIS_802_11_RATES); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_DESIRED_RATES; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_PREAMBLE	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RT_802_11_PREAMBLE)); </pre>

	<pre> wrq.u.data.length = sizeof(RT_802_11_PREAMBLE); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_PREAMBLE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_WEP_STATUS	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_WEP_STATUS)); wrq.u.data.length = sizeof(NDIS_802_11_WEP_STATUS); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_WEP_STATUS; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_AUTHENTICATION_MODE	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_AUTHENTICATION_MODE)); wrq.u.data.length = sizeof(NDIS_802_11_AUTHENTICATION_MODE); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_AUTHENTICATION_MODE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_INFRASTRUCTURE_MODE	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_NETWORK_INFRASTRUCTURE)); wrq.u.data.length = sizeof(NDIS_802_11_NETWORK_INFRASTRUCTURE); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_INFRASTRUCTURE_MODE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_REMOVE_WEP	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_KEY_INDEX)); wrq.u.data.length = sizeof(NDIS_802_11_KEY_INDEX); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_REMOVE_WEP; </pre>

	ioctl(socket_id, RT_PRIV_IOCTL , &wrq);
RT_OID_802_11_RESET_COUNTERS	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); wrq.u.data.length = 0; wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_RESET_COUNTERS; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_RTS_THRESHOLD	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_RTS_THRESHOLD)); wrq.u.data.length = sizeof(NDIS_802_11_RTS_THRESHOLD); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_RTS_THRESHOLD; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_FRAGMENTATION_THRESHOLD	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_FRAGMENTATION_THRESHOLD)); wrq.u.data.length = sizeof(NDIS_802_11_FRAGMENTATION_THRESHOLD); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_FRAGMENTATION_THRESHOLD; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_POWER_MODE	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_POWER_MODE)); wrq.u.data.length = sizeof(NDIS_802_11_POWER_MODE); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_POWER_MODE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_TX_POWER_LEVEL	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_TX_POWER_LEVEL)); </pre>

	<pre> wrq.u.data.length = sizeof(NDIS_802_11_TX_POWER_LEVEL); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_TX_POWER_LEVEL; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_TX_POWER_LEVEL_1	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_TX_POWER_LEVEL_1; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_NETWORK_TYPE_IN_USE	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_NETWORK_TYPE)); wrq.u.data.length = / sizeof(NDIS_802_11_NETWORK_TYPE); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_NETWORK_TYPE_IN_USE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_RX_ANTENNA_SELECTED	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_ANTENNA)); wrq.u.data.length = sizeof(NDIS_802_11_ANTENNA); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_RX_ANTENNA_SELECTED; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_TX_ANTENNA_SELECTED	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_ANTENNA)); wrq.u.data.length = sizeof(NDIS_802_11_ANTENNA); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_TX_ANTENNA_SELECTED; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>

RT_OID_802_11_ADD_WPA	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, 32); wrq.u.data.length = 32; wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_ADD_WPA; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_REMOVE_KEY	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_REMOVE_KEY)); wrq.u.data.length = sizeof(NDIS_802_11_REMOVE_KEY); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_REMOVE_KEY; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_ADD_KEY	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, keylength); //5,10,13,26 wrq.u.data.length = keylength L; wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_ADD_KEY; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_SET_IEEE8021X	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(BOOLEAN)); wrq.u.data.length = sizeof(BOOLEAN); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_SET_IEEE8021X; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_SET_IEEE8021X_REQUIRE_KEY	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(BOOLEAN)); wrq.u.data.length = sizeof(BOOLEAN); </pre>

	<pre> wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_SET_IEEE8021X_REQUIRE_KEY; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_ADD_WEP	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, keylength); //5,10,13,26 wrq.u.data.length = keylength; wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_RADIO; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_CONFIGURATION	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_CONFIGURATION)); wrq.u.data.length = sizeof(NDIS_802_11_CONFIGURATION); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_CONFIGURATION; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_SET_COUNTERMEASURES	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); wrq.u.data.length = 0; wrq.u.data.pointer = data; wrq.u.data.flags = OID_SET_COUNTERMEASURES; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_DISASSOCIATE	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); wrq.u.data.length = 0; wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_DISASSOCIATE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_PMKID	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); wrq.u.data.length = keylength; //follow your setting </pre>

	<pre> wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_PMKID; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_WPA_SUPPLICANT_SUPPORT	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(BOOLEAN)); wrq.u.data.length = sizeof(BOOLEAN); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_WPA_SUPPLICANT_SUPPORT; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_WPA_SUPPLICANT_SUPPORT	<pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_WPA_SUPPLICANT_SUPPORT; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_SET_DEL_MAC_ENTRY	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0xdd, 6); strcpy(wrq.ifr_name, name); wrq.u.data.length = 6; wrq.u.data.pointer = data; wrq.u.data.flags = RT_SET_DEL_MAC_ENTRY; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_SET_HT_PHYMODE OID_GET_SET_TOGGLE	<pre> typedef struct { RT_802_11_PHY_MODE PhyMode; UCHAR TransmitNo; UCHAR HtMode; //HTMODE_GF or HTMODE_MM UCHAR ExtOffset; //extension channel above or below UCHAR MCS; </pre>

	<pre> UCHAR BW; UCHAR STBC; UCHAR SHORTGI; UCHAR rsv; } OID_SET_HT_PHYMODE ; RT_802_11_PHY_MODE tmp_ht_mode; sprintf(wrq.ifr_name, "ra0"); wrq.u.data.pointer = (caddr_t) & tmp_ht_mode; wrq.u.data.length = sizeof(RT_802_11_PHY_MODE); wrq.u.data.flags = RT_OID_802_11_SET_HT_PHYMODE OID_GET_SET_TOGGLE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
--	--

6.2.4 Get Raw Data with Flags

IOCTL Function	
Get Raw Data by I/O Control Interface with Flags	
Function Type	IOCTL
RT_OID_DEVICE_NAME	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, 255); wrq.u.data.length = 255; wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_DEVICE_NAME; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_VERSION_INFO	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RT_VERSION_INFO)); wrq.u.data.length = sizeof(RT_VERSION_INFO); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_VERSION_INFO; </pre>

	ioctl(socket_id, RT_PRIV_IOCTL , &wrq);
OID_802_11_BSSID_LIST	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, BssLen); wrq.u.data.length = BssLen; wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_BSSID_LIST; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_3_CURRENT_ADDRESS	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(CurrentAddress)); wrq.u.data.length = sizeof(CurrentAddress); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_3_CURRENT_ADDRESS; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_GEN_MEDIA_CONNECT_STATUS	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_MEDIA_STATE)); wrq.u.data.length = sizeof(NDIS_MEDIA_STATE); wrq.u.data.pointer = data; wrq.u.data.flags = OID_GEN_MEDIA_CONNECT_STATUS; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_BSSID	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_MAC_ADDRESS)); wrq.u.data.length = sizeof(NDIS_802_11_MAC_ADDRESS); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_BSSID; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_SSID	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_SSID)); </pre>

	<pre> wrq.u.data.length = sizeof(NDIS_802_11_SSID); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_SSID; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_QUERY_LINK_STATUS	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RT_802_11_LINK_STATUS)); wrq.u.data.length = sizeof(RT_802_11_LINK_STATUS); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_QUERY_LINK_STATUS; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_CONFIGURATION	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_CONFIGURATION)); wrq.u.data.length = sizeof(NDIS_802_11_CONFIGURATION); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_CONFIGURATION; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_RSSI_TRIGGER	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ulInfo)); wrq.u.data.length = sizeof(ulInfo); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_RSSI_TRIGGER; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_RSSI	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ulInfo)); wrq.u.data.length = sizeof(ulInfo); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_RSSI; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>

RT_OID_802_11_RSSI_1	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ullInfo)); wrq.u.data.length = sizeof(ullInfo); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_RSSI_1; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_RSSI_2	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ullInfo)); wrq.u.data.length = sizeof(ullInfo); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_RSSI_2; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_STATISTICS	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_STATISTICS)); wrq.u.data.length = sizeof(NDIS_802_11_STATISTICS); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_STATISTICS; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_GEN_RCV_OK	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ullInfo)); wrq.u.data.length = sizeof(ullInfo); wrq.u.data.pointer = data; wrq.u.data.flags = OID_GEN_RCV_OK; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_GEN_RCV_NO_BUFFER	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ullInfo)); wrq.u.data.length = sizeof(ullInfo); </pre>

	<pre> wrq.u.data.pointer = data; wrq.u.data.flags = OID_GEN_RCV_NO_BUFFER; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_PHY_MODE	<pre> typedef enum _RT_802_11_PHY_MODE { PHY_11BG_MIXED = 0, PHY_11B, PHY_11A, PHY_11ABG_MIXED, PHY_11G, PHY_11ABGN_MIXED, // both band 5 PHY_11N, // 6 PHY_11GN_MIXED, // 2.4G band 7 PHY_11AN_MIXED, // 5G band 8 PHY_11BGN_MIXED, // if check 802.11b. 9 PHY_11AGN_MIXED, // if check 802.11b. 10 } RT_802_11_PHY_MODE sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ulInfo)); wrq.u.data.length = sizeof(ulInfo); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_PHY_MODE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_STA_CONFIG	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RT_802_11_STA_CONFIG)); wrq.u.data.length = sizeof(RT_802_11_STA_CONFIG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_STA_CONFIG; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
OID_802_11_RTS_THRESHOLD	<pre> sprintf(name, "ra0"); </pre>

	<pre>strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RtsThresh)); wrq.u.data.length = sizeof(RtsThresh); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_RTS_THRESHOLD; ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
OID_802_11_FRAGMENTATION_THRESHOLD	<pre>sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(FragThresh)); wrq.u.data.length = sizeof(FragThresh); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_FRAGMENTATION_THRESHOLD; ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
OID_802_11_POWER_MODE	<pre>sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(PowerMode)); wrq.u.data.length = sizeof(PowerMode); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_POWER_MODE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
RT_OID_802_11_RADIO	<pre>sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RadioState)); wrq.u.data.length = sizeof(RadioState); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_RADIO; ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
OID_802_11_INFRASTRUCTURE_MODE	<pre>sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(BssType)); wrq.u.data.length = sizeof(BssType); wrq.u.data.pointer = data;</pre>

	<pre>wrq.u.data.flags = OID_802_11_INFRASTRUCTURE_MODE;</pre> <pre>ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
RT_OID_802_11_PREAMBLE	<pre>sprintf(name, "ra0");</pre> <pre>strcpy(wrq.ifr_name, name);</pre> <pre>memset(data, 0, sizeof(PreamType));</pre> <pre>wrq.u.data.length = sizeof(PreamType);</pre> <pre>wrq.u.data.pointer = data;</pre> <pre>wrq.u.data.flags = RT_OID_802_11_PREAMBLE;</pre> <pre>ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
OID_802_11_AUTHENTICATION_MODE	<pre>sprintf(name, "ra0");</pre> <pre>strcpy(wrq.ifr_name, name);</pre> <pre>memset(data, 0, sizeof(AuthMode));</pre> <pre>wrq.u.data.length = sizeof(AuthMode);</pre> <pre>wrq.u.data.pointer = data;</pre> <pre>wrq.u.data.flags = OID_802_11_AUTHENTICATION_MODE;</pre> <pre>ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
OID_802_11_WEP_STATUS	<pre>sprintf(name, "ra0");</pre> <pre>strcpy(wrq.ifr_name, name);</pre> <pre>memset(data, 0, sizeof(WepStatus));</pre> <pre>wrq.u.data.length = sizeof(WepStatus);</pre> <pre>wrq.u.data.pointer = data;</pre> <pre>wrq.u.data.flags = OID_802_11_WEP_STATUS;</pre> <pre>ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
OID_802_11_TX_POWER_LEVEL	<pre>sprintf(name, "ra0");</pre> <pre>strcpy(wrq.ifr_name, name);</pre> <pre>memset(data, 0, sizeof(ULONG));</pre> <pre>wrq.u.data.length = sizeof(ULONG);</pre> <pre>wrq.u.data.pointer = data;</pre> <pre>wrq.u.data.flags = OID_802_11_TX_POWER_LEVEL;</pre> <pre>ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
OID_802_11_TX_POWER_LEVEL_1	<pre>sprintf(name, "ra0");</pre> <pre>strcpy(wrq.ifr_name, name);</pre>

	<pre>memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_TX_POWER_LEVEL_1; ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
OID_802_11_NETWORK_TYPES_SUPPORTED	<pre>sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, 16); wrq.u.data.length = 16; wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_NETWORK_TYPES_SUPPORTED; ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
OID_802_11_NETWORK_TYPE_IN_USE	<pre>sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_NETWORK_TYPE_IN_USE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
RT_OID_802_11_QUERY_EEPROM_VERSION	<pre>sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_QUERY_EEPROM_VERSION; ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
RT_OID_802_11_QUERY_FIRMWARE_VERSION	<pre>sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_QUERY_FIRMWARE_VERSION;</pre>

	ioctl(socket_id, RT_PRIV_IOCTL , &wrq);
RT_OID_802_11_QUERY_NOISE_LEVEL	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(UCHAR)); wrq.u.data.length = sizeof(UCHAR); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_QUERY_NOISE_LEVEL; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_EXTRA_INFO	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_EXTRA_INFO; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_QUERY_PIDVID	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_QUERY_PIDVID; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_WE_VERSION_COMPILED	<pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(UINT)); wrq.u.data.length = sizeof(UINT); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_WE_VERSION_COMPILED; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_QUERY_LAST_TX_RATE	<pre> HTTRANSMIT_SETTING tmpHT; sprintf(wrq.ifr_name, "ra0"); </pre>

	<pre> wrq.u.data.pointer = (caddr_t) & tmpHT; wrq.u.data.flags = RT_OID_802_11_QUERY_LAST_TX_RATE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
RT_OID_802_11_QUERY_LAST_RX_RATE	<pre> HTTRANSMIT_SETTING tmpHT; sprintf(wrq.ifr_name, "ra0"); wrq.u.data.pointer = (caddr_t) & tmpHT; wrq.u.data.flags = RT_OID_802_11_QUERY_LAST_RX_RATE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq); </pre>
SHOW_CONN_STATUS	<pre> u_char buffer[IW_PRIV_SIZE_MASK]; sprintf(wrq.ifr_name, "ra0"); wrq.u.data.pointer = (caddr_t) buffer; wrq.u.data.flags = SHOW_CONN_STATUS; ioctl(socket_id, RTPRIV_IOCTL_SHOW, &wrq); </pre>

6.2.5 Set Raw Data with Flags

IOCTL Function	
Get Raw Data by I/O Control Interface with Flags	
Function Type	IOCTL
RT_OID_802_11_SET_HT_PHYMODE OID_GET_SET_TOGGLE	<pre> typedef struct { RT_802_11_PHY_MODE PhyMode; UCHAR TransmitNo; UCHAR HtMode; //HTMODE_GF or HTMODE_MM UCHAR ExtOffset; //extension channel above or below UCHAR MCS; UCHAR BW; UCHAR STBC; UCHAR SHORTGI; UCHAR rsv; } OID_SET_HT_PHYMODE ; RT_802_11_PHY_MODE tmp_ht_mode; </pre>

	<pre>sprintf(wrq.ifr_name, "ra0"); wrq.u.data.pointer = (caddr_t) & tmp_ht_mode; wrq.u.data.length = sizeof(RT_802_11_PHY_MODE); wrq.u.data.flags = RT_OID_802_11_SET_HT_PHYMODE OID_GET_SET_TOGGLE; ioctl(socket_id, RT_PRIV_IOCTL, &wrq);</pre>
--	---

Ralink Website document

**for stevej@cradlepoint.com
And Company Use Only**

7 IOCTL INSTRUCTIONS

7.1 Get Data

7.1.1 GET station connection status:

Linux console command: iwpriv ra0 connStatus

sample code =>

```
u_char buffer[IW_PRIV_SIZE_MASK];
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) buffer;
wrq.u.data.flags = SHOW_CONN_STATUS;
ioctl(socket_id, RTPRIV_IOCTL_SHOW, &wrq);
```

7.1.2 GET station statistics information:

Linux console command: iwpriv ra0 stat

sample code =>

```
u_char buffer[IW_PRIV_SIZE_MASK];
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) buffer;
wrq.u.data.flags = 0;
ioctl(socket_id, RTPRIV_IOCTL_STATISTICS, &wrq);
```

7.1.3 GET AP list table:

Linux console command: iwpriv ra0 get_site_survey

sample code =>

```
u_char buffer[4096];
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) buffer;
wrq.u.data.flags = 0;
ioctl(socket_id, RTPRIV_IOCTL_GSITESURVEY, &wrq);
```

7.1.4 GET scan table:

sample code =>

```
u_char buffer[4096];
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) buffer;
wrq.u.data.length = 4096;
wrq.u.data.flags = OID_802_11_BSSID_LIST;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
PNDIS_802_11_BSSID_LIST_EX pBssidList = (PNDIS_802_11_BSSID_LIST_EX) buffer;
```

7.1.5 GET station's MAC:

sample code =>

```
u_char buffer[6];
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) buffer;
wrq.u.data.flags = OID_802_3_CURRENT_ADDRESS;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

7.1.6 GET station connection status:

Sample code =>

```
#define NdisMediaStateConnected    1
#define NdisMediaStateDisconnected 0
NDIS_MEDIA_STATE MediaState;
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) & MediaState;
wrq.u.data.flags = OID_GEN_MEDIA_CONNECT_STATUS;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

7.1.7 GET AP's BSSID

Sample code =>

```
char BSSID[6];
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) BSSID;
wrq.u.data.flags = OID_802_11_BSSID;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

7.1.8 GET SSID

Sample code =>

```
NDIS_802_11_SSID SSID;
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) &SSID;
wrq.u.data.flags = OID_802_11_SSID;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

7.1.9 GET station's last TX related information:

Sample code =>

```
HTTRANSMIT_SETTING tmpHT;
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) &tmpHT;
wrq.u.data.flags = RT_OID_802_11_QUERY_LAST_TX_RATE;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

7.1.10 GET station's last RX related information:

Sample code =>

```
HTTRANSMIT_SETTING tmpHT;
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) &tmpHT;
wrq.u.data.flags = RT_OID_802_11_QUERY_LAST_RX_RATE;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

7.1.11 GET station's wireless mode:

Sample code =>

```
typedef enum _RT_802_11_PHY_MODE {
    PHY_11BG_MIXED = 0,
    PHY_11B,
    PHY_11A,
    PHY_11ABG_MIXED,
```

```

PHY_11G,
PHY_11ABGN_MIXED,           // both band           5
PHY_11N,                     //                6
PHY_11GN_MIXED,             // 2.4G band       7
PHY_11AN_MIXED,             // 5G band         8
PHY_11BGN_MIXED,            // if check 802.11b. 9
PHY_11AGN_MIXED,            // if check 802.11b. 10
} RT_802_11_PHY_MODE

unsigned long tmp_mode;
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) & tmp_mode;
wrq.u.data.flags = RT_OID_802_11_PHY_MODE;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);

```

7.1.12 GET Bss type:

Sample code =>

```

typedef enum _NDIS_802_11_NETWORK_INFRASTRUCTURE
{
    Ndis802_11IBSS,
    Ndis802_11Infrastructure,
    Ndis802_11AutoUnknown,
    Ndis802_11Monitor,
    Ndis802_11InfrastructureMax // Not a real value, defined as upper bound
} NDIS_802_11_NETWORK_INFRASTRUCTURE

NDIS_802_11_NETWORK_INFRASTRUCTURE BssType;
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) & BssType;
wrq.u.data.flags = OID_802_11_INFRASTRUCTURE_MODE;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);

```

7.1.13 GET Authentication Mode:

Sample code =>

```

typedef enum _NDIS_802_11_AUTHENTICATION_MODE
{
    Ndis802_11AuthModeOpen,
    Ndis802_11AuthModeShared,
    Ndis802_11AuthModeAutoSwitch,
    Ndis802_11AuthModeWPA,
    Ndis802_11AuthModeWPAPSK,
    Ndis802_11AuthModeWPA_None,
    Ndis802_11AuthModeWPA2,
    Ndis802_11AuthModeWPA2PSK,
    Ndis802_11AuthModeWPA1WPA2,
    Ndis802_11AuthModeWPA1PSKWPA2PSK,
    Ndis802_11AuthModeMax // Not a real mode, defined as upper bound
} NDIS_802_11_AUTHENTICATION_MODE

NDIS_802_11_AUTHENTICATION_MODE AuthMode;
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) & AuthMode;
wrq.u.data.flags = OID_802_11_AUTHENTICATION_MODE;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);

```

7.1.14 GET Encryption Type:

Sample code =>

```
typedef enum _NDIS_802_11_WEP_STATUS
{
    Ndis802_11WEPEnabled,
    Ndis802_11Encryption1Enabled = Ndis802_11WEPEnabled,
    Ndis802_11WEPDisabled,
    Ndis802_11EncryptionDisabled = Ndis802_11WEPDisabled,
    Ndis802_11WEPKeyAbsent,
    Ndis802_11Encryption1KeyAbsent = Ndis802_11WEPKeyAbsent,
    Ndis802_11WEPNotSupported,
    Ndis802_11EncryptionNotSupported = Ndis802_11WEPNotSupported,
    Ndis802_11Encryption2Enabled,
    Ndis802_11Encryption2KeyAbsent,
    Ndis802_11Encryption3Enabled,
    Ndis802_11Encryption3KeyAbsent,
    Ndis802_11Encryption4Enabled,    // TKIP or AES mix
    Ndis802_11Encryption4KeyAbsent,
} NDIS_802_11_WEP_STATUS, *PNDIS_802_11_WEP_STATUS,

NDIS_802_11_WEP_STATUS WepStatus;
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) & WepStatus;
wrq.u.data.flags = OID_802_11_WEP_STATUS;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

7.1.15 GET RSSI 0 (unit: db)

Sample code =>

```
long rssi_0
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) & rssi_0;
wrq.u.data.flags = RT_OID_802_11_RSSI;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

7.1.16 GET RSSI 1 (unit: db)

Sample code =>

```
long rssi_1
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) & rssi_1;
wrq.u.data.flags = RT_OID_802_11_RSSI_1;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

7.1.17 GET RSSI 2 (unit: db)

Sample code =>

```
long rssi_2
sprintf(wrq.ifr_name, "ra0");
wrq.u.data.pointer = (caddr_t) & rssi_2;
wrq.u.data.flags = RT_OID_802_11_RSSI_2;
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

7.1.18 GET Driver wireless extension version

Sample code =>

```
Unsigned int wext_version;  
sprintf(wrq.ifr_name, "ra0");  
wrq.u.data.pointer = (caddr_t) & wext_version;  
wrq.u.data.flags = RT_OID_WE_VERSION_COMPILED;  
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

Ralink Website document

**for stevej@cradlepoint.com
And Company Use Only**

7.2 How to display rate, BW:

```

HTTRANSMIT_SETTING HTSetting;
Double Rate;
double b_mode[] = {1, 2, 5.5, 11};
float g_Rate[] = { 6,9,12,18,24,36,48,54};
switch(HTSetting.field.MODE)
{
    case 0:
        if (HTSetting.field.MCS >=0 && HTSetting.field.MCS<=3)
            Rate = b_mode[HTSetting.field.MCS];
        else if (HTSetting.field.MCS >=8 && HTSetting.field.MCS<=11)
            Rate = b_mode[HTSetting.field.MCS-8];
        else
            Rate = 0;
        break;
    case 1:
        if ((HTSetting.field.MCS >= 0) && (HTSetting.field.MCS < 8))
            Rate = g_Rate[HTSetting.field.MCS];
        else
            Rate = 0;
        break;
    case 2:
    case 3:
        if (0 == bGetHTTxRateByBW_GI_MCS(HTSetting.field.BW, HTSetting.field.ShortGI,
            HTSetting.field.MCS,
            &Rate))
            Rate = 0;
            break;
    default:
        Rate = 0;
        break;
}

char bGetHTTxRateByBW_GI_MCS(int nBW, int nGI, int nMCS, double* dRate)
{
    double HTTxRate20_800[16]={6.5, 13.0, 19.5, 26.0, 39.0, 52.0, 58.5, 65.0, 13.0, 26.0, 39.0, 52.0, 78.0, 104.0, 117.0, 130.0};
    double HTTxRate20_400[16]={7.2, 14.4, 21.7, 28.9, 43.3, 57.8, 65.0, 72.2, 14.444, 28.889, 43.333, 57.778, 86.667, 115.556, 130.000, 144.444};
    double HTTxRate40_800[18]={13.5, 27.0, 40.5, 54.0, 81.0, 108.0, 121.5, 135.0, 27.0, 54.0, 81.0, 108.0, 162.0, 216.0, 243.0, 270.0, 6.0, 39.0};
    double HTTxRate40_400[18]={15.0, 30.0, 45.0, 60.0, 90.0, 120.0, 135.0, 150.0, 30.0, 60.0, 90.0, 120.0, 180.0, 240.0, 270.0, 300.0, 6.7, 43.3};

    // no TxRate for (BW = 20, GI = 400, MCS = 32) & (BW = 20, GI = 400, MCS = 32)
    if (((nBW == BW_20) && (nGI == GI_400) && (nMCS == 32)) ||
        ((nBW == BW_20) && (nGI == GI_800) && (nMCS == 32)))
        return 0; //false

    if( nBW == BW_20 && nGI == GI_800)
        *dRate = HTTxRate20_800[nMCS];
    else if( nBW == BW_20 && nGI == GI_400)
        *dRate = HTTxRate20_400[nMCS];
    else if( nBW == BW_40 && nGI == GI_800)
        *dRate = HTTxRate40_800[nMCS];
    else if( nBW == BW_40 && nGI == GI_400)
        *dRate = HTTxRate40_400[nMCS];
    else
        return 0; //false

    return 1; //true
}

```