

# RALINK TECHNOLOGY, CORP.

## RALINK RT2860 LINUX STATION RELEASE NOTES & USER'S GUIDE

RALINK RT2800 PCI/MINIPCI/CARDBUS/PCIE WIRELESS CARD

Copyright © 2006, 2007, 2008, 2009 Ralink Technology,  
Corp.

### All Rights Reserved.

This document is property of Ralink Technology Corporation. Transmittal, receipt, or possession of this document does not express, license, or imply any rights to use, sell, design, or manufacture from this information or the software documented herein. No reproduction, publication, or disclosure of this information, in whole or in part, shall be allowed, unless the prior written consent of Ralink Technology Corporation is obtained.

NOTE: THIS DOCUMENT CONTAINS SENSITIVE INFORMATION AND HAS RESTRICTED DISTRIBUTION.

## Proprietary Notice and Liability Disclaimer

The confidential Information, technology or any Intellectual Property embodied therein, including without limitation, specifications, product features, data, source code, object code, computer programs, drawings, schematics, know-how, notes, models, reports, contracts, schedules and samples, constitute the Proprietary Information of Ralink (hereinafter "Proprietary Information")

All the Proprietary Information is provided "AS IS". No Warranty of any kind, whether express or implied, is given hereunder with regards to any Proprietary Information or the use, performance or function thereof. Ralink hereby disclaims any warranties, including but not limited warranties of non-infringement, merchantability, completeness, accuracy, fitness for any particular purpose, functionality and any warranty related to course of performance or dealing of Proprietary Information. In no event shall Ralink be liable for any special, indirect or consequential damages associated with or arising from use of the Proprietary Information in any way, including any loss of use, data or profits.

Ralink retains all right, title or interest in any Proprietary Information or any Intellectual Property embodied therein. The Proprietary Information shall not in whole or in part be reversed, decompiled or disassembled, nor reproduced or sublicensed or disclosed to any third party without Ralink's prior written consent.

Ralink reserves the right, at its own discretion, to update or revise the Proprietary Information from time to time, of which Ralink is not obligated to inform or send notice. Please check back if you have any question. Information or items marked as "not yet supported" shall not be relied on, nor taken as any warranty or permission of use.

Ralink Technology Corporation (Taiwan)  
5F, No.36, Tai-Yuen Street,  
ChuPei City  
HsinChu Hsien 302, Taiwan, ROC  
Tel +886-3-560-0868  
Fax +886-3-560-0818

Sales Taiwan: [Sales@ralinktech.com.tw](mailto:Sales@ralinktech.com.tw)  
Technical Support Taiwan: [FAE@ralinktech.com.tw](mailto:FAE@ralinktech.com.tw)  
<http://www.ralinktech.com/>

## 1 CONTENTS

|        |  |    |        |                          |    |
|--------|--|----|--------|--------------------------|----|
| 1      | CONTENTS .....                           | 3  | 4.2.20 | WPAPSK .....             | 18 |
| 2      | VERSION HISTORY .....                    | 7  | 4.2.21 | WmmCapable .....         | 18 |
| 2.1    | [V2.1.0.0] .....                         | 7  | 4.2.22 | IEEE80211H .....         | 18 |
| 2.2    | [V1.8.0.0] .....                         | 7  | 4.2.23 | PSMode .....             | 18 |
| 2.3    | [V1.7.0.0] .....                         | 7  | 4.2.24 | AutoRoaming .....        | 18 |
| 2.4    | [V1.6.0.0] .....                         | 8  | 4.2.25 | RoamThreshold .....      | 18 |
| 2.5    | [V1.5.0.0] .....                         | 8  | 4.2.26 | TGnWiFiTest .....        | 18 |
| 2.6    | [V1.4.0.0] .....                         | 8  | 4.2.27 | WirelessEvent .....      | 19 |
| 2.7    | [V1.3.0.0] .....                         | 8  | 4.2.28 | CarrierDetect .....      | 19 |
| 2.8    | [V1.2.1.0] .....                         | 9  | 4.2.29 | HT_RDG .....             | 19 |
| 2.9    | [V1.2.0.0] .....                         | 9  | 4.2.30 | HT_EXTCHA .....          | 19 |
| 2.10   | [V1.1.0.0] .....                         | 9  | 4.2.31 | HT_OpMode .....          | 19 |
| 2.11   | [V1.0.0.0] .....                         | 9  | 4.2.32 | HT_MpduDensity .....     | 19 |
| 3      | README .....                             | 10 | 4.2.33 | HT_BW .....              | 19 |
| 3.1.1  | ModelName: .....                         | 10 | 4.2.34 | HT_AutoBA .....          | 20 |
| 3.1.2  | Driver IName: .....                      | 10 | 4.2.35 | HT_AMSDU .....           | 20 |
| 3.1.3  | Supporting Kernel: .....                 | 10 | 4.2.36 | HT_BAWinSize .....       | 20 |
| 3.1.4  | Description: .....                       | 10 | 4.2.37 | HT_GI .....              | 20 |
| 3.1.5  | Contents: .....                          | 10 | 4.2.38 | HT_MCS .....             | 20 |
| 3.1.6  | Features: .....                          | 10 | 4.2.39 | HT_MIMOPSMODE .....      | 20 |
| 3.1.7  | Build Instructions: .....                | 10 | 4.2.40 | HT_BADecline=Value ..... | 20 |
| 4      | CONFIGURATION: .....                     | 12 | 4.3    | MORE INFORMATION .....   | 21 |
| 4.1    | CONFIGURATION FILE : RT2860STA.DAT ..... | 12 | 5      | WIRELESS TOOLS .....     | 21 |
| 4.2    | USAGE .....                              | 13 | 5.1    | IWPRIV USAGE .....       | 21 |
| 4.2.1  | CountryRegion .....                      | 14 | 5.1.1  | DriverVersion .....      | 21 |
| 4.2.2  | CountryRegionForABand .....              | 14 | 5.1.2  | CountryRegion .....      | 22 |
| 4.2.3  | CountryCode .....                        | 14 | 5.1.3  | CountryRegionABand ..... | 22 |
| 4.2.4  | SSID .....                               | 15 | 5.1.4  | SSID .....               | 23 |
| 4.2.5  | WirelessMode .....                       | 15 | 5.1.5  | WirelessMode .....       | 23 |
| 4.2.6  | Channel .....                            | 15 | 5.1.6  | TxBurst: .....           | 23 |
| 4.2.7  | BGProtection .....                       | 15 | 5.1.7  | PktAggregate: .....      | 23 |
| 4.2.8  | TxPreamble .....                         | 16 | 5.1.8  | TxPreamble: .....        | 24 |
| 4.2.9  | RTSThreshold .....                       | 16 | 5.1.9  | TxPower: .....           | 24 |
| 4.2.10 | FragThreshold .....                      | 16 | 5.1.10 | Channel .....            | 24 |
| 4.2.11 | TxBurst .....                            | 16 | 5.1.11 | BGProtection: .....      | 24 |
| 4.2.12 | PktAggregate .....                       | 16 | 5.1.12 | RTSThreshold: .....      | 24 |
| 4.2.13 | NetworkType .....                        | 16 | 5.1.13 | FragThreshold: .....     | 25 |
| 4.2.14 | AuthMode .....                           | 16 | 5.1.14 | NetworkType: .....       | 25 |
| 4.2.15 | EncrypType .....                         | 17 | 5.1.15 | AuthMode: .....          | 25 |
| 4.2.16 | DefaultKeyID .....                       | 17 | 5.1.16 | EncrypType: .....        | 25 |
| 4.2.17 | WEP KeyType .....                        | 17 | 5.1.17 | DefaultKeyID: .....      | 25 |
| 4.2.18 | WEP Hex Key .....                        | 17 | 5.1.18 | Key1 .....               | 26 |
| 4.2.19 | WEP Key String .....                     | 17 | 5.1.19 | Key2 .....               | 26 |
|        |  |    | 5.1.20 | Key3 .....               | 26 |
|        |  |    | 5.1.21 | Key4 .....               | 26 |

|        |                            |    |        |  |    |
|--------|----------------------------|----|--------|--|----|
| 5.1.22 | WPAPSK .....               | 26 | 5.2.19 | HtAutoBa .....                           | 34 |
| 5.1.23 | WmmCapable .....           | 27 | 5.2.20 | CountryRegion .....                      | 34 |
| 5.1.24 | IEEE80211H .....           | 27 | 5.2.21 | CountryRegionABand .....                 | 34 |
| 5.1.25 | PSMode .....               | 27 | 5.2.22 | CountryCode .....                        | 34 |
| 5.1.26 | ResetCounter .....         | 27 | 5.2.23 | PktAggregate .....                       | 34 |
| 5.1.27 | Debug .....                | 28 | 5.2.24 | WmmCapable .....                         | 34 |
| 5.1.28 | CarrierDetect .....        | 28 | 5.2.25 | IEEE80211H .....                         | 34 |
| 5.1.29 | HtRdg .....                | 28 | 5.2.26 | NetworkType .....                        | 35 |
| 5.1.30 | HtExtcha .....             | 28 | 5.2.27 | AuthMode .....                           | 35 |
| 5.1.31 | HtOpMode .....             | 28 | 5.2.28 | EncrypType .....                         | 35 |
| 5.1.32 | HtMpduDensity .....        | 29 | 5.2.29 | DefaultKeyID .....                       | 35 |
| 5.1.33 | HtBw .....                 | 29 | 5.2.30 | Key1 .....                               | 35 |
| 5.1.34 | HtAutoBa .....             | 29 | 5.2.31 | Key2 .....                               | 35 |
| 5.1.35 | HtAmsdu .....              | 29 | 5.2.32 | Key3 .....                               | 35 |
| 5.1.36 | HtBaWinSize .....          | 29 | 5.2.33 | Key4 .....                               | 35 |
| 5.1.37 | HtGi .....                 | 30 | 5.2.34 | WPAPSK .....                             | 35 |
| 5.1.38 | HtMcs .....                | 30 | 5.3    | IWPRIV EXAMPLES .....                    | 35 |
| 5.1.39 | HtProtect .....            | 30 | 5.3.1  | Infrastructure .....                     | 35 |
| 5.1.40 | HtMimoPs .....             | 30 | 5.3.2  | Ad-Hoc .....                             | 36 |
| 5.1.41 | FixedTxMode .....          | 30 | 5.3.3  | Get site survey .....                    | 37 |
| 5.1.42 | LongRetry .....            | 31 | 5.3.4  | Get Statistics .....                     | 37 |
| 5.1.43 | ShortRetry .....           | 31 | 5.3.5  | ANY SSID .....                           | 37 |
| 5.1.44 | HtBaDecline=Value .....    | 31 | 5.4    | IWLIST .....                             | 37 |
| 5.1.45 | HtDisallowTKIP=Value ..... | 31 | 5.5    | IWCONFIG .....                           | 37 |
| 5.1.46 | wsc_ap_band=Value .....    | 31 | 6      | WPS – WI-FI PROTECTED SETUP .....        | 39 |
| 5.1.47 | BeaconLostTime=Value ..... | 32 | 6.1    | IWPRIV USAGE.....                        | 39 |
| 5.1.48 | AutoRoaming=Value .....    | 32 | 6.1.1  | wsc_conf_mode .....                      | 39 |
| 5.1.49 | SiteSurvey=Value .....     | 32 | 6.1.2  | wsc_mode .....                           | 40 |
| 5.2    | IWPRIV SHOW USAGE .....    | 32 | 6.1.3  | wsc_pin .....                            | 40 |
| 5.2.1  | SSID .....                 | 32 | 6.1.4  | wsc_ssid .....                           | 40 |
| 5.2.2  | WirelessMode .....         | 33 | 6.1.5  | wsc_start .....                          | 40 |
| 5.2.3  | TxBurst .....              | 33 | 6.1.6  | wsc_stop.....                            | 40 |
| 5.2.4  | TxPreamble .....           | 33 | 6.1.7  | wsc_gen_pincode .....                    | 41 |
| 5.2.5  | TxPower .....              | 33 | 6.1.8  | wsc_cred_count .....                     | 41 |
| 5.2.6  | Channel .....              | 33 | 6.1.9  | wsc_cred_ssid.....                       | 41 |
| 5.2.7  | BGProtection .....         | 33 | 6.1.10 | wsc_cred_auth .....                      | 41 |
| 5.2.8  | RTSThreshold .....         | 33 | 6.1.11 | wsc_cred_encr .....                      | 42 |
| 5.2.9  | FragThreshold .....        | 33 | 6.1.12 | wsc_cred_keyIdx .....                    | 42 |
| 5.2.10 | HtBw .....                 | 33 | 6.1.13 | wsc_cred_key .....                       | 42 |
| 5.2.11 | HtMcs .....                | 33 | 6.1.14 | wsc_cred_mac .....                       | 43 |
| 5.2.12 | HtGi .....                 | 33 | 6.1.15 | wsc_conn_by_idx .....                    | 43 |
| 5.2.13 | HtOpMode .....             | 33 | 6.1.16 | wsc_auto_conn .....                      | 43 |
| 5.2.14 | HtExtcha .....             | 34 | 6.2    | WPS STA AS AN ENROLLEE OR REGISTRAR .... | 43 |
| 5.2.15 | HtMpduDensity .....        | 34 | 6.2.1  | Enrollee Mode .....                      | 44 |
| 5.2.16 | HtBaWinSize .....          | 34 | 6.2.2  | Registrar Mode .....                     | 44 |
| 5.2.17 | HtRdg .....                | 34 | 6.3    | WPS IOCTL USAGE .....                    | 46 |
| 5.2.18 | HtAmsdu .....              | 34 |        |  |    |

|                |   |                    |   |    |
|----------------|---|--------------------|---|----|
| 6.3.1          | iwpriv commands without argument          | 7.4.1              | BBPID .....                             | 59 |
|                | 46  | 7.4.2              | BBPID=Value .....                       | 59 |
| 6.3.2          | iwpriv commands with one INT              | 7.5                | IWPRIV RAO MAC [PARAMETERS]=[VAL] ..... | 59 |
| argument ..... | 46  | 7.5.1              | MAC_OFFSET .....                        | 59 |
| 6.3.3          | iwpriv commands with string               | 7.5.2              | MAC_OFFSET=Value .....                  | 60 |
| argument ..... | 47  | 7.6                | IWPRIV RAO E2P [PARAMETERS]=[VAL].....  | 60 |
| 6.4            | WPS IOCTL SAMPLE PROGRAM .....            | 7.6.1              | EEP_ADDR .....                          | 60 |
|                | 47  | 7.6.2              | EEP_ADDR=Value .....                    | 60 |
| 7              | ATE TEST COMMAND FORMAT .....             | 7.7                | EXAMPLE .....                           | 60 |
|                | 50  | 7.7.1              | Hardware access .....                   | 60 |
| 7.1            | IWPRIV RAO SET [PARAMETERS]=[VAL] .....   | 7.7.2              | Statistic counter operation .....       | 60 |
|                | 51  | 7.7.3              | Suggestion: .....                       | 60 |
| 7.1.1          | ATE .....                                 | 7.8                | ATED.....                               | 61 |
| 7.1.2          | ATEDA .....                               | 7.8.1              | Introduction .....                      | 61 |
| 7.1.3          | ATESA .....                               | 7.8.2              | Environment setup .....                 | 61 |
| 7.1.4          | ATEBSSID .....                            | 7.8.3              | How to use ated for ATE purpose .       | 61 |
| 7.1.5          | ATECHANNEL .....                          |                    |   |    |
| 7.1.6          | ATETXPOW0 .....                           | 8                  | IOCTL .....                             | 63 |
| 7.1.7          | ATETXPOW1 .....                           | 8.1                | PARAMETERS FOR IWCONFIG .....           | 63 |
| 7.1.8          | ATETXFREQOFFSET.....                      | 8.2                | PARAMETERS FOR IWPRIV .....             | 66 |
| 7.1.9          | ATETXLEN .....                            | 8.2.1              | Set Data, Parameters is Same as         |    |
| 7.1.10         | ATETXCNT .....                            | iwpriv             | 66                                      |    |
| 7.1.11         | ATETXMODE (Refer to TxMode) ...           | 8.2.2              | Get Data, Parameters is the same as     |    |
| 7.1.12         | ATETXBW (Refer to TxMode) .....           | iwpriv             | 67                                      |    |
| 7.1.13         | ATETXGI (Refer to TxMode) .....           | 8.2.3              | Set Raw Data with Flags.....            | 67 |
| 7.1.14         | ATETXMCS (Refer to TxMode) .....          | 8.2.4              | Get Raw Data with Flags .....           | 71 |
| 7.1.15         | ATETXANT .....                            | 8.2.5              | Set Raw Data with Flags.....            | 76 |
| 7.1.16         | ATERXANT .....                            |                    |   |    |
| 7.1.17         | ATERXFER .....                            | 9                  | IOCTL HOW TO .....                      | 77 |
| 7.1.18         | ATESHOW .....                             | 9.1                | GET DATA .....                          | 77 |
| 7.1.19         | ATEHELP .....                             | 9.1.1              | GET IPv4 and MAC apping table:..        | 77 |
| 7.1.20         | ResetCounter .....                        | 9.1.2              | GET IPv6 and MAC mapping table:         |    |
| 7.1.21         | ATERRF .....                              | 77                 |   |    |
| 7.1.22         | ATEWRF1 .....                             | 9.1.3              | GET station connection status: .....    | 77 |
| 7.1.23         | ATEWRF2 .....                             | 9.1.4              | GET station statistics information:77   |    |
| 7.1.24         | ATEWRF3 .....                             | 9.1.5              | GET AP list table: .....                | 78 |
| 7.1.25         | ATEWRF4 .....                             | 9.1.6              | GET scan table: .....                   | 78 |
| 7.2            | TX MODE, MCS, BW AND GI SELECTION TABLE   | 9.1.7              | GET station's MAC: .....                | 78 |
|                | 55  | 9.1.8              | GET station connection status: .....    | 79 |
| 7.3            | EXAMPLES .....                            | 9.1.9              | GET AP's BSSID .....                    | 79 |
|                | 56  | 9.1.10             | GET SSID .....                          | 79 |
| 7.3.1          | Check EVM & Power.....                    | 9.1.11             | GET station's last TX related           |    |
| 7.3.2          | Check Carrier .....                       | information: ..... | 79                                      |    |
| 7.3.3          | Check specturm mask .....                 | 9.1.12             | GET station's last RX related           |    |
| 7.3.4          | Frequency offset tuning .....             | information: ..... | 80                                      |    |
| 7.3.5          | Rx .....                                  | 9.1.13             | GET station's wireless mode: .....      | 80 |
| 7.3.6          | Show all ate parameters .....             | 9.1.14             | GET Bss type: .....                     | 81 |
| 7.3.7          | Online help .....                         |                    |   |    |
| 7.3.8          | Display Rx Packet Count and RSSI          |                    |   |    |
| 7.4            | IWPRIV RAO BBP [PARAMETERS]=[VALUE] ..... |                    |   |    |
|                | 59  |                    |   |    |

## Ralink RT2860 Linux Station Release Notes & User's Guide

|        |                                |    |         |                               |    |
|--------|--------------------------------|----|---------|-------------------------------|----|
| 9.1.15 | GET Authentication Mode: ..... | 81 | 9.1.20  | GET Driver wireless extension |    |
| 9.1.16 | GET Encryption Type: .....     | 82 | version | 83                            |    |
| 9.1.17 | GET RSSI 0 (unit: db) .....    | 83 | 9.2     | HOW TO DISPLAY RATE, BW:..... | 84 |
| 9.1.18 | GET RSSI 1 (unit: db) .....    | 83 | 9.3     | SET DATA FOR N MODE .....     | 86 |
| 9.1.19 | GET RSSI 2 (unit: db) .....    | 83 | 9.4     | SET HT MODE:.....             | 86 |

## 2 VERSION HISTORY

### 2.1 [V2.1.0.0]

1. New generation schema for multiple OS porting
2. Fixed Ad-hoc ping failed in noisy environment. (Probe Response has too many retry packet then cause "not enough space in MgmtRing")
3. Fixed WPA(2)PSK issue when group cipher of AP is WEP40 or WEP104.
4. Modified iwpriv ra0 get\_site\_survey:  
In scan list result: Security shows "NONE" when AP is OPEN/NONE,  
shows "WEP" when AP is OPEN/WEP or SHARED/WEP,  
shows "WPAPSK(WPA2PSK)/TKIP(AES)" when AP is WPAPSK(WPA2PSK)/TKIP(AES)  
shows "WPA(WPA2)/TKIP(AES)" when AP is WPA(WPA2)/TKIP(AES)
5. Fixed WPS failed with D-Link DIR-628 in 5GHz.
6. Support kthread.
7. Add New A band channel list region 15 contains the whole channels in the A band region 4 and the new CE channel 167,169,171,173
8. Add New IEEE802.11r functionality.
9. Fixed WPA2-Enterprise failed when AP reboot or turn off then turn on.
10. Fixed STA cannot connect to 11B only AP when the setting of is PHY\_11GN.

### 2.2 [V1.8.0.0]

1. Fixed compile error when CARRIER\_DETECTION\_SUPPORT is enabled.
2. Add "iwpriv ra0 set CarrierDetect=0(or 1)"
3. Add new WSC hardware push button function
4. Add Ad-Hoc to support N rate.
5. Migrate Mesh supporting to Draft-2.0.
6. Support WAPI functionality
7. Fixed suspend/resume error when ra0 down, ra0 up.
8. Support Linux Kernel 2.6.27
9. Fixed WPS failed when AP is not in scan table or AP's channel changing after user sets "iwpriv ra0 wsc\_start"
10. Fixed DLS A-MPDU established failed.

### 2.3 [V1.7.0.0]

1. Support SIOCSIWGENIE, SIOCGIWGENIE, SIOCSIWMLME, SIOCGIWENCODEEXT, and SIOCSIWPMKSA.
2. Support IWEVGENIE in iwlist ra0 scan.
3. Support DLS
4. Fixed connection failed with Range Maximizer - 515 AP (Marvell Chip) when security is WPAPSK/TKIP.
5. Fixed length error of RSN/SSN IE for WpaSupplicant.
6. Fixed WPAPSK rekey problem when A-MSDU is enabled.
7. Fixed NetworkManager cannot detect ra0 when ra0 is not up.
8. Add IEEE802.11d Client Mode: None, Flexible, Strcit.
9. Add Station N only mode. (Only connects to N-AP)
10. Add Global country domain(ch1-11:active scan, ch12-14 passive scan)
11. Enhance PCIe advance power saving
12. Modified iwpriv ra0 get\_site\_survey: When security of AP is OPEN/WEP or SHARED/WEP, show UNKNOW/WEP in scan list.

13. When the secondary channel of AP exceeds the country region's range, station will auto fallback to 20MHz. i.e. need both control and secondary channel are both in country region's channel list.
14. Fixed crash in LinkDown when there are >64 APs exists.

## 2.4 [V1.6.0.0]

1. Fixed issue of Radar Channel flag building with HAS\_EXT\_BUILD\_CHANNEL\_LIST=n.
2. Fixed issue of Adhoc-STA would create in radar channel.
3. Support Mesh
4. Support Linux Kernel 2.6.24
5. Support SNMP
6. Support Debug Diagnose
7. Add Makefile.NonLoadableModule for non-loadable module
8. Add two ioctl commands to change tx long/short retry limit.
9. Fixed WPS STA is hard to do WPS process with Broadcom WPS AP Proxy and Marvell WPS External Registrar.

## 2.5 [V1.5.0.0]

1. New code base - RT28xx.
2. Add BaSmartHardTransmit mechanism.
3. Support Linux Kernel 2.6 suspend and resume.
4. Support extened channel list.
5. Add "iwconfig rate" setting for legacy rate.
6. Add make install/uninstall to Makfile.
7. Fixed issue of showing SNR1 information.
8. ATE: Add command "iwpriv ra0 set ATELDE2P=1" to overwrite all EEPROM contents from a .bin file.
9. Change IRQ LOCK to SEM LOCK
10. Support Non-GPL MD5
11. Fixed one Ethernet convert porting issue on RT28xx.
12. Fixed extened channel list checking issue on RT28xx.

## 2.6 [V1.4.0.0]

1. Fixed Legacy Wi-Fi WMM S06 fail.
2. Fixed WPAPSK failed when 2860 STA Aggregation is enabled and connects with 2860 N/Aggregation AP.
3. Fixed "iwconfig ra0 essid"
4. Send DIS-ASSOC request to AP when ra0 down.
5. Support 5-GHz band ATE.
6. Fixed fixed rate issue in N mode and fixed rate ioctl.
7. Add Legacy Power Saving Mode.
8. Fixed W52 with Activity scan issue in ABG\_MIXED and ABGN\_MIXED mode.
9. Fixed ping failed with Broadcom N AP when AP is GF enabled and STA is auto rate.
10. Support custom wireless event.
11. Modify rate adaptation for fast ramp-up tuning.

## 2.7 [V1.3.0.0]

1. Support Monitor Mode with WireShark.(Usage: iwconfig ra0 mode monitor)
2. Update Rate Adaptation Algorithm.
3. Add ATE function(also QA supported).
4. Support IPv6 Ethernet Convert Mechanism.
5. Support NetworkManager, wpa\_supplicant by using wext.



6. Fixed Auto Rate Select issue.(When RT2860 Linux STA links up with N-AP then change to link up with legacy-AP)
7. Fixed Fast-Roaming Fail Issue.

## 2.8 [V1.2.1.0]

1. Fixed segmentation fault when size of iwpriv ra0 get\_site\_survey result exceeded 4096.
2. Add MAT related iwpriv commands.
3. Add AP's wireless mode info to iwpriv ra0 get\_site\_survey
4. Modify bitrate info in iwlist ra0 scan.

## 2.9 [V1.2.0.0]

1. Update NicConfig2 default value.
2. Modify STA to retrieve the MCS of AP(from Beacon) and save to StaActive structure.
3. Add WPS re-generate PIN command: iwpriv ra0 wsc\_gen\_pincode.
4. Do NOT re-build M-messages in WPS state machine timeout timer function.
5. Fixed compile error in non-DBG mode.

## 2.10 [V1.1.0.0]

1. Fixed WI-FI test item 5.2.2.9 #S7, STA will fail to authenticate when AP set fragmentation to 500.
2. Fixed iwpriv security setting issue.
3. Re-organize the Rx data path.
4. Update Tx Power mechanism.
5. Support WPS In-band(EAP) & Out-Of-band(UPnP) Enrollee mode and In-band(EAP) Registrar mode.
6. Add WPS related iwpriv commands
7. Support Big-Endian.

## 2.11 [V1.0.0.0]

1. Chariot Throughput ok
2. Driver security support: Open/Shared WEP, WPA-PSK, WPA2-PSK, WPA-NONE.
3. Support 32/64-bit OS
4. Support A-MPDU and A-MSDU

## 3 README

### 3.1.1 ModelName:

RT2860 WLAN Linux Driver

### 3.1.2 Driver IName:

Kernel 2.4.x: rt2860.o

Kernel 2.6.x: rt2860.ko

### 3.1.3 Supporting Kernel:

Linux kernel 2.4 and 2.6 series.

Tested in Redhat 7.3 or later.

### 3.1.4 Description:

This is a linux device driver for Ralink RT2860 ABGN WLAN Card.

### 3.1.5 Contents:

Makefile:            Makefile

\*.c:                c files

\*.h:                header files

### 3.1.6 Features:

This driver implements basic IEEE802.11.

Infrastructure and Ad-Hoc mode with open or shared or WPA-PSK or WPA2-PSK authentication method.

NONE, WEP, TKIP and AES encryption.

### 3.1.7 Build Instructions:

- 1> \$tar -xvzf yyyy\_mmdd\_RT2860\_Linux\_STA\_x.x.x.x.tgz  
go to "./yyyy\_mmdd\_RT2860\_Linux\_STA\_x.x.x.x" directory.
- 2> In Makefile  
set the "MODE = STA" in Makefile  
choose the TARGET to Linux by set "TARGET = LINUX"

- define the linux kernel source include file path LINUX\_SRC modify to meet your need.
- 3> In os/linux/config.mk  
define the GCC and LD of the target machine.  
define the compiler flags CFLAGS.  
modify to meet your need.
- \*\* Build for being controlled by NetworkManager**  
Please set 'HAS\_WPA\_SUPPLICANT=y' and 'HAS\_NATIVE\_WPA\_SUPPLICANT\_SUPPORT=y'.
- \*\* Build for being controlled by WpaSupplicant with Ralink Driver**  
Please set 'HAS\_WPA\_SUPPLICANT=y' and 'HAS\_NATIVE\_WPA\_SUPPLICANT\_SUPPORT=n'.
- 4> compile driver source code  
\$make
- 5> \$cp RT2860STA.dat /etc/Wireless/RT2860STA/RT2860STA.dat  
# !!!check if it is a binary file before loading !!!
- 6> load driver  
#[kernel 2.4]
- # \$/sbin/insmod rt2860sta.o  
# \$/sbin/ifconfig ra0 inet YOUR\_IP up
- #[kernel 2.6]
- # \$/sbin/insmod rt2860sta.ko  
# \$/sbin/ifconfig ra0 inet YOUR\_IP up
- 7> unload driver  
\$/sbin/ifconfig ra0 down  
\$/sbin/rmmod rt2860sta

## 4 CONFIGURATION:

RT2860 driver can be configured via following interfaces, i.e.

1. configuration file
2. "iwconfig" command
3. "iwpriv" command

NOTE:

- modify configuration file "RT2860STA.dat" in /etc/Wireless/RT2860STA/RT2860STA.dat.
- iwconfig/iwpriv comes with kernel.
- iwpriv usage, please refer to below sections for details.

### 4.1 CONFIGURATION FILE : RT2860STA.DAT

```
# Copy this file to /etc/Wireless/RT2860STA/RT2860STA.dat
# This file is a binary file and will be read on loading rt.o module.
#
# Use "vi -b RT2860STA.dat" to modify settings according to your need.
#
# 1.) set NetworkType to
#      "Adhoc" for using Adhoc-mode,
#      otherwise using Infrastructure
# 2.) set Channel to
#      "0" for auto-select on Infrastructure mode
# 3.) set SSID for connecting to your Accss-point.
# 4.) AuthMode can be
#      "WEPAUTO",
#      "OPEN",
#      "SHARED",
#      "WPAPSK",
#      "WPA2PSK",
#      "WPANONE"
# 5.) EncrypType can be
#      "NONE",
#      "WEP",
#      "TKIP",
#      "AES"
# for more information refer to the Readme file.
#
#The word of "Default" must not be removed
Default
CountryRegion=5
CountryRegionABand=7
CountryCode=
SSID=Dennis2860AP
NetworkType=Infra
WirelessMode=9
Channel=0
BasicRate=15
BeaconPeriod=100
```

```

TxPower=100
BGProtection=0
TxPreamble=0
RTSThreshold=2347
FragThreshold=2346
TxBurst=1
PktAggregate=0
WmmCapable=0
AckPolicy=0;0;0;0
AuthMode=OPEN
EncrypType=NONE
WPAPSK=
DefaultKeyID=1
Key1Type=0
Key1Str=
Key2Type=0
Key2Str=
Key3Type=0
Key3Str=
Key4Type=0
Key4Str=
PSMode=CAM
AutoRoaming=0
RoamThreshold=70
HT_RDG=1
HT_EXTCHA=0
HT_OpMode=1
HT_MpduDensity=4
HT_BW=1
HT_AutoBA=1
HT_AMSDU=0
HT_BAWinSize=64
HT_GI=1
HT_MCS=33
HT_MIMOPSMODE=3
IEEE80211H=0
TgnWifiTest=0
WirelessEvent=0
CarrierDetect=0

```

Note:

WMM parameters

```

WmmCapable    ; Set it as 1 to turn on WMM Qos support
AckPolicy1~4   ; Ack policy which support normal Ack or no Ack
                ; (AC_BK, AC_BE, AC_VI, AC_VO)

```

All WMM parameters do not support iwpriv command but 'WmmCapable', please store all parameter to RT2860STA.dat, and restart driver.

## 4.2 USAGE

Syntax is 'Param'='Value' and describes below.

## SectionNumber Parameter

Value:

...  
...  
...

### 4.2.1 CountryRegion

Value:

| Region | Channels |
|--------|----------|
| 0      | 1-11     |
| 1      | 1-13     |
| 2      | 10-11    |
| 3      | 10-13    |
| 4      | 14       |
| 5      | 1-14     |
| 6      | 3-9      |
| 7      | 5-13     |

### 4.2.2 CountryRegionForABand

Value:

| Region | Channels   |
|--------|--|
| 0      | 36, 40, 44, 48, 52, 56, 60, 64, 149, 153, 157, 161, 165  |
| 1      | 36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140                          |
| 2      | 36, 40, 44, 48, 52, 56, 60, 64   |
| 3      | 52, 56, 60, 64, 149, 153, 157, 161   |
| 4      | 149, 153, 157, 161, 165  |
| 5      | 149, 153, 157, 161   |
| 6      | 36, 40, 44, 48   |
| 7      | 36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140, 149, 153, 157, 161, 165 |
| 8      | 52, 56, 60, 64   |
| 9      | 36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 132, 136, 140, 149, 153, 157, 161, 165                |
| 10     | 36, 40, 44, 48, 149, 153, 157, 161, 165  |
| 11     | 36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 149, 153, 157, 161                               |

### 4.2.3 CountryCode

Value:

AG, AR, AW, AU, AT, BS, BB, BM, BR, BE, BG, CA, KY, CL, CN, CO, CR, CY, CZ, DK, DO, EC, SV, FI, FR, DE, GR, GU, GT, HT, HN, HK, HU, IS, IN, ID, IE, IL, IT, JP, JO, LV, LI, LT, LU, MY, MT, MA, MX, NL, NZ, NO, PE, PT, PL, RO, RU, SA, CS, SG, SK, SI, ZA, KR, ES, SE, CH, TW, TR, GB, UA, AE, US, VE

NOTE:

"": Using default setting.

2.4 G - channels 1 ~ 11

5G - channels 52 ~ 64, 100 ~ 140, 149 ~ 165

---

#### 4.2.4 SSID

Value:

0~z, 1~32 ASCII characters.

---

#### 4.2.5 WirelessMode

Value:

0: legacy 11b/g mixed  
1: legacy 11B only  
2: legacy 11A only   // Not support in RflicType=1(id=RFIC\_5225)  
                          // and RflicType=2(id=RFIC\_5325)  
3: legacy 11a/b/g mixed   // Not support in RflicType=1(id=RFIC\_5225)  
                          // and RflicType=2(id=RFIC\_5325)  
4: legacy 11G only  
5: 11ABGN mixed  
6: 11N only  
7: 11GN mixed  
8: 11AN mixed  
9: 11BGN mixed  
10: 11AGN mixed

---

#### 4.2.6 Channel

Value:

This value depends on the CountryRegion or CountryRegionForABand setting.

---

#### 4.2.7 BGProtection

Value:

0: Auto  
1: Always on  
2: Always off

---

#### 4.2.8 TxPreamble

Value:

0: Preamble Long  
1: Preamble Short  
2: Auto

---

#### 4.2.9 RTSThreshold

Value:

1 ~ 2347

---

#### 4.2.10 FragThreshold

Value:

256 ~ 2346

---

#### 4.2.11 TxBurst

Value:

0: Disable  
1: Enable

---

#### 4.2.12 PktAggregate

Value:

0: Disable  
1: Enable

---

#### 4.2.13 NetworkType

Value:

Infra: infrastructure mode  
Adhoc: adhoc mode

---

#### 4.2.14 AuthMode

Value:

OPEN: For open system  
SHARED: For shared key system  
WEPAUTO: Auto switch between OPEN and SHARED  
WPAPSK: For WPA pre-shared key (Infra)  
WPA2PSK: For WPA2 pre-shared key (Infra)



WPANONE: For WPA pre-shared key (Adhoc)

WPA:

WPA2:

---

#### 4.2.15 EncryptType

Value:

NONE: For AuthMode=OPEN

WEP: For AuthMode=OPEN or AuthMode=SHARED

TKIP: For AuthMode=WPAPSK or WPA2PSK

AES: For AuthMode=WPAPSK or WPA2PSK

---

#### 4.2.16 DefaultKeyID

Value:

1 ~ 4

---

#### 4.2.17 WEP KeyType

Key1Type=value

Key2Type=value

Key3Type=value

Key4Type=value

Value:

0: hexadecimal type

1: ASCII type

(usage: reading profile only)

---

#### 4.2.18 WEP Hex Key

Key1=value

Key2=value

Key3=value

Key4=value

Value:

10 or 26 hexadecimal characters eg: 012345678

5 or 13 ASCII characters eg: passwd

(usage : "iwpriv" only)

---

#### 4.2.19 WEP Key String

Key1Str=value

Key2Str=value

Key3Str=value

Key4Str=value

Value:

10 or 26 characters (key type=0)  
 5 or 13 characters (key type=1)  
 (usage : reading profile only)

---

#### 4.2.20 WPAPSK

Value:

8 ~ 63 ASCII or  
 64 HEX characters

---

#### 4.2.21 WmmCapable

Value:

0: Disable WMM  
 1: Enable WMM

---

#### 4.2.22 IEEE80211H

Enable IEEE802.11h support

Value:

0: Disable  
 1: Enable

---

#### 4.2.23 PSMode

Value:

|          |                       |
|----------|-----------------------|
| CAM      | Constantly Awake Mode |
| Max_PSP  | Max Power Savings     |
| Fast_PSP | Power Save Mode       |

---

#### 4.2.24 AutoRoaming

Value:

0: Disabled  
 1: Enabled

---

#### 4.2.25 RoamThreshold

Value:

0 ~ 255

---

#### 4.2.26 TGNWiFiTest

Value:

0: Disabled  
1: Enabled

---

#### 4.2.27 WirelessEvent

Value:  
  
0: Disabled  
1: Enabled

---

#### 4.2.28 CarrierDetect

Value:  
  
0: Disabled  
1: Enabled

---

#### 4.2.29 HT\_RDG

Value:  
  
0: Disabled  
1: Enabled

---

#### 4.2.30 HT\_EXTCHA

Value:  
  
0: Below  
1: Above

---

#### 4.2.31 HT\_OpMode

Value:  
  
0: HT mixed format  
1: HT greenfield format

---

#### 4.2.32 HT\_MpduDensity

Value:  
  
0 ~ 7

---

#### 4.2.33 HT\_BW

Value:  
  
0: 20MHz

1: 40MHz

---

#### 4.2.34 HT\_AutoBA

Value:

0: Disabled

1: Enabled

---

#### 4.2.35 HT\_AMSDU

Value:

0: Disabled

1: Enabled

---

#### 4.2.36 HT\_BAWinSize

Value:

1 ~ 64

---

#### 4.2.37 HT\_GI

Value:

0: long GI

1: short GI

---

#### 4.2.38 HT\_MCS

Value:

0 ~ 15

33: auto

---

#### 4.2.39 HT\_MIMOPSMODE

Value:

0: Static SM Power Save Mode

2: Reserved

1: Dynamic SM Power Save Mode

3: SM enabled

(not yet fully supported)

---

#### 4.2.40 HT\_BADecline=Value

Reject BA request from AP

Value:

0: Disabled  
1: Enabled

## 4.3 MORE INFORMATION

If you want for rt2860 driver to auto-load at boot time:

- A) choose ra0 for first RT2860 WLAN card, ra1 for second RT2860 WLAN card, etc.
- B) create(edit) 'ifcfg-ra0' file in /etc/sysconfig/network-scripts/,  
edit( or add the line) in /etc/modules.conf:  
alias ra0 rt2860sta
- C) edit(create) the file /etc/sysconfig/network-scripts/ifcfg-ra0  
DEVICE='ra0'  
ONBOOT='yes'

NOTE:

- if you use dhcp, add this line too.  
BOOTPROTO='dhcp'
- D) To ease the Default Gateway setting,  
add the line  
GATEWAY=x.x.x.x  
in /etc/sysconfig/network

## 5 WIRELESS TOOLS

### 5.1 IWPRIV USAGE

This is detailed explanation of each parameters for iwpriv.

Before reading this document, make sure you already read README.

`iwpriv ra0 set [parameters]=[Value]`

NOTE:

Execute one iwpriv/set command simultaneously.

#### 5.1.1 DriverVersion

Check driver version by issue iwpriv set command.

Range: Any value

Value:

0

### 5.1.2 CountryRegion

Set country region.

Range:

0 ~ 7

Value:

| Region | Channels |
|--------|----------|
| 0      | 1-11     |
| 1      | 1-13     |
| 2      | 10-11    |
| 3      | 10-13    |
| 4      | 14       |
| 5      | 1-14     |
| 6      | 3-9      |
| 7      | 5-13     |

### 5.1.3 CountryRegionABand

Set country region for A band.

Range:

{0~10}

Value:

| Region | Channels   |
|--------|--|
| 0      | 36, 40, 44, 48, 52, 56, 60, 64, 149, 153, 157, 161, 165  |
| 1      | 36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140                          |
| 2      | 36, 40, 44, 48, 52, 56, 60, 64   |
| 3      | 52, 56, 60, 64, 149, 153, 157, 161   |
| 4      | 149, 153, 157, 161, 165  |
| 5      | 149, 153, 157, 161   |
| 6      | 36, 40, 44, 48   |
| 7      | 36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140, 149, 153, 157, 161, 165 |
| 8      | 52, 56, 60, 64   |
| 9      | 36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 132, 136, 140, 149, 153, 157, 161, 165                |
| 10     | 36, 40, 44, 48, 149, 153, 157, 161, 165  |
| 11     | 36, 40, 44, 48, 52, 56, 60, 64, 100, 104, 108, 112, 116, 120, 149, 153, 157, 161                               |

---

#### 5.1.4 SSID

Set AP SSID

Range:

{0 ~ z, 1 ~ 32 ASCII characters}

Value:

---

#### 5.1.5 WirelessMode

Set Wireless Mode

Range:

{0 ~ 10}

Value:

0: legacy 11b/g mixed  
1: legacy 11B only  
2: legacy 11A only  
3: legacy 11a/b/g mixed  
4: legacy 11G only  
5: 11ABGN mixed  
6: 11N only  
7: 11GN mixed  
8: 11AN mixed  
9: 11BGN mixed  
10: 11AGN mixed

---

#### 5.1.6 TxBurst:

Set TxBurst Enable or Disable

Range:

{0,1}

Value:

0: Disable,  
1: Enable

---

#### 5.1.7 PktAggregate:

Set Tx Aggregate Enable or Disable

Range:

{0,1}

Value:

0: Disable,  
1: Enable

---

#### 5.1.8 TxPreamble:

Set TxPreamble

Range:

{0~2}

Value:

0: Preamble Long  
1: Preamble Short  
2: Auto

---

#### 5.1.9 TxPower:

Set Tx power in percentage

Range:

{0 ~ 100}

Value:

---

#### 5.1.10 Channel

Set Channel, depends on CountryRegion or CountryRegionABand

---

#### 5.1.11 BGProtection:

Set 11B/11G Protection

Range:

{0~2}

Value:

0: Auto,  
1: Always on  
2: Always off

---

#### 5.1.12 RTSThreshold:

Set RTS Threshold

Range:



{1 ~ 2347}

Value:

---

#### 5.1.13 FragThreshold:

Set Fragment Threshold

Range:

{256 ~ 2346}

Value:

---

#### 5.1.14 NetworkType:

Set Network type

Range:

{Infra, Adhoc}

Value:

---

#### 5.1.15 AuthMode:

Set Authentication Mode

Range:

{OPEN, SHARED, WEPAUTO, WPAPSK, WPA2PSK, WPANONE}

Value:

---

#### 5.1.16 EncrypType:

Set Encryption Type

Range:

{NONE, WEP, TKIP, AES}

Value:

---

#### 5.1.17 DefaultKeyID:

Set Default Key ID

Range:

{1 ~ 4}

Value:

---

#### 5.1.18 Key1

Set Key1 String

Range:

5 ASCII characters or 10 hex number, or  
13 ASCII characters or 26 hex numbers

Value:

---

#### 5.1.19 Key2

Set Key2 String

Range:

5 ASCII characters or 10 hex number or  
13 ASCII characters or 26 hex numbers

Value:

---

#### 5.1.20 Key3

Set Key3 String

Range:

5 ASCII characters or 10 hex number or  
13 ASCII characters or 26 hex numbers

Value:

---

#### 5.1.21 Key4

Set Key4 String

Range:

5 ASCII characters or 10 hex number or  
13 ASCII characters or 26 hex numbers

Value:

---

#### 5.1.22 WPAPSK

WPA Pre-Shared Key

Range:

8~63 ASCII or 64 hex characters

Value:

---

#### 5.1.23 WmmCapable

Set WMM Capable

Range:

0, 1

Value:

0: Disable WMM,  
1: Enable WMM

---

#### 5.1.24 IEEE80211H

Enabel IEEE802.11h support

Range:

0, 1

Value:

0: Disable  
1: Enable

---

#### 5.1.25 PSMode

Set Power Saving Mode

Range:

{CAM, MAX\_PSP, FAST\_PSP}

Value:

---

#### 5.1.26 ResetCounter

Reset statistics counter

Range:

Any vlaue

Value:

0

### 5.1.27 Debug

Set on debug level

Range:

{0 ~ 5}

Value:

|          |                                      |
|----------|--------------------------------------|
| 0: OFF   | no debug message display             |
| 1: ERROR | display error message                |
| 2: WARN  | display warning message              |
| 3: TRACE | display trace message, usually used. |
| 4: INFO  | display informatic message           |
| 5: LOUD  | display all message                  |

### 5.1.28 CarrierDetect

Value:

0: Disabled  
1: Enabled

### 5.1.29 HtRdg

Enable HT Reverse Direction Grant.

Value:

0: Disabled  
1: Enabled

### 5.1.30 HtExtcha

To locate the 40MHz channel in combination with the control.

Value:

0: Below  
1: Above

### 5.1.31 HtOpMode

Change HT operation mode.

Value:

0: HT mixed format  
1: HT greenfield format

---

#### 5.1.32 HtMpduDensity

Minimum separation of MPDUs in an A-MPDU. (based on 802.11n D2.0)

Value:

0 ~ 7

0: no restriction

1: 1/4  $\mu$ s

2: 1/2  $\mu$ s

3: 1  $\mu$ s

4: 2  $\mu$ s

5: 4  $\mu$ s

6: 8  $\mu$ s

7: 16  $\mu$ s

---

#### 5.1.33 HtBw

Support channel width.

Value:

0: 20MHz

1: 40MHz

---

#### 5.1.34 HtAutoBa

Enable auto block acknowledgment (Block Ack).

Value:

0: Disabled

1: Enabled

---

#### 5.1.35 HtAmsdu

Enable aggregation of multiple MSDUs in one MPDU.

Value:

0: Disabled

1: Enabled

---

#### 5.1.36 HtBaWinSize

Set BA WinSize.

Value:

1 ~ 64

---

#### 5.1.37 HtGi

Support Short/Long GI.

Value:

0: long GI  
1: short GI

---

#### 5.1.38 HtMcs

MCS rate selection.

Value:

0 ~ 15  
33: auto

---

#### 5.1.39 HtProtect

Enable HT protection for legacy device.

Value:

0: Disable  
1: Enable

---

#### 5.1.40 HtMimoPs

MIMO power save mode selection. (based on 802.11n D2.0)

Value:

0: Static SM (Spatial Multiplexing) Power Save Mode  
1: Dynamic SM Power Save Mode  
2: Reserved  
3: SM enabled  
(not fully support yet)

---

#### 5.1.41 FixedTxMode

Set Fixed Tx Mode for fixed rate setting

Value:

Mode= CCK

|         |             |
|---------|-------------|
| MCS = 0 | => 1Mbps    |
| MCS= 1  | => 2Mbps    |
| MCS= 2  | => 5.5 Mbps |
| MCS= 3  | => 11 Mbps  |

Mode = OFDM

|         |           |
|---------|-----------|
| MCS = 0 | => 6Mbps  |
| MCS= 1  | => 9Mbps  |
| MCS= 2  | => 12Mbps |
| MCS= 3  | => 18Mbps |
| MCS= 4  | => 24Mbps |
| MCS= 5  | => 36Mbps |
| MCS= 6  | => 48Mbps |
| MCS= 7  | => 54Mbps |

---

#### 5.1.42 LongRetry

Usage:

iwpriv ra0 set LongRetry=value

Value:

0 ~ 255

---

#### 5.1.43 ShortRetry

Usage:

iwpriv ra0 set ShortRetry=value

Value:

0 ~ 255

---

#### 5.1.44 HtBaDecline=Value

Reject BA request from AP

Value:

0: Disabled

1: Enabled

---

#### 5.1.45 HtDisallowTKIP=Value

When cipher is WEP or TKIP, STA would connect to 11N AP with legacy rate

Enable/Disable N rate with 11N ap when cipher is WEP or TKIP

Default setting is disable

Value:

0: False

1: True

---

#### 5.1.46 wsc\_ap\_band=Value

Setting prefer band to do WPS with dual band WPS AP

Default value is auto (2)

Value:

0 : prefer 2.4G

1 : prefer 5G

2 : auto

---

#### 5.1.47 BeaconLostTime=Value

Change Beacon Lost Time

Default value is 4 seconds

Value:

1 ~ 60 seconds

---

#### 5.1.48 AutoRoaming=Value

Enable/Disable auto roaming mechanism

Default setting is disable.

Value:

0: Disabled

1: Enabled

---

#### 5.1.49 SiteSurvey=Value

Scan with specific SSID after Link Up

Value:

0~z, 1~32 ascii characters

---

### 5.2 IWPRIV SHOW USAGE

This is the status of each parameter for "iwpriv ra0 show".

iwpriv ra0 show [parameters]

from 4.2.35~4.2.38

iwpriv mesh0 show [parameters]

---

#### 5.2.1 SSID

Show AP SSID



---

### 5.2.2 WirelessMode

Show Wireless Mode

---

### 5.2.3 TxBurst

Show TxBurst

---

### 5.2.4 TxPreamble

Show TxPreamble

---

### 5.2.5 TxPower

Show TxPower

---

### 5.2.6 Channel

Show Channel

---

### 5.2.7 BGProtection

Show BGProtection

---

### 5.2.8 RTSThreshold

Show RTSThreshold

---

### 5.2.9 FragThreshold

Show FragThreshold

---

### 5.2.10 HtBw

Show HtBw

---

### 5.2.11 HtMcs

Show HtMcs

---

### 5.2.12 HtGi

Show HtGi

---

### 5.2.13 HtOpMode

Show HtOpMode

---

#### 5.2.14 HtExtcha

Show HtExtcha

---

#### 5.2.15 HtMpduDensity

Show HtMpduDensity

---

#### 5.2.16 HtBaWinSize

Show HtBaWinSize

---

#### 5.2.17 HtRdg

Show HtRdg

---

#### 5.2.18 HtAmsdu

Show HtAmsdu

---

#### 5.2.19 HtAutoBa

Show HtAutoBa

---

#### 5.2.20 CountryRegion

Show CountryRegion

---

#### 5.2.21 CountryRegionABand

Show CountryRegionABand

---

#### 5.2.22 CountryCode

Show CountryCode

---

#### 5.2.23 PktAggregate

Show PktAggregate

---

#### 5.2.24 WmmCapable

Show WmmCapable

---

#### 5.2.25 IEEE80211H

Show IEEE80211H

---

---

### 5.2.26 NetworkType

Show NetworkType

---

### 5.2.27 AuthMode

Show AuthMode

---

### 5.2.28 EncrypType

Show EncrypType

---

### 5.2.29 DefaultKeyID

Show DefaultKeyID

---

### 5.2.30 Key1

Show Key1

---

### 5.2.31 Key2

Show Key2

---

### 5.2.32 Key3

Show Key3

---

### 5.2.33 Key4

Show Key4

---

### 5.2.34 WPAPSK

Show WPAPSK

---

## 5.3 IWPRIV EXAMPLES

---

### 5.3.1 Infrastructure

#### 5.3.1.1 OPEN/NONE

Config STA to link with AP which is OPEN/NONE (Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Infra
2. iwpriv ra0 set AuthMode=OPEN
3. iwpriv ra0 set EncrypType=NONE
4. iwpriv ra0 set SSID="AP's SSID"

### 5.3.1.2 SHARED/WEP

Config STA to link with AP which is SHARED/WEP(Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Infra
2. iwpriv ra0 set AuthMode=SHARED
3. iwpriv ra0 set EncrypType=WEP
4. iwpriv ra0 set DefaultKeyID=1
5. iwpriv ra0 set Key1="AP's wep key"
6. iwpriv ra0 set SSID="AP's SSID"

### 5.3.1.3 WPAPSK/TKIP

Config STA to link with AP which is WPAPSK/TKIP (Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Infra
2. iwpriv ra0 set AuthMode=WPAPSK
3. iwpriv ra0 set EncrypType=TKIP
4. iwpriv ra0 set SSID="AP's SSID"
5. iwpriv ra0 set WPAPSK="AP's wpa-preskared key"
6. iwpriv ra0 set SSID="AP's SSID"

### 5.3.1.4 WPAPSK/AES

Config STA to link with AP which is WPAPSK/AES (Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Infra
2. iwpriv ra0 set AuthMode=WPAPSK
3. iwpriv ra0 set EncrypType=AES
4. iwpriv ra0 set SSID="AP's SSID"
5. iwpriv ra0 set WPAPSK="AP's wpa-preskared key"
6. iwpriv ra0 set SSID="AP's SSID"

### 5.3.1.5 WPA2PSK/TKIP

Config STA to link with AP which is WPA2PSK/TKIP(Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Infra
2. iwpriv ra0 set AuthMode=WPA2PSK
3. iwpriv ra0 set EncrypType=TKIP
4. iwpriv ra0 set SSID="AP's SSID"
5. iwpriv ra0 set WPAPSK=12345678
6. iwpriv ra0 set SSID="AP's SSID"

---

## 5.3.2 Ad-Hoc

### 5.3.2.1 OPEN/NONE

Config STA to create/link as adhoc mode, which is OPEN/NONE(Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Adhoc

2. iwpriv ra0 set AuthMode=OPEN
3. iwpriv ra0 set EncrypType=NONE
4. iwpriv ra0 set SSID="Adhoc's SSID"

### 5.3.2.2 WPANONE/TKIP

Config STA to create/link as adhoc mode, which is WPANONE/TKIP(Authentication/Encryption)

1. iwpriv ra0 set NetworkType=Adhoc
2. iwpriv ra0 set AuthMode=WPANONE
3. iwpriv ra0 set EncrypType=TKIP
4. iwpriv ra0 set SSID="AP's SSID"
5. iwpriv ra0 set WPAPSK=12345678
6. iwpriv ra0 set SSID="AP's SSID"

### 5.3.3 Get site survey

Usage:

```
iwpriv ra0 get_site_survey
```

### 5.3.4 Get Statistics

Usage:

```
iwpriv ra0 stat ;read statistic counter
iwpriv ra0 set ResetCounter=0 ;reset statistic counter
```

### 5.3.5 ANY SSID

Link with an AP which is the largest strength, set ANY SSID (ssidLen=0)

Usage:

```
iwconfig ra0 essid ""
or,
iwpriv ra0 set SSID=""
```

## 5.4 IWLIST

This is detailed explanation of each parameter for iwlist.

```
iwlist ra0 scanning ; list the results after scanning(manual rescan)
```

## 5.5 IWCONFIG

The following are our support in standard configuration – iwconfig

1. iwconfig ra0 essid {NN|on|off} ;set essid
2. iwconfig ra0 mode {managed|ad-hoc|...} ;set wireless mode
3. iwconfig ra0 freq N.NNNN[k|M|G]] ;set frequency

4. iwconfig ra0 channel N ;set channel
5. iwconfig ra0 ap {N|off|auto} ;set AP address
6. iwconfig ra0 nick N ;set nickname
7. iwconfig ra0 rate {N|auto|fixed} ;set rate
8. iwconfig ra0 rts {N|auto|fixed|off} ;set RTS threshold
9. iwconfig ra0 frag {N|auto|fixed|off} ;set Fragment threshold
10. iwconfig ra0 enc {NNNN-NNNN|off} ;set encryption type
11. iwconfig ra0 power {period N|timeout N} ;set power management modes

NOTE:

Please refer to the main page of 'iwconfig', 'iwlist' and 'iwpriv' for wireless extension usage.

## 6 WPS – WI-FI PROTECTED SETUP

### Simple Config Architectural Overview

This section presents a high-level description of the Simple Config architecture. Much of the material is taken directly from the Simple Config specification.

Figure 1 depicts the major components and their interfaces as defined by Wi-Fi Simple Config Spec. There are three logical components involved: the Registrar, the access point (AP), and the Enrollee.

The Enrollee is a device seeking to join a WLAN domain. Once an Enrollee obtains a valid credential, it becomes a member.

A Registrar is an entity with the authority to issue and revoke domain credentials. A registrar can be integrated into an AP.

The AP can be either a WLAN AP or a wireless router.

### Components and Interfaces

Registration initiation is ordinarily accomplished by a user action such as powering up the Enrollee and, optionally, running a setup wizard on the Registrar (PC).

## 6.1 IWPRIV USAGE

This is detailed explanation of each iwpriv parameter.

Before reading this document, make sure you already read README.

`iwpriv ra0 [commands]=[Value]`

NOTE:

Wireless extension private handlers.

### 6.1.1 wsc\_conf\_mode

Set WPS conf mode.

Range:

{0, 1, 2}

Value:

0: WPS Disabled

1: Enrollee

2: Registrar

---

### 6.1.2 wsc\_mode

Set WPS mode, PIN or PBC.

Range:

{1, 2}

Value:

1: PIN

2: PBC

---

### 6.1.3 wsc\_pin

Set the enrollee's PIN Code.

Range:

{00000000 ~ 99999999}

Value:

---

### 6.1.4 wsc\_ssid

Set WPS AP SSID.

Range:

{0~z, 1~32 ASCII characters}

Value:

---

### 6.1.5 wsc\_start

Trigger RT2860 STA driver to do WPS process.

Range:

NULL

Value:

---

### 6.1.6 wsc\_stop



Stop WPS process.

Range:

NULL

Value:

---

#### 6.1.7 wsc\_gen\_pincode

Generate new PIN code.

Range:

NULL

Value:

---

#### 6.1.8 wsc\_cred\_count

Set count of WPS credential.

Range:

{1 ~ 8}

Value:

---

#### 6.1.9 wsc\_cred\_ssid

Set SSID into credtentail [idx].

Range:

{"idx ssid\_str"}

Value:

idx: 0 ~ 7

ssid\_str: 0~z, 1~32 ASCII characters

e.g.

iwpriv ra0 wsc\_cred\_ssid "0 wps\_ap1"

---

#### 6.1.10 wsc\_cred\_auth

Set AuthMode into credtentail [idx].

Range:

{"idx auth\_str"}

Value:

idx: 0 ~ 7

auth\_str: OPEN, WPAPSK, WPA2PSK, SHARED, WPA, WPA2

e.g.

iwpriv ra0 wsc\_cred\_auth "0 WPAPSK"

---

#### 6.1.11 wsc\_cred\_encr

Set EncryptType into credtentail [idx].

Range:

{"idx encr\_str"}

Value:

idx: 0 ~ 7

encr\_str: NONE, WEP, TKIP, AES

e.g.

iwpriv ra0 wsc\_cred\_encr "0 TKIP"

---

#### 6.1.12 wsc\_cred\_keyIdx

Set Key Index into credtentail [idx].

Range:

{"idx key\_index"}

Value:

idx: 0 ~ 7

key\_index: 1 ~ 4

e.g.

iwpriv ra0 wsc\_cred\_keyIdx "0 1"

---

#### 6.1.13 wsc\_cred\_key

Set Key into credtentail [idx].

Range:

{"idx key"}

Value:

idx: 0 ~ 7

key: ASCII string (wep\_key\_len(=5,13), passphrase\_len(=8~63))

OR

Hex string (wep\_key\_len(=10,26), passphrase\_len(=64))

e.g.

iwpriv ra0 wsc\_cred\_key "0 12345678" ;; Passphrase

iwpriv ra0 wsc\_cred\_key "0 abcd" ;; WEP Key

#### 6.1.14 wsc\_cred\_mac

Set AP's MAC into credtentail[idx].

Range:

{"idx mac\_str"}

Value:

idx: 0 ~ 7

mac\_str: xx:xx:xx:xx:xx:xx

e.g.

iwpriv ra0 wsc\_cred\_mac "0 00:11:22:33:44:55"

#### 6.1.15 wsc\_conn\_by\_idx

Connect AP by credential index.

Range:

{0 ~ 7}

Value:

idx: 0 ~ 7

#### 6.1.16 wsc\_auto\_conn

Set driver to re-connecting to AP or not after registration.

Range:

{0, 1}

Value:

0: Disabled, driver won't re-connect to AP with new configurations.

1: Enabled, driver will re-connect to AP with new configurations.

## 6.2 WPS STA AS AN ENROLLEE OR REGISTRAR

#### 6.2.1.1 PIN mode:

A) Adding an Enrollee to AP+Registrar (EAP)  
[AP+Registrar]<----EAP---->[Enrollee Client]

B) Adding an Enrollee with external Registrar (UPnP/EAP)  
[External Registrar]<----UPnP---->[AP Proxy]<----EAP---->[Enrollee Client]

'EAP' indicates to use wireless medium and 'UPnP' indicates to use wired or wireless medium.

- How to get the Enrollee PinCode? Use 'iwpriv ra0 stat' on the Enrollee.

- (ii) [RT2860 Linux WPS STA]  
iwpriv ra0 wsc\_conf\_mode 1 ;; Enrollee  
iwpriv ra0 wsc\_mode 1 ;; PIN  
iwpriv ra0 wsc\_ssid "AP's SSID"  
iwpriv ra0 wsc\_start
- (iii) If the registration is successful, the Enrollee will be re-configured with the new parameters, and will connect to the AP with these new parameters.

## Running Scenarios (case 'a' only)

- a. Adding an Enrollee to AP+Registrar (EAP)  
[AP+Registrar]<----EAP---->[Client]
- (i) [AP+Registrar]  
Start PBC on the Registrar.
- (ii) [RT2860 Linux WPS STA]  
iwpriv ra0 wsc\_conf\_mode 1 ;; Enrollee  
iwpriv ra0 wsc\_mode 2 ;; PBC  
iwpriv ra0 wsc\_start
- (iii) If the registration is successful, the Enrollee will be re-configured with the new parameters, and will connect to the AP with these new parameters.

#### 6.2.2.1 PIN mode:

#### Running Scenarios (case 'a' and 'b')

- a. Configure the un-configured AP  
[Unconfigured AP]<----EAP---->[Registrar]
- b. Configure the configured AP  
Configured AP]<----EAP---->[Registrar]
- (i) [AP]  
Start PIN on the Enrollee WPS AP.
- (ii) [RT2860 Linux WPS STA]  
iwpriv ra0 wsc\_conf\_mode 2 ;; Registrar  
iwpriv ra0 wsc\_mode 1 ;; PIN  
iwpriv ra0 wsc\_pin xxxxxxxx ;; AP's PIN Code  
iwpriv ra0 wsc\_ssid "AP's SSID"  
iwpriv ra0 wsc\_start
- (iii) If the registration is successful;

in case 'a':

The Registrar will be re-configured with the new parameters, and will connect to the AP with these new parameters;

in case 'b':

The Registrar will be re-configured with AP's configurations, and will connect to the AP with these new parameters.

#### 6.2.2.2 PBC mode:

#### Running Scenarios (case 'a' and 'b')

- a. Configure the un-configured AP  
[Unconfigured AP]<----EAP---->[Registrar]
  - b. Configure the configured AP  
Configured AP]<----EAP---->[Registrar]
  - (i) [AP]  
Start PBC on the Enrollee WPS AP.
  - (ii) [RT2860 Linux WPS STA]  
iwpriv ra0 wsc\_conf\_mode 2 ;; Registrar  
iwpriv ra0 wsc\_mode 2 ;; PBC  
iwpriv ra0 wsc\_start
  - (iii) If the registration is successful;
- in case 'a':

The Registrar will be re-configured with the new parameters, and will connect to the AP with these new parameters;

in case 'b':

The Registrar will be re-configured with AP's configurations, and will connect to the AP with these new parameters.

## 6.3 WPS IOCTL USAGE

Detail parameters and arguments; please refer to above section for detail.

### 6.3.1 iwpriv commands without argument

1. iwpriv ra0 wsc\_start
2. iwpriv ra0 wsc\_stop
3. iwpriv ra0 wsc\_gen\_pincode

e.g.

```
memset(&lwreq, 0, sizeof(lwreq));
sprintf(lwreq.ifr_name, "ra0", 3);
lwreq.u.mode = WSC_STOP;

/* Perform the private ioctl */
if(ioctl(skfd, RTPRIV_IOCTL_SET_WSC_PROFILE_U32_ITEM , &lwreq) < 0)
{
    fprintf(stderr, "Interface doesn't accept private ioctl...\n");
    return -1;
}
```

### 6.3.2 iwpriv commands with one INT argument

1. iwpriv ra0 wsc\_cred\_count 1
2. iwpriv ra0 wsc\_conn\_by\_idx 1
3. iwpriv ra0 wsc\_auto\_conn 1
4. iwpriv ra0 wsc\_conf\_mode 1
5. iwpriv ra0 wsc\_mode 1
6. iwpriv ra0 wsc\_pin 12345678

e.g.

```
memset(&lwreq, 0, sizeof(lwreq));
lwreq.u.data.length = 1;
cred_count = 1;
((int *) buffer)[i] = (int) cred_count;
offset = sizeof(int);

sprintf(lwreq.ifr_name, "ra0", 3);
lwreq.u.mode = WSC_CREDENTIAL_COUNT;
memcpy(lwreq.u.name + offset, buffer, IFNAMSIZ - offset);

/* Perform the private ioctl */
if(ioctl(skfd, RTPRIV_IOCTL_SET_WSC_PROFILE_U32_ITEM , &lwreq) < 0)
{
    fprintf(stderr, "Interface doesn't accept private ioctl...\n");
    return -1;
}
```

### 6.3.3 iwpriv commands with string argument

1. iwpriv ra0 wsc\_ssid "0 xxxxx"
2. iwpriv ra0 wsc\_cred\_ssid "0 xxxxx"
3. iwpriv ra0 wsc\_cred\_auth "0 WPAESK"
4. iwpriv ra0 wsc\_cred\_encr "0 TKIP"
5. iwpriv ra0 wsc\_cred\_keyIdx "0 1"
6. iwpriv ra0 wsc\_cred\_key "0 12345"
7. iwpriv ra0 wsc\_cred\_mac "0 00:11:22:33:44:55"

e.g.

```
memset(&lwreq, 0, sizeof(lwreq));
memset(buffer, 0, 2048);
sprintf(lwreq.ifr_name, "ra0", 3);
sprintf(buffer, "0 wps_ssid_1");
lwreq.u.data.length = strlen(buffer) + 1;
lwreq.u.data.pointer = (caddr_t) buffer;
lwreq.u.data.flags = WSC_CREDENTIAL_SSID ;

/* Perform the private ioctl */
if(ioctl(skfd, RTPRIV_IOCTL_SET_WSC_PROFILE_STRING_ITEM , &lwreq) < 0)
{
    fprintf(stderr, "Interface doesn't accept private ioctl...\n");
    return -1;
}
```

## 6.4 WPS IOCTL SAMPLE PROGRAM

```
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
#include <assert.h>
#include <netinet/in.h> /* for sockaddr_in */
#include <fcntl.h>
#include <time.h>
#include <sys/times.h>
#include <unistd.h>
#include <sys/socket.h> /* for connect and socket*/
#include <sys/stat.h>
#include <err.h>
#include <errno.h>
#include <asm/types.h>
#include </usr/include/linux/wireless.h>
#include <sys/ioctl.h>

#define IFNAMSIZ 16

#define RTPRIV_IOCTL_SET_WSC_PROFILE_U32_ITEM (SIOCWFIRSTPRIV + 0x14)
#define RTPRIV_IOCTL_SET_WSC_PROFILE_STRING_ITEM (SIOCWFIRSTPRIV + 0x16)

enum {
    WSC_CREDENTIAL_COUNT = 1,
    WSC_CREDENTIAL_SSID = 2,
    WSC_CREDENTIAL_AUTH_MODE = 3,
    WSC_CREDENTIAL_ENCR_TYPE = 4,
    WSC_CREDENTIAL_KEY_INDEX = 5,
    WSC_CREDENTIAL_KEY = 6,
    WSC_CREDENTIAL_MAC = 7,
    WSC_SET_DRIVER_CONNECT_BY_CREDENTIAL_IDX = 8,
    WSC_SET_DRIVER_AUTO_CONNECT = 9,
    WSC_SET_CONF_MODE = 10, // Enrollee or Registrar
    WSC_SET_MODE = 11, // PIN or PBC
    WSC_SET_PIN = 12,
```

```

        WSC_SET_SSID = 13,
        WSC_START = 14,
        WSC_STOP = 15,
        WSC_GEN_PIN_CODE = 16,
};

int main()
{
    struct iwreq lwreq;
    char        buffer[2048] = {0};
    int         cred_count;
    int         offset = 0;          /* Space for sub-ioctl index */
    int         skfd, i = 0;         /* generic raw socket desc. */

    skfd = socket(AF_INET, SOCK_DGRAM, 0);
    if (skfd < 0)
        return -1;

    //////////// WSC_STOP ////////////
    memset(&lwreq, 0, sizeof(lwreq));
    sprintf(lwreq.ifr_name, "ra0", 3);
    lwreq.u.mode = WSC_STOP;

    /* Perform the private ioctl */
    if(ioctl(skfd, RTPRIV_IOCTL_SET_WSC_PROFILE_U32_ITEM, &lwreq) < 0)
    {
        fprintf(stderr, "Interface doesn't accept private ioctl...\n");
        return -1;
    }
    //////////////////////////////////////

    //////////// WSC_CREDENTIAL_COUNT ////////////
    memset(&lwreq, 0, sizeof(lwreq));
    lwreq.u.data.length = 1;
    cred_count = 1;
    ((int *) buffer)[i] = (int) cred_count;
    offset = sizeof(int);

    sprintf(lwreq.ifr_name, "ra0", 3);
    lwreq.u.mode = WSC_CREDENTIAL_COUNT;
    memcpy(lwreq.u.name + offset, buffer, IFNAMSIZ - offset);

    /* Perform the private ioctl */
    if(ioctl(skfd, RTPRIV_IOCTL_SET_WSC_PROFILE_U32_ITEM, &lwreq) < 0)
    {
        fprintf(stderr, "Interface doesn't accept private ioctl...\n");
        return -1;
    }
    //////////////////////////////////////

    //////////// WSC_CREDENTIAL_SSID ////////////
    memset(&lwreq, 0, sizeof(lwreq));
    memset(buffer, 0, 2048);
    sprintf(lwreq.ifr_name, "ra0", 3);
    sprintf(buffer, "0 wps_ssid_1");
    lwreq.u.data.length = strlen(buffer) + 1;
    lwreq.u.data.pointer = (caddr_t) buffer;
    lwreq.u.data.flags = WSC_CREDENTIAL_SSID;

    /* Perform the private ioctl */
    if(ioctl(skfd, RTPRIV_IOCTL_SET_WSC_PROFILE_STRING_ITEM, &lwreq) < 0)
    {
        fprintf(stderr, "Interface doesn't accept private ioctl...\n");
        return -1;
    }
    //////////////////////////////////////

```



```
close(skfd);  
return 0;  
}
```

## 7 ATE TEST COMMAND FORMAT

### IMPORTANT

IF YOU ARE NOT FAMILIAR WITH HARDWARE, IT IS RECOMMENDED NOT TO MODIFY HARDWARE DEFAULT VALUE.

## 7.1 IWPRIV RAO SET [PARAMETERS]=[VAL]

|                                       |             |                                     |                  |
|---------------------------------------|-------------|-------------------------------------|------------------|
| <b>Syntax:</b><br>Section# parameters |             | <b>Example</b><br>11.1.5 ATECHANNEL |                  |
|                                       | Explanation |                                     | Set ATE channel. |
| Value:                                |             | Value:                              |                  |
| 0:                                    | ...         | 1:                                  |                  |
| 1:                                    | ...         | 2:                                  |                  |
| :                                     | ...         | :                                   |                  |

### 7.1.1 ATE

Set ATE actions.

Value:

- ATESTART - Stop AP & ATE function.
- ATESTOP - Start AP function.
- TXCONT - Start AP continuous TX, for power mask.
- TXCARR - Start AP carrier test, for frequency calibration.
- TXFRAME - Transmit frame, for EVM.
- RXFRAME - Continuous RX, for PER/FER.

### 7.1.2 ATEDA

Set ATE frame header addr1.

Value:

xx:xx:xx:xx:xx:xx ; hex

### 7.1.3 ATESA

Set ATE frame header addr2.

Value:

xx:xx:xx:xx:xx:xx ; hex

### 7.1.4 ATEBSSID

Set ATE frame header addr3.

Value:

xx:xx:xx:xx:xx:xx ; hex

### 7.1.5 ATECHANNEL

Set ATE Channel, deimal.

Value:

802.11b/g: 1 ~ 14 depends on CountryRegion setting

#### 7.1.6 ATETXPOW0

Set ATE Tx power for Antenna 1.

Value:

0 ~ 31 ; 5-bits only, decimal

#### 7.1.7 ATETXPOW1

Set ATE Tx power for Antenna 2.

Value:

0 ~ 31 ; 5-bits only, decimal

#### 7.1.8 ATETXFREQOFFSET

Set ATE RF frequency offset.

Value:

0 ~ 63 ; unit: 2KHz, decimal

#### 7.1.9 ATETXLEN

Set ATE frame length.

Value:

24 ~ 1500 ; decimal

#### 7.1.10 ATETXCNT

Set ATE frame Tx count.

Value:

1 ~ ; 32-bit, decimal

#### 7.1.11 ATETXMODE (Refer to TxMode)

Set ATE Tx Mode.

Value:

0: CCK 802.11b

- |                |             |
|----------------|-------------|
| 1: OFDM        | 802.11g     |
| 2: HT_MIX      | 802.11b/g/n |
| 3: Green Field | 802.11n     |

---

#### 7.1.12 ATETXBW (Refer to TxMode)

Set ATE Tx Bandwidth.

Value:

- 0: 20MHz
- 1: 40MHz

---

#### 7.1.13 ATETXGI (Refer to TxMode)

Set ATE Tx Guard Interval.

Value:

- 0: Long
- 1: Short

---

#### 7.1.14 ATETXMCS (Refer to TxMode)

Set ATE Tx MCS type.

Value:

0 ~ 15

---

#### 7.1.15 ATETXANT

Set ATE TX antenna.

Value:

- 0: All
- 1: Antenna one
- 2: Antenna two

---

#### 7.1.16 ATERXANT

Set ATE RX antenna.

Value:

- 0: All
- 1: Antenna one
- 2: Antenna two
- 3: Antenna three

#### 7.1.17 ATERXFER

Set ATE to periodic show up RxCount (per-second) and RxTotalCount.

Value:

- 0: Disable counter show up
- 1: Enable counter show up

#### 7.1.18 ATESHOW

Show all parameters of ATE.

Value:

1

#### 7.1.19 ATEHELP

List all commands of ATE.

Value:

1

#### 7.1.20 ResetCounter

Reset statistic counter.

Value:

0

#### 7.1.21 ATERRF

Read all of the RF registers.

Value:

1

#### 7.1.22 ATEWRF1

Write the RF register 1.

Value:

xxxxxxx ;32-bit, hex

#### 7.1.23 ATEWRF2

Write the RF register 2.

Value:

xxxxxxx ;32-bit, hex

#### 7.1.24 ATEWRF3

Write the RF register 3.

Value:

xxxxxxx ;32-bit, hex

#### 7.1.25 ATEWRF4

Write the RF register 4.

Value:

xxxxxxx ;32-bit, hex

### 7.2 TX MODE, MCS, BW AND GI SELECTION TABLE

|  |  |
|--|--|
| MODE = 0, Legacy CCK   |  |
| MCS = 0  | Long Preamble CCK 1Mbps                  |
| MCS = 1  | Long Preamble CCK 2Mbps                  |
| MCS = 2  | Long Preamble CCK 5.5Mbps                |
| MCS = 3  | Long Preamble CCK 11Mbps                 |
| MCS = 8  | Short Preamble CCK 1Mbps, * illegal rate |
| MCS = 9  | Short Preamble CCK 2Mbps                 |
| MCS = 10   | Short Preamble 5.5Mbps                   |
| MCS = 11   | Short Preamble 11Mbps                    |
| Notes:<br>Other MCS codes are reserved in legacy CCK mode.<br>BW, SGI and STBC are reserved in legacy CCK mode.  |  |
| MODE = 1, Legacy OFDM  |  |
| MCS = 0  | 6Mbps                                    |
| MCS = 1  | 9Mbps                                    |
| MCS = 2  | 12Mbps                                   |
| MCS = 3  | 18Mbps                                   |
| MCS = 4  | 24Mbps                                   |
| MCS = 5  | 36Mbps                                   |
| MCS = 6  | 48Mbps                                   |
| MCS = 7  | 54Mbps                                   |
| Notes:<br>Other MCS code in legacy CCK mode is reserved.<br>When BW = 1, duplicate legacy OFDM is sent.<br>SGI, STBC are reserved in legacy OFDM mode. |  |
| MODE = 2, HT Mixed Mode  |  |
| MODE = 3, HT Greenfield  |  |
| MCS = 0 (1S)   | (BW=0, SGI=0) 6.5Mbps                    |

|   |                                  |
|---|----------------------------------|
| MCS = 1   | (BW=0, SGI=0) 13Mbps             |
| MCS = 2   | (BW=0, SGI=0) 19.5Mbps           |
| MCS = 3   | (BW=0, SGI=0) 26Mbps             |
| MCS = 4   | (BW=0, SGI=0) 39Mbps             |
| MCS = 5   | (BW=0, SGI=0) 52Mbps             |
| MCS = 6   | (BW=0, SGI=0) 58.5Mbps           |
| MCS = 7   | (BW=0, SGI=0) 65Mbps             |
| MCS = 8 (2S)  | (BW=0, SGI=0) 13Mbps             |
| MCS = 9   | (BW=0, SGI=0) 26Mbps             |
| MCS = 10  | (BW=0, SGI=0) 39Mbps             |
| MCS = 11  | (BW=0, SGI=0) 52Mbps             |
| MCS = 12  | (BW=0, SGI=0) 78Mbps             |
| MCS = 13  | (BW=0, SGI=0) 104Mbps            |
| MCS = 14  | (BW=0, SGI=0) 117Mbps            |
| MCS = 15  | (BW=0, SGI=0) 130Mbps            |
| MCS = 32  | (BW=1, SGI=0) HT duplicate 6Mbps |
| <p>Notes:</p> <p>When BW=1, PHY_RATE = PHY_RATE * 2</p> <p>When SGI=1, PHY_RATE = PHY_RATE * 10/9</p> <p>The effects of BW and SGI are accumulative.</p> <p>When MCS=0~7(1S, One Tx Stream), STBC option is supported. SGI option is supported. BW option is supported.</p> <p>When MCS=8~15(2S, Two Tx Stream), STBC option is NOT supported. SGI option is supported. BW option is supported.</p> <p>When MCS=32, only SGI option is supported. BW and STBC option are not supported. (BW =1, STBC=0)</p> <p>Other MCS code in HT mode is reserved.</p> <p>When STBC is supported. Only STBC = 1 is allowed. STBC will extend the transmission range but will not increase transmission rate.</p> |                                  |

## 7.3 EXAMPLES

### 7.3.1 Check EVM & Power

```
iwpriv ra0 set ATE=ATESTART
iwpriv ra0 set ATEDA=00:11:22:33:44:55
iwpriv ra0 set ATESA=00:aa:bb:cc:dd:ee
iwpriv ra0 set ATEBSSID=00:11:22:33:44:55
iwpriv ra0 set ATECHANNEL=1           ; set Channel
iwpriv ra0 set ATETXMODE=1           ; set TX-Mode.
iwpriv ra0 set ATETXMCS=7            ; set MCS type.
iwpriv ra0 set ATETXBW=0             ; set Bandwidth
iwpriv ra0 set ATETXGI=0             ; set Long GI.
iwpriv ra0 set ATETXLEN=1024         ; set packet length.
iwpriv ra0 set ATETXPOW0=18
iwpriv ra0 set ATETXPOW1=18
iwpriv ra0 set ATETXCNT=100000
iwpriv ra0 set ATETXFRAME
...
iwpriv ra0 set ATETXPOW0=19
...
iwpriv ra0 set ATETXPOW0=20
...
iwpriv ra0 set ATE=ATESTART
```



### 7.3.2 Check Carrier

```
iwpriv ra0 set ATE=ATESTART
iwpriv ra0 set ATECHANNEL=1           ; set Channel
iwpriv ra0 set ATETXMODE=1           ; set TX-Mode.
iwpriv ra0 set ATETXMCS=7            ; set MCS type.
iwpriv ra0 set ATETXBW=0             ; set Bandwidth
iwpriv ra0 set ATETXCNT=200          ; Tx frame count(decmial)
iwpriv ra0 set ATE=TXFRAME           ; Start Tx Frame(inform BBP to change, modulation mode)
iwpriv ra0 set ATE=TXCARR            ; Start Tx carrier, Measure carrier with instrument
iwpriv ra0 set ATETXPOW0=05
iwpriv ra0 set ATETXPOW1=05
iwpriv ra0 set ATETXFREQOFFSET=19
iwpriv ra0 set ATE=ATESTART
```

### 7.3.3 Check specturm mask

```
iwpriv ra0 set ATE=ATESTART
iwpriv ra0 set ATECHANNEL=1           ; set Channel
iwpriv ra0 set ATETXMODE=1           ; set TX-Mode.
iwpriv ra0 set ATETXMCS=7            ; set MCS type.
iwpriv ra0 set ATETXBW=0             ; set Bandwidth
iwpriv ra0 set ATETXCNT=200          ; Tx frame count(decmial)
iwpriv ra0 set ATE=TXFRAME           ; Start Tx Frame(inform BBP to change, modulation mode)
iwpriv ra0 set ATE=TXCONT            ; Start continuous TX, Measure specturm mask with instrument
iwpriv ra0 set ATETXPOW0=5
iwpriv ra0 set ATETXPOW1=5
iwpriv ra0 set ATE=ATESTART
```

### 7.3.4 Frequency offset tuning

```
iwpriv ra0 set ATE=ATESTART
iwpriv ra0 set ATECHANNEL=1           ; set Channel
iwpriv ra0 set ATETXMODE=1           ; set TX-Mode.
iwpriv ra0 set ATETXMCS=7            ; set MCS type.
iwpriv ra0 set ATETXCNT=200          ; Tx frame count(decmial)
iwpriv ra0 set ATETXFREQOFFSET=0      ; Set frequency offset 0(decimal)
iwpriv ra0 set ATE=TXFRAME           ; Start Tx Frame
iwpriv ra0 set ATE=TXCARR            ; Start Tx carrier, Measure carrier frequency with instrument
iwpriv ra0 set ATETXFREQOFFSET=10    ; Dynamic turning frequency offset, 10(decimal)
iwpriv ra0 set ATETXFREQOFFSET=20    ; Dynamic turning frequency offset, 20(decimal)
iwpriv ra0 set ATE=ATESTART          ; Stop, Store the tuning result to EEPROM
```

### 7.3.5 Rx

```
iwpriv ra0 set ATE=ATESTART
iwpriv ra0 set ATECHANNEL=1           ; set Channel
iwpriv ra0 set ResetCounter=0         ; Reset statistic counter
iwpriv ra0 set ATETXMODE=1           ; set TX-Mode.
iwpriv ra0 set ATETXMCS=7            ; set MCS type.
iwpriv ra0 set ATETXBW=0             ; set Bandwidth
iwpriv ra0 set ATE=RXFRAME           ; Start Rx,
iwpriv ra0 set ATERXFER=1            ; show RxCnt and RSSI/per-antenna, Transmit test packets
iwpriv ra0 set ATE=ATESTART          ; Stop
iwpriv ra0 stat                     ; get statistics counter
```

```
iwpriv ra0 set ATERXFER=1
iwpriv ra0 set ATERXANT=1
```

```
iwpriv ra0 set ATE=ATESTART
iwpriv ra0 set ATERXANT=0
iwpriv ra0 set ATE=RXFRAME
```

---

### 7.3.6 Show all ate parameters

```
iwpriv ra0 set ATESHOW=1
```

```
Mode=4
TxPower0=0
TxPower1=0
TxAntennaSel=0
RxAntennaSel=0
BBPCurrentBW=0
GI=0
MCS=7
TxMode=1
Addr1=00:11:22:aa:bb:cc
Addr2=00:11:22:aa:bb:cc
Addr3=00:11:22:aa:bb:cc
Channel=1
TxLength=1024
TxCount=40000
TxRate=11
RFFreqOffset=0
```

---

### 7.3.7 Online help

```
iwpriv ra0 set ATEHELP=1
```

```
ATE=ATESTART, ATESTOP, TXCONT, TXCARR, TXFRAME, RXFRAME
ATEDA
ATESA
ATEBSSID
ATECHANNEL, range:0~14
ATETXPOW0, set power level of antenna 1.
ATETXPOW1, set power level of antenna 2.
ATETXANT, set TX antenna. 0:all, 1:antenna one, 2:antenna two.
ATERXANT, set RX antenna.0:all, 1:antenna one, 2:antenna tow, 3:antenna three.
ATETXFREQOFFSET, set frequency offset, range 0~63
ATETXBW, set BandWidth, 0:20MHz, 1:40MHz.
ATETXLEN, set Frame length, range 24~1500
ATETXCNT, set how many frame going to transmit.
ATETXRATE, set rate, reference to rate table.
ATETXMCS, set MCS, reference to rate table.
ATETXMODE, set Mode 0:CCK, 1:OFDM, 2:HT-Mix, 3:GreenField, reference to rate table.
ATETXGI, set GI interval, 0:Long, 1:Short
ATERXFER, 0:disable Rx Frame error rate. 1:enable Rx Frame error rate.
ATESHOW, display all parameters of ATE.
ATEHELP, online help.
```

### 7.3.8 Display Rx Packet Count and RSSI

```
iwpriv ra0 set ATE=RXFRAME      Start Rx
iwpriv ra0 set ATERXANT=0       Enable All Three Rx Antennas
iwpriv ra0 set ATERXFER=1       Enable Rx Frame Error Rate: RxCnt/RxTotal
```

MImePeriodicExec: Rx packet cnt = 2/4  
 MImePeriodicExec: Rx AvgRssi0=-88, AvgRssi1=-80, AvgRssi2=-91

MImePeriodicExec: Rx packet cnt = 2/6  
 MImePeriodicExec: Rx AvgRssi0=-86, AvgRssi1=-77, AvgRssi2=-89...  
 ...

```
iwpriv ra0 set ATE=RXFRAME      Start Rx
iwpriv ra0 set ATERXANT=1       Enable Three Rx Antenna-1
iwpriv ra0 set ATERXFER=1       Enable Rx Frame Error Rate: RxCnt/RxTotal
```

MImePeriodicExec: Rx packet cnt = 0/7  
 MImePeriodicExec: Rx AvgRssi=-87

MImePeriodicExec: Rx packet cnt = 7/14  
 MImePeriodicExec: Rx AvgRssi=-90  
 ...  
 ...

## 7.4 IWPRIV RA0 BBP [PARAMETERS]=[VALUE]

Read/Write BBP register by ID number.

### 7.4.1 BBPID

Read BBP register, BBPID only, no "=" symbol.  
 BBPID:  
 0 ~ xx ; decimal, 8-bit

### 7.4.2 BBPID=Value

Write BBP register.  
 BBPID:  
 0 ~ xx ; decimal, 8-bit  
  
 Value:  
  
 00 ~ FF ; hexadecimal, 8-bit

## 7.5 IWPRIV RA0 MAC [PARAMETERS]=[VAL]

Read/Write MAC register by offset.

### 7.5.1 MAC\_OFFSET

Read MAC register, MAC\_OFFSET only, no “=” symbol.

MAC\_OFFSET:

0000 ~ FFFF ; hexadecimal, 16-bit

### 7.5.2 MAC\_OFFSET=Value

Write MAC register.

MAC\_OFFSET:

0000 ~ FFFF ; hexadecimal, 16-bit

Value:

0000 ~FFFF ; hexadecimal, 32-bit

## 7.6 IWPRIV RA0 E2P [PARAMETERS]=[VAL]

Read/Write EEPROM content by address.

### 7.6.1 EEP\_ADDR

Read EEPROM content, EEP\_ADDR only, no “=” symbol.

EEP\_ADDR:

00 ~ FF ; hexadecimal, 16-bit alignment (0, 2, 4, 6, 8, A, C, ...)

### 7.6.2 EEP\_ADDR=Value

Write EEPROM content.

EEP\_ADDR:

00 ~ FF ; hexadecimal, 16-bit alignment (0, 2, 4, 6, 8, A, C, ...)

Value:

0000 ~FFFF ; hexadecimal, 16-bit

## 7.7 EXAMPLE

### 7.7.1 Hardware access

|                           |                                      |
|---------------------------|--------------------------------------|
| iwpriv ra0 bbp 0          | # read BBP register 0                |
| iwpriv ra0 bbp 0=12       | # write BBP register 0 as 0x12       |
| iwpriv ra0 mac 0          | # read MAC register 0                |
| iwpriv ra0 mac 0=1234abcd | # write MAC register 0 as 0x1234abcd |
| iwpriv ra0 e2p 0          | # read E2PROM 0                      |
| iwpriv ra0 e2p c=12ab     | # write E2PROM 0xc as 0x12ab         |

### 7.7.2 Statistic counter operation

|                               |                           |
|-------------------------------|---------------------------|
| iwpriv ra0 stat               | # read statistic counter  |
| iwpriv ra0 set ResetCounter=0 | # reset statistic counter |

### 7.7.3 Suggestion:

1. To turn on ATE functionality, you have to add compile flag "RALINK\_ATE" to Makefile
2. Before doing ATE testing, please stop AP function
3. If you want to test another ATE action, prefer to stop AP & ATE function
4. All ATE function settings will lose efficacy after reboot.
5. Before hardware register access, please reference hardware spec.

Note.

In ATE mode, the channel must set via "ATECHANNEL"

## 7.8 ATED

ated - user space ATE agent program for RT2860 linux driver, Ralink Tech. Corp.

RT2860 ATE daemon - ated, which comes with RT2860 linux driver.

Here will explain the relationship between the linux driver, Windows QA GUI and RT2860 ATE daemon.

In addition, this will teach you how to use this ATE daemon.

### 7.8.1 Introduction

The ated is an optional user space component for RT2860 linux driver.

When ated starts, AP enters ATE mode (i.e. ATESTART) immediately.

It behaves as a proxy between Windows QA GUI and RT2860 linux driver when ATE process proceeds.

And ated will be killed automatically when Windows QA GUI is closed.

You can kill it manually, too (for example, type '\$killall ated').

RT2860 linux driver will leave ATE mode either ated is killed or QA GUI is closed.

### 7.8.2 Environment setup

1. Connect the platform you want to test directly with a Windows host by ether network line.
2. In the Windows host, run WinPcap\_4\_0.exe for the QA GUI.

### 7.8.3 How to use ated for ATE purpose

1. First you should set both "HAS\_ATE=y" and "HAS\_2860\_QA=y" in the file `~/Module/os/linux/config.mk` and compile the driver.
2. Modify the Makefile according to our target "PLATFORM".
3. Change the path of "CROSS\_COMPILE" if needed.
4. Remove "-I\$(INCLUDE)" about in line 39 if your target "PLATFORM" is not "PC".
5. Then type 'make' command to compile the source code of the daemon.
6. After the driver interface "ra0" has started up, attach both of "ra0" and the ethernet interface to the bridge interface "br0".
7. Manually start ated, type '\$ated -bbrX -iraX'. (For further usage of options, type \$ated -h)
8. In the Windows host, run RT2860QA\_ATE.exe.
9. Select the wired network adapter.
10. Choose 2860\_ATE, and then press OK.

Note:

The names of WLAN interface (default is "ra0") and Bridge interface(default is "br0") must be specified manually (for example : '\$ated -b br1 -ira2') if your WLAN interface or Bridge interface is not "ra0" or "br0" respectively !

## 8 IOCTL

### 8.1 PARAMETERS FOR IWCONFIG

| Access | Description                     | ID            | Parameters   |
|--------|---------------------------------|---------------|--|
| Get    | BSSID, MAC Address              | SIOCGIFHWADDR | wrq->u.name, (length = 6)  |
|        | WLAN Name                       | SIOCGIWNAME   | wrq->u.name = "RT2860 Wireless", length = strlen(wrq->u.name)  |
|        | SSID                            | SIOCGIWESSID  | erq = &wrq->u.essid;<br><br>if(OPSTATUS_TEST_FLAG(pAd,fOP_STATUS_MEDIA_STATE_CONNECTED))<br>{<br>erq->flags=1;<br>erq->length = pAd-> CommonCfg.SsidLen;<br>Status = copy_to_user(erq->pointer,<br>pAd-> CommonCfg.Ssid, erq->length);<br>}<br>else<br>{<br>erq->flags=0;<br>erq->length=0;<br>}   |
|        | Channel / Frequency (Hz)        | SIOCGIWFREQ   | wrq->u.freq.m = pAd-> CommonCfg.Channel;<br>wrq->u.freq.e = 0;<br>wrq->u.freq.i = 0;   |
|        | Node name/nickname              | SIOCGIWNICKN  | erq = &wrq->u.data;<br>erq->length = strlen(pAd->nickn);<br>Status = copy_to_user(erq->pointer, pAd->nickn, erq->length);  |
|        | Bit Rate (bps)                  | SIOCGIWRATE   | wrq->u.bitrate.value = RateIdTo500Kbps[pAd-> CommonCfg.TxRate] * 500000;<br>wrq->u.bitrate.disabled = 0;   |
|        | RTS/CTS threshold               | SIOCGIWRTS    | wrq->u.rts.value = (INT) pAd-> CommonCfg.RtsThreshold;<br>wrq->u.rts.disabled = (wrq->u.rts.value == MAX_RTS_THRESHOLD);<br>wrq->u.rts.fixed = 1;  |
|        | Fragmentation threshold (bytes) | SIOCGIWFRAG   | wrq->u.frag.value = (INT) pAd-> CommonCfg.FragmentThreshold;<br>wrq->u.frag.disabled = (wrq->u.frag.value >= MAX_FRAG_THRESHOLD);<br>wrq->u.frag.fixed = 1;  |
|        | Encoding token & mode           | SIOCGIWENCODE | index = (wrq->u.encoding.flags & IW_ENCODE_INDEX) - 1;<br>if ((index < 0)    (index >= NR_WEP_KEYS))<br>index = pAd-> CommonCfg.DefaultKeyId; // Default key for tx (shared key)<br>if (pAd-> CommonCfg.AuthMode == Ndis802_11AuthModeOpen)<br>wrq->u.encoding.flags = IW_ENCODE_OPEN;<br>else if (pAd-> CommonCfg.AuthMode == Ndis802_11AuthModeShared)<br>wrq->u.encoding.flags = IW_ENCODE_RESTRICTED;<br>if (pAd-> CommonCfg.WepStatus == Ndis802_11WEPDisabled)<br>wrq->u.encoding.flags  = IW_ENCODE_DISABLED;<br>else<br>{<br>if(wrq->u.encoding.pointer)<br>{<br>wrq->u.encoding.length = pAd->SharedKey[index].KeyLen;<br>Status = copy_to_user(wrq->u.encoding.pointer,<br>pAd->SharedKey[index].Key,<br>pAd->SharedKey[index].KeyLen);<br>wrq->u.encoding.flags  = (index + 1);<br>}<br>} |

# Ralink RT2860 Linux Station Release Notes & User's Guide

|        | AP's MAC address         | SIOCGIWAP    | <pre>wrq-&gt;u.ap_addr.sa_family = ARPHRD_ETHER; memcpy(wrq-&gt;u.ap_addr.sa_data, &amp;pAd-&gt;CommonCfg.Bssid, ETH_ALEN);</pre>   |
|--------|--------------------------|--------------|---|
|        | Operation Mode           | SIOCGIWMODE  | <pre>if (ADHOC_ON(pAd)) {     BssType = Ndis802_11IBSS;     wrq-&gt;u.mode = IW_MODE_ADHOC; } else if (INFRA_ON(pAd)) {     BssType = Ndis802_11Infrastructure;     wrq-&gt;u.mode = IW_MODE_INFRA; } else {     BssType = Ndis802_11AutoUnknown;     wrq-&gt;u.mode = IW_MODE_AUTO; }</pre>  |
|        |                          |              |   |
| Access | Description              | ID           | Parameters  |
| Set    | SSID                     | SIOCSIWESSID | <pre>erq = &amp;wrq-&gt;u.essid; memset(&amp;Ssid, 0x00, sizeof(NDIS_802_11_SSID)); if (erq-&gt;flags) {     if (erq-&gt;length &gt; IW_ESSID_MAX_SIZE)     {         Status = -E2BIG;         break;     } } Status = copy_from_user(Ssid.Ssid, erq-&gt;pointer, (erq-&gt;length - 1)); Ssid.SsidLength = erq-&gt;length - 1; //minus null character. } else {     Ssid.SsidLength = 0; // ANY ssid     memcpy(pSsid-&gt;Ssid, "", 0);     pAd-&gt;CommonCfg.BssType = BSS_INFRA;     pAd-&gt;CommonCfg.AuthMode = Ndis802_11AuthModeOpen;     pAd-&gt;CommonCfg.WepStatus = Ndis802_11EncryptionDisabled; } pSsid = &amp;Ssid; if (pAd-&gt;Mlme.CntlMachine.CurrState != CNTL_IDLE) {     MlmeRestartStateMachine(pAd); } pAd-&gt;MlmeAux.CurrReqIsFromNdis = FALSE; MlmeEnqueue(pAd,     MLME_CNTL_STATE_MACHINE,     OID_802_11_SSID,     sizeof(NDIS_802_11_SSID),     (VOID *)pSsid); Status = NDIS_STATUS_SUCCESS; StateMachineTouched = TRUE;</pre> |
|        | Channel / Frequency (Hz) | SIOCSIWFREQ  | <pre>frq = &amp;wrq-&gt;u.freq; if((frq-&gt;e == 0) &amp;&amp; (frq-&gt;m &lt;= 1000))     chan = frq-&gt;m; // Setting by channel number else     MAP_KHZ_TO_CHANNEL_ID( (frq-&gt;m /100) , chan); pAd-&gt;CommonCfg.Channel = chan;</pre>   |
|        | node name/nickname       | SIOCSIWNICKN | <pre>erq = &amp;wrq-&gt;u.data; if (erq-&gt;flags) {     if (erq-&gt;length &lt;= IW_ESSID_MAX_SIZE)         Status = copy_from_user(pAd-&gt;nickn, erq-&gt;pointer, erq-&gt;length);     else         Status = -E2BIG;</pre>   |



# Ralink RT2860 Linux Station Release Notes & User's Guide

|                                    |              |   |   |
|------------------------------------|--------------|---|---|
|                                    |              |   | } |
| Bit Rate<br>(bps)                  | SIOCSIWRATE  | RTMPSetDesiredRates(pAd, wrq->u.bitrate.value);   |   |
| RTS/CTS threshold                  | SIOCSIWRTS   | RtsThresh = wrq->u.rts.value;<br>if (wrq->u.rts.disabled)<br>RtsThresh = MAX_RTS_THRESHOLD;<br>if((RtsThresh > 0) && (RtsThresh <= MAX_RTS_THRESHOLD))<br>pAd->CommonCfg.RtsThreshold = (USHORT)RtsThresh;<br>else if (RtsThresh == 0)<br>pAd->CommonCfg.RtsThreshold = MAX_RTS_THRESHOLD;  |   |
| Fragmentation threshold<br>(bytes) | SIOCSIWFRAG  | FragThresh = wrq->u.frag.value;<br>if (wrq->u.rts.disabled)<br>FragThresh = MAX_FRAG_THRESHOLD;<br>if ( (FragThresh >= MIN_FRAG_THRESHOLD) &&<br>(FragThresh <= MAX_FRAG_THRESHOLD))<br>pAd->CommonCfg.FragmentThreshold = (USHORT)FragThresh;<br>else if (FragThresh == 0)<br>pAd->CommonCfg.FragmentThreshold = MAX_FRAG_THRESHOLD;<br>if (pAd->CommonCfg.FragmentThreshold == MAX_FRAG_THRESHOLD)<br>pAd->CommonCfg.bFragmentZeroDisable = TRUE;<br>else<br>pAd->CommonCfg.bFragmentZeroDisable = FALSE;   |   |
| Encoding<br>token & mode           | SIOCSIWENCOD | index = (wrq->u.encoding.flags & IW_ENCODE_INDEX) - 1;<br>if((index < 0)    (index >= NR_WEP_KEYS))<br>index = pAd->CommonCfg.DefaultKeyId; // Default key for tx (shared key)<br><br>if(wrq->u.encoding.pointer)<br>{<br>len = wrq->u.encoding.length;<br>if(len > WEP_LARGE_KEY_LEN)<br>len = WEP_LARGE_KEY_LEN;<br><br>memset(pAd->SharedKey[index].Key, 0x00, MAX_LEN_OF_KEY);<br>Status = copy_from_user(pAd->SharedKey[index].Key,<br>wrq->u.encoding.pointer, len);<br>pAd->SharedKey[index].KeyLen = len <= WEP_SMALL_KEY_LEN ?<br>WEP_SMALL_KEY_LEN : WEP_LARGE_KEY_LEN;<br>}<br>pAd->CommonCfg.DefaultKeyId = (UCHAR) index;<br>if (wrq->u.encoding.flags & IW_ENCODE_DISABLED)<br>pAd->CommonCfg.WepStatus = Ndis802_11WEPDisabled;<br>else<br>pAd->CommonCfg.WepStatus = Ndis802_11WEPEnabled;<br><br>if (wrq->u.encoding.flags & IW_ENCODE_RESTRICTED)<br>pAd->CommonCfg.AuthMode = Ndis802_11AuthModeShared;<br>else<br>pAd->CommonCfg.AuthMode = Ndis802_11AuthModeOpen;<br><br>if(pAd->CommonCfg.WepStatus == Ndis802_11WEPDisabled)<br>pAd->CommonCfg.AuthMode = Ndis802_11AuthModeOpen; |   |
| AP's MAC address                   | SIOCSIWAP    | Status = copy_from_user(&Bssid, &wrq->u.ap_addr.sa_data,<br>sizeof(NDIS_802_11_MAC_ADDRESS));<br>if (pAd->Mlme.CntlMachine.CurrState != CNTL_IDLE)<br>{<br>MlmeRestartStateMachine(pAd);<br>}<br>pAd->MlmeAux.CurrReqIsFromNdis = FALSE;<br>MlmeEnqueue(pAd,<br>MLME_CNTL_STATE_MACHINE,<br>OID_802_11_BSSID,<br>sizeof(NDIS_802_11_MAC_ADDRESS),<br>(VOID *)&Bssid);<br>Status = NDIS_STATUS_SUCCESS;<br>StateMachineTouched = TRUE;   |   |

|  |                |             |   |
|--|----------------|-------------|---|
|  | Operation Mode | SIOCSIWMODE | <pre> if(wrq-&gt;u.mode == IW_MODE_ADHOC) {     if (pAd-&gt;CommonCfg.BssType != BSS_ADHOC)     {         pAd-&gt;bConfigChanged = TRUE;     }     pAd-&gt;CommonCfg.BssType = BSS_ADHOC; } else if (wrq-&gt;u.mode == IW_MODE_INFRA) {     if (pAd-&gt;CommonCfg.BssType != BSS_INFRA)     {         pAd-&gt;bConfigChanged = TRUE;     }     pAd-&gt;CommonCfg.BssType = BSS_INFRA; } else {     Status = -EINVAL; } } pAd-&gt;CommonCfg.WpaState = SS_NOTUSE; </pre> |
|--|----------------|-------------|---|

## 8.2 PARAMETERS FOR IWPRIV

Please refer section 3 to have iwpriv parameters and values.

Parameters:

```

int    socket_id;
char    name[25];           // interface name
char    data[255];         // command string
struct  iwreq wrq;

```

Default setting:

```

wrq.ifr_name = name = "ra0";           // interface name
wrq.u.data.pointer = data;             // data buffer of command string
wrq.u.data.length = strlen(data);      // length of command string
wrq.u.data.flags = 0;

```

Data Structure:

Please refer to `./include/oid.h` for update and detail definition.

### 8.2.1 Set Data, Parameters is Same as iwpriv

| Command and IOCTL Function |                              |  |
|----------------------------|------------------------------|--|
| Set Data                   |                              |  |
| Function Type              | Command                      | IOCTL  |
| <b>RTPRIV_IOCTL_SET</b>    | iwpriv ra0 set SSID=RT2860AP | <pre> sprintf(name, "ra0"); strcpy(data, "SSID=RT2860AP"); strcpy(wrq.ifr_name, name); wrq.u.data.length = strlen(data); wrq.u.data.pointer = data; wrq.u.data.flags = 0; ioctl(socket_id, RTPRIV_IOCTL_SET, &amp;wrq); </pre> |

### 8.2.2 Get Data, Parameters is the same as iwpriv

| Command and IOCTL Function      |                            |   |
|---------------------------------|----------------------------|---|
| Get Data                        |                            |   |
| Function Type                   | Command                    | IOCTL   |
| <b>RTPRIV_IOCTL_STATISTICS</b>  | lwpriv ra0 stat            | sprintf(name, "ra0");<br>strcpy(data, "stat");<br>strcpy(wrq.ifr_name, name);<br>wrq.u.data.length = strlen(data);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = 0;<br>ioctl(socket_id, <b>RTPRIV_IOCTL_STATISTICS</b> , &wrq);             |
| <b>RTPRIV_IOCTL_GSITESURVEY</b> | lwpriv ra0 get_site_survey | sprintf(name, "ra0");<br>strcpy(data, "get_site_survey");<br>strcpy(wrq.ifr_name, name);<br>wrq.u.data.length = strlen(data);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = 0;<br>ioctl(socket_id, <b>RTPRIV_IOCTL_GSITESURVEY</b> , &wrq); |

### 8.2.3 Set Raw Data with Flags

| IOCTL Function                                   |   |
|--|---|
| Set Raw Data by I/O Control Interface with Flags |   |
| Function Type                                    | IOCTL   |
| <b>RT_OID_802_11_COUNTRY_REGION</b>              | sprintf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(UCHAR));<br>wrq.u.data.length = sizeof(UCHAR);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = <b>RT_OID_802_11_COUNTRY_REGION</b> ;<br>ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq);                         |
| <b>OID_802_11_BSSID_LIST_SCAN</b>                | sprintf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>wrq.u.data.length = 0;<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = <b>OID_802_11_BSSID_LIST_SCAN</b> ;<br>ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq);  |
| <b>OID_802_11_SSID</b>                           | sprintf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(NDIS_802_11_SSID));<br>wrq.u.data.length = sizeof(NDIS_802_11_SSID);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = <b>OID_802_11_SSID</b> ;<br>ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq);                |
| <b>OID_802_11_BSSID</b>                          | sprintf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(NDIS_802_11_MAC_ADDRESS));<br>wrq.u.data.length = sizeof(NDIS_802_11_MAC_ADDRESS);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = <b>OID_802_11_BSSID</b> ;<br>ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq); |
| <b>RT_OID_802_11_RADIO</b>                       | sprintf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(BOOLEAN));<br>wrq.u.data.length = sizeof(BOOLEAN);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = <b>RT_OID_802_11_RADIO</b> ;<br>ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq);                              |

# Ralink RT2860 Linux Station Release Notes & User's Guide

|                                |   |
|--------------------------------|---|
| RT_OID_802_11_PHY_MODE         | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RT_802_11_PHY_MODE)); wrq.u.data.length = sizeof(RT_802_11_PHY_MODE); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_PHY_MODE; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>  |
| RT_OID_802_11_STA_CONFIG       | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RT_802_11_STA_CONFIG)); wrq.u.data.length = sizeof(RT_802_11_STA_CONFIG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_STA_CONFIG; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>                                  |
| OID_802_11_DESIRED_RATES       | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_RATES)); wrq.u.data.length = sizeof(NDIS_802_11_RATES); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_DESIRED_RATES; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>  |
| RT_OID_802_11_PREAMBLE         | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RT_802_11_PREAMBLE)); wrq.u.data.length = sizeof(RT_802_11_PREAMBLE); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_PREAMBLE; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>  |
| OID_802_11_WEP_STATUS          | <pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_WEP_STATUS)); wrq.u.data.length = sizeof(NDIS_802_11_WEP_STATUS); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_WEP_STATUS; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>                                  |
| OID_802_11_AUTHENTICATION_MODE | <pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_AUTHENTICATION_MODE)); wrq.u.data.length = sizeof(NDIS_802_11_AUTHENTICATION_MODE); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_AUTHENTICATION_MODE; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>       |
| OID_802_11_INFRASTRUCTURE_MODE | <pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_NETWORK_INFRASTRUCTURE)); wrq.u.data.length = sizeof(NDIS_802_11_NETWORK_INFRASTRUCTURE); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_INFRASTRUCTURE_MODE; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre> |
| OID_802_11_REMOVE_WEP          | <pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_KEY_INDEX)); wrq.u.data.length = sizeof(NDIS_802_11_KEY_INDEX); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_REMOVE_WEP; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>                                    |
| RT_OID_802_11_RESET_COUNTERS   | <pre> printf(name, "ra0"); strcpy(wrq.ifr_name, name); wrq.u.data.length = 0; wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_RESET_COUNTERS; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>   |

# Ralink RT2860 Linux Station Release Notes & User's Guide

|                                    |  |
|------------------------------------|--|
| OID_802_11_RTS_THRESHOLD           | printf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(NDIS_802_11_RTS_THRESHOLD));<br>wrq.u.data.length = sizeof(NDIS_802_11_RTS_THRESHOLD);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = <b>OID_802_11_RTS_THRESHOLD</b> ;<br>ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq);                               |
| OID_802_11_FRAGMENTATION_THRESHOLD | printf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(NDIS_802_11_FRAGMENTATION_THRESHOLD));<br>wrq.u.data.length = sizeof(NDIS_802_11_FRAGMENTATION_THRESHOLD);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = <b>OID_802_11_FRAGMENTATION_THRESHOLD</b> ;<br>ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq); |
| OID_802_11_POWER_MODE              | printf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(NDIS_802_11_POWER_MODE));<br>wrq.u.data.length = sizeof(NDIS_802_11_POWER_MODE);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = <b>OID_802_11_POWER_MODE</b> ;<br>ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq);  |
| OID_802_11_TX_POWER_LEVEL          | printf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(NDIS_802_11_TX_POWER_LEVEL));<br>wrq.u.data.length = sizeof(NDIS_802_11_TX_POWER_LEVEL);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = <b>OID_802_11_TX_POWER_LEVEL</b> ;<br>ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq);                            |
| RT_OID_802_11_TX_POWER_LEVEL_1     | printf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(ULONG));<br>wrq.u.data.length = sizeof(ULONG);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = <b>RT_OID_802_11_TX_POWER_LEVEL_1</b> ;<br>ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq);   |
| OID_802_11_NETWORK_TYPE_IN_USE     | printf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(NDIS_802_11_NETWORK_TYPE));<br>wrq.u.data.length = / sizeof(NDIS_802_11_NETWORK_TYPE);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = <b>OID_802_11_NETWORK_TYPE_IN_USE</b> ;<br>ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq);                         |
| OID_802_11_RX_ANTENNA_SELECTED     | printf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(NDIS_802_11_ANTENNA));<br>wrq.u.data.length = sizeof(NDIS_802_11_ANTENNA);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = <b>OID_802_11_RX_ANTENNA_SELECTED</b> ;<br>ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq);                                     |
| OID_802_11_TX_ANTENNA_SELECTED     | printf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(NDIS_802_11_ANTENNA));<br>wrq.u.data.length = sizeof(NDIS_802_11_ANTENNA);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = <b>OID_802_11_TX_ANTENNA_SELECTED</b> ;<br>ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq);                                     |
| RT_OID_802_11_ADD_WPA              | printf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, 32);<br>wrq.u.data.length = 32;<br>wrq.u.data.pointer = data;   |

# Ralink RT2860 Linux Station Release Notes & User's Guide

|                                      |   |
|--------------------------------------|---|
|                                      | <pre>wrq.u.data.flags = RT_OID_802_11_ADD_WPA; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq);</pre>   |
| OID_802_11_REMOVE_KEY                | <pre>printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_REMOVE_KEY)); wrq.u.data.length = sizeof(NDIS_802_11_REMOVE_KEY); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_REMOVE_KEY; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq);</pre>          |
| OID_802_11_ADD_KEY                   | <pre>printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, keylength); //5,10,13,26 wrq.u.data.length = keylength L; wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_ADD_KEY; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq);</pre>  |
| OID_802_11_SET_IEEE8021X             | <pre>printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(BOOLEAN)); wrq.u.data.length = sizeof(BOOLEAN); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_SET_IEEE8021X; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq);</pre>                                     |
| OID_802_11_SET_IEEE8021X_REQUIRE_KEY | <pre>printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(BOOLEAN)); wrq.u.data.length = sizeof(BOOLEAN); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_SET_IEEE8021X_REQUIRE_KEY; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq);</pre>                         |
| OID_802_11_ADD_WEP                   | <pre>printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, keylength); //5,10,13,26 wrq.u.data.length = keylength; wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_RADIO; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq);</pre>   |
| OID_802_11_CONFIGURATION             | <pre>printf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_CONFIGURATION)); wrq.u.data.length = sizeof(NDIS_802_11_CONFIGURATION); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_CONFIGURATION; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq);</pre> |
| OID_SET_COUNTERMEASURES              | <pre>printf(name, "ra0"); strcpy(wrq.ifr_name, name); wrq.u.data.length = 0; wrq.u.data.pointer = data; wrq.u.data.flags = OID_SET_COUNTERMEASURES; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq);</pre>  |
| OID_802_11_DISASSOCIATE              | <pre>printf(name, "ra0"); strcpy(wrq.ifr_name, name); wrq.u.data.length = 0; wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_DISASSOCIATE; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq);</pre>  |
| OID_802_11_PMKID                     | <pre>printf(name, "ra0"); strcpy(wrq.ifr_name, name); wrq.u.data.length = keylength; //follow your setting wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_PMKID; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq);</pre>   |

|  |  |
|--|--|
| RT_OID_WPA_SUPPLICANT_SUPPORT                        | printf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(BOOLEAN));<br>wrq.u.data.length = sizeof(BOOLEAN);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = RT_OID_WPA_SUPPLICANT_SUPPORT;<br>ioctl(socket_id, RT_PRIV_IOCTL, &wrq);  |
| RT_OID_WPA_SUPPLICANT_SUPPORT                        | printf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(ULONG));<br>wrq.u.data.length = sizeof(ULONG);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = RT_OID_WPA_SUPPLICANT_SUPPORT;<br>ioctl(socket_id, RT_PRIV_IOCTL, &wrq);  |
| RT_SET_DEL_MAC_ENTRY                                 | sprintf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0xdd, 6);<br>strcpy(wrq.ifr_name, name);<br>wrq.u.data.length = 6;<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = RT_SET_DEL_MAC_ENTRY;<br>ioctl(socket_id, RT_PRIV_IOCTL, &wrq);  |
| RT_OID_802_11_SET_HT_PHYMODE  <br>OID_GET_SET_TOGGLE | typedef struct {<br>RT_802_11_PHY_MODE PhyMode;<br>UCHAR TransmitNo;<br>UCHAR HtMode; //HTMODE_GF or HTMODE_MM<br>UCHAR ExtOffset; //extension channel above or below<br>UCHAR MCS;<br>UCHAR BW;<br>UCHAR STBC;<br>UCHAR SHORTGI;<br>UCHAR rsv;<br>} OID_SET_HT_PHYMODE ;<br><br>RT_802_11_PHY_MODE tmp_ht_mode;<br>sprintf(wrq.ifr_name, "ra0");<br>wrq.u.data.pointer = (caddr_t) &tmp_ht_mode;<br>wrq.u.data.length = sizeof(RT_802_11_PHY_MODE);<br>wrq.u.data.flags = RT_OID_802_11_SET_HT_PHYMODE  <br>OID_GET_SET_TOGGLE;<br>ioctl(socket_id, RT_PRIV_IOCTL, &wrq); |

#### 8.2.4 Get Raw Data with Flags

| IOCTL Function                                   |   |
|--|---|
| Get Raw Data by I/O Control Interface with Flags |   |
| Function Type                                    | IOCTL   |
| RT_OID_DEVICE_NAME                               | sprintf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, 255);<br>wrq.u.data.length = 255;<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = RT_OID_DEVICE_NAME;<br>ioctl(socket_id, RT_PRIV_IOCTL, &wrq); |
| RT_OID_VERSION_INFO                              | sprintf(name, "ra0");<br>strcpy(wrq.ifr_name, name);<br>memset(data, 0, sizeof(RT_VERSION_INFO));<br>wrq.u.data.length = sizeof(RT_VERSION_INFO);<br>wrq.u.data.pointer = data;<br>wrq.u.data.flags = RT_OID_VERSION_INFO;  |

# Ralink RT2860 Linux Station Release Notes & User's Guide

|  |  |
|--|--|
|  | ioctl(socket_id, <b>RT_PRIV_IOCTL</b> , &wrq);   |
| <b>OID_802_11_BSSID_LIST</b>           | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, BssLen); wrq.u.data.length = BssLen; wrq.u.data.pointer = data; wrq.u.data.flags = <b>OID_802_11_BSSID_LIST</b>; ioctl(socket_id, <b>RT_PRIV_IOCTL</b>, &amp;wrq); </pre>  |
| <b>OID_802_3_CURRENT_ADDRESS</b>       | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(CurrentAddress)); wrq.u.data.length = sizeof(CurrentAddress); wrq.u.data.pointer = data; wrq.u.data.flags = <b>OID_802_3_CURRENT_ADDRESS</b>; ioctl(socket_id, <b>RT_PRIV_IOCTL</b>, &amp;wrq); </pre>                      |
| <b>OID_GEN_MEDIA_CONNECT_STATUS</b>    | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_MEDIA_STATE)); wrq.u.data.length = sizeof(NDIS_MEDIA_STATE); wrq.u.data.pointer = data; wrq.u.data.flags = <b>OID_GEN_MEDIA_CONNECT_STATUS</b>; ioctl(socket_id, <b>RT_PRIV_IOCTL</b>, &amp;wrq); </pre>               |
| <b>OID_802_11_BSSID</b>                | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_MAC_ADDRESS)); wrq.u.data.length = sizeof(NDIS_802_11_MAC_ADDRESS); wrq.u.data.pointer = data; wrq.u.data.flags = <b>OID_802_11_BSSID</b>; ioctl(socket_id, <b>RT_PRIV_IOCTL</b>, &amp;wrq); </pre>             |
| <b>OID_802_11_SSID</b>                 | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_SSID)); wrq.u.data.length = sizeof(NDIS_802_11_SSID); wrq.u.data.pointer = data; wrq.u.data.flags = <b>OID_802_11_SSID</b>; ioctl(socket_id, <b>RT_PRIV_IOCTL</b>, &amp;wrq); </pre>                            |
| <b>RT_OID_802_11_QUERY_LINK_STATUS</b> | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RT_802_11_LINK_STATUS)); wrq.u.data.length = sizeof(RT_802_11_LINK_STATUS); wrq.u.data.pointer = data; wrq.u.data.flags = <b>RT_OID_802_11_QUERY_LINK_STATUS</b>; ioctl(socket_id, <b>RT_PRIV_IOCTL</b>, &amp;wrq); </pre>  |
| <b>OID_802_11_CONFIGURATION</b>        | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_CONFIGURATION)); wrq.u.data.length = sizeof(NDIS_802_11_CONFIGURATION); wrq.u.data.pointer = data; wrq.u.data.flags = <b>OID_802_11_CONFIGURATION</b>; ioctl(socket_id, <b>RT_PRIV_IOCTL</b>, &amp;wrq); </pre> |
| <b>OID_802_11_RSSI_TRIGGER</b>         | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ullInfo)); wrq.u.data.length = sizeof(ullInfo); wrq.u.data.pointer = data; wrq.u.data.flags = <b>OID_802_11_RSSI_TRIGGER</b>; ioctl(socket_id, <b>RT_PRIV_IOCTL</b>, &amp;wrq); </pre>                                      |
| <b>RT_OID_802_11_RSSI</b>              | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ullInfo)); wrq.u.data.length = sizeof(ullInfo); wrq.u.data.pointer = data; wrq.u.data.flags = <b>RT_OID_802_11_RSSI</b>; </pre>   |



# Ralink RT2860 Linux Station Release Notes & User's Guide

|                          |   |
|--------------------------|---|
|                          | ioctl(socket_id, RT_PRIV_IOCTL, &wrq);  |
| RT_OID_802_11_RSSI_1     | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(uInfo)); wrq.u.data.length = sizeof(uInfo); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_RSSI_1; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>  |
| RT_OID_802_11_RSSI_2     | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(uInfo)); wrq.u.data.length = sizeof(uInfo); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_RSSI_2; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>  |
| OID_802_11_STATISTICS    | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(NDIS_802_11_STATISTICS)); wrq.u.data.length = sizeof(NDIS_802_11_STATISTICS); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_STATISTICS; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>   |
| OID_GEN_RCV_OK           | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(uInfo)); wrq.u.data.length = sizeof(uInfo); wrq.u.data.pointer = data; wrq.u.data.flags = OID_GEN_RCV_OK; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>  |
| OID_GEN_RCV_NO_BUFFER    | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(uInfo)); wrq.u.data.length = sizeof(uInfo); wrq.u.data.pointer = data; wrq.u.data.flags = OID_GEN_RCV_NO_BUFFER; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>   |
| RT_OID_802_11_PHY_MODE   | <pre> typedef enum _RT_802_11_PHY_MODE { PHY_11BG_MIXED = 0, PHY_11B, PHY_11A, PHY_11ABG_MIXED, PHY_11G, PHY_11ABGN_MIXED,           // both band  5 PHY_11N,                    // 6 PHY_11GN_MIXED,             // 2.4G band  7 PHY_11AN_MIXED,             // 5G band   8 PHY_11BGN_MIXED,           // if check 802.11b.  9 PHY_11AGN_MIXED,           // if check 802.11b. 10 } RT_802_11_PHY_MODE  sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(uInfo)); wrq.u.data.length = sizeof(uInfo); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_PHY_MODE; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre> |
| RT_OID_802_11_STA_CONFIG | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RT_802_11_STA_CONFIG)); wrq.u.data.length = sizeof(RT_802_11_STA_CONFIG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_STA_CONFIG; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>  |

# Ralink RT2860 Linux Station Release Notes & User's Guide

|                                    |  |
|------------------------------------|--|
| OID_802_11_RTS_THRESHOLD           | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RtsThresh)); wrq.u.data.length = sizeof(RtsThresh); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_RTS_THRESHOLD; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>             |
| OID_802_11_FRAGMENTATION_THRESHOLD | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(FragThresh)); wrq.u.data.length = sizeof(FragThresh); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_FRAGMENTATION_THRESHOLD; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre> |
| OID_802_11_POWER_MODE              | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(PowerMode)); wrq.u.data.length = sizeof(PowerMode); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_POWER_MODE; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>                |
| RT_OID_802_11_RADIO                | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(RadioState)); wrq.u.data.length = sizeof(RadioState); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_RADIO; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>                |
| OID_802_11_INFRASTRUCTURE_MODE     | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(BssType)); wrq.u.data.length = sizeof(BssType); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_INFRASTRUCTURE_MODE; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>           |
| RT_OID_802_11_PREAMBLE             | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(PreamType)); wrq.u.data.length = sizeof(PreamType); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_PREAMBLE; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>               |
| OID_802_11_AUTHENTICATION_MODE     | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(AuthMode)); wrq.u.data.length = sizeof(AuthMode); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_AUTHENTICATION_MODE; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>         |
| OID_802_11_WEP_STATUS              | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(WepStatus)); wrq.u.data.length = sizeof(WepStatus); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_WEP_STATUS; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>                |
| OID_802_11_TX_POWER_LEVEL          | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_TX_POWER_LEVEL; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>                    |

# Ralink RT2860 Linux Station Release Notes & User's Guide

|                                      |  |
|--------------------------------------|--|
| OID_802_11_TX_POWER_LEVEL_1          | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_TX_POWER_LEVEL_1; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>          |
| OID_802_11_NETWORK_TYPES_SUPPORTED   | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, 16); wrq.u.data.length = 16; wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_NETWORK_TYPES_SUPPORTED; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>                         |
| OID_802_11_NETWORK_TYPE_IN_USE       | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = OID_802_11_NETWORK_TYPE_IN_USE; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>       |
| RT_OID_802_11_QUERY_EEPROM_VERSION   | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_QUERY_EEPROM_VERSION; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>   |
| RT_OID_802_11_QUERY_FIRMWARE_VERSION | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_QUERY_FIRMWARE_VERSION; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre> |
| RT_OID_802_11_QUERY_NOISE_LEVEL      | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(UCHAR)); wrq.u.data.length = sizeof(UCHAR); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_QUERY_NOISE_LEVEL; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>      |
| RT_OID_802_11_EXTRA_INFO             | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_EXTRA_INFO; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>             |
| RT_OID_802_11_QUERY_PIDVID           | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(ULONG)); wrq.u.data.length = sizeof(ULONG); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_802_11_QUERY_PIDVID; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>           |
| RT_OID_WE_VERSION_COMPILED           | <pre> sprintf(name, "ra0"); strcpy(wrq.ifr_name, name); memset(data, 0, sizeof(UINT)); wrq.u.data.length = sizeof(UINT); wrq.u.data.pointer = data; wrq.u.data.flags = RT_OID_WE_VERSION_COMPILED; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq); </pre>             |

| RT_OID_802_11_QUERY_LAST_TX_RATE | HTTRANSMIT_SETTING tmpHT;<br>sprintf(wrq.ifr_name, "ra0");<br>wrq.u.data.pointer = (caddr_t) & tmpHT;<br>wrq.u.data.flags = RT_OID_802_11_QUERY_LAST_TX_RATE;<br>ioctl(socket_id, RT_PRIV_IOCTL, &wrq); |
|----------------------------------|---|
| RT_OID_802_11_QUERY_LAST_RX_RATE | HTTRANSMIT_SETTING tmpHT;<br>sprintf(wrq.ifr_name, "ra0");<br>wrq.u.data.pointer = (caddr_t) & tmpHT;<br>wrq.u.data.flags = RT_OID_802_11_QUERY_LAST_RX_RATE;<br>ioctl(socket_id, RT_PRIV_IOCTL, &wrq); |
| SHOW_IPV4_MAT_INFO               | u_char buffer[IW_PRIV_SIZE_MASK];<br>sprintf(wrq.ifr_name, "ra0");<br>wrq.u.data.pointer = (caddr_t) buffer;<br>wrq.u.data.flags = SHOW_IPV4_MAT_INFO;<br>ioctl(socket_id, RTPRIV_IOCTL_SHOW, &wrq);    |
| SHOW_IPV6_MAT_INFO               | u_char buffer[IW_PRIV_SIZE_MASK];<br>sprintf(wrq.ifr_name, "ra0");<br>wrq.u.data.pointer = (caddr_t) buffer;<br>wrq.u.data.flags = SHOW_IPV6_MAT_INFO;<br>ioctl(socket_id, RTPRIV_IOCTL_SHOW, &wrq);    |
| SHOW_ETH_CLONE_MAC               | u_char buffer[IW_PRIV_SIZE_MASK];<br>sprintf(wrq.ifr_name, "ra0");<br>wrq.u.data.pointer = (caddr_t) buffer;<br>wrq.u.data.flags = SHOW_ETH_CLONE_MAC;<br>ioctl(socket_id, RTPRIV_IOCTL_SHOW, &wrq);    |
| SHOW_CONN_STATUS                 | u_char buffer[IW_PRIV_SIZE_MASK];<br>sprintf(wrq.ifr_name, "ra0");<br>wrq.u.data.pointer = (caddr_t) buffer;<br>wrq.u.data.flags = SHOW_CONN_STATUS;<br>ioctl(socket_id, RTPRIV_IOCTL_SHOW, &wrq);      |

## 8.2.5 Set Raw Data with Flags

| IOCTL Function                                       |   |
|--|---|
| Get Raw Data by I/O Control Interface with Flags     |   |
| Function Type  | IOCTL   |
| RT_OID_802_11_SET_HT_PHYMODE  <br>OID_GET_SET_TOGGLE | <pre>typedef struct {     RT_802_11_PHY_MODE PhyMode;     UCHAR    TransmitNo;     UCHAR    HtMode;    //HTMODE_GF or HTMODE_MM     UCHAR    ExtOffset; //extension channel above or below     UCHAR    MCS;     UCHAR    BW;     UCHAR    STBC;     UCHAR    SHORTGI;     UCHAR    rsv; } OID_SET_HT_PHYMODE ;  RT_802_11_PHY_MODE tmp_ht_mode; sprintf(wrq.ifr_name, "ra0"); wrq.u.data.pointer = (caddr_t) &amp; tmp_ht_mode; wrq.u.data.length = sizeof(RT_802_11_PHY_MODE); wrq.u.data.flags = RT_OID_802_11_SET_HT_PHYMODE   OID_GET_SET_TOGGLE; ioctl(socket_id, RT_PRIV_IOCTL, &amp;wrq);</pre> |

## 9 IOCTL HOW TO

### 9.1 GET DATA

#### 9.1.1 GET IPv4 and MAC apping table:

Linux console command: iwpriv ra0 ipv4\_matinfo

sample code =>

```
u_char buffer[IW_PRIV_SIZE_MASK];

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) buffer;

wrq.u.data.flags = SHOW_IPV4_MAT_INFO ;

ioctl(socket_id, RTPRIV_IOCTL_SHOW , &wrq);
```

#### 9.1.2 GET IPv6 and MAC mapping table:

Linux console command: iwpriv ra0 ipv6\_matinfo

sample code =>

```
u_char buffer[IW_PRIV_SIZE_MASK];

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) buffer;

wrq.u.data.flags = SHOW_IPV6_MAT_INFO ;

ioctl(socket_id, RTPRIV_IOCTL_SHOW , &wrq);
```

#### 9.1.3 GET station connection status:

Linux console command: iwpriv ra0 connStatus

sample code =>

```
u_char buffer[IW_PRIV_SIZE_MASK];

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) buffer;

wrq.u.data.flags = SHOW_CONN_STATUS ;

ioctl(socket_id, RTPRIV_IOCTL_SHOW , &wrq);
```

#### 9.1.4 GET station statistics information:

Linux console command: iwpriv ra0 stat

sample code =>

```
u_char buffer[IW_PRIV_SIZE_MASK];

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) buffer;

wrq.u.data.flags = 0;

ioctl(socket_id, RTPRIV_IOCTL_STATISTICS, &wrq);
```

---

#### 9.1.5 GET AP list table:

Linux console command: iwpriv ra0 get\_site\_survey

sample code =>

```
u_char buffer[4096];

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) buffer;

wrq.u.data.flags = 0;

ioctl(socket_id, RTPRIV_IOCTL_GSITESURVEY, &wrq);
```

---

#### 9.1.6 GET scan table:

sample code =>

```
u_char buffer[4096];

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) buffer;

wrq.u.data.length = 4096;

wrq.u.data.flags = OID_802_11_BSSID_LIST;

ioctl(socket_id, RT_PRIV_IOCTL, &wrq);

PNDIS_802_11_BSSID_LIST_EX pBssidList = (PNDIS_802_11_BSSID_LIST_EX) buffer;
```

---

#### 9.1.7 GET station's MAC:

sample code =>

```
u_char buffer[6];

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) buffer;
```

```
wrq.u.data.flags = OID_802_3_CURRENT_ADDRESS ;  
  
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

---

#### 9.1.8 GET station connection status:

Sample code =>

```
#define NdisMediaStateConnected      1  
  
#define NdisMediaStateDisconnected  0  
  
NDIS_MEDIA_STATE MediaState;  
  
sprintf(wrq.ifr_name, "ra0");  
  
wrq.u.data.pointer = (caddr_t) &MediaState;  
  
wrq.u.data.flags = OID_GEN_MEDIA_CONNECT_STATUS ;  
  
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

---

#### 9.1.9 GET AP's BSSID

Sample code =>

```
char BSSID[6];  
  
sprintf(wrq.ifr_name, "ra0");  
  
wrq.u.data.pointer = (caddr_t) BSSID;  
  
wrq.u.data.flags = OID_802_11_BSSID ;  
  
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

---

#### 9.1.10 GET SSID

Sample code =>

```
NDIS_802_11_SSID SSID;  
  
sprintf(wrq.ifr_name, "ra0");  
  
wrq.u.data.pointer = (caddr_t) &SSID;  
  
wrq.u.data.flags = OID_802_11_SSID ;  
  
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

---

#### 9.1.11 GET station's last TX related information:

Sample code =>

```
HTTRANSMIT_SETTING tmpHT;  
  
sprintf(wrq.ifr_name, "ra0");
```

```

wrq.u.data.pointer = (caddr_t) & tmpHT;

wrq.u.data.flags = RT_OID_802_11_QUERY_LAST_TX_RATE ;

ioctl(socket_id, RT_PRIV_IOCTL, &wrq);

```

---

#### 9.1.12 GET station's last RX related information:

Sample code =>

```

HTTRANSMIT_SETTING tmpHT;

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) & tmpHT;

wrq.u.data.flags = RT_OID_802_11_QUERY_LAST_RX_RATE ;

ioctl(socket_id, RT_PRIV_IOCTL, &wrq);

```

---

#### 9.1.13 GET station's wireless mode:

Sample code =>

```

typedef enum _RT_802_11_PHY_MODE {

    PHY_11BG_MIXED = 0,

    PHY_11B,

    PHY_11A,

    PHY_11ABG_MIXED,

    PHY_11G,

    PHY_11ABGN_MIXED,           // both band           5

    PHY_11N,                   //                    6

    PHY_11GN_MIXED,           // 2.4G band         7

    PHY_11AN_MIXED,           // 5G band            8

    PHY_11BGN_MIXED,          // if check 802.11b.  9

    PHY_11AGN_MIXED,          // if check 802.11b. 10

} RT_802_11_PHY_MODE

unsigned long tmp_mode;

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) & tmp_mode;

wrq.u.data.flags = RT_OID_802_11_PHY_MODE ;

```



```
ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

#### 9.1.14 GET Bss type:

Sample code =>

```
typedef enum _NDIS_802_11_NETWORK_INFRASTRUCTURE
{
    Ndis802_11IBSS,

    Ndis802_11Infrastructure,

    Ndis802_11AutoUnknown,

    Ndis802_11Monitor,

    Ndis802_11InfrastructureMax // Not a real value, defined as upper bound
} NDIS_802_11_NETWORK_INFRASTRUCTURE

NDIS_802_11_NETWORK_INFRASTRUCTURE BssType;

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) & BssType;

wrq.u.data.flags = OID_802_11_INFRASTRUCTURE_MODE ;

ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

#### 9.1.15 GET Authentication Mode:

Sample code =>

```
typedef enum _NDIS_802_11_AUTHENTICATION_MODE
{
    Ndis802_11AuthModeOpen,

    Ndis802_11AuthModeShared,

    Ndis802_11AuthModeAutoSwitch,

    Ndis802_11AuthModeWPA,

    Ndis802_11AuthModeWPAPSK,

    Ndis802_11AuthModeWPA_None,

    Ndis802_11AuthModeWPA2,

    Ndis802_11AuthModeWPA2PSK,

    Ndis802_11AuthModeWPA1WPA2,
```

```

Ndis802_11AuthModeWPA1PSKWPA2PSK,

Ndis802_11AuthModeMax      // Not a real mode, defined as upper bound
} NDIS_802_11_AUTHENTICATION_MODE

NDIS_802_11_AUTHENTICATION_MODE   AuthMode;

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) & AuthMode;

wrq.u.data.flags = OID_802_11_AUTHENTICATION_MODE ;

ioctl(socket_id, RT_PRIV_IOCTL, &wrq);

```

---

#### 9.1.16 GET Encryption Type:

Sample code =>

```

typedef enum _NDIS_802_11_WEP_STATUS
{
    Ndis802_11WEPEnabled,

    Ndis802_11Encryption1Enabled = Ndis802_11WEPEnabled,

    Ndis802_11WEPDisabled,

    Ndis802_11EncryptionDisabled = Ndis802_11WEPDisabled,

    Ndis802_11WEPKeyAbsent,

    Ndis802_11Encryption1KeyAbsent = Ndis802_11WEPKeyAbsent,

    Ndis802_11WEPNotSupported,

    Ndis802_11EncryptionNotSupported = Ndis802_11WEPNotSupported,

    Ndis802_11Encryption2Enabled,

    Ndis802_11Encryption2KeyAbsent,

    Ndis802_11Encryption3Enabled,

    Ndis802_11Encryption3KeyAbsent,

    Ndis802_11Encryption4Enabled,    // TKIP or AES mix

    Ndis802_11Encryption4KeyAbsent,
} NDIS_802_11_WEP_STATUS, *PNDIS_802_11_WEP_STATUS,

NDIS_802_11_WEP_STATUS   WepStatus;

sprintf(wrq.ifr_name, "ra0");

```

```
wrq.u.data.pointer = (caddr_t) & WepStatus;

wrq.u.data.flags = OID_802_11_WEP_STATUS;

ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

---

#### 9.1.17 GET RSSI 0 (unit: db)

Sample code =>

```
long rssi_0

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) & rssi_0;

wrq.u.data.flags = RT_OID_802_11_RSSI;

ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

---

#### 9.1.18 GET RSSI 1 (unit: db)

Sample code =>

```
long rssi_1

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) & rssi_1;

wrq.u.data.flags = RT_OID_802_11_RSSI_1;

ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

---

#### 9.1.19 GET RSSI 2 (unit: db)

Sample code =>

```
long rssi_2

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) & rssi_2;

wrq.u.data.flags = RT_OID_802_11_RSSI_2;

ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

---

#### 9.1.20 GET Driver wireless extension version

Sample code =>

```
Unsigned int wext_version;

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) & wext_version;
```

```
wrq.u.data.flags = RT_OID_WE_VERSION_COMPILED ;

ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```

## 9.2 HOW TO DISPLAY RATE, BW:

```
HTTRANSMIT_SETTING HTSetting;

Double Rate;

double b_mode[] = {1, 2, 5.5, 11};

float g_Rate[] = { 6,9,12,18,24,36,48,54};

switch(HTSetting.field.MODE)
{
    case 0:
        if (HTSetting.field.MCS >=0 && HTSetting.field.MCS<=3)
            Rate = b_mode[HTSetting.field.MCS];
        else if (HTSetting.field.MCS >=8 && HTSetting.field.MCS<=11)
            Rate = b_mode[HTSetting.field.MCS-8];
        else
            Rate = 0;
        break;
    case 1:
        if ((HTSetting.field.MCS >= 0) && (HTSetting.field.MCS < 8))
            Rate = g_Rate[HTSetting.field.MCS];
        else
            Rate = 0;
        break;
    case 2:
    case 3:
        if (0 == bGetHTTxRateByBW_GI_MCS(HTSetting.field.BW,
            HTSetting.field.ShortGI,
            HTSetting.field.MCS,
            &Rate))
            Rate = 0;
        break;
```

```

        default:

            Rate = 0;

            break;

    }

char bGetHTTxRateByBW_GI_MCS(int nBW, int nGI, int nMCS, double* dRate)

{

    double HTTxRate20_800[16]={6.5, 13.0, 19.5, 26.0, 39.0, 52.0, 58.5, 65.0, 13.0, 26.0, 39.0, 52.0, 78.0,
    104.0, 117.0, 130.0};

    double HTTxRate20_400[16]={7.2, 14.4, 21.7, 28.9, 43.3, 57.8, 65.0, 72.2, 14.444, 28.889, 43.333, 57.778,
    86.667, 115.556, 130.000, 144.444};

    double HTTxRate40_800[18]={13.5, 27.0, 40.5, 54.0, 81.0, 108.0, 121.5, 135.0, 27.0, 54.0, 81.0, 108.0,
    162.0, 216.0, 243.0, 270.0, 6.0, 39.0};

    double HTTxRate40_400[18]={15.0, 30.0, 45.0, 60.0, 90.0, 120.0, 135.0, 150.0, 30.0, 60.0, 90.0, 120.0,
    180.0, 240.0, 270.0, 300.0, 6.7, 43.3};

    // no TxRate for (BW = 20, GI = 400, MCS = 32) & (BW = 20, GI = 400, MCS = 32)

    if (((nBW == BW_20) && (nGI == GI_400) && (nMCS == 32)) ||

        ((nBW == BW_20) && (nGI == GI_800) && (nMCS == 32)))

        return 0; //false

    if( nBW == BW_20 && nGI == GI_800)

        *dRate = HTTxRate20_800[nMCS];

    else if( nBW == BW_20 && nGI == GI_400)

        *dRate = HTTxRate20_400[nMCS];

    else if( nBW == BW_40 && nGI == GI_800)

        *dRate = HTTxRate40_800[nMCS];

    else if( nBW == BW_40 && nGI == GI_400)

        *dRate = HTTxRate40_400[nMCS];

    else

        return 0; //false

    return 1; //true

}

```

### 9.3 SET DATA FOR N MODE

### 9.4 SET HT MODE:

Sample code =>

```
typedef struct {
    RT_802_11_PHY_MODE    PhyMode;

    UCHAR                  TransmitNo;

    UCHAR                  HtMode;           //HTMODE_GF or HTMODE_MM
    UCHAR                  ExtOffset;       //extension channel above or below
    UCHAR                  MCS;
    UCHAR                  BW;
    UCHAR                  STBC;
    UCHAR                  SHORTGI;
    UCHAR                  rsv;
} OID_SET_HT_PHYMODE ;

RT_802_11_PHY_MODE tmp_ht_mode;

sprintf(wrq.ifr_name, "ra0");

wrq.u.data.pointer = (caddr_t) & tmp_ht_mode;

wrq.u.data.length = sizeof(RT_802_11_PHY_MODE);

wrq.u.data.flags = RT_OID_802_11_SET_HT_PHYMODE | OID_GET_SET_TOGGLE ;

ioctl(socket_id, RT_PRIV_IOCTL, &wrq);
```