

---

# Kismet Hybrid Rocket Engine Static Fire 5

Static Fire Test Operations Procedures

Compiled on 2020-12-04

# Static Fire Test Operations Procedures

---

## Contents

---

This document contains two procedures:

- The *Fill System Check* procedure comprises steps for validating the integrity of the system plumbing and correct operation of the test data acquisition system, using carbon dioxide.
- The *Static Fire Test* comprises steps for operating the fill system and conducting a static fire test of the engine.

## Personnel Required

---

The test operations team consists of nine personnel:

- 1 ☐ The **Operations Director [OPS]** directs operations procedures and communicates with the other test personnel.
- 2 ☐ The **Primary Fill Operator [PRIMARY]** operates all manual valves for the fill system.
- 3 ☐ The **Secondary Fill Operator [SECONDARY]** is the backup for **PRIMARY**, and communicates with OPS. If **PRIMARY** becomes incapacitated, **SECONDARY** is responsible for removing them from danger.
- 4 ☐ The **DAQ Technician [DAQ]** monitors and operates the test data acquisition system.
- 5 ☐ the **Control System Operator [CONTROL]** operates the test control system, including actuation of remote valves and engine ignition.
- 6 ☐ **Perimeter Guard 1 [P1]**, **Perimeter Guard 2 [P2]**, **Perimeter Guard 3 [P3]**, and perivfull ensure that no unauthorized personnel enter the testing area during test operations.

## Sign-Off

---

*To be completed by all test personnel after reading and familiarization with procedures*

- |   |   |       |       |
|---|---|-------|-------|
| 1 | <input type="checkbox"/> <b>Operations Director [OPS]</b>           | _____ | _____ |
| 2 | <input type="checkbox"/> <b>Primary Fill Operator [PRIMARY]</b>     | _____ | _____ |
| 3 | <input type="checkbox"/> <b>Secondary Fill Operator [SECONDARY]</b> | _____ | _____ |
| 4 | <input type="checkbox"/> <b>DAQ Technician [DAQ]</b>                | _____ | _____ |
| 5 | <input type="checkbox"/> <b>Control System Operator [CONTROL]</b>   | _____ | _____ |
| 6 | <input type="checkbox"/> <b>Perimeter Guard 1 [P1]</b>              | _____ | _____ |
| 7 | <input type="checkbox"/> <b>Perimeter Guard 2 [P2]</b>              | _____ | _____ |
| 8 | <input type="checkbox"/> <b>Perimeter Guard 3 [P3]</b>              | _____ | _____ |
| 9 | <input type="checkbox"/> <b>Perimeter Guard 4 [P4]</b>              | _____ | _____ |

## Prior to Start

---

- 1    ☐ Ensure that the following procedures are complete:
- 2        ☐ Combustion Chamber Assembly procedure
- 3        ☐ Oxidizer Tank Assembly procedure
- 4        ☐ Plumbing Setup procedure
- 5        ☐ Oxidizer Tank Stand Setup procedure
- 6        ☐ Tank Heating Setup procedure
- 7        ☐ Test Stand Setup procedure
- 8        ☐ Data Acquisition Setup procedure
- 9        ☐ Test Control System Setup procedure
- 10       ☐ Perimeter Checks procedure
- 11   ☐ Ensure that all personnel as defined above are available and have completed the sign-off.
- 12   ☐ Ensure that the following personnel have walkie-talkies and communication is functional:
- 13        ☐ OPS
- 14        ☐ SECONDARY
- 15        ☐ DAQ
- 16        ☐ P1
- 17        ☐ P2
- 18        ☐ P3
- 19        ☐ P4
- 20   ☐ Ensure that all spectators and test personnel are wearing safety glasses and hearing protection.
- 21   ☐ Ensure that PRIMARY and SECONDARY are wearing face shields and have no exposed skin.
- 22   ☐ Ensure that PRIMARY is wearing thermal gloves.
- 23   ☐ Ensure that PRIMARY is in possession of the supply cylinder gasket.
- 24   ☐ Ensure that SECONDARY is in possession of a multimeter.
- 25   ☐ Ensure that OPS is in possession of the system control key.

## Fill System Check Procedure

---

- 1    ☐ SECONDARY: Confirm that the ignition wires are not connected to the engine.
- 2    ☐ CONTROL: Actuate the Tank Heating Valve in order to test the tank heating system.
- 3    ☐ DAQ: Confirm that the water temperature is increasing.
- 4    ☐ CONTROL: Close the Tank Heating Valve.
- 5    ☐ PRIMARY: Open the Tank Heating Drain Valve.
- 6    ☐ PRIMARY: Confirm that the following valves are initially closed:
- 7        ☐ Cylinder Valve (SC-1)
- 8        ☐ Remote Fill Valve (MV-1)
- 9        ☐ Parallel Fill Valve (BA-2)

- 10      ☐ Tank Vent Valve (MV-2)
- 11      ☐ Line Vent Valve (BA-3)
- 12      ☐ Injector Valve (IJ-1)
- 13      ☐ **PRIMARY**: Confirm that the following valves are initially open:
- 14          ☐ Series Fill Valve (BA-1)
- 15      ☐ **OPS**: Confirm that ops is in possession of the system control key.
- 16      ☐ **DAQ**: Confirm that all pressure transducers are reading atmospheric.
- 17      ☐ **DAQ**: Confirm that all load cells are reading the determined zero point.
- 18      ☐ **P1, P2, P3, P4**: Close the perimeter and do not allow any further personnel to enter the testing area.
- 19      ☐ **SECONDARY**: Confirm that no personnel are in the testing area other than **PRIMARY** and **SECONDARY**.
- 20      ☐ **PRIMARY**: Remove all covers from the plumbing:
- 21          ☐ Tank Vent Valve
- 22          ☐ Pressure Relief Valve
- 23          ☐ Line Vent Valve
- 24      ☐ **PRIMARY**: Remove the cap from the carbon dioxide supply cylinder.
- 25      ☐ **PRIMARY**: Connect the fill line to the supply cylinder with the gasket, hand tighten, and then tighten with a wrench. Do not force a connection.
- 26      ☐ **PRIMARY**: Slowly open the Cylinder Valve (SC-1) through  $\frac{3}{4}$  of a turn.
- If leaks are observed:
- 27          ☐ **PRIMARY**: Close the Cylinder Valve (SC-1).
- 28          ☐ **PRIMARY**: Slowly open the Line Vent Valve (BA-3).
- 29          ☐ **PRIMARY**: Slowly open the Parallel Fill Valve (BA-2).
- 30          ☐ **DAQ**: Confirm that the Fill Pressure Transducer is reading atmospheric pressure.
- 31          ☐ **OPS**: Abort test procedures and revisit the plumbing setup.
- 32      ☐ **PRIMARY**: Communicate the supply cylinder pressure as visible on the Pressure Gauge.
- 33      ☐ **DAQ**: Communicate the supply cylinder pressure as read by the Fill Pressure Transducer.
- 34      ☐ **DAQ**: Confirm that the two measurements are in agreement.
- 35      ☐ **OPS**: Give the system control key to **CONTROL**.
- 36      ☐ **CONTROL**: Engage the key switch and power on the control boxes.
- 37      ☐ **CONTROL**: Open the Tank Vent Valve (MV-2).
- 38      ☐ **CONTROL**: Open the Remote Fill Valve (MV-1).
- If leaks are observed:
- 39          ☐ **CONTROL**: Close the Remote Fill Valve (MV-1).
- 40          ☐ **PRIMARY**: Close the Cylinder Valve (SC-1).
- 41          ☐ **PRIMARY**: Slowly open the Line Vent Valve (BA-3).
- 42          ☐ **PRIMARY**: Slowly open the Parallel Fill Valve (BA-2).

- 43        ☐ **CONTROL**: Open the Remote Fill Valve (MV-1).
- 44        ☐ **DAQ**: Confirm that the Fill Pressure Transducer is reading atmospheric pressure.
- 45        ☐ **OPS**: Abort test procedures and revisit the plumbing setup.
- If the Remote Fill Valve fails to open:
  - 46        ☐ **PRIMARY**: Close the Cylinder Valve (SC-1).
  - 47        ☐ **PRIMARY**: Slowly open the Line Vent Valve (BA-3).
  - 48        ☐ **PRIMARY**: Slowly open the Parallel Fill Valve (BA-2).
  - 49        ☐ **DAQ**: Confirm that the Fill Pressure Transducer is reading atmospheric pressure.
  - 50        ☐ **OPS**: Abort test procedures and revisit the plumbing setup.
- 51        ☐ **DAQ**: Confirm that the oxidizer tank mass is increasing.
- 52        ☐ **DAQ**: Confirm that the oxidizer tank pressure is increasing.
- 53        ☐ **CONTROL**: Close the Remote Fill Valve (MV-1).
- 54        ☐ **PRIMARY**: Open the Line Vent Valve (BA-3).
- 55        ☐ **DAQ**: Confirm that the Oxidizer Tank Pressure Transducer is reading atmospheric pressure.
- 56        ☐ **PRIMARY**: Close the Cylinder Valve (SC-1).
- 57        ☐ **CONTROL**: Open the Remote Fill Valve (MV-1).
- 58        ☐ **DAQ**: Confirm that the Fill Pressure Transducer is reading atmospheric pressure.
- 59        ☐ **PRIMARY**: Disconnect the fill line from the supply cylinder.
- 60        ☐ **PRIMARY**: Replace the cap on the carbon dioxide supply cylinder.
- 61        ☐ **OPS**: Wait for at least 3 minutes before proceeding.
- 62        ☐ **P1, P2, P3, P4**: Open the perimeter.
- 63        ☐ **OPS**: Proceed with final setup for the Static Fire Test procedure.

## Prior to Static Fire Test

---

- 1 ☐ Confirm that the nozzle is filled with water and not leaking.
- 2 ☐ Confirm that there are no fire hazards within the testing area.
- 3 ☐ Confirm that the cameras are set up at the correct locations.

## Static Fire Test - Remote Control Procedure

---

- 1 ☐ **SECONDARY**: Confirm that the ignition wires are not connected to the engine.
- 2 ☐ **PRIMARY**: Confirm that the following valves are initially closed:
  - 3 ☐ Cylinder Valve (SC-1)
  - 4 ☐ Remote Fill Valve (MV-1)
  - 5 ☐ Parallel Fill Valve (BA-2)
  - 6 ☐ Tank Vent Valve (MV-2)
  - 7 ☐ Line Vent Valve (BA-3)
  - 8 ☐ Injector Valve (IJ-1)
- 9 ☐ **PRIMARY**: Confirm that the following valves are initially open:
  - 10 ☐ Series Fill Valve (BA-1)
- 11 ☐ **OPS**: Ensure that ops is in possession of the system control key.
- 12 ☐ **DAQ**: Confirm that all pressure transducers are reading atmospheric pressure.
- 13 ☐ **DAQ**: Confirm that all load cells are reading the determined zero point.
- 14 ☐ **DAQ**: Confirm that all thermistors are reading ambient temperature.
- 15 ☐ **PAUSE POINT**
- 16 ☐ **P1, P2, P3, P4**: Close the perimeter and do not allow any further personnel to enter the testing area.
- 17 ☐ **SECONDARY**: Confirm that there are no personnel present in the testing area other than **PRIMARY** and **SECONDARY**.
- 18 ☐ **PRIMARY**: Remove all covers from the plumbing:
  - 19 ☐ Tank Vent Valve
  - 20 ☐ Pressure Relief Valve
  - 21 ☐ Line Vent Valve
  - 22 ☐ Nozzle
- 23 ☐ **PRIMARY**: Turn on the air compressor by adjusting the regulator to maximum.
- 24 ☐ **PRIMARY**: Confirm that the pressure gauge on the air compressor is reading approximately 85 psi.
- 25 ☐ **PRIMARY**: Pressurize the Injector Valve.
- 26 ☐ **DAQ**: Confirm that the pressure switch for the Injector Valve is reading 0V.
- 27 ☐ **SECONDARY**: Confirm that the resistance across the ignition coils is between 2.5  $\Omega$  and 3  $\Omega$ :
  - 28 ☐ Primary ignition coil
  - 29 ☐ Secondary ignition coil

- 30 ☐ **SECONDARY**: Connect the ignition connectors to the RLCS ignition cable.
- 31 ☐ **PRIMARY**: Remove the cap from the nitrous oxide supply cylinder.
- 32 ☐ **PRIMARY**: Connect the fill line to the supply cylinder with the gasket, hand tighten, and then tighten with a wrench. Do not force the connection.
- 33 ☐ **PRIMARY**: Slowly open the supply cylinder through  $\frac{3}{4}$  of a turn.
- If leaks are observed:
    - 34 ☐ **PRIMARY**: Close the Cylinder Valve (SC-1).
    - 35 ☐ **PRIMARY**: Slowly open the Line Vent Valve (BA-3).
    - 36 ☐ **PRIMARY**: Slowly open the Parallel Fill Valve (BA-2).
    - 37 ☐ **DAQ**: Confirm that the Fill Pressure Transducer is reading atmospheric pressure.
    - 38 ☐ **SECONDARY**: Disconnect the ignition connectors from the RLCS ignition cable.
    - 39 ☐ **PRIMARY**: Turn off the air compressor and depressurize the Injector Valve.
    - 40 ☐ **OPS**: Abort test procedures and revisit the plumbing setup.
- 41 ☐ **PRIMARY**: Communicate the supply cylinder pressure as visible on the Pressure Gauge.
- 42 ☐ **DAQ**: Communicate the supply cylinder pressure as read by the Fill Pressure Transducer.
- 43 ☐ **DAQ**: Confirm that the two pressure measurements are in agreement.
- 44 ☐ **PRIMARY**: Turn on the camera.
- 45 ☐ **PRIMARY** and **SECONDARY**: Retreat to the mission control area.
- 46 ☐ **CONTROL**: Confirm that all actuator controls are in the "off" position:
- 47 ☐ Remote Fill Valve (MV-1)
  - 48 ☐ Tank Vent Valve (MV-2)
  - 49 ☐ Injector Valve (IJ-1)
  - 50 ☐ Primary Ignition
  - 51 ☐ Secondary Ignition
- 52 ☐ **PAUSE POINT**
- 53 ☐ **OPS**: Poll the following personnel for GO/NO GO status:
- 54 ☐ **P1**
  - 55 ☐ **P2**
  - 56 ☐ **P3**
  - 57 ☐ **P4**
  - 58 ☐ **DAQ**
  - 59 ☐ **CONTROL**
  - 60 ☐ **PRIMARY**
  - 61 ☐ **SECONDARY**
- 62 ☐ **OPS**: Give the system control key to **CONTROL**.
- 63 ☐ **CONTROL**: Engage the key switch and power on the control boxes.
- 64 ☐ **CONTROL**: Open the Tank Vent Valve (MV-2).
- 65 ☐ **CONTROL**: Open the Remote Fill Valve (MV-1).

- If leaks are observed:

- ☐ **CONTROL**: Close the Remote Fill Valve (MV-1).
- ☐ **PRIMARY**: Open the Line Vent Valve (BA-3) using the ropes.
- ☐ **OPS**: Proceed only when the oxidizer tank has fully vented.
- ☐ **PRIMARY**: and **SECONDARY**: Approach the test plumbing.
- ☐ **PRIMARY**: Close the Cylinder Valve (SC-1).
- ☐ **CONTROL**: Open the Remote Fill Valve (MV-1).
- ☐ **DAQ**: Confirm that the Fill Pressure Transducer is reading atmospheric pressure.
- ☐ **SECONDARY**: Disconnect the ignition connectors from the RLCS ignition cable.
- ☐ **PRIMARY**: Turn off the air compressor and depressurize the Injector Valve.
- ☐ **OPS**: Abort test procedures and revisit plumbing setup.

- If the Remote Fill Valve fails to open:

- ☐ **PRIMARY**: Close the Cylinder Valve (SC-1).
- ☐ **PRIMARY**: Slowly open the Line Vent Valve (BA-3).
- ☐ **PRIMARY**: Slowly open the Parallel Fill Valve (BA-2).
- ☐ **DAQ**: Confirm that the Fill Pressure Transducer is reading atmospheric pressure.
- ☐ **SECONDARY**: Disconnect the ignition connectors from the RLCS ignition cable.
- ☐ **PRIMARY**: Turn off the air compressor and depressurize the Injector Valve.
- ☐ **OPS**: Abort test procedures and revisit the control system setup.

- ☐ **OPS**: Proceed only when a white plume is visible from the Tank Vent Valve (MV-2).

- ☐ **CONTROL**: Close the Tank Vent Valve (MV-2).

- ☐ **CONTROL**: Close the Remote Fill Valve (MV-1).

- If the Remote Fill Valve fails to close:

- ☐ **PRIMARY** and **SECONDARY**: Approach the test plumbing.
- ☐ **PRIMARY**: Close the Series Fill Valve (BA-1).
- ☐ **PRIMARY** and **SECONDARY**: Retreat to the mission control area.

- ☐ **CONTROL**: Open the Tank Heating Valve.

- ☐ **DAQ**: Proceed only when the oxidizer tank pressure is at least 750 psi.

- If the oxidizer tank pressure does not reach 750 psi:

- ☐ **CONTROL**: Close the Tank Heating Valve.
- ☐ **PRIMARY**: Open the Line Vent Valve (BA-3) using the ropes.
- ☐ **OPS**: Proceed only when the system has fully vented.
- ☐ **PRIMARY** and **SECONDARY**: Approach the test plumbing.
- ☐ **PRIMARY**: Close the Cylinder Valve (SC-1).
- ☐ **CONTROL**: Open the Tank Vent Valve (MV-2).
- ☐ **CONTROL**: Open the Remote Fill Valve (MV-1).
- ☐ **DAQ**: Confirm that the Oxidizer Tank Pressure Transducer is reading atmospheric pressure.
- ☐ **SECONDARY**: Disconnect the ignition connectors from the RLCS ignition cable.
- ☐ **PRIMARY**: Turn off the air compressor and depressurize the Injector Valve.
- ☐ **OPS**: Abort test procedures and revisit the tank heating setup.

- ☐ **CONTROL**: Close the Tank Heating Valve.

- ☐ **PAUSE POINT**



- 104    ☐ **P2**: Move to the viewing location.
- 105    ☐ **CONTROL**: Perform the engine startup procedure:
- 106        ☐ Arm the Primary Ignition switch.
- 107        ☐ Hold down the Fire button until black smoke is observed. Continuously communicate the ignition current reading as displayed by the control box.
- In the event of a failed ignition (smoke not observed within 1 minute):

108            ☐ **CONTROL**: Disarm the Primary Ignition Switch.

109            ☐ **CONTROL**: Arm the Secondary Ignition Switch.

110            ☐ **OPS**: Revisit ignition setup.
  - In the event of a second failed ignition (smoke not observed within 1 minute):

111            ☐ **CONTROL**: Disarm the secondary ignition switch.

112            ☐ **PRIMARY**: Open the Line Vent Valve (BA-3) using the ropes.

113            ☐ **OPS**: Proceed only when the oxidizer tank is fully vented.

114            ☐ **PRIMARY** and **SECONDARY**: Approach the test plumbing.

115            ☐ **PRIMARY**: Close the Cylinder Valve (SC-1).

116            ☐ **CONTROL**: Open the Remote Fill Valve (MV-1).

117            ☐ **CONTROL**: Open the Tank Vent Valve (MV-2).

118            ☐ **DAQ**: Confirm that the Oxidizer Tank Pressure Transducer is reading atmospheric pressure.

119            ☐ **SECONDARY**: Disconnect the ignition connectors from the RLCS ignition cable.

120            ☐ **PRIMARY**: Turn off the air compressor and depressurize the Injector Valve.

121            ☐ **OPS**: Abort test procedures and proceed to teardown.
- 122        ☐ **CONTROL**: Start the engine by opening the Injector Valve.
- 123    ☐ **ALL**: Observe the plume.
- 124    ☐ **PAUSE POINT**
- 125    ☐ **P2**: Return to your assigned position.
- 126    ☐ **OPS**: Wait for at least 3 minutes before proceeding.
- 127    ☐ **DAQ**: Confirm that the Oxidizer Tank Pressure Transducer is reading atmospheric pressure.
- 128    ☐ **CONTROL**: Open the Tank Vent Valve (MV-2).
- 129    ☐ **PRIMARY** and **SECONDARY**: Approach the plumbing setup.
- 130    ☐ **PRIMARY**: Close the Cylinder Valve (SC-1).
- 131    ☐ **CONTROL**: Open the Remote Fill Valve (MV-1).
- 132    ☐ **DAQ**: Confirm that the Fill Pressure Transducer is reading atmospheric pressure.
- 133    ☐ **PRIMARY**: Disconnect the fill line from the supply cylinder.
- 134    ☐ **PRIMARY**: Replace the cap on the nitrous oxide cylinder.
- 135    ☐ **PRIMARY**: Turn off the air compressor and depressurize the Injector Valve.
- 136    ☐ **OPS**: Wait at least 3 minutes before proceeding.
- 137    ☐ **DAQ**: Confirm that the nozzle thermistors are reading below 100 °C, unless suspected faulty.
- 138    ☐ **P1, P2, P3, P4**: Open the perimeter.
- 139    ☐ **DAQ**: Continue to monitor the thermistor readings and inform **OPS** if the combustion chamber temperature exceeds 190 °C.
- 140    ☐ **OPS**: Proceed with teardown and disassembly.