

# Command List

---

WISOL

December 19, 2016

## List

---

SIGFOX command	.....	3
WIFI command		7

## Command

### MODEL and Firmware Ver.

MODEL	Firmware
SFM20R	EVBSFM20R_V200

## SIGFOX command

Command	Name	Description												
AT	Dummy Command	Just returns 'OK' and does nothing else. Can be used to check communication.												
AT\$SB=bit[,bit]	Send Bit	Send a bit status (0 or 1). Optional bit flag indicates if AX-SFEU should receive a downlink frame.												
AT\$SF=frame[,bit]	Send Frame	Send payload data, 1 to 12 bytes. Optional bit flag indicates if AX-SFEU should receive a downlink frame.												
AT\$SO	Manually send out of band message	Send the out-of-band message.												
AT\$TR?	Get the transmit repeat	Returns the number of transmit repeats. Default: 2												
AT\$TR=?	Get transmit range	Returns the allowed range of transmit repeats.												
AT\$TR=uint	Get transmit repeat	Sets the transmit repeat.												
AT\$uint?	Get Register	Query a specific configuration register's value. See chapter "Registers" for a list of registers.												
AT\$uint=uint	Set Register	Change a configuration register.												
AT\$uint=?	Get Register Range	Returns the allowed range of transmit repeats.												
AT\$IF=uint	Set TX Frequency	Set the output carrier macro channel for Sigfox frames.												
AT\$IF?	Get TX Frequency	Get the currently chosen TX frequency.												
AT\$DR=uint	Set RX Frequency	Set the reception carrier macro channel for Sigfox frames.												
AT\$DR?	Get RX Frequency	Get the currently chosen RX frequency.												
AT\$CW=uint,bit[,uint_opt]	Continuous Wave	<p>To run emission tests for Sigfox certification it is necessary to send a continuous wave, i.e. just the base frequency without any modulation. Parameters:</p> <table> <tr> <th>Name</th><th>Range</th><th>Description</th></tr> <tr> <td>Frequency</td><td>800000000–999999999, 0</td><td>Continuous wave frequency in Hz. Use 868130000 for Sigfox or 0 to keep previous frequency.</td></tr> <tr> <td>Mode</td><td>0, 1</td><td>Enable or disable carrier wave.</td></tr> <tr> <td>Power</td><td>0–14</td><td>dBm of signal   Default: 14</td></tr> </table>	Name	Range	Description	Frequency	800000000–999999999, 0	Continuous wave frequency in Hz. Use 868130000 for Sigfox or 0 to keep previous frequency.	Mode	0, 1	Enable or disable carrier wave.	Power	0–14	dBm of signal   Default: 14
Name	Range	Description												
Frequency	800000000–999999999, 0	Continuous wave frequency in Hz. Use 868130000 for Sigfox or 0 to keep previous frequency.												
Mode	0, 1	Enable or disable carrier wave.												
Power	0–14	dBm of signal   Default: 14												
AT\$CB=uint_opt,bit	Test Mode: TX constant byte	<p>For emission testing it is useful to send a specific bit pattern. The first parameter specifies the byte to send. Use '–1' for a (pseudo-)random pattern. Parameters:</p> <table> <tr> <th>Name</th><th>Range</th><th>Description</th></tr> <tr> <td>Pattern</td><td>0–255, –1</td><td>Byte to send. Use '–1' for a (pseudo-)random pattern.</td></tr> <tr> <td>Mode</td><td>0, 1</td><td>Enable or disable pattern test mode.</td></tr> </table>	Name	Range	Description	Pattern	0–255, –1	Byte to send. Use '–1' for a (pseudo-)random pattern.	Mode	0, 1	Enable or disable pattern test mode.			
Name	Range	Description												
Pattern	0–255, –1	Byte to send. Use '–1' for a (pseudo-)random pattern.												
Mode	0, 1	Enable or disable pattern test mode.												
AT\$T?	Get Temperature	Measure internal temperature and return it in $1/10^{\text{th}}$ of a degree Celsius.												
AT\$V?	Get Voltages	Return current voltage and voltage measured during the last transmission in mV.												

Command	Name	Description
AT\$I=uint	Information	<p>Display various product information:</p> <ul style="list-style-type: none"> <li>0: Software Name &amp; Version Example Response: AX-SFEU 1.0.6-ETSI</li> <li>1: Contact Details Example Response: support@axsem.com</li> <li>2: Silicon revision lower byte Example Response: 8F</li> <li>3: Silicon revision upper byte Example Response: 00</li> <li>4: Major Firmware Version Example Response: 1</li> <li>5: Minor Firmware Version Example Response: 0</li> <li>7: Firmware Variant (Frequency Band etc. (EU/US)) Example Response: ETSI</li> <li>8: Firmware VCS Version Example Response: v1.0.2-36</li> <li>9: SIGFOX Library Version Example Response: DL0-1.4</li> <li>10: Device ID Example Response: 00012345</li> <li>11: PAC Example Response: 0123456789ABCDEF</li> </ul>
AT\$P=uint	Set Power Mode	<p>To conserve power, the AX-SFEU can be put to sleep manually. Depending on power mode, you will be responsible for waking up the AX-SFEU again!</p> <ul style="list-style-type: none"> <li>0: software reset (settings will be reset to values in flash)</li> <li>1: sleep (send a break to wake up)</li> <li>2: deep sleep (toggle GPIO9 or RESET_N pin to wake up; the AX-SFEU is not running and all settings will be reset!)</li> </ul>
AT\$WR	Save Config	<p>Write all settings to flash (RX/TX frequencies, registers) so they survive reset/deep sleep or loss of power. Use AT\$P=0 to reset the AX-SFEU and load settings from flash.</p>
AT\$TM=mode,config	Activates the Sigfox Testmode	<p>Available test modes:</p> <ul style="list-style-type: none"> <li>0. TX BPSK Send only BPSK with Synchro Bit + Synchro frame + PN sequence: No hopping centered on the TX_frequency. Config bits 0 to 6 define the number of repetitions. Bit 7 of config defines if a delay is applied or not in the loop</li> <li>1. TX Protocol: Tx mode with full protocol with Sigfox key: Send Sigfox protocol frames with initiate downlink flag = True. Config defines the number of repetitions.</li> <li>2. RX Protocol: This mode tests the complete downlink protocol in Downlink only. Config defines the number of repetitions.</li> <li>3. RX GFSK: RX mode with known pattern with SB + SF + Pattern on RX_frequency (internal comparison with received frame ⇔ known pattern = AA AA B2 27 1F 20 41 84 32 68 C5 BA AE 79 E7 F6 DD 9B. Config defines the number of repetitions. Config defines the number of repetitions.</li> <li>4. RX Sensitivity: Does uplink + downlink frame with Sigfox key and specific timings. This test is specific to SIGFOX's test equipments &amp; softwares.</li> <li>5. TX Synthesis: Does one uplink frame on each Sigfox channel to measure frequency synthesis step</li> </ul>
AT\$SE	Starts AT\$TM-3,255 indefinitely	Convenience command for sensitivity tests

## WIFI command

Command	Name	Description
AT+CWLAP	Lists available APs	<ssid> string, SSID of AP <rsi> signal strength <mac> string MAC address