

# **WT9932P4-MINI-A1 Development Board Guide**

Version 1.0

## **Disclaimer and Copyright Notice**

Information in this document, including the URL addresses for reference, is subject to change without notice.

This document is provided "as is" without warranty of any kind, including any warranty of merchantability, fitness for a particular purpose, or non-infringement, and any warranty that any proposal, specification, or sample is referred to elsewhere. This document disclaims all liability, including liability for infringement of any patent, arising out of the use of the information in this document. This document does not grant any license, express or implied, by estoppel or otherwise, to use any intellectual property.

The Wi-Fi Alliance member logo is owned by the Wi-Fi Alliance.

All trade names, trademarks and registered trademarks mentioned herein are the property of their respective owners and are hereby acknowledged.

### **Notice**

The content of this manual is subject to change due to product version upgrade or other reasons. WIRELESS-TAG Technology Co.,limited reserves the right to modify the contents of this manual without any notice or prompting. Ltd. makes every effort to provide accurate information in this manual, but WIRELESS-TAG Technology Co.,limited does not ensure that the contents of the manual are completely free of errors, and all statements, information and recommendations in this manual do not constitute any express or implied warranty.

## Revision History

Version	Date	Developed/changed content	Modifier By	Auditor
V1.0	2025-6-9	Creating Documents	Pail	Louie



## Contents

1. Development Board Introduction .....	5
1.1. Development Board Overview .....	5
1.2. Development Board Pictures .....	5
2. Getting Started .....	6
2.1. Component Introduction .....	6
2.2. Preliminary .....	8
2.3. Hardware Setup .....	8
2.4. Software Setup .....	8
3. Hardware Reference .....	9
3.1. Block Diagram .....	9
3.2. Header Block .....	9
4. Related Documents .....	13
5. Contact Us .....	13



# 1. Development Board Introduction

## 1.1. Development Board Overview

WT9932P4-MINI-A1 development board is a multimedia development board based on WT0132P4-A1 core board designed by Wireless-tag Technology Co., Limited. The WT0132P4-A1 core board based on Espressif ESP32-P4 series chip, featuring a dual-core 360 MHz RISC-V processor and 32 MB PSRAM. Additionally, the ESP32-P4 supports various peripherals such as USB 2.0, MIPI-CSI and MIPI-DSI, making it ideal for cost-effective, low-power multimedia product development.

## 1.2. Development Board Pictures




Figure 1: WT9932P4-MINI-A1 Development Board (front)




Figure 2: WT9932P4-MINI-A1 Development Board (back)

## 2. Getting Started

This section provides a brief introduction to WT9932P4-MINI-A1 development board, instructions on how to do the initial hardware setup and how to flash firmware onto it.

### 2.1. Component Introduction




Figure 3: WT9932P4-MINI-A1 Development Board Component Description (front)




Figure 4: WT9932P4-MINI-A1 Development Board Component Description (back)

The key components of the board are described in a clockwise direction.

Key Component	Description
J5	Some of the available pins on the core board have been routed to J5. For more details, see <a href="#">Header Block</a> .
MIPI-CSI	MIPI CSI FPC connector is used for connecting external camera module to enable image transmission.
MIPI-DSI	MIPI DSI FPC connector is used for connecting displays.
Reset Key	Resets the board.
Boot Key	The boot mode control button. Press the <b>Reset Key</b> while holding down the <b>Boot Key</b> to reset WT0132P4-A1 and enter firmware download mode. Firmware can then be downloaded to SPI flash via the USB-to-UART Port.
J6	Some of the available pins on the core board have been routed to J6. For more details, see <a href="#">Header Block</a> .
USB to UART	This port can be used to power the board, flash firmware to the chip, and communicate with the WT0132P4-A1 via the USB-to-UART Bridge Chip.
LED of Power	Lights up when the development board is connected to the power supply through any of the power supply connectors.
Power Switch	Power On/Off Switch. Toggling toward the ON sign powers the board on (5 V), toggling away from the ON sign powers the board off.
USB 2.0	The USB 2.0 Type-C Port connected to the USB 2.0 OTG Full-Speed interface of the ESP32-P4 chip on the WT0132P4-A1 core board. When communicating with other devices via this port, ESP32-P4 acts as a USB device connecting to a USB host, which can also be used as the power supply interface of the development board.



USB 2.0	The USB 2.0 Type-C Port connected to the USB 2.0 OTG High-Speed interface of the ESP32-P4 chip on the WT0132P4-A1 core board. When communicating with other devices via this port, ESP32-P4 acts as a USB host and supply power to the other devices.
USIM Card	USIM card slot for inserting a USIM card to realize the communication function based on the mobile communication network.
Mini-PCle	Mini-PCle interface, connected to the UART and USB interfaces of the ESP32-P4 chip on the WT0132P4-A1 core board, can be used to extend the communication capability of the development board.

## 2.2. Preliminary

- WT9932P4-MINI-A1
- USB-C cables
- Computer running Windows, Linux, or macOS
- LCD (Optional)
- Camera (Optional)
- CAT.1 Module and USIM card (Optional)

## 2.3. Hardware Setup

Connect the WT9932P4-MINI-A1 to your computer using a USB cable. The board can be powered through any of the USB Type-C ports. The USB-to-UART Port is recommended for flashing firmware and debugging.

## 2.4. Software Setup

To set up your development environment and flash an application example onto your board, please follow the instructions in [ESP-IDF Get Started](#). Or go to [Wireless-Tag GitHub Examples](#), development board application examples have been stored, download compile and burn the application to the



development board to start development.

## 3. Hardware Reference

### 3.1. Block Diagram

The block diagram below shows the components of WT9932P4-MINI-A1 and their interconnections.




Figure 3: WT9932P4-MINI-A1 Block Diagram

### 3.2. Header Block

The tables below provide the Name and Function of the pin header(J5、J6),The pin header names are shown in [Development Board Pictures](#).

Table 1: Detailed Functional Description of J5 Pin Header

No.	Name	Function
1	IO33	GPIO33, I3CMST_SDA, GPSPI SPI2 WP, EMAC PHY TXEN, DBG_PSRAM_DQ5
2	IO26	GPIO26, USB1P1_N1
3	IO32	GPIO32, I3CMST_SCL, GPSPI SPI2 HOLD, EMAC RMII CLK, DBG_PSRAM_DQ4
4	IO27	GPIO27, USB1P1_P1
5	IO35	GPIO35, GPSPI SPI2 IO5, EMAC PHY TXD1, DBG_PSRAM_DQ7

6	IO37	GPIO37, UART0_TXD, GPSPI SPI2 IO7
7	VO4	Power out (Output voltage range 0.5~2.7V or 3.3V, maximum output current 0.2A)
8	IO38	GPIO38, UART0_RXD, GPSPI SPI2 DQS
9	IO48	GPIO48, SD1_CDATA7_PAD, GMAC_PHY_RXER_PAD
10	IO39	GPIO39, SD1_CDATA0_PAD, REF_50M_CLK_PAD
11	IO47	GPIO47, SD1_CDATA6_PAD, GMAC_PHY_RXD1_PAD
12	IO40	GPIO40, SD1_CDATA1_PAD, GMAC_PHY_TXEN_PAD
13	IO46	GPIO46, SD1_CDATA5_PAD, GMAC_PHY_RXD0_PAD
14	IO41	GPIO41, SD1_CDATA2_PAD, GMAC_PHY_TXD0_PAD
15	IO45	GPIO45, SD1_CDATA4_PAD, GMAC_PHY_RXDV_PAD
16	IO42	GPIO42, SD1_CDATA3_PAD, GMAC_PHY_TXD1_PAD
17	IO53	GPIO53, GMAC_PHY_RXD1_PAD, ADC2_CHANNEL6, ANA_COMP1
18	IO43	GPIO43, SD1_CCLK_PAD, GMAC_PHY_TXER_PAD
19	IO54	GPIO54, GMAC_PHY_RXER_PAD, ADC2_CHANNEL7, ANA_COMP1
20	IO44	GPIO44, SD1_CCMD_PAD, GMAC_RMII_CLK_PAD
21	IO31	GPIO31, GPSPI SPI2 Q, EMAC PHY RXER, DBG_PSRAM_HOLD
22	IO30	GPIO30, GPSPI SPI2 CK, EMAC PHY RXD1, DBG_PSRAM_WP
23	IO49	GPIO49, GMAC_PHY_TXEN_PAD, ADC2_CHANNEL2
24	IO29	GPIO29, GPSPI SPI2 D, EMAC PHY RXD0, DBG_PSRAM_Q
25	IO50	GPIO50, GMAC_RMII_CLK_PAD, ADC2_CHANNEL3
26	IO28	GPIO28, GPSPI SPI2 CS, EMAC PHY RXDV, DBG_PSRAM_D
27	IO51	GPIO51, GMAC_PHY_RXDV_PAD, ADC2_CHANNEL4,

		ANA_COMP0
28	IO34	GPIO34, GPSPi SPI2 IO4, EMAC PHY TXD0, DBG_PSRAM_DQ6
29	IO52	GPIO52, GMAC_PHY_RXD0_PAD, ADC2_CHANNEL5, ANA_COMP0
30	IO35	GPIO35, GPSPi SPI2 IO5, EMAC PHY TXD1, DBG_PSRAM_DQ7

**Table 2: Detailed Functional Description of J6 Pin Header**

No.	Name	Function
1	3V3	3.3 V power supply (output)
2	IO23	GPIO23, ADC1_CHANNEL7, REF_50M_CLK_PAD
3	3V3	3.3 V power supply (output)
4	IO22	GPIO22, ADC1_CHANNEL6
5	3V3	3.3 V power supply (output)
6	IO21	GPIO21, ADC1_CHANNEL5
7	IO20	GPIO20, ADC1_CHANNEL4
8	GND	GROUND
9	IO19	GPIO19, ADC1_CHANNEL3
10	GND	GROUND
11	IO18	GPIO18, ADC1_CHANNEL2
12	GND	GROUND
13	IO17	GPIO17, ADC1_CHANNEL1
14	GND	GROUND
15	VCC_5V	5 V power supply (output)
16	IO16	GPIO16, ADC1_CHANNEL0
17	VCC_5V	5 V power supply (output)
18	EN	Enable ESP32-P4
19	IO1	GPIO1, LP_GPIO1, XTAL_32K_P
20	IO15	GPIO15, LP_GPIO15, LP_UART_RXD_PAD,

		TOUCH_CHANNEL13
21	IO0	GPIO0, LP_GPIO0, XTAL_32K_N
22	IO14	GPIO14, LP_GPIO14, LP_UART_TXD_PAD, TOUCH_CHANNEL12
23	IO9	GPIO9, UART0_CTS_PAD, SPI2_CK_PAD, LP_GPIO9, TOUCH_CHANNEL7
24	GND	GROUND
25	IO6	GPIO6, SPI2_HOLD_PAD, LP_GPIO6, TOUCH_CHANNEL4
26	GND	GROUND
27	VIN_5V	Development board 5 V supply (input)
28	IO13	GPIO13, UART1_CTS_PAD, LP_GPIO13, TOUCH_CHANNEL11
29	VIN_5V	Development board 5 V supply (input)
30	IO12	GPIO12, UART1_RTS_PAD, LP_GPIO12, TOUCH_CHANNEL10

## 4. Related Documents

WT0132P4-A1 datasheet: <https://en.wireless-tag.com/product-item-56.html>

WT9932P4-MINI-A1 schematic: <https://en.wireless-tag.com/product-item-67.html>

## 5. Contact Us

Official website: [www.wireless-tag.com](http://www.wireless-tag.com)

Contact Email: [gtm@wireless-tag.com](mailto:gtm@wireless-tag.com)

Technical support e-mail: [technical@wireless-tag.com](mailto:technical@wireless-tag.com)

