

```

@Done
@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@@
@
@ Memtest.s
@
@
@
@
@ Description: Contains code for testing the SRAM and DRAM
@             This code is normally ran before copying the system from ROM to SRAM or DRAM
@
@ Table of Contents:
@   - mem_test: Tests the memory address range that is passed.
@               The test erases anything stored here before.
@
@
@
@
@ Revision History:
@ Name           Comment           Date
@ Will Werst     Initial version   Some lonely night around 6/10/17
@ Will Werst     Comment           October 2017

.include      "at91rm9200.inc"
.include      "system.inc"

.text
.arm

@ mem_test
@
@ Description: Tests memory of passed memory section.
@             In the process of testing memory, this function destroys all data
@             that was in the memory already.
@
@ Operational Description:
@
@ Arguments: r0 - starting address to test memory integrity
@            r1 - length of data to test memory integrity of
@
@ Return values: r0 - TRUE if success, FALSE if failure
@                r1 - value read from memory
@                r2 - value expected in memory
@                r3 - relative address where error occurred
@
@ Local variables: r0 - base address - unchanged
@                  r1 - length of memory - unchanged
@                  r2 - relative location into memory
@                  r3 - incrementer value used to generate sequences of data to load into memory
@                  r4 - value to load into memory
@
@ Shared variables: None
@
@ Global Variables: None
@
@ Inputs: None
@
@ Outputs: None
@
@ Error Handling: None
@
@ Algorithms: None

```

```

@
@ Data Structures: None
@
@ Limitations: None
@
@ Registers Changed (besides ARM convention r0-r3): None
@
@ Known Bugs: None
@
@ Special notes: None
@
@ Revision History:
@ Name          Comment          Date
@ Will Werst     Initial version  6/22/2017

.global mem_test
mem_test:
    PUSH {r4, r5, lr}
    LDR r3, =0                @Load incrementer value
    LDR r4, =0
mem_test_loop:
    LDR r5, =0x3F35D4B3
    ADDS r3, r5                @Increment incrementer value
    BCS success               @If have used all incrementer values, and thus overflowed, return
    LDR r2, =0                @Load the initial location to load into memory
    PUSH {r4}                 @Store current starting value to recover later for when checking
writedata:
    STR r4, [r0, r2]          @Load value into memory
    ADDS r4, r3                @Increment value to load into memory
    SBC r4, r4, #1            @Subtract carry flag so that wrapping occurs at 2^32 + 1, not
    2^32
    ADD r2, #4                @Increment the relative location to load into memory
    CMP r2, r1                @Check if written to all locations in memory
    BLT writedata             @If haven't, then keep writing, else go to check memory
    LDR r2, =0                @Reset initial location in memory
    POP {r4}                  @Recover starting value and check data in memory
checkdata:
    LDR r5, [r0, r2]          @Load value from memory
    CMP r5, r4
    BNE failure
    ADDS r4, r3                @Increment value to load into memory
    SBC r4, r4, #1            @Subtract carry flag so that wrapping occurs at 2^32 + 1, not
    2^32
    ADD r2, #4                @Increment the relative location to load into memory
    CMP r2, r1                @Check if written to all locations in memory
    BLT checkdata
    B mem_test_loop
failure:
    LDR r0, =FALSE
    MOV r1, r5
    MOV r3, r2
    MOV r2, r4
    B mem_test_end
success:
    LDR r0, =TRUE
    @B mem_test_end
mem_test_end:
    POP {r4, r5, pc}

.end

```