



**K A C O**



new energy.

**Modbus Protocol blueplanet  
100-125 NX3**

## Application Note

# Instructions for use

## Modbus Protocol

### Table of contents

<b>1</b>	<b>General information .....</b>	<b>3</b>
1.1	Scope .....	3
1.2	More information .....	3
1.3	Target group .....	3
<b>2</b>	<b>Register Map .....</b>	<b>4</b>
2.1	Scaling factors .....	4
2.2	SunSpec register map .....	4
2.3	Address calculation example .....	5
2.3.1	Example .....	6
<b>3</b>	<b>Register description .....</b>	<b>6</b>
3.1	Common Block (Device ID001) .....	7
<b>4</b>	<b>FAQ .....</b>	<b>7</b>

# 1 General information

## 1.1 Scope

This document describes the general aspects of the MODBUS protocol of the KACO string and battery inverter series. The inverters support a subset of data models according to the SunSpec specification. For a detailed description of particular models refer to [8]. In this document the supported subset is highlighted.

Besides that KACO supports some vendor specific models which will be described in [9].

### Supported MODBUS protocols (new devices with dedicated web interface)

- Modbus-TCP/UDP

### Supported Inverter Model

- blueplanet 100 NX3 ; blueplanet 125 NX3

### Supported SW Version

WR series	Firmware V.	Supported Models Device ID
blueplanet 100-125 NX3	V5.0.2.4	<b>001, 103, 113, 120, 121, 122, 123, 126, 129, 130, 132, 135, 136, 145, 160, 704, 64201, 64204, 64205, 64203, 64310</b>
	V5.0.3.1	001, 103, 113, 120, 121, 122, 123, 126, 129, 130, 132, 135, 136, 145, 160, <b>701, 702, 704, 707, 708, 709, 710, 714</b> , 64201, 64204, 64205, 64203, 64310
	V5.0.3.3	001, 103, 113, 120, 121, 122, 123, 126, <b>127</b> , 129, 130, 132, 135, 136, 145, 160, 701, 702, 704, 707, 708, 709, 710, 714, 64201, <b>64202</b> , 64204, 64205, 64203, 64310
	V5.1.7.2	001, 103, 113, 120, 121, 122, 123, 126, 127, 129, 130, 132, 135, 136, 145, 160, 701, 702, <b>703</b> , 704, <b>705, 706</b> , 707, 708, 709, 710, <b>711, 712, 713</b> , 714, <b>715</b> , 64201, 64202, 64204, 64205, 64303, 64310
	V5.1.9.0	001, 103, 113, 120, 121, 122, 123, 126, 127, 129, 130, 132, 135, 136, 145, 160, 701, 702, 703, 704, 705, 706, 707, 708, 709, 710, 711, 712, 713, 714, 715, 64201, 64202, 64204, 64205, 64303, 64310

Tab. 1: Supported SW Version

## 1.2 More information

### Modbus-Organisation

[1] <http://www.modbus.org>

[2] Modbus\_Application\_Protocol\_V1\_1b3.pdf

[3] Modbus\_Messaging\_Implementation\_Guide\_V1\_0b.pdf

### SunSpec-Spezifikation

[4] <http://www.sunspec.org>

[5] SunSpec-Alliance-Specification-Common-Models-v1.5.pdf

[6] SunSpec Alliance Specification - Inverter Models v1.1.pdf

[7] SunSpec Information Models – 12041.pdf (SunSpec Information Modellspezifikation SunSpec Alliance Interoperabilitätsspezifikation V1.8)

### SunSpec-Modelle

[8] SunSpec-Information-Model-Reference.xlsx

[9] SunSpec-Information-Model-Reference-Kaco.xlsx

## 1.3 Target group

All activities described in the document may only be carried out by specially trained personnel with the following qualifications:

- Knowledge about IP-based network protocols
- Knowledge of the modbus specifications
- Knowledge of the SunSpec modbus specifications
- Education concerning the installation and configuration of IT systems
- Training in the handling of hazards and risks during the installation and operation of electrical units and plants.

- Education concerning the installation and start-up of electrical units and plants.
- Knowledge of applicable standards and directives.
- Knowledge and adherence to this document with all safety notices.

## 2 Register Map

### 2.1 Scaling factors

“SF” in below table is an abbreviation of “Scaling Factor”. You can calculate a real value of specific address using SF value, received value via MODBUS and following equation.

$$\{\text{Read Value}\} = \{\text{Received value via MODBUS}\} * 10^{\{\text{SF}\}}$$

#### Example:

Address offset 29 and 30 mean DC voltage and the DCV-SF value is -1. If a received value via MODBUS is 5042, DC voltage is as follow.

$$\{\text{DC Voltage}\} = (5042) * 10^{(-1)} = 504.2 \text{ Volt}$$

The way to use Scale Factor is the same of SunSpec specifications.

### 2.2 SunSpec register map

The register map must start with the SunSpec ID, indicating that the following registers are Modbus/SunSpec registers. The base register address is 40001, and has the following representation:

Address Start / End	Size	R/W	Name	Type	Units	SF	Description	Value Range
40001 40002	2	R	SunSpec ID	uint32	-	-	Uniquely identifies this as a SunSpec Modbus Map	0x53756e53

After this SunSpecID the supported SunSpec models follow one by one. To retrieve the offsets for the supported SunSpec models in the register map, the headers for each have to be parsed until a specific “END\_OF\_MAP” model is found. This model has the following content:

Address Offsett	Block off-set	Size	R/W	Name	Type	Units	SF	Description	Value Range
0	-	1	R	SunSpec DID	uint16	-	-	End of Register map	0xFFFF
1	-	1	R	SunSpec Length	uint16	-	-	Model length	0

## 2.3 Address calculation example

**WARNING!** If a device does not contain the same firmware version according to the specification "SunSpec Modbus Interface" version, parameters may be called incorrectly. If Modbus-UDP is activated, all connected devices need same firmware-version.

**NOTE:** In a Modbus communication robustly constructed against model changes, first all models are read out and then the register addresses are calculated.

1. Search for the string "Su"nS" -> in the example 40001 [Pos. 1]
2. Advance by the length of the string: i.e. + 2 auf 40003
3. Reading the model names -> 1 [Pos. 2]
4. Reading the model length -> 66 [Pos. 3]
5. Advance to the next model ->  $40003 + 2 + 66 = 40071$  [Pos. 4]
6. Reading the name (result depends on which models are supported)
7. Reading the length (result depends on which models are supported)
8. Move forward to the next model [Pos. 5]
9. Repeat the procedure to the end. [Pos. 6]




Fig. 1: Address calculation model

This method to enumerate all supported models can be repeated, until the “END\_OF\_MAP” model with DID 0xFFFF is found.

To retrieve an explicit value from a certain model, the offset of that value has to be added to the models offset retrieved in the manner above.

### 2.3.1 Example

#### Example for power control over Model DID123

This example will show, how to set a power control value of 50% P over SunSpec model DID123.

1. During init phase run the SunSpec register map lookup (wie in Kapitel 4.2 beschrieben [See section 2.2► Page 4]) to find out the offset of the start register of SunSpec model DID123. This step has to be preformed only once during init phase.
2. For this example we assume, that this step gives us a start address of SunSpec model DID123 of 40290 ((be aware of the difference between register number and its address, wie in Kapitel 4.2 beschrieben [See section 2.2► Page 4])
3. Setting ‘WMaxLimPct’ register in SunSpec model DID123. For this we need to lookup the relative address offset of ‘WMaxLimPct’ register address within the model definition of SunSpec model DID123 to retrieve its absolute address within the register map:

WMaxLimPct relativer Adress-Offset = 5

DID123-Startadresse = 40290

WMaxLimPct absolute Adresse = 40290 + 5 = 40295

1. Now that we have the absolute register offset to write, the desired power control value need to be correctly scaled. Therefor the scale factor ‘WMaxLimPct\_SF’ is needed. In our example reading this will return a scale factor of ‘-1’. With this we calculate the value to set to the ‘WMaxLimPct’ register (wie in Kapitel 4.1 beschrieben [See section 2.1► Page 4]):

Register value = 50.0(%) / 10-1 = 500

1. Now the desired value 500 (=0x01f4) may be set using a Modbus write command on the absolute address 40295 (=0x9d67). The value set must be in legal ranges, otherwise a Modbus exception will be returned. For example using the ModbusTCP write single register command 0x06:

TX:00 0c 00 00 00 06 01 06 9d 67 01 f4

RX:00 0c 00 00 00 06 01 06 9d 67 01 f4

1. Enable power limitation by writing ‘WMaxLim\_Ena’ Register. Like in the previous step, we need to lookup the absolute address of ‘WMaxLim\_Ena’ register.

WMaxLim\_Ena relative address offset = 9

DID123 start address = 40290

WMaxLim\_Ena absolute address = 40290 + 9 = 40299

1. Writing a ‘1’ = ENABLED to the register address 40299 will start external power control. For example using the ModbusTCP write single register command 0x06:

TX: 00 0d 00 00 00 06 01 06 9d 6b 00 01

RX: 00 0d 00 00 00 06 01 06 9d 6b 00 01

## 3 Register description



### NOTE

For a detailed description of particular models / registers refer to SunSpec Models xls.!



### NOTE

Again – keep in mind, that when you refer to a specific address in a model you’ve to use the register\_address – 1 > on the wire!



### NOTE

#### Setting specific functions via model 123

Refer to the Chapter “Specifications” in the device manual. You will find additional explanations of functions there, as well as examples that use sample parameters.

### 3.1 Common Block (Device ID001)

The register description for “Common Block (DID 001) is only an example may not reflect the current implementation.

Address Offset	Block Offset	Size	R/W	Name	Type	Units	SF	Description	Value Range
0	-	1	R	SunSpec DID	uint16	-	-	SunSpec Common Model	001 (dec)
1	-	1	R	SunSpec Length	uint16	-	-	Model Length	66 (dec)
2	0	16	R	Manufacturer	string	-	-		„KACO new energy“
18	16	16	R	Model	string	-	-	KACO inverter name	e.g. “Powador 39.0 TL3”
34	32	8	R	Options	string	-	-	Data logger ID-String	e.g. “390TL”
42	40	8	R	Version	string	-	-	The packet version of the currently installed software	e.g. “V2.10”
50	48	16	R	Serial Number	string	-	-	Serial number set during production process	e.g. “39.0TL011 23456”
66	64	1	-	Device Address	uint16	-	-	Not implemented	-
67	65	1	R	-	pad	-	-	Force even alignment	0

## 4 FAQ

Fault	Cause
What communication protocol should be used?	The SunSpec protocol provided and the KACO extension list pave the way for dynamic addressing. Update these protocols at regular intervals.
What should I do if the device does not answer?	Check whether you can reach the device using a ping (device address). In the event of a fault, please check the communication line.
Modbus is not displaying the value expected.	<p>Check whether you have performed the calculation via the chosen start address in accordance with the example - Calculation model addresses. Address calculation example [See section 2.3 ▶ Page 5]</p> <p>Das „SunSpec Client Help Tool ...“ supports you in calculating a desired register address. You can also find this tool under Downloads/Software.</p>

