

HSPICE/SPICE Interface Reference

Product Version IC23.1
June 2023

© 2023 Cadence Design Systems, Inc. All rights reserved.
Printed in the United States of America.

Cadence Design Systems, Inc. (Cadence), 2655 Seely Ave., San Jose, CA 95134, USA.

Open SystemC, Open SystemC Initiative, OSCI, SystemC, and SystemC Initiative are trademarks or registered trademarks of Open SystemC Initiative, Inc. in the United States and other countries and are used with permission.

Trademarks: Trademarks and service marks of Cadence Design Systems, Inc. contained in this document are attributed to Cadence with the appropriate symbol. For queries regarding Cadence's trademarks, contact the corporate legal department at the address shown above or call 800.862.4522.

All other trademarks are the property of their respective holders.

Restricted Permission: This publication is protected by copyright law and international treaties and contains trade secrets and proprietary information owned by Cadence. Unauthorized reproduction or distribution of this publication, or any portion of it, may result in civil and criminal penalties. Except as specified in this permission statement, this publication may not be copied, reproduced, modified, published, uploaded, posted, transmitted, or distributed in any way, without prior written permission from Cadence. Unless otherwise agreed to by Cadence in writing, this statement grants Cadence customers permission to print one (1) hard copy of this publication subject to the following conditions:

1. The publication may be used only in accordance with a written agreement between Cadence and its customer.
2. The publication may not be modified in any way.
3. Any authorized copy of the publication or portion thereof must include all original copyright, trademark, and other proprietary notices and this permission statement.
4. The information contained in this document cannot be used in the development of like products or software, whether for internal or external use, and shall not be used for the benefit of any other party, whether or not for consideration.

Disclaimer: Information in this publication is subject to change without notice and does not represent a commitment on the part of Cadence. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information.

Cadence is committed to using respectful language in our code and communications. We are also active in the removal and replacement of inappropriate language from existing content. This product documentation may however contain material that is no longer considered appropriate but still reflects long-standing industry terminology. Such content will be addressed at a time when the related software can be updated without end-user impact.

Restricted Rights: Use, duplication, or disclosure by the Government is subject to restrictions as set forth in FAR52.227-14 and DFAR252.227-7013 et seq. or its successor

Contents

1

<u>Introduction</u>	5
<u>Product Overview</u>	5
<u>SPICE</u>	5
<u>HSPICE</u>	5
<u>Simulation Flow</u>	6

2

<u>SPICE Circuit Simulation Interface</u>	9
<u>Overview</u>	9
<u>control file</u>	10
<u>netlist file</u>	11
<u>spice.inp file</u>	11
<u>spice.sim file</u>	11
<u>si.inp file: Used as Input to SPICE</u>	11
<u>si.log file: Produced from the Simulation Run</u>	12
<u>si.out file: Output of a SPICE Simulation Run</u>	12

3

<u>HSPICE Circuit Simulation Interface</u>	17
<u>Overview</u>	17
<u>Running HSPICE</u>	17
<u>Creating the Schematic</u>	18
<u>Generating the Run Directory</u>	19
<u>Editing the Control File</u>	19
<u>Starting the Analysis Run</u>	19
<u>Generating the Netlist</u>	20
<u>Creating the Input File</u>	20
<u>Running the Simulation</u>	20
<u>Translating the Output</u>	21

HSPICE/SPICE Interface Reference

<u>Viewing the Results</u>	21
<u>Hierarchical Netlisting</u>	21
<u>Primitive Cell Requirements</u>	22
<u>Example</u>	22
4	
<u>HSPICE/SPICE Elements</u>	25
<u>HSPICE/SPICE Model and Element Parameters</u>	27
<u>Resistor</u>	27
<u>Capacitor</u>	28
<u>Inductor</u>	28
<u>Transmission Line</u>	29
<u>Diode</u>	30
<u>BJT</u>	31
<u>JFET</u>	33
<u>MOSFET</u>	34
<u>Element Formats</u>	37
<u>Model Format</u>	39
<u>Index</u>	41

Introduction

This chapter includes the following topics:

- [Product Overview](#)
- [Simulation Flow](#)

Note: Ensure that the following third party tools are installed before you use the HSPICE or SPICE interface:

- HSPICE® simulator from Synopsys, Inc
- SPICE® simulator from University of California at Berkeley

Product Overview

SPICE

SPICE is a general-purpose circuit simulator developed by the University of California at Berkeley. It is used for nonlinear DC, nonlinear transient, and linear AC analysis. Cadence does not sell the SPICE program but supplies a copy of this public Domain program and its manual free of charge when you purchase the interface.

HSPICE


HSPICE is a general-purpose circuit simulator from Synopsys, Inc. It has an extensive set of built-in device models, including models for small geometry MOSFETs and MESFETs. The program is compatible with SPICE and MSING input formats. Cadence supports a library of primitives and a full interface for HSPICE.

Licensing Requirements

- For information on licensing in the Virtuoso Studio Design Environment, see [Virtuoso Software Licensing and Configuration Guide](#).
- For information on licensing for the HSPICE simulator, contact Synopsys, Inc.
- For information on licensing for the SPICE simulator, contact the University of California at Berkeley.

Simulation Flow

The following chart shows the flow of the tasks involved in running a simulation using HSPICE. This manual covers the products in the shaded boxes.



HSPICE/SPICE Interface Reference

Introduction

HSPICE/SPICE Interface Reference

Introduction

SPICE Circuit Simulation Interface

This chapter contains the following topics:

- [Overview](#)
- [Example of a SPICE Simulation Run](#)

Overview


To set up and run a basic simulation using menus and forms, refer to [Simulation Environment Help](#). Here is information specific to running the SPICE simulator:

- SPICE does not have a command to read an input file, so the *netlist* file must be specified in the *control* file with the simulation environment file inclusion function, “[!netlist]”; this tells the interface to include the *netlist* file in the file that is passed to SPICE. For an example of this, refer to the sample SPICE *control* file in [“Example of a SPICE Simulation Run”](#). Any other command or stimulus files you want to use as input to SPICE can be specified in the same way.
- The template *control* file for SPICE includes two other files in addition to the *netlist* file, *spice.inp* and *spice.sim*. These files are for stimulus data and simulator commands. The *Initialize* command from the Simulation menu automatically creates templates for these files in a new run directory.
- The waveform interface for SPICE does not handle multiple analysis simulation runs. To view waveforms, perform one analysis for each simulation run.
- The Waveform Display program does not display results of AC small-signal analysis simulation runs. Use the SPICE .PRINT or .PLOT commands to generate SPICE text output, and read it using the view output command.

Example of a SPICE Simulation Run

This section shows an example of input and output files needed for running a SPICE simulation.

The following input and output files are for running the simulation on the inverter shown below:



- The *control* file is used as an input for running the simulation.
- The netlist file created by running the netlister on the design.
- The *si.inp* file is created by the simulation interface and is passed to SPICE. This file is formed by including the specified files in the control file and mapping the user-defined names to numbers suitable for SPICE.
- The *spice.inp* file is created by the *Initialize* command. Modify this file by adding the stimulus data.
- The *spice.sim* file is created by the *Initialize* command. Modify this file by adding the simulator commands.
- The *si.log* file is the log of the simulation run.
- The *si.out* file is the text output created by SPICE.

control file

* Spice control file

```
.options acct opts nopage limpts=1000
.width in=80 out=80
[!spice.inp]
[!netlist]
[!spice.sim]
.end
```

HSPICE/SPICE Interface Reference

SPICE Circuit Simulation Interface

***netlist* file**

```
* net 1 = vdd!
* net 0 = gnd!
* net 2 = /OUT
* net 3 = /IN
.MODEL Model1 pmos level=2 vto=-.7 kp=1.5e-05 gamma=.4
+lambda=.03 tox=6.e-07 xqc=.5
* pmos(0) = /1
M$#0 1 3 2 1 Model1 l=2u w=6u
* capacitor(1) = /2
C$#1 2 0 poly 1pf
.MODEL Model3 nmos level=2 vto=.7 kp=3.e-05 gamma=.2 +lambda=.02
+ tox=6.e-07 xqc=.5
* nmos(2) = /0
M$#2 2 3 0 0 Model3 l=2u w=4u
```

***spice.inp* file**

```
vdd [#vdd!] [#gnd!] dc 5v
vin [#/IN] 0 pw1 0 0 100ns 5v 150ns 5v 250ns 0
```

***spice.sim* file**

```
.tran 1ns 300ns
```

***si.inp* file: Used as Input to SPICE**

```
* Spice control file
.options acct opts nopage limpts=1000
.width in=80 out=80
vdd 1 0 dc 5v
vin 3 0 pw1 0 0 100ns 5v 150ns 5v 250ns 0
* net 1 = vdd!
* net 0 = gnd!
* net 2 = /OUT
* net 3 = /IN
.MODEL Model1 pmos level=2 vto=-.7 kp=1.5e-05 gamma=.4
+lambda=.03 tox=6.e-07 xqc=.5
* pmos(0) = /1
M$#0 1 3 2 1 Model1 l=2u w=6u
* capacitor(1) = /2
C$#1 2 0 poly 1pf
.MODEL Model3 nmos level=2 vto=.7 kp=3.e-05 gamma=.2
+lambda=.02
+ tox=6.e-07 xqc=.5
* nmos(2) = /0
M$#2 2 3 0 0 Model3 l=2u w=4u
.tran 1ns 300ns

.end
```

HSPICE/SPICE Interface Reference

SPICE Circuit Simulation Interface

***si.log* file: Produced from the Simulation Run**

```
si version 4.0.55 Wed Apr 18 21:51:31 PDT 1990 (cds2082)
si: Loading user defined simulation run control file "~/.simrc".
si: Loading simulation environment file "/usr/mnt2/hpeter/4.0/group/spice/test2/
run1/si.env".
si: Loading simulation capabilities file "/usr/mnt2/hpeter/4.0/etc/skill/si/
simcap.ile".

Running simulation in directory: "/usr/mnt2/hpeter/4.0/group/spice/test2/run1".

Running netlist
Begin netlist:      Apr 26 11:58:45 1990
    simulation library path = ". ~"
    simulation library = testLib
    library configuration = default
    cell = spice.cct2
    view = schematic
    view list = ("spice" "cmos.sch" "schematic")
    stopping view list = ("spice")
End netlist:      Apr 26 11:58:54 1990

Running simin
Running runsim with simulator: "spice"

Begin simulation:      Apr 26 11:58:56 1990
End simulation:      Apr 26 12:02:38 1990

Running simout
Simulation completed successfully.
```

***si.out* file: Output of a SPICE Simulation Run**

```
***4/26/90 ***** SPICE 2G.6 3/16/83 *****14:35:31***

* SPICE CONTROL FILE

**** INPUT LISTING  TEMPERATURE = 27.000 DEG C

*****
.OPTIONS ACCT OPTS NOPAGE LIMPTS=1000
.WIDTH IN=80 OUT=80
VDD vdd! gnd! DC 5V
VIN /IN gnd! PWL 0 0 100NS 5V 150NS 5V 250NS 0
* NET 1      =      VDD!
* NET 0      =      GND!
* NET 2      =      /OUT
* NET 3      =      /IN
.MODEL MODEL1 PMOS LEVEL=2      VTO=-.7 KP=1.5E-05
      GAMMA=.4
+LAMBDA=.03      TOX=6      .E-07 XQC=.5
* PMOS(0) = /1
M/1 vdd! /IN /OUT vdd! MODEL1 L=2U      W=6U
* CAPACITOR(1) = /2
C/2 /OUT gnd! POLY 1PF
.MODEL MODEL3 NMOS LEVEL=2 VTO=.7 KP=3.E-05 GAMMA=.2
+ LAMBDA=.02
+ TOX=6.E-07      XQC=.5
* NMOS(2) = /0
M/0 /OUT /IN gnd! gnd! MODEL3 L=2U      W=4U
.TRAN 1NS 300NS
.END
```

HSPICE/SPICE Interface Reference

SPICE Circuit Simulation Interface

```

*****
**** MOSFET MODEL PARAMETERS TEMPERATURE = 27.000 DEG C
      MODEL1      MODEL3
TYPE      PMOS      NMOS
LEVEL     2.000     2.000
VTO       -0.700     0.700
KP         1.50D-05   3.00D-05
GAMMA      0.400     0.200
LAMBDA     3.00D-02   2.00D-02
TOX        6.00D-07   6.00D-07
XQC        0.500     0.500
**** OPTION SUMMARY TEMPERATURE = 27.000 DEG C
DC ANALYSIS -
GMIN       =          1.000D-12
RELTOL     =          1.000D-03
ABSTOL     =          1.000D-12
VNTOL      =          1.000D-06
LVLCOD     =          1
ITL1       =          100
ITL2       =          50
PIVTOL     =          1.000D-13
PIVREL     =          1.000D-03
TRANSIENT ANALYSIS -
METHOD     =          TRAP
MAXORD     =          2
CHGTOL     =          1.000D-14
TRTOL      =          7.000D+00
LVLTIM     =          2
MU         =          0.500
ITL3       =          4
ITL4       =          10
ITL5       =          5000
MISCELLANEOUS -
LIMPTS     =          1000
LIMTIM     =          2
CPTIME     =          100000000
NUMDGT     =          4
TNOM       =          27.000
DEFL       =          1.000D-04
DEFW       =          1.000D-04
DEFAD      =          0.000D+00
DEFAS      =          0.000D+00

*****
MOSFET MODEL PARAMETERS TEMPERATURE = 27.000 DEG C
      MODEL1      MODEL3
TYPE      PMOS      NMOS
LEVEL     2.000     2.000
VTO       -0.700     0.700
KP         1.50D-05   3.00D-05
GAMMA      0.400     0.200
LAMBDA     3.00D-02   2.00D-02
TOX        6.00D-07   6.00D-07
XQC        0.500     0.500
**** OPTION SUMMARY TEMPERATURE = 27.000 DEG C
DC ANALYSIS -
GMIN       =          1.000D-12
RELTOL     =          1.000D-03
ABSTOL     =          1.000D-12
VNTOL      =          1.000D-06
LVLCOD     =          1

```

HSPICE/SPICE Interface Reference

SPICE Circuit Simulation Interface

```

ITL1      =      100
ITL2      =      50
PIVTOL    =      1.000D-13
PIVREL    =      1.000D-03
TRANSIENT ANALYSIS -
METHOD     =      TRAP
MAXORD     =      2
CHGTOL     =      1.000D-14
TRTOL      =      7.000D+00
LVLTIM     =      2
MU         =      0.500
ITL3       =      4
ITL4       =      10
ITL5       =      5000
MISCELLANEOUS -
LIMPTS     =      1000
LIMTIM     =      2
CPTIME     =      100000000
NUMDGT     =      4
TNOM       =      27.000
DEFL       =      1.000D-04
DEFW       =      1.000D-04
DEFAD      =      0.000D+00
DEFAS      =      0.000D+00
*****
INITIAL TRANSIENT SOLUTION  TEMPERATURE = 27.000 DEG C
NODE VOLTAGE NODE VOLTAGE NODE VOLTAGE
(vdd!) 5.0000 (/OUT) 5.0000 (/IN) 0.0000
VOLTAGE SOURCE CURRENTS
NAME      CURRENT
VDD       -6.933D-12
VIN        0.000D+00
TOTAL POWER DISSIPATION 3.47D-11 WATTS
*****
OPERATING POINT INFORMATION  TEMPERATURE = 27.000 DEG C
**** MOSFETS
      M/1      M/0
MODEL     MODEL1  MODEL3
ID         6.80E-12  1.93E-12
VGS        -5.000    0.000
VDS         0.000    5.000
VBS         0.000    0.000
JOB CONCLUDED
**** JOB STATISTICS SUMMARY  TEMPERATURE = 27.000 DEG C
NUNODS    NCNODS    NUMNOD    NUMEL    DIODES    BJTS    JFETS    MFETS
4          4         4         5         0         0       0       2
NUMTEM     ICVFLG    JTRFLG    JACFLG    INOISE    IDIST    NOGO
1          0        301        0         0         0       0
NSTOP      NTTBR     NTTAR     IFILL     IOPS      PERSPA
6.         13.       13.       0.        21.       63.889
NUMTTP     NUMRTP     NUMNIT    MAXMEM    MEMUSE    COPYKNT
71.        4.        170.     249984    1576     15052.
READIN     0.42
SETUP      0.05
TRCURV     0.00      0.
DCAN       0.18      13.
DCDCMP     0.067     2.
DCSOL      0.067
ACAN       0.00      0.
TRANAN     3.63      170.
OUTPUT     0.00

```

HSPICE/SPICE Interface Reference

SPICE Circuit Simulation Interface

```
LOAD      3.067
CODGEN    0.000      1fs      0.
CODEXC    0.000
MACINS    0.000
OVERHEAD  0.07
TOTAL JOB TIME  4.35
*****
```

HSPICE/SPICE Interface Reference

SPICE Circuit Simulation Interface

HSPICE Circuit Simulation Interface

This chapter contains the following topics:

- [Overview](#)
- [Running HSPICE](#)
- [Hierarchical Netlisting](#)

Overview

Using the HSPICE interface is similar to using the SPICE interface. Before reading this chapter, which contains information specific to running an HSPICE simulation, read the chapter on the SPICE interface.

- With the HSPICE interface you can
 - Generate flat or hierarchical netlists
 - Run local and remote simulations
 - Use element and model parameters supported by HSPICE
- HSPICE differs from SPICE in its handling of waveform output from multiple analysis simulation runs.

The waveforms are written in the Parameter Storage Format (PSF) format if the *psf=1* option is set in your *control* file. The waveforms are stored in the *psf* directory in the simulation run directory and can be viewed using the Waveform Display program.

Running HSPICE

This section describes the following:

- Creating the schematic

HSPICE/SPICE Interface Reference

HSPICE Circuit Simulation Interface

- Generating the run directory
- Editing the control file
- Starting the analysis run
- Generating the netlist
- Creating the input file
- Running the simulation
- Translating the output
- Viewing the results

Most of this information is covered in greater detail in the [Virtuoso Schematic Editor L](#) and [Simulation Environment Help](#). Here you will find only what is specific to HSPICE.

Creating the Schematic

Create schematics for HSPICE simulation in the same way as any other schematic in the Virtuoso Studio Design Environment. The main difference is that each cell in the schematic (for example, transistors, resistors, capacitors) must have a *symbol* and an *hspice* view to be recognized by the HSPICE interface. For a list of the netlisting properties required for the *hspice* view, see [“Primitive Cell Requirements”](#).

Generating the Run Directory

The first time you run a simulation, select the *Initialize* command from the Simulation menu to generate a run directory. This run directory is where the *control*, *netlist*, and simulation input and output files are kept for the simulation being run. When you want to keep an older simulation instead of overwriting it, you can generate and use multiple simulation run directories. Refer to [*Simulation Environment Help*](#).

Editing the Control File

When the system initially creates the run directory, it also creates a dummy *control* file.

Edit this file to include any information that is not in the schematic. Add the *psf* option on the *.options* line in the *control* file. Set *psf=1* or *psf=2*, which tells HSPICE to generate a waveform file in the binary or ASCII PSF format respectively, as required by the simulation environment. You can also specify just the *.option* keyword in the control file. To disable the PSF and other options in an hspiceD netlist specify just the *.option* keyword in the control file.

Note: From the IC 6.1.2 release, Cadence does not support the WSF waveform format. Because of this, do not add the *sda=2* option in the control file to enable HSPICE to create waveforms in the WSF format.

Edit the *hspice.inp* file to add stimulus data and edit the *hspice.sim* file to add simulator commands.

Starting the Analysis Run

With the schematic entered and the *control* file generated, you are ready to start the simulation. Select the *Netlist/Simulate* command from the Simulation menu. This command netlists the schematic and starts the simulation; simulation can be run in the background or foreground. Each step in the analysis process is described below.

Generating the Netlist

The simulation environment creates an HSPICE netlist for the desired schematic. This netlist contains the connectivity description in the proper format for HSPICE. See “Formatting Functions” for information about formats. You can generate a flat or a hierarchical netlist. Both have the same information, but their formats are different. You control the type of netlist generated by setting the *simNetlistHier* simulation environment variable. If this variable is set to *t*, a hierarchical netlist is created; otherwise, a flat netlist is created by default. Typically, you set this variable in your *.simrc* file.

Note the following:

- By default, parameter values are converted to engineering notation in HSPICE netlist. For example, the parameter `w=100u` is written as `W=100e-6` in the netlist. Set the `setEngNotation` environment variable to in your *.cdsenv* file to print the parameter values as is (without conversion to engineering notation) in the netlist.

```
hspiceD.envOpts setEngNotation boolean nil
```

To revert to the default behavior, set the variable to *t*. For example:

```
hspiceD.envOpts setEngNotation boolean t
```

- For devices other than diodes and MOS transistors, the netlister netlists only a predefined list of parameters. If you add user defined parameters in the CDF Simulation Information (*simInfo*) of devices other than diodes and MOS transistors, those parameters will not be netlisted. For such devices, you can write a custom netlist procedure to netlist user defined parameters.

Creating the Input File

Once the netlist is generated, the HSPICE interface automatically translates the instance and net names in the *control*, *hspice.inp*, *hspice.sim*, and *netlist* files to legal names for HSPICE. When the translation completes, these files are assembled to create the HSPICE *si.inp* input file.

Running the Simulation

When the simulator input file (*si.inp*) is created, simulation starts. If the *simHost* variable is set to a different machine, the simulation runs remotely.

For more information about remote simulation, refer to [*Simulation Environment Help*](#).

Translating the Output

When the simulation is finished, the simulation interface translates net and instance names that were previously translated back to the original user-assigned names. The resulting translated text output is stored in the *si.out* file.

Viewing the Results

The simulation environment notifies you when analysis is complete so you can view the outputs. Information about the simulation run is recorded in the *si.log* file when a background simulation is run.

Hierarchical Netlisting

The hierarchical netlister produces a netlist that is easier to read and understand than one that has been flattened. For more information about flat netlisting, refer to [*Simulation Environment Help*](#). The following are primary features of a hierarchical netlist:

- The hierarchy of the netlist duplicates the hierarchy of your design. The netlister creates a separate subcircuit for each cell in your schematic. This can dramatically reduce the number of lines in the netlist, since the subcircuit definition is printed only once and all instances of the cell are netlisted as calls to the subcircuit.
- Unlike the flat netlister, which translates every instance and net name to a unique name, the hierarchical netlister translates only names that are illegal to HSPICE. To avoid naming conflicts, the hierarchical netlister makes every effort to keep the original user-assigned names in the netlist. When necessary, names are mapped, but the mapping is minimal. Characters that are illegal in HSPICE names are

. , () [] \$ ' < >

When any of these characters is found in a name, the character is automatically deleted. In some cases, the name is completely remapped. Usually this occurs when you have specified a name that is too long. HSPICE names are limited to eight characters. If a name is longer than eight characters, it is mapped by the interface.

When HSPICE maps the entire name, it assigns a unique number preceded by an *n* for net names, an *i* for instance names, and an *m* for macro and model names.

The first character of an element name in the netlist indicates the element type. The netlister automatically adds a prefix to all instance names. For example, MOSFET instance names are prefixed with *m*, and resistor names with *r*.

Primitive Cell Requirements

A cell must have both a *symbol* and an *hspice* view to be recognized by the HSPICE interface. The *hspice* view for a cell must contain the same pins that exist in the *symbol* view for the cell. For netlisting, define the following properties in the *hspice* view:

■ **NLPElementPostamble**

Indicates to the flat netlister how to format the element cards for an instance of the cell.

■ **NLPModelPreamble**

Indicates to the flat netlister how to format the model card for an instance of the cell.

■ **hnlHspiceFormatInst**

Indicates to the hierarchical netlister what procedure to call to format and print the element cards for an instance of the cell.

■ **hnlHspiceParamList**

Indicates to the hierarchical netlister what parameters can be inherited. The value of this parameter must be the name of a Cadence SKILL™ language variable, whose value is the list of parameters that can be inherited. Any parameter that does not appear on this list cannot inherit its value and must be assigned fixed values.

■ **hnlHspiceFormatModel**

Indicates to the hierarchical netlister what procedure to call to format and print the model card for an instance of the cell.

Example

The following are the property values for the above netlisting properties in the *hspice* view of the *nmos* cell in the *sample* library:

```
NLPElementPostamble = nlpExpr("[@NLPElementComment:%\n]
                             [ @NLPnmosElementCard]")
NLPModelPreamble = nlpExpr("[@NLPmosfetModelCard]")
hnlHspiceFormatInst = "hnlHspicePrintNMOSfetElement()"
hnlHspiceParamList = "hnlHspiceMOSfetParamList"
hnlHspiceFormatModel = "hnlHspicePrintMOSfetModel()"
```

The flat netlister uses expressions defined in the *nlpglobals* cell to format elements and models. The first two properties, therefore, tell the netlister to format the element and model cards with the *NLPnmosElementCard* and *NLPmosfetModelCard* expressions, defined in the *hspice* view of the *nlpglobals* cell.

HSPICE/SPICE Interface Reference

HSPICE Circuit Simulation Interface

For hierarchical netlisting, the element and model cards are formatted using the procedures defined in the *hspice* formater. For the *nmos* transistor, these procedures are called *hnlHspicePrintNMOSfetElement* and *hnlHspicePrintMOSfetModel*.

HSPICE/SPICE Interface Reference

HSPICE Circuit Simulation Interface

HSPICE/SPICE Elements

This chapter contains the following topics:

- HSPICE/SPICE Elements and Corresponding Library Cells

This section lists the HSPICE/SPICE elements and the corresponding cells in the sample library.

- HSPICE/SPICE Model and Element Parameters

This section has information about the library cells, terminal names, element and model parameters, for each HSPICE/SPICE element.

- Formatting Functions

This section has information about the formatting functions for each HSPICE/SPICE element.

HSPICE/SPICE Elements and Corresponding Library Cells

HSPICE/SPICE Element (Model Type)	Library Cell
R	res
R	resistor
C	cap
C	capacitor
C	pcapacitor
L	inductor
T	tline
G	soi.vc
G	vcisrc
E	sov.vc
E	vcvsrc
F	soi.ic
H	sov.ic
V	sov
V	vsrc
I	soi
I	isrc
D	diode
D	pdiode
Q(npn)	npn
Q(npn)	npns
Q(pnp)	pnp
Q(pnp)	pnps
J(njf)	njfet

HSPICE/SPICE Interface Reference

HSPICE/SPICE Elements

HSPICE/SPICE Element (Model Type)	Library Cell
J(pjf)	pjfet
M(nmos)	ndepl
M(nmos)	nfet
M(nmos)	nmos
M(nmos)	nmosd
M(nmos)	nmose
M(nmos)	nsftn
M(nmos)	nxfr
M(pmos)	pdepl
M(pmos)	pfet
M(pmos)	pmos
M(pmos)	pmosd
M(pmos)	pmose
M(pmos)	psftn
M(pmos)	pxfr

HSPICE/SPICE Model and Element Parameters

Resistor

HSPICE/SPICE Element: Resistor

Element Name: R

Used by Library Cells: *res, resistor*

Terminal Name	Level of Simulation	Direction
A	Circuit	inputOutput
Y	Circuit	inputOutput

HSPICE/SPICE Interface Reference

HSPICE/SPICE Elements

Element Parameter	Data Type	Units
r	float	ohms
tc	string	--

Capacitor

HSPICE/SPICE Element: Capacitor

Element Named: **C**

Used by Library Cells: *cap, capacitor, pcapacitor*

Terminal Name	Level of Simulation	Direction
Y	Circuit	inputOutput
gnd!	Circuit	inputOutput

Element Parameter	Data Type	Units
c	float	farads
ic	string	--

Inductor

HSPICE/SPICE Element: Inductor

Element Name: **L**

Used by Library Cell: *inductor*

Terminal Name	Level of Simulation	Direction
PLUS	Circuit	inputOutput
MINUS	Circuit	inputOutput

HSPICE/SPICE Interface Reference

HSPICE/SPICE Elements

Element Parameter	Data Type	Units
l	float	henrys
ic	string	--

Transmission Line

HSPICE/SPICE Element: Transmission Line

Element Name: T

Used by Library Cell: *tline*

Terminal Name	Level of Simulation	Direction
N1	Circuit	inputOutput
N2	Circuit	inputOutput
N3	Circuit	inputOutput
N4	Circuit	inputOutput

Element Parameter	Data Type	Units
z0	float	ohms
td	float	seconds
f	float	hertz
nl	float	unitless
ic	string	--

HSPICE/SPICE Interface Reference

HSPICE/SPICE Elements

Diode

HSPICE/SPICE Element: Diode

Element Name: D

Model Type: D

Used by Library Cell: *diode*

Terminal Name	Level of Simulation	Direction
PLUS	Circuit	inputOutput
MINUS	Circuit	inputOutput

Element Parameter	Data Type	Units
area	float	unitless
off	string	“off”
ic	string	--

Model Parameter	Data Type	Units
is	float	amperes
rs	float	ohms
n	float	unitless
tt	float	seconds
cjo	float	farads
vj	float	volts
m	float	unitless
eg	float	electronvolts
xti	float	unitless
kf	float	unitless
af	float	unitless
fc	float	unitless

HSPICE/SPICE Interface Reference

HSPICE/SPICE Elements

Model	Parameter	Data Type	Units
	ibv	float	amperes
	bv	float	volts

BJT

HSPICE/SPICE Element: BJT

Element Name: Q

Model Type: NPN, PNP

Used by Library Cells: *npn, npns, pnp, pnps*

Terminal Name	Level of Simulation	Direction
C	Circuit	inputOutput
B	Circuit	inputOutput
E	Circuit	inputOutput
SUB	Circuit	inputOutput

Element Parameter	Data Type	Units
area	float	unitless
off	string	"off"
ic	string	--

Model Parameter	Data Type	Units
is	float	amperes
bf	float	unitless
nf	float	unitless
ise	float	amperes
ne	float	unitless
br	float	unitless

HSPICE/SPICE Interface Reference

HSPICE/SPICE Elements

Model Parameter	Data Type	Units
nr	float	unitless
isc	float	amperes
nc	float	unitless
rb	float	ohms
rbm	float	ohms
re	float	ohms
rc	float	ohms
cje	float	farads
vje	float	volts
mje	float	unitless
tf	float	seconds
xtf	float	unitless
itf	float	amperes
ptf	float	degrees
cjc	float	farads
vjc	float	volts
mjc	float	unitless
xcjc	float	unitless
tr	float	seconds
cjs	float	farads
vjs	float	volts
mjs	float	unitless
xtb	float	unitless
eg	float	electronvolts
xti	float	unitless
kf	float	unitless
af	float	unitless

HSPICE/SPICE Interface Reference

HSPICE/SPICE Elements

Model Parameter	Data Type	Units
fc	float	unitless
vtf	float	volts
irb	float	amperes
ikr	float	amperes
var	float	volts
vaf	float	volts
ikf	float	amperes

JFET

HSPICE/SPICE Element: JFET

Element Name: J

Model Type: NJF, PJF

Used by Library Cells: *njfet*, *pjfet*

Terminal Name	Level of Simulation	Direction
D	Circuit	inputOutput
G	Circuit	inputOutput
S	Circuit	inputOutput

Element Parameter	Data Type	Units
area	float	unitless
off	string	“off”
ic	string	--

Model Parameter	Data Type	Units
vto	float	volts
beta	float	amperes/square volts

HSPICE/SPICE Interface Reference

HSPICE/SPICE Elements

Model Parameter	Data Type	Units
lambda	float	1/volts
rd	float	ohms
rs	float	ohms
cgs	float	farads
cgd	float	farads
pb	float	volts
is	float	amperes
kf	float	unitless
af	float	unitless
fc	float	unitless

MOSFET

HSPICE/SPICE Element: MOSFET

Element Name: M

Model Type: NMOS, PMOS

Used by Library Cells: *ndepl, nfet, nmos, mosd, nmose, nsftn, nxfr, pdepl, pfet, pmos, pmos, pmose, psftn, pxfr*

Terminal Name	Level of Simulation	Direction
D	Circuit	inputOutput
G	Circuit	inputOutput
S	Circuit	inputOutput
B	Circuit	inputOutput

Element Parameter	Data Type	Units
l	float	meters
w	float	meters

HSPICE/SPICE Interface Reference

HSPICE/SPICE Elements

Element Parameter	Data Type	Units
ad	float	square meters
as	float	square meters
pd	float	meters
ps	float	meters
nrd	float	unitless
nrs	float	unitless
off	string	“off”
ic	string	--

Model Parameter	Data Type	Units
level	integer	unitless
vto	float	volts
kp	float	amperes/volts squared
gamma	float	volts**0.5
phi	float	volts
lambda	float	1/volts
rd	float	ohms
rs	float	ohms
cbd	float	farads
cbs	float	farads
is	float	amperes
pb	float	volts
cgso	float	farads/meter
cgdo	float	farads/meter
cgbo	float	farads/meter
rsh	float	ohms/square

HSPICE/SPICE Interface Reference

HSPICE/SPICE Elements

Model Parameter	Data Type	Units
cj	float	farads/square meter
mj	float	unitless
cjsw	float	farads/meter
mjsw	float	unitless
js	float	amperes/square meter
tox	float	meters
nsub	float	1/cubic centimeters
nss	float	1/square centimeters
nfs	float	1/square centimeters
tpg	integer	unitless
xj	float	meters
ld	float	meters
uo	float	square centimeters/volt seconds
ucrit	float	volts/centimeter
uexp	float	unitless
utra	float	unitless
vmax	float	meters/second
neff	float	unitless
xqc	float	unitless
kf	float	unitless
af	float	unitless
fc	float	unitless
delta	float	unitless
theta	float	1/volts
eta	float	unitless
kappa	float	unitless

Formatting Functions

This section describes the formatting functions included with the HSPICE/SPICE interface. The cells in the *sample* library that use these formatting functions are also listed. The syntax for these formatting functions is that of the *nlpglobal* functions, but the same parameters are also defined in the *hspice* formatter for hierarchical netlisting.

This section uses the following notations:

<...>	name in the brackets is an identifier
{...}	item(s) in braces can be repeated as many times as necessary
[...]	item(s) in brackets are optional
@name	value of property name is substituted

Element Formats

Below is the list of HSPICE/SPICE elements and their formats:

res

r<name> <A> <Y> @r @ns @tc1 @tc2 @scale @rsh ac=@ac m=@m

The *res* cell in the *sample* library uses this format.

resistor

r<name> <PLUS> <MINUS> @r @ns @tc1 @tc2 @scale @rsh ac=@ac m=@m

The *resistor* cell in the *sample* library uses this format.

cap

c<name> <Y> gnd! @c @ns @tc1 @tc2 @scale @cj ic=@ic m=@m

The *cap* cell in the *sample* library uses this format.

capacitor

c<name> <PLUS> <MINUS> @c @ns @tc1 @tc2 @scale @cj ic=@ic m=@m

The *capacitor* and *pcapacitor* cells in the *sample* library use this format.

HSPICE/SPICE Interface Reference

HSPICE/SPICE Elements

inductor

```
l<name> <PLUS> <MINUS> @l @tc1 @tc2 @nt ic=@ic
```

The *inductor* cell in the *sample* library uses this format.

transmission line

```
t<name> <N1> <N2> <N3> <N4> z0=@z0 td=@td f=@f nl=@nl ic=@ic
```

The *tline* cell in the *sample* library uses this format.

diode

```
d<name> <PLUS> <MINUS> <cellName> w=@w l=@l area=@area pj=@pj wp=@wp lp=@lp wm=@wm  
lm=@lm @off ic=@ic m=@m
```

The *diode* and *pdiode* cells in the *sample* library use this format.

BJT

```
q<name> <C> <B> <E> <SUB> <cellName> area=@area @off ic=@ic m=@m
```

The *npns* and *pnps* cells in the *sample* library use this format.

JFET

```
j<name> <D> <G> <S> <cellName> area=@area w=@w l=@l @off ic=@ic m=@m
```

The *njfet* and *pjfet* cells in the *sample* library use this format.

MOSfet

```
m<name> <D> <G> <S> <B> <cellName> w=@w l=@l ad=@ad as=@as pd=@pd ps=@ps nrd=@nrd  
nrs=@nrs off" off ic=@ic m=@m
```

The *ndepl*, *nfet*, *nsftn*, *pdepl*, *pfet*, and *psftn* cells in the *sample* library use this format.

NMOSfet

```
m<name> <D> <G> <S> gnd! <cellName> w=@w l=@l ad=@ad as=@as pd=@pd ps=@ps nrd=@nrd  
nrs=@nrs off" off ic=@ic m=@m
```

The *nxfr*, *nmos*, *nmosd*, and *nmose* cells in the *sample* library use this format.

HSPICE/SPICE Interface Reference

HSPICE/SPICE Elements

NPN

```
q<name> <C> <B> <E> vee! <cellName> area=@area off" off ic=@ic m=@m
```

The *npn* cell in the *sample* library uses this format.

PMOSfet

```
"m<name><D> <G> <S> vdd! <cellName> w=@w l=@l ad=@ad as=@as pd=@pd ps=@ps nrd=@nrd  
nrs=@nrs off" off ic=@ic m=@m
```

The *pxfr*, *pmos*, *pmosd*, and *pmose* cells in the *sample* library use this format.

PNP

```
"q<name> <C> <B> <E> vcc! <cellName> @area off" off ic=@ic m=@m
```

The *pnp* cell in the *sample* library uses this format.

Model Format

Below is the list of HSPICE/SPICE models and their model card format.

Diode

```
.model <cellName> d level=@level area=@area eg=@eg is=@is jsw=@jsw n=@n pj=@pj  
tlew=@tlew xti=@xti ibv=@ibv tcv=@tcv vb=@vb af=@af kf=@kf rs=@rs trs=@trs  
cjo=@cjo cjp=@cjp cta=@cta ctp=@ctp fc=@fc fcs=@fcs m=@m mjsw=@mjsw pb=@pb  
php=@php tt=@tt ef=@ef er=@er jf=@jf jr=@jr w=@w l=@l tox=@tox wm=@wm lm=@lm  
wp=@wp lp=@lp xm=@xm xp=@xp xoi=@xoi xom=@xom
```

The *diode* and *pdiode* cells in the *sample* library use this format.

BJT

```
.model <cellName> @modelType bf=@bf br=@br bulk=@bulk eg=@eg is=@is iss=@iss nf=@nf  
nr=@nr subs=@subs isc=@isc ise=@ise nc=@nc ne=@ne vaf=@vaf var=@var ikf=@ikf  
ikr=@ikr irb=@irb rb=@rb rbm=@rbm re=@re rc=@rc cjc=@cjc cje=@cje cjs=@cjs  
fc=@fc mjc=@mjc mje=@mje mjs=@mjs vjc=@vjc vje=@vje vjs=@vjs xcjc=@xcjc  
itf=@itf ptf=@ptf tf=@tf tr=@tr vtf=@vtf xtf=@xtf tlev=@tlev tre1=@tre1  
tre2=@tre2 trb1=@trb1 trb2=@trb2 trc1=@trc1 trc2=@trc2 trm1=@trm1 trm2=@trm2  
xtb=@xtb xti=@xti af=@af kf=@kf
```

The *npn*, *npns*, *pnp*, and *pnps* cells in the *sample* library use this format.

HSPICE/SPICE Interface Reference

HSPICE/SPICE Elements

JFET

```
.model <cellName> @modelType level=%s" level a=@a alpha=@alpha beta=@beta d=@d  
  gamds=@gamds lambda=@lambda w=@w l=@l wdel=@wdel ldel=@ldel tcv=@tcv vto=@vto  
  eg=@eg gap1=@gap1 gap2=@gap2 is=@is n=@n ni=@ni xti=@xti af=@af kf=@kf rd=@rd  
  rg=@rg rs=@rs trd=@trd trg=@trg trs=@trs cgd=@cgd cgs=@cgs fc=@fc m=@m pb=@pb  
  capop=@capop ctd=@ctd cts=@cts tt=@tt bex=@bex lam1=@lam1 nchan=@nchan  
  sat=@sat ucrit=@ucrit vbi=@vbi vgexp=@vgexp vp=@vp tlev=@tlev tlevc=@tlevc  
  tpb=@tpb
```

The *njfet* and *pjfet* cells in the *sample* library use this format.

MOSfet

```
.model <cellName> @modelType level=@level vto=@vto nss=@nss tpg=@tpg phi=@phi  
  gamma=@gamma nsub=@nsub bulk=@bulk bex=@bex kp=@kp lambda=@lambda  
  ecrit=@ecrit neff=@neff nfs=@nfs ucrit=@ucrit uexp=@uexp uo=@uo utra=@utra  
  vmax=@vmax xj=@xj ld=@ld theta=@theta clm=@clm dns=@dns fds=@fds mbl=@mb1  
  mob=@mob nu=@nu nwe=@nwe nwm=@nwm scm=@scm tcv=@tcv ufds=@ufds vbo=@vbo  
  vfds=@vfds vsh=@vsh wic=@wic fl=@fl mob=@mob af=@af kf=@kf cgbo=@cgbo  
  cgdo=@cgdo cgso=@cgso cox=@cox meto=@meto tox=@tox wd=@wd capop=@capop  
  cf1=@cf1 cf2=@cf2 cf3=@cf3 cf4=@cf4 cf5=@cf5 cf6=@cf6 alpha=@alpha is=@is  
  js=@js jsw=@jsw vcr=@vcr cbd=@cbd cbs=@cbs cj=@cj cjsw=@cjsw mj=@mj mjsw=@mjsw  
  pb=@pb php=@php ldif=@ldif rd=@rd rs=@rs rsh=@rsh trd=@trd trs=@trs  
  delta=@delta kappa=@kappa eta=@eta
```

The *ndepl*, *nfet*, *nmos*, *nmosd*, *nmose*, *nsftn*, *nxfr*, *pdepl*, *pfet*, *pmos*, *pmosd*, *pmose*, *psftn*, and *pxfr* cells in the *sample* library use this format.

Index

C

circuit simulation interfaces [5](#)
commands, create new run [9](#)
create new run command [9](#)

E

elements, HSPICE/SPICE [26](#)

F

files
 HSPICE
 control [19](#)
 hspice.inp [19](#), [20](#)
 hspice.sim [19](#)
 si.log [21](#)
 si.out [21](#)
 SPICE
 control [10](#)
 netlist [11](#), [12](#)
 spice.inp [11](#)
 spice.sim [11](#)
formatting functions [37](#)
 element format [37](#)
 model format [39](#)

H

HSPICE
 primitive cell requirements [22](#)

L

library cells [26](#)

M

model and element parameters [27](#)

N

netlisting
 HSPICE
 hierarchical [21](#)
 name mapping [21](#)
 netlisting properties [22](#)
variables
 simNetlistHier [20](#)

P

properties, HSPICE
 netlisting [22](#)

S

simulation models [27](#)
simulation run example, SPICE [10](#)

V

variables, HSPICE
 simHost [20](#)

W

waveform, SPICE [9](#)