


DRAM - Basic Knowledge


Purdue SoCET - AI Hardware - DRAM Controller team. Studied with [this](#) webpage.

Basic IO



- Dual Function Address Bits
 - **RAS_n**: Row Address Strobe
 - **CAS_n**: Column Address Strobe
 - **WE_n**: Write Enable Strobe
 - During Activation (**ACT_n**=0). They are used as row addressing, **A0-16**
 - During R/W/Pre (**ACT_n**=1). They combinationally define what function is operating. At the same time, other address bits will determine the column selection
- Posedge of **CK_t** and negedge of **CK_c**: All address & control signals are sampled at crossing to have exact timing
- Posedge of **DQS_t** and negedge of **DQS_c**: also differential property as **CK**. Data is sampled at both edges, into **DQ**
- **DQ**: Carry actual data bits. Same width as column width. **x4** means **DQ[3:0]**; **x8** means **DQ[7:0]**; **x16** means **DQ[15:0]**
- **CAS Latency**: latency from read to **DQ**. **CAS Write Latency** is for write

Bankgroups and Banks



- cmd/addr: select address and commands
- local IO: communicate with sense amplifier
- global IO: connect BG# into DQ

Single Storage Structure

- wordline: row; bitline: column
- Need to be refreshed: why it is called **Dynamic RAM**
- Steps:
 1. Activate; row select
 2. R/W; column select
 3. Pre-charge: close the row
 4. RDA (Read Auto-Precharge) / WRA (Write Auto-Precharge): can combine 2 & 3
- Write / Read are **Burst Oriented**

Total DRAM Capacity Calculation

- $Total_Capacity = num_row * num_col * width_col * num_BG * num_bank$
- $Page_size = num_col * width_col = \text{number of bits per row}$


Example: row=A0-16; column=A0-A9; Width_col: x4; BG=4; num_bank=4.

We can calculate:

$$Total_Capacity = 2^{16} * 2^{10} * 4 * 4 * 4 = 4 \text{ GB}$$

$$Page_Size = 2^{10} * 4 = 4 \text{ KB}$$

DRAM Sub-system



- User Logic: send logic address and R/W request
- Controller: parse the logic address to physical address, and issue commands (like basic IO above) to DDR PHY
- PHY: actual signal send to DRAM

ZQ Calibration

This can be used to calibrate internal banks of 240 ohm resistor, connected to DQ# pins, with external reference resistor.

Vref DQ Calibration

Standard Reference (JEDEC)

- 2.7 Pinout Description
- 3.# Functions
 - 3.1 Functional State Diagram
 - 3.3 Initialization Process
 - 3.5 Mode Register: set up different things
- 4.1 Commands