

HELVARNET PROTOCOL

Connection

To establish a TCP connection and therefore communicate with the router, the third-party device is required to connect to listener port number **50000**. When using the UDP protocol, the third-party device is required to send a message to destination port number **50001** in the router.

Routing entries of the following type allow generic data transmission over Ethernet:

- ETHERNET TRANSMIT triggered by a group / block / [scene](#) recall: This causes transmission of a generic string, from a single [router](#) .

When the entry is triggered, a connection to the third party [device](#) is instigated from the router. The [IP address](#) and port to which the connection to the third-party device is made is determined from the routing entry's configuration:

- To send [TCP](#) messages from the router to the third-party device, the router connects to a listener port provided in the third-party device. It is recommended that this listener port is in the range of 49152 to 65535.
- To send [UDP](#) messages from the router to the third-party device, it is recommended that the destination port in the third-party device is in the range of 49152 to 65535.
- Additionally, the IP address of the router that is responsible for the transmission of the generic string also needs to be configured.

System Access and Message Routing

Messages from the third-party [device](#) can be targeted at any [router](#) in the system.

If access has not been granted or has been blocked to a particular router, then communications can still be achieved to that router via any other router in the system, provided that you have the [IP address](#) of another router and the third-party device is allowed access to it.

If a query message needs to be sent to a router for which access has not been granted, then the query message can be sent to any of the alternative routers, following this the response to the query – the query reply message – will be returned by the router to which the query was originally sent.

Message Format

Any message sent to, or received from, a router can be in either ASCII or raw binary form (see Command Format for more information). Messages must not exceed the maximum length of 1500 bytes. The format of the data contained within messages is defined by the protocol. A query reply message from the router will be in the same format as the query command message sent i.e. if a query message is sent in ASCII form then the reply will also be in ASCII. Throughout

this document, ASCII format examples will be used. **Push Messages** are internally generated messages from routers to external HelvarNet clients. **Device Types in Helvar: Routers (905 Digidim Router, 910 Digidim Router, 920 Imagine Router,** Ballasts, Button Panels (Modular Control Panels), Converters, DALI Controller, Dimmers, HID, Input Units, IR Receiver Panel (170), LED Drivers, Remote Control Handset, Rotary Switch, Sensors, Sliders, Switching Units

Network Topology

A topology is a description of the arrangement of the various elements (nodes, connecting lines, etc.) of a communication network.

There are two types of network topology that can be applied to a [router](#) :

- single cluster
- multicluster

The following sections describe what these topologies are and which one you should use.

Single cluster and multicluster

A cluster is a collection of routers that work together or have some common locational element. For example, in a large building with several floors, all routers on a single floor could belong to the same cluster; routers on another floor could belong to another cluster; and so on.

Note: A cluster could also map to a logical network strategy. For example, on a layer 3 network, if routers are assigned on different IP subnets, clusters can be mapped directly on to those subnets. Clients are no longer part of the clustering system. They can be located anywhere on the network.

We recommend that a single cluster should contain no more than 30 routers.

Which topology type to use

First, the type of topology depends on how many routers the system has:

- Use single cluster for systems with no **more than 30 routers**.
- Use multicluster for systems with **30 routers** or more.

Second, the type of topology depends on whether communications between the routers is confined to a logical IP subnet or spans multiple IP subnets.

- If the IP network is a layer 2 network, the router system can constitute a single cluster or multiple clusters.
- If the IP network is a **layer 3** network and the router communications are **confined to a logical IP subnet**, the router system can be made up of a single cluster or multiple clusters.

- If the IP network is a **layer 3** network and the router communications are required to **traverse across logical IP subnets**, the routers system will contain multiple clusters.

Same IP subnet

Members of a cluster must reside on the same IP subnet as the other members of the same cluster.

Defining a cluster and its members

The cluster is determined by allocating a portion of the IP to be the cluster's identifier. This portion, which must lead from the left, is determined by the accompanying setting called 'cluster mask'.

This mask is very similar to the subnet mask and follows the same IP masking rules. The cluster member is determined by the part of the IP address that is masked out by the cluster mask.

Examples:

- A router with an IP address of 192.168.1.1 with a cluster mask of 255.255.255.0 has a cluster identifier of 192.168.1.0 and a cluster member identifier of 0.0.0.1.
- A router with an IP address of 172.28.228.10 with a cluster mask of 255.255.255.0 has a cluster identifier of 172.28.228.0 and a cluster member identifier of 0.0.0.1.
- A router with an IP address of 172.28.228.10 with a cluster mask of 255.255.0.0 has a cluster identifier of 172.28.0.0 and a cluster member identifier of 0.0.228.10.
- A router with an IP address of 10.254.0.1 with a cluster mask of 255.255.255.0 has a cluster identifier of 10.254.0.0 and a cluster member identifier of 0.0.0.1.
- A router with an IP address of 10.254.0.1 with a cluster mask of 255.255.0.0 has a cluster identifier of 10.254.0.0 and a cluster member identifier of 0.0.0.1.
- A router with an IP address of 10.254.0.1 with a cluster mask of 255.0.0.0 has a cluster identifier of 10.0.0.0 and a cluster member identifier of 0.254.0.1.

Note: The default cluster mask of 255.255.255.0 will suffice for most network addressing strategies.

Command Table

Commands can be sent in either ASCII (text) or raw format. In ASCII format, the commands are split into parameters and in raw format the commands are split into binary Words which contain the parameters.

Each command contains:

- a command number.
- parameters that address devices or lighting operations.
- parameters that are required to accompany the commands.

ASCII Format

The ASCII format requires that certain rules concerning special characters, parameter identifiers, and delimiters be adhered to. These rules are as follows:

1. The ASCII string must begin with the command character '>' and end with the Terminator character '#'.
2. Replies to queries begin with the character '?' and the data concerning a query's response is separated from the query string using the character '='. Similarly, the whole query response string is terminated with the character '#' that signals the end of the reply, or '\$' that signals the end of a partial response. For example, a response that contains more data than the maximum message size would be split into 2 responses. The first partial response would be terminated by '\$', and the second partial response would be terminated by '#'.
3. Error / Diagnostic messages begin with the character '!' and, again, end in '#'.
4. Unless they are optional, all of the parameters required for the command must be included; otherwise the message is rejected and discarded.
5. The ASCII parameters are not required to be ordered.
6. The parameter identifiers are to be included as shown in the following table, i.e. all alphabetic identifiers should be in upper case.

Description	Character	Optional	Hex	Character Type
Command	>	No	0x3E	Message Type
Internal Command	<	No	0x3C	Message Type
Reply	?	No	0x3F	Message Type
Error / Diagnostic	!	No	0x21	Message Type
Terminator	#	No	0x23	Special
Partial reply terminator	\$	No	0x24	Special
Answer	=	No	0x3D	Special
Delimiter	,	No	0x2C	Delimiter
Parameter ID Delimiter	:	No	0x3A	Delimiter
Address Delimiter	.	No	0x2E	Delimiter

Sequence Number	Q	For internal commands only	0x51	Parameter ID
HelvarNet Version	V	Version 1 only (assumes version 1)	0x56	Parameter ID
Command	C	No	0x43	Parameter ID
Acknowledgment	A	Yes (assumes a value of 0)	0x41	Parameter ID
Address	@	No	0x40	Parameter ID
Group	G	Yes (assumes a value of 1)	0x47	Parameter ID
Scene	S	Yes (assumes a value of 1)	0x53	Parameter ID
Block	B	Yes (assumes a value of 1)	0x42	Parameter ID
Fade Time	F	Yes (assumes 700ms)	0x46	Parameter ID
Level	L	No	0x4C	Parameter ID
Proportion	P	No	0x50	Parameter ID
Display Screen	D	No	0x44	Parameter ID
Time	T	No	0x54	Parameter ID
Latitude	N	No	0x4E	Parameter ID
Longitude	E	No	0x45	Parameter ID

Time Zone Difference	Z	No	0x5A	Parameter ID
Daylight Saving Time (DST)	Y	No	0x59	Parameter ID
Constant Light Scene	K	Yes (assumes false)	0x4B	Parameter ID
Force Store Scene - Intensity	O	Yes (assumes false)	0x4F	Parameter ID
Force Store Scene - Colour	H	Yes (assumes false)	0x48	Parameter ID
Colour X	CX	Yes (assumes false)	0x4358	Parameter ID
Colour Y	CY	Yes (assumes false)	0x48	Parameter ID
Mireds	M	Yes (assumes false)	0x4D	Parameter ID
Colour Ignore	CI	Yes (assumes false)	0x4349	Parameter ID
Device Category	DC	Yes (assumes false)	0x4443	Parameter ID

For example, in the command Recall Group 1234, Block 5, Scene 6, Fade Time 32 s, the string is sent as follows, including the delimiters and the start character '>' and stop character '#':

>V:1,C:11,G:1234,B:5,S:6,F:3200#

Configuration Commands

201 - Store Scene (Group)

Set the scene level for channels in the specified group. **If the 'Force' flag is clear, channels with 'ignore' already stored in the Scene Table are not affected.**

Command

Command (201), Group (1..16383), Force Store (1=ON, 0=OFF) / Block (1..8) / Scene (1..16), Level (0..100)

ASCII Example

To store an output level of 75% as scene 5 in scene block 2, across group 17:

```
>V:1,C:201,G:17,O:1,B:2,S:5,L:75#
```

202 - Store Scene (Channel)

Set the scene level for the channel.

Special values for the L Parameter

253: Last Level

254: Ignore

If the Force flag is clear and 'ignore' is already stored in the Scene Table for the channel, then the scene is not stored.

Command

Command (202), Cluster (1..253) / Router (1..254), [Subnet](#) (1..4) / Device (1..255), Force Store (1=ON, 0=OFF) / Block (1..8) / Scene (1..16), Level (0..100)

ASCII Example

To store an output level of 75% as scene 5 in scene block 2, at channel 2.2.1.1:

```
>V:1,C:202,@2.2.1.1,O:1,B:2,S:5,L:75#
```

203 - Store As Scene (Group)

Stores the current levels of channels in the group into the specified block / scene. **If the 'Force' flag is clear, channels with 'ignore' already stored in the Scene Table are not affected.**

Command

Command (203), Group (1..16383), Force Store (1=ON, 0=OFF) / Block (1..8) / Scene (1..16)

ASCII Example

To store the current levels of all channels in group 17 as scene 5 in scene block 2:

```
>V:1,C:203,G:17,O:1,B:2,S:5#
```

204 - Store As Scene (Channel)

Stores the current level of the channel into the specified block / scene. **If the Force flag is clear and 'ignore' is already stored in the Scene Table for the channel, then the scene is not stored.**

Command

Command (204), Cluster (1..253) / Router (1..254), [Subnet](#) (1..4) / Device (1..255), Force Store (1=ON, 0=OFF) / Block (1..8) / Scene (1..16), Level (0..100)

ASCII Example

To store the current level of channel 2.2.1.1 as scene 5 in scene block 2:

```
>V:1,C:204,@2.2.1.1,O:1,B:2,S:5#
```

205 - Reset Emergency Battery and Total Lamp Time (Group)

Reset the Emergency Battery and Total Lamp Time across a group.

Note: This command has no effect if sent to a group containing non-emergency devices.

Command

Command (205), Group (1..16383)

ASCII Example

To reset the Emergency Battery Time and Total Lamp time across group 56:

```
>V:1,C:205,G:56#
```

206 - Reset Emergency Battery and Total Lamp Time (Device)

Reset the Emergency Battery and Total Lamp Time at a device.

Note: This command has no effect if sent to a non-emergency device.

Command

Command (206), Cluster (1..253) / Router (1..254), Subnet (1..4) / Device (1..255)

ASCII Example

To reset the Emergency Battery Time and Total Lamp time of an emergency lighting ballast at address 8.67.2.37:

>V:1,C:206,@8.67.2.37#

Name	Parameters				
Store Scene (Group)	Command Number 201	Group 1..16383	Force Store Block 1..8 Scene 1..16	Level 0..100%	
Store Scene (Device)	Command Number 202	Cluster 1..253 Router 1..254	Subnet 1..4 Device 1..255	Force Store Block 1..8 Scene 1..16	Level 0..100% Special values: 253=Last Level; 254=Ignore
Store As Scene (Group)	Command Number 203	Group 1..16383	Force Store Block 1..8 Scene 1..16		
Store As Scene (Device)	Command Number 204	Cluster 1..253 Router 1..254	Subnet 1..4 Device 1..255	Force Store Block 1..8 Scene 1..16	
Reset Emergency Battery and Total Lamp Time (Group)	Command Number 205	Group 1..16383			

Control Commands

11 - Recall Scene (Group)

Send a [scene](#) recall across a group.

Note:

- To call a constant light scene, use the Constant Light flag (with a parameter value of 1).

Command

Command (11), Group (1..16383), Block (1..8), Scene (1..16), Constant Light (1=ON, 0=OFF), Fade Time (0..6553.5s)

ASCII Example

To recall constant light scene 5 in scene block 2, across group 17, with a fade time of 90 seconds:

```
>V:1,C:11,G:17,K:1,B:2,S:5,F:9000#
```

12 - Recall Scene (Device)

Send a scene recall to a device .

Note: This command should not be sent to any device other than a [load](#) (control gear). Otherwise you will receive a diagnostic response if one was requested.

Command

Command (12), Cluster (1..253), Router (1..254), [Subnet](#) (1..4), Device (1..255), Block (1..8), Scene (1..16), Fade Time (0..6553.5s)

ASCII Example

To recall scene 4 in scene block 7, in a device at address 1.2.3.4, with a fade time of 1 second:

```
>V:1,C:12,B:7,S:4,F:100,@1.2.3.4#
```

13 - Direct Level (Group)

Change the output level of all channels in a group.

Command

Command (13), Group (1..16383), Level (0..100), Fade Time (0..6553.5s)

ASCII Example

To change the output level to 60 % across group 17, with a fade time of 90 seconds:

```
>V:1,C:13,G:17,L:60,F:9000#
```

14 - Direct Level (Device)

Change the level of a load .

Command

Command (14), Cluster (1..253) / Router (1..254), Subnet (1..4) / Device (1..255), Level (0..100), Fade Time (0..6553.5s)

ASCII Example

To change the output level to 60 % in a device at address 1.2.3.4, with a fade time of 90 seconds:

```
>V:1,C:14,L:60,F:9000,@1.2.3.4#
```

Proportion Control Commands

When sending a 'Direct Proportion' value, this value relates to a proportion of the difference between the last recalled scene level or direct level and the output limits of the device.

When sending a positive value, this is a proportion of the difference of said level and 100 % level. For example, if the last recalled scene level or direct level is 44 % and you send a 'Direct Proportion at 50%' command, then the level rises from 44 % to 72 % ($100 - 44 = 56$; $56 \times 50 \% = 28$; $28 + 44 = 72$).

When sending a negative proportion value, this is a proportion of the difference of the last recalled scene or direct level and 0 %, which so happens to be a proportion of the level itself. For example, if the level is at 44 % and you send a command to perform the 'Direct Proportion' function at -50 %, then the level decreases to 22 % (i.e. 50 % of 44 %).

Notes:

- The range for the 'Direct Proportion' and 'Modify Proportion' functions is -100 % to 100%.
- Any succeeding 'Direct Proportion' commands will also use the last recalled scene or direct level as a base mark.

When sending a 'Modify Proportion' value, the same formula applies, only you are changing the currently applied 'Direct Proportion' value.

Take the example above resulting in a 'Direct Proportion' level of 72 %. If you send a 'Modify Proportion at 5 %' command, then the level rises from 72 % to approx. 75 % ($100 - 44 = 56$; $56 \times 55 \% = 30.8$; $30.8 + 44 = 74.8$).

When sending a negative value, the formula subtracts that value from the 'Direct Proportion' level e.g. Still using the same example, if you send 'Modify Proportion at -5 %' command, then

the level decreases from 72% to approx. 69 % ($100 - 44 = 56$; $56 \times 45 \% = 25.2$; $25.2 + 44 = 69.2$).

15 – Direct Proportion (Group)

Send a ‘Direct Proportion’ message across a group ($\pm 100 \%$).

Command

Command (15), Group (1..16383), Proportion ($-100..100$), Fade Time (0..6553.5s)

ASCII Example

To send a direct proportion of 72 % across group 17 (with a fade time of 90 seconds):

```
>V:1,C:15,P:72,G:17,F:9000#
```

16 - Direct Proportion (Device)

Send a ‘Direct Proportion’ message to a load ($\pm 100\%$).

Command

Command (16), Cluster (1..253) / Router (1..254), Subnet (1..4), Device (1..255), Proportion ($-100..100$), Fade Time (0..6553.5s)

ASCII Example

To send a direct proportion of 72% in a device at address 1.2.3.4 (with a fade time of 90 seconds):

```
>V:1,C:16,P:72,F:9000,@1.2.3.4#
```

17 - Modify Proportion (Group)

Modify a ‘Direct Proportion’ level sent to a group ($\pm 100 \%$).

Command

Command (17), Group (1..16383), Proportion Change ($-100..100$), Fade Time (0..6553.5s)

ASCII Example

To send a modify proportion of 5 % across group 17, with a fade time of 90 seconds:

```
>V:1,C:17,P:5,G:17,F:9000#
```

18 - Modify Proportion (Device)

Modify a 'Direct Proportion' level sent to a load ($\pm 100\%$).

Command

Command (18), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Proportion Change (-100..100), Fade Time (0..6553.5s)

ASCII Example

To send a modify proportion of 5 % in a device at address 1.2.3.4, with a fade time of 90 seconds:

```
>V:1,C:18,P:5,F:9000,@1.2.3.4#
```

Emergency Test Control Commands

Emergency Test commands should only be sent to [DALI](#) emergency lighting ballasts, otherwise the emergency test will not be performed. **See [DALI Emergency Lighting](#) for more information about emergency lighting and how to test it.**

Note:

- Starting or stopping an Emergency Test will cause the corresponding 'Test Done' flag to be cleared.

19 - Emergency Function Test (Group)

Request an Emergency Function Test across a group.

Note:

- This command has no effect if sent to a group containing non-emergency devices.

Command

Command (19), Group (1..16383)

ASCII Example

To request an Emergency Function Test across group 56:

```
>V:1,C:19,G:56#
```

20 - Emergency Function Test (Device)

Request an Emergency Function Test to an emergency lighting ballast.

Note:

- This command has no effect if sent to a non-emergency device.

Command

Command (20), Cluster (1..253) / Router (1..254), Subnet (1..4) / Device (1..255)

ASCII Example

To request an Emergency Function Test to an emergency lighting ballast at address 8.67.2.37:

```
>V:1,C:20,@8.67.2.37#
```

21 - Emergency Duration Test (Group)

Request an Emergency Duration Test across a group.

Note:

- This command has no effect if sent to a group containing non-emergency devices.

Command

Command (21), Group (1..16383)

ASCII Example

To request an Emergency Duration Test across group 56:

```
>V:1,C:21,G:56#
```

22 - Emergency Duration Test (Device)

Request an Emergency Duration Test to an emergency lighting ballast.

Note:

- This command has no effect if sent to a non-emergency device.

Command

Command (22), Cluster (1..253) / Router (1..254), Subnet (1..4) / Device (1..255)

ASCII Example

To request an Emergency Duration Test to an emergency lighting ballast at address 8.67.2.37:

```
>V:1,C:22,@8.67.2.37#
```

23 - Stop Emergency Tests (Group)

Stop all Emergency Tests across a group.

Note:

- This command has no effect if sent to a group containing non-emergency devices.

Command

Command (23), Group (1..16383)

ASCII Example

To stop all Emergency Tests across group 56:

```
>V:1,C:23,G:56#
```

24 - Stop Emergency Tests (Device)

Stop any Emergency Test running in an emergency ballast.

Note:

- This command has no effect if sent to a non-emergency device.

Command

Command (24), Cluster (1..253) / Router (1..254), Subnet (1..4) / Device (1..255)

ASCII Example

To stop any Emergency Test to an emergency lighting ballast at address 8.67.2.37:

```
>V:1,C:24,@8.67.2.37#
```

Command Type	Command Number	Target	Additional Parameters	Fade Time
Recall Scene (Group)	11	Group 1..16383	CL 1 or 0, Block 1..8, Scene 1..16	0..6553.5s
Recall Scene (Device)	12	Cluster 1..253, Router 1..254	Subnet 1..4, Device 1..255, Block 1..8, Scene 1..16	0..6553.5s
Direct Level (Group)	13	Group 1..16383	Level 0..100%	0..6553.5s
Direct Level (Device)	14	Cluster 1..253, Router 1..254	Subnet 1..4, Device 1..255, Level 0..100%	0..6553.5s
Direct Proportion (Group)	15	Group 1..16383	Proportion 0..100%	0..6553.5s
Direct Proportion (Device)	16	Cluster 1..253, Router 1..254	Subnet 1..4, Device 1..255, Proportion 0..100%	0..6553.5s
Modify Proportion (Group)	17	Group 1..16383	Proportion Change - 100..100%	0..6553.5s
Modify Proportion (Device)	18	Cluster 1..253, Router 1..254	Subnet 1..4, Device 1..255, Proportion Change - 100..100%	0..6553.5s
Emergency Function Test (Group)	19	Group 1..16383		
Emergency Function Test (Device)	20	Cluster 1..253, Router 1..254	Subnet 1..4, Device 1..255	
Emergency Duration Test (Group)	21	Group 1..16383		
Emergency Duration Test (Device)	22	Cluster 1..253, Router 1..254	Subnet 1..4, Device 1..255	
Stop Emergency Tests (Group)	23	Group 1..16383		
Stop Emergency Tests (Device)	24	Cluster 1..253, Router 1..254	Subnet 1..4, Device 1..255	

HelvarNet Errors/Diagnostics

The routers are capable of providing useful diagnostic information for all possible Ethernet I/O messages received from a 3rd party [device](#) . The diagnostic response can provide information concerning whether a message was successful, was invalid or was not appropriate for a specified address.

Successful queries will simply be replied with the answer.

However, if the query is invalid or does not contain the correct parameters then an error diagnostic will be returned, instead of the expected answer, with the original query.

For lighting or configuration commands diagnostic information is available on demand and is achieved by specifying that you want this information returned using the Ethernet I/O 'Acknowledgment' feature.

In the ASCII format this will mean attaching the parameter ID 'A' with a parameter value of 1 or in the RAW format by switching the 'Acknowledgment' flag on in the command word.

The following table shows you the raw value and ASCII description for each error message:

Raw Value	ASCII Description
0	Success
1	Error - Invalid group index parameter
2	Error - Invalid cluster parameter
3	Error - Invalid router parameter
4	Error - Invalid subnet parameter
5	Error - Invalid device parameter
6	Error - Invalid sub device parameter
7	Error - Invalid block parameter
8	Error - Invalid scene parameter
9	Error - Cluster does not exist
10	Error - Router does not exist
11	Error - Device does not exist
12	Error - Property does not exist
13	Error - Invalid RAW message size
14	Error - Invalid messages type
15	Error - Invalid message command
16	Error - Missing ASCII terminator
17	Error - Missing ASCII parameter
18	Error - Incompatible version

The error message contains the command data which was sent, followed by the data concerning the erroneous command. *See below for an example error message in ASCII and raw formats.*

Example ASCII Format

If you send the following Query Device type command:

>V:1,C:104,@:2.2.1.1#

If the device does not exist, then the reply will be:

!V:1,C:104,@:2.2.1.1=11#

Query Commands

General Query Commands

101 - Query Clusters

When you send a Query Clusters command, the reply provides you with all the Cluster IDs that exist in the system.

Command

Send: Command (101)

Reply

Returns a bit field indicating the presence of all clusters:

Command (101), Cluster Count, 8x32 bit Words detailing the existence of the clusters 1-253 (bits 0, 254, 255 are always zero)

ASCII Example

If you send the following Query Clusters command:

>V:1,C:101#

If there are clusters 1, 2 and 253, then the reply will be:

?V:1,C:101=1,2,253#

102 - Query Routers

When you send a Query Routers command, the reply provides you with all the Cluster Member (Router) IDs that exist in the specified cluster.

Command

Send: Command (102), Cluster (1..253)

Reply

Returns a bit field indicating the presence of all routers within the specified cluster:

Command (102), Router Count / Cluster ID (1..253), 8x32 bit Words detailing the existence of the routers 1-254 (bits 0 and 255 are always zero)

ASCII Example

If you send the following Query Routers in cluster 253 command:

```
>V:1,C:102,@253#
```

If there are routers 252, 253 and 254 in cluster 253, then the reply will be:

```
?V:1,C:102,@253=252,253,254#
```

103 - Query Last Scene In Block (LSIB)

When you send a Query Last [Scene](#) In Block command, the reply provides you with the last scene that was recalled in the specified scene block.

Note

If no scene has been recalled, Query Last Scene In Block replies may also return current block status information.

See table below for the status description, ASCII reply information and HEX reply information.

Status Description	ASCII Reply	HEX Reply
Off	128	0x0080
Min level	129	0x0081
Max level	130	0x0082
Last Scene Percentage (0%)	137	0x0089
Last Scene Percentage (1%)	138	0x008A
Last Scene Percentage (100%)	237	0x00ED

Command

Send: Command (103), Group (1..16383), Block (1..8)

Reply

Returns the number of the last recalled scene in the scene block:

Command (103), Group (1..16383), Block (1..8), Last Scene In Block (1..16)

ASCII Example

If you send the following Query LSIB command (including the group and scene block parameters):

>V:1,C:103,G:5,B:2#

If the last scene called in the block is 4, then the reply will be:

?V:1,C:103,G:5,B:2=4#

109 - Query Last Scene In Group (LSIG)

When you send a Query Last [Scene](#) In Group command, the reply provides you with the last scene that was recalled in the specified group.

Note: If no scene has been recalled, Query Last Scene In Group replies may also return current group status information.

See table below for the status description, ASCII reply information and HEX reply information

Status Description	ASCII Reply	HEX Reply
Off	128	0x0080
Min level	129	0x0081
Max level	130	0x0082
Last Scene Percentage (0%)	137	0x0089
Last Scene Percentage (1%)	138	0x008A
Last Scene Percentage (100%)	237	0x00ED

Command

Send: Command (109), Group (1..16383)

Reply

Returns the number of the last recalled scene in the group:

Command (109), Group (1..16383), Last Scene In Group (1..128)

ASCII Example

If you send the following Query LSIG command:

>V:2,C:109,G:5#

If the last scene called in the group is 78, then the reply will be:

?V:2,C:109,G:5=78#

104 - Query Device Type

[DALI](#) , Digidim, Imagine ([SDIM](#)) and [DMX](#) devices are all capable of returning a device type. Devices can return more than one piece of type information.

For an ASCII query the response will be four comma separated values, the last of which is the protocol; the penultimate is the device type; and the remaining two are extra device information.

For a raw query the response will be returned in a 32 bit Word. The least significant byte contains the protocol; the next least significant byte contains the main device type; the two most significant bytes contain extra device information.

The devices protocols are as follows:

Protocol	Values
DALI	0x01
Digidim	0x02
Imagine / SDIM	0x04
DMX	0x08

Note: Only certain combinations of device types are valid or make sense.

Command

Send: Command (104), Cluster (1..253), Router (1..254), [Subnet](#) (1..4), Device (1..255)

Reply

Returns the device type:

Command (104), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Device Type (see tables below)

ASCII Example

If you send the following Query Device Type command (including the full address of the device):

```
>V:1,C:104,@2.2.1.1#
```

If the device is a 100 Rotary, then the reply will be:

```
?V:1,C:104,@2.2.1.1=00100802#
```

DALI Device Type Information

Device Type	Byte3–Byte1 (MSBytes)	Byte0 (LSByte)
Fluorescent Lamps	0x00	0x01
Self-contained emergency lighting	0x01	0x01
Discharge lamps (excluding fluorescent lamps)	0x02	0x01
Low voltage halogen lamps	0x03	0x01
Incandescent lamps	0x04	0x01
Conversion into D.C. voltage (IEC 60929)	0x05	0x01
LED modules	0x06	0x01
Switching function (i.e., Relay)	0x07	0x01
Colour control	0x08	0x01
Sequencer	0x09	0x01
Undefined	0x0B – 0xFE	0x01

Digidim Control Device Type Information

Device Type	Byte3 (MSB)	Byte2	Byte1	Byte0 (LSB)
100 – Rotary	0x00	0x10	0x08	0x02
110 – Single Sider	0x00	0x11	0x07	0x02
111 – Double Sider	0x00	0x11	0x14	0x02
121 – 2 Button On/Off + IR	0x00	0x12	0x13	0x02
122 – 2 Button Modifier + IR	0x00	0x12	0x20	0x02
124 – 5 Button + IR	0x00	0x12	0x44	0x02

Device Type	Byte3 (MSB)	Byte2	Byte1	Byte0 (LSB)
125 – 5 Button + Modifier + IR	0x00	0x12	0x51	0x02
126 – 8 Button + IR	0x00	0x12	0x68	0x02
170 – IR Receiver	0x00	0x17	0x01	0x02
312 – Multisensor	0x00	0x31	0x25	0x02
410 – Ballast (1-10V Converter)	0x00	0x41	0x08	0x02
416S – 16A Dimmer	0x00	0x41	0x60	0x02
425S – 25A Dimmer	0x00	0x42	0x52	0x02
444 – Mini Input Unit	0x00	0x44	0x43	0x02
450 – 800W Dimmer	0x00	0x45	0x04	0x02
452 – 1000W Universal Dimmer	0x00	0x45	0x28	0x02
455 – 500W Thruster Dimmer	0x00	0x45	0x59	0x02
458/DIMB – 8-Channel Dimmer	0x00	0x45	0x80	0x02
459/CTRB – 8-Ch Ballast Controller	0x74	0x45	0x81	0x02
459/SWB – 8-Ch Relay Module	0x04	0x45	0x83	0x02
460 – DALI-to-SDIM Converter	0x00	0x46	0x03	0x02
472 – Din Rail 1-10V/DS/8 Converter	0x00	0x47	0x26	0x02
474 – 4-Ch Ballast (Output Unit)	0x00	0x47	0x40	0x02
474 – 4-Ch Ballast (Relay Unit)	0x00	0x47	0x41	0x02
490 – Blinds Unit	0x00	0x49	0x00	0x02
494 – Relay Unit	0x00	0x49	0x48	0x02
498 – Relay Unit	0x00	0x49	0x66	0x02
804 – Digidim 4	0x00	0x80	0x45	0x02
924 – LCD TouchPanel	0x00	0x82	0x40	0x02
935 – Scene Commander (6 Buttons)	0x00	0x93	0x56	0x02
939 – Scene Commander (10 Buttons)	0x00	0x93	0x94	0x02
942 – Analogue Input Unit	0x00	0x94	0x24	0x02
459/CPT4 – 4-Ch Options Module	0x00	0x45	0x86	0x02

Imagine (SDIM) Device Type Information

Device Type	Byte3 (MSB)	Byte2	Byte1	Byte0 (LSB)
No device present	0x00	0x00	0x00	0x04
474 – 4 Channel Ballast Controller - Relay Unit	0x00	0x00	0xF1	0x04
474 – 4 Channel Ballast Controller - Output Unit	0x00	0x00	0xF2	0x04
458/SW8 – 8-Channel Relay Module	0x00	0x00	0xF3	0x04
458/CTR8 – 8-Channel Ballast Controller	0x00	0x00	0xF4	0x04
458/OPT4 – Options Module	0x00	0x00	0xF5	0x04
498 – 8-Channel Relay Unit	0x00	0x00	0xF6	0x04

Device Type	Byte3 (MSB)	Byte2	Byte1	Byte0 (LSB)
458/DIM8 – 8-Channel Dimmer	0x00	0x00	0xF7	0x04
HES92060 – Sine Wave Dimmer	0x00	0x00	0xF8	0x04
Ambience4 Dimmer	0x00	0x00	0xF9	0x04
HES92020 – SCR Dimmer	0x00	0x00	0xFA	0x04
HES98020 – Output Unit	0x00	0x00	0xFB	0x04
HES92220 – Transistor Dimmer	0x00	0x00	0xFC	0x04
HES98180-98291 – Relay Unit	0x00	0x00	0xFE	0x04
Dimmer (old style, type undefined)	0x00	0x00	0xFF	0x04

DMX Device Type Information

Device Type	Byte3 (MSB)	Byte2	Byte1	Byte0 (LSB)
DMX No device present	0x00	0x00	0x00	0x08
DMX Channel In	0x00	0x00	0x01	0x08
DMX Channel Out	0x00	0x00	0x02	0x08

Digidim Control Key Type Information

Key Type	Byte3 (MSB)	Byte2	Byte1	Byte0 (LSB)
SinglePress	0x00	0x00	0x00	0x01
TimedPress	0x00	0x00	0x00	0x02
ToggleSolo	0x00	0x00	0x00	0x03
ToggleBlock	0x00	0x00	0x00	0x04
TouchDimBlock	0x00	0x00	0x00	0x05
TouchDimSolo	0x00	0x00	0x00	0x06
Modifier	0x00	0x00	0x00	0x07
EdgeMode	0x00	0x00	0x00	0x08
Slider	0x00	0x00	0x00	0x09
AnalogueInput	0x00	0x00	0x00	0x0A
Rotary	0x00	0x00	0x00	0x0B
PIR	0x00	0x00	0x00	0x0C
ContantLight	0x00	0x00	0x00	0x0D
SliderInputUnit	0x00	0x00	0x00	0x0E

100 - Query Device Types and Addresses

When targeted at a subnet it will respond with all of the devices types with corresponding index, as in command 104. The device type and index pairs are in this format: Device Type @ index.

ASCII Example

If you send the following Query Device Type command (including the full address of the device):

```
>V:2,C:100@2.2.1#
```

If the DALI subnet has 2 devices, one being a 100 Rotary at index 1, and the other being a 110 Slider at index 10, then the reply will be:

```
?V:2,C:100@2.2.1.1=00100802@1,00110702@10#
```

105 - Query Description Group

[DALI](#) , Digidim, Imagine ([SDIM](#)) and [DMX](#) devices are all capable of returning a description of the group.

The replies in the following examples are the default descriptions for those devices/objects. However, the reply will return group name according to the conventions you have applied to your [lighting system](#) via Designer. For example, if the group has been named 'Building' then this will be returned in the Query Description Group reply.

Note: The query description group replies are case sensitive as per the Microsoft Windows ® ASCII extended character set.

Command

Send: Command (105), Group (1...16383)

Reply

Returns: Command (105), Group (1...16383), Group description

ASCII Example

If you send the following Query Description Group command (including the group number):

```
>>V:1,C:105,G:5#
```

The reply will be the command sent and the reply containing the group description of the group requested i.e.

```
?V:1,C:105,G:5=Group 5#
```

106 - Query Description Device

[DALI](#) , Digidim, Imagine ([SDIM](#)) and [DMX](#) devices are all capable of returning a description of a specific device.

The replies in the following examples are the default descriptions for those devices/objects. However, the reply will return group name according to the conventions you have applied to your lighting system via Designer. For example, if the device has been named 'Ballast 10' then this will be returned in the Query Description Group reply.

Note: The query description device replies are case sensitive as per the Microsoft Windows ® ASCII extended character set.

Command

Send: Command (106), Cluster (1..253), Router (1..254), [Subnet](#) (1..4), Device (1..255)

Reply

Returns a description of the device:

Command (106), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Device description

ASCII Example

If you send the following Query Description Device command (including the full address of the device):

```
>V:1,C:106,@2.2.1.1#
```

If the device is called 'Ballast', then the reply will be:

```
?V:1,C:106,@2.2.1.1=Ballast#
```

Discovery Query Commands

The following set of commands are extensions to version 1 and are designed to allow for the discovery of a Helvar router system.

107 - Query Workgroup Name - UDP Broadcast

By broadcasting this command all Helvar routers that exist on a network, providing that they can see the message, will respond with the Workgroup name to which they belong. If there are multiple workgroups, then there will be responses from all routers in all workgroups.

ASCII Example

If you broadcast (using UDP) the following Query Workgroup Name command:

```
>V:2,C:107#
```

All routers will respond with:

```
?V:2,C:107=WorkgroupName#
```

For example, a router with workgroup name 'Restaurant' will respond with:

```
?V:2,C:107=Restaurant#
```

108 - Query Workgroup Membership

A router will respond to this query with the address strings of the routers that are members of the workgroup.

An address string contains the IP address of the router, and takes the form of '@10.254.1.1'.

ASCII Example

If you send the following Query Workgroup Membership command:

```
>V:2,C:108#
```

A typical response will be:

```
?V:2,C:108=@10.254.1.1,@10.254.1.2,@10.254.1.3#
```

165 - Query Groups

A router will respond to this query with the group identifiers of all groups that have been programmed to the router's workgroup.

The response is a comma delimited string of group identifiers.

ASCII Example

If you send the following Query Groups command:

```
>V:2,C:165#
```

A typical response will be:

```
?V:2,C:165=1,2,3,4,...,100#
```


Note: (33-128) in the above example represents scenes 33 to 128.

Device State Query Commands

110 - Query Device State

E.g. disabled, lamp fault, missing, overtemperature, Function Test in progress, Function Test passed etc.

Command

Send: Command (110), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Returns the device state:

Command (110), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Device State (see table below)

ASCII Example

If you send the following Query Device State command (including the full address of the device):

>V:1,C:110,@2.2.1.1#

If the device has been disabled, then the reply will be:

?V:1,C:110,@2.2.1.1=1#

Device State Flags Table

State	Description	Flag Value
NSDisabled	Device or subdevice has been disabled	0x00000001
NSLampFailure	Unspecified lamp problem	0x00000002
NSMissing	Device previously existed but is not currently present	0x00000004
NSFaulty	Address issues / unknown control device / DALI load responding with multireplies	0x00000008
NSRefreshing	Device is being discovered	0x00000010
NSReserved	Internal use	0x00000020
NSReserved		0x00000040
NSReserved	Internal use	0x00000080
NSEM_Resting	Load is off while powered by emergency supply	0x00000100

State	Description	Flag Value
NSEM_Reserved		0x00000200
NSEM_InEmergency	No mains power supplied	0x00000400
NSEM_InProlong	Mains restored, still using emergency power	0x00000800
NSEM_FTInProgress	Functional Test is running	0x00001000
NSEM_DTInProgress	Duration Test is running	0x00002000
NSEM_Reserved		0x00004000
NSEM_Reserved		0x00008000
NSEM_DTPending	Duration Test requested but not started	0x00010000
NSEM_FTPending	Functional Test requested but not started	0x00020000
NSEM_BatteryFail	Battery failure	0x00040000
NSReserved	Internal use	0x00080000
NSReserved	Internal use	0x00100000
NSEM_Inhibit	Prevents emergency mode	0x00200000
NSEM_FTRequested	Functional Test has been requested	0x00400000
NSEM_DTRequested	Duration Test has been requested	0x00800000
NSEM_Unknown	Initial state	0x01000000
NSOverTemperature	Load is overheating	0x02000000
NSOverCurrent	Load drawing too much current	0x04000000
NSCommsError	Communications error	0x08000000
NSSevereError	Over temperature and/or over current	0x10000000
NSBadReply	Malformed reply received	0x20000000
NSReserved		0x40000000
NSDeviceMismatch	Actual load type doesn't match expected	0x80000000

111 - Query Device Is Disabled

Query whether the device has been disabled.

Command

Send: Command (111), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Returns the lamp state:

Command (111), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Device Disabled State (1=Disabled, 0=Enabled)

ASCII Example

If you send the following Query Device Is Disabled command (including the full address of the device):

```
>V:1,C:111,@1.1.2.58#
```

If the device has been disabled, then the reply will be:

```
?V:1,C:111,@1.1.2.58=1#
```

112 - Query Lamp Failure

Query whether the lamp has failed.

Note: This command should not be sent to any device other than a ballast, otherwise you will receive a 'Property does not exist' error message. See [Error / Diagnostic Messages](#).

Command

Send: Command (112), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Returns the lamp state:

Command (112), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Lamp Failure State (1=Failed, 0=OK)

ASCII Example

If you send the following Query Lamp Failure command (including the full address of the device):

```
>V:1,C:112,@1.1.2.58#
```

If the lamp has failed, then the reply will be:

```
?V:1,C:112,@1.1.2.58=1#
```

113 - Query Device Is Missing

Query whether the device is missing.

Command

Send: Command (113), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Returns a message indicating whether the device is missing or not:

Command (113), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Device Missing State (1=Missing, 0=Present)

ASCII Example

If you send the following Query Device Is Missing command (including the full address of the device):

```
>V:1,C:113,@2.2.1.1#
```

If the device is missing, then the reply will be:

```
?V:1,C:113,@2.2.1.1=1#
```

114 - Query Device Is Faulty

Query whether the device is faulty.

Command

Send: Command (114), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Returns a message indicating whether the device is faulty or not:

Command (114), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Device Faulty State (1=Faulty, 0=OK)

ASCII Example

If you send the following Query Device Is Faulty command (including the full address of the device):

```
>V:1,C:114,@2.2.1.1#
```

If the device is faulty, then the reply will be:

```
?V:1,C:114,@2.2.1.1=1#
```


129 - Query Emergency Battery Failure

Query whether the emergency ballast's battery has failed.

Note: This command should not be sent to any device other than an emergency ballast, otherwise you will receive a 'Property does not exist' error message. See [Error / Diagnostic Messages](#).

Command

Send: Command (129), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Returns the emergency battery state:

Command (129), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Battery Failure State (1=Failed, 0=OK)

ASCII Example

If you send the following Query Emergency Battery Failure command (including the full address of the device):

```
>V:1,C:129,@1.1.2.58#
```

If the emergency ballast's battery has failed, then the reply will be:

```
?V:1,C:129,@1.1.2.58=1#
```

Measurement / Input / Level Query Commands

Note: Devices / subdevices of this type must be configured in Designer before you can query their measurement, input(s) or level. Specifically, they must be grouped

150 - Query Measurement

For analogue types, e.g. light measurement (Multisensor), analogue input (Analogue Input Unit).

Note: If sent to a digital device / subdevice which does not perform any measurement, for example a Button Panel, then you will receive a 'Property does not exist' error message. See [Error / Diagnostic Messages](#)..

Command

Send: Command (150), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Subdevice (1..16)

Reply

Returns the measurement from the device / subdevice:

Command (150), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Subdevice (1..16), Measurement (1..100)

ASCII Example

If you send the following Query Measurement command (including the full address of the subdevice):

```
>V:1,C:150,@2.2.1.1.4#
```

If the measurement from the subdevice is 100, then the reply will be:

```
?V:1,C:150,@2.2.1.1.4=100#
```

151 - Query Inputs

Returns the state or digital input(s) of: a device (e.g. for the PIR detector of a Multisensor - 0x01=occupied within past minute, 0x00=unoccupied); or the LEDs of a button panel; or the switch inputs of an input unit. If sent to the device level, summarises the digital input state. If sent to the subdevice level, gives the state of that subdevice's input.

Note: Before running Query Inputs, make sure that the input source has been set via Designer for input devices such as the [444 Mini Input Unit](#) or [942 Analogue Input Unit](#) . See [Analogue Mode Configuration](#) and [Edge Mode Configuration](#).

Command

Send: Command (151), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Subdevice (1..16)

Reply

Returns the input state of the device / subdevice:

Command (151), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Subdevice (1..16), Input State (see below)

The majority of subdevices have on and off states and are therefore represented by 0 (OFF) or 1 (ON). For example, buttons with LEDs will either be pressed (LED on) or not pressed (LED off). See below for the exceptions.

Mini Input Unit: As there are 8 inputs on this device there will be 8 states e.g. 01001100 would be represented in ASCII as 50.

Slider: 0..100 (level in %)

Analogue Input Unit: 0..100 (level in %)

ASCII Example

If you send the following Query Inputs command to a subdevice (including the full address of the subdevice):

```
>V:1,C:151,@2.2.1.1.4#
```

If the state of the subdevice is ON, then the reply will be:

```
?V:1,C:151,@2.2.1.1.4=1#
```

152 - Query Load Level

Note: This command should not be sent to any device other than a load (control gear), otherwise you will receive a 'Property does not exist' error message. See [Error / Diagnostic Messages](#).

Command

Send: Command (152), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Command (152), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Load Level (1..100)

ASCII Example

If you send the following Query Load Level command (including the full address of the device):

```
>V:1,C:152,@1.1.2.15#
```

If the load level is 25%, then the reply will be:

```
?V:1,C:152,@1.1.2.15=25#
```

Note: Query load level commands may also report a level even though the device may be set to 'Off'. This is because the load level is set below the switch on level.

- Levels above 50% may be subject to a 1% swing when returning levels due to the DALI standard [logarithmic dimming curve](#) . E.g. setting the level of a DALI ballast to 93% in Designer will cause the router to actually return a level of 92% when queried using Ethernet I/O. This is because 93% is not accounted for in the DALI logarithmic dimming curve. The router always assigns the closest dimming curve level to the level set in Designer. For further information see [DALI Logarithmic Dimming Levels](#)

ASCII Example

If you send the following Query Load Level command (including the full address of the device):

```
>V:1,C:152,@1.1.2.15#
```

If the load level is set at 1% and the switch on level is 2%, then the reply will be:

```
?V:1,C:152,@1.1.2.15=2147483649#
```

The ASCII and Raw reply responses, 2147483649 and 0x80000001 are synonymous. If these replies are returned following a query load level request then the device at the specified address is 'Off' even though it appears 'On'.

Power Consumption Query Commands

160 - Query Power Consumption

Query the power consumption of a device.

Note: If the power consumption of the device is unknown, then you will receive a value of 0 in the reply.

Command

Send: Command (160), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Command (160), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255), Power (in W)

ASCII Example

If you send the following Query Power Consumption command (including the full address of the device):

>V:1,C:160,@1.1.2.15#

If the power consumption of the device is 23 W, then the reply will be:

?V:1,C:160,@1.1.2.15=23#

161 - Query Group Power Consumption

Query the power consumption of all devices in a group.

Note: If the total power consumption of the devices in the group are unknown, then you will receive a value of 0 in the reply.

Command

Send: Command (161), Group (1..16383)

Reply

Command (161), Group (1..16383), Power Consumption (in Watts)

ASCII Example

If you send the following Query Group Power Consumption command (including the group number):

>V:1,C:161,G:16#

If the group's power consumption is 105 W, then the reply will be:

?V:1,C:161,G:16=105#

Emergency Test Query Commands

170 - Query Emergency Function Test Time

Note: Emergency Test queries should only be sent to emergency ballasts, otherwise you will receive a 'Property does not exist' error message. See [Error / Diagnostic Messages](#).

Command

Send: Command (170), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Command (170), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255),
Emergency Function Test Time (hh:mm:ss dd-mmm-yyyy)

ASCII Example

If you send the following Query Emergency Function Test Time command (including the full address of the device):

```
>V:1,C:170,@1.1.2.15#
```

If the Emergency Function Test Time is 08:00 on 1st July 2009, then the reply will be:

```
?V:1,C:170,@1.1.2.15=08:00:00 01-Jul-2009#
```

171 - Query Emergency Function Test State

Note:

- Emergency Test queries should only be sent to emergency ballasts, otherwise you will receive a 'Property does not exist' error message. See [Error / Diagnostic Messages](#).

Command

Send: Command (171), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Command (171), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255),
Emergency Function Test State (combinations of the following emergency state values).

Emergency State Values

State	Value
Pass	0
Lamp Failure	1
Battery Failure	2
Faulty	4
Failure	8
Test Pending	16
Unknown	32

ASCII Example

If you send the following Query Emergency Function Test Pending command (including the full address of the device):

```
>V:1,C:171,@1.1.2.15#
```

If the Emergency Function Test is pending, then the reply will be:

?V:1,C:171,@1.1.2.15=16#

172 - Query Emergency Duration Test Time

Note: Emergency Test queries should only be sent to emergency ballasts, otherwise you will receive a 'Property does not exist' error message. See [Error / Diagnostic Messages](#).

Command

Send: Command (172), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Command (172), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255),
Emergency Duration Test Time (hh:mm:ss dd-mmm-yyyy)

ASCII Example

If you send the following Query Emergency Duration Test Time command (including the full address of the device):

>V:1,C:172,@1.1.2.15#

If the Emergency Duration Test Time is 06:00 on 1st January 2010, then the reply will be:

?V:1,C:172,@1.1.2.15=06:00:00#

173 - Query Emergency Duration Test State

Note: Emergency Test queries should only be sent to emergency ballasts, otherwise you will receive a 'Property does not exist' error message. See [Error / Diagnostic Messages](#).

Command

Send: Command (173), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Command (173), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255),
Emergency Duration Test Pending (combinations of the emergency state values described in command 171)

ASCII Example

If you send the following Query Emergency Duration Test Pending command (including the full address of the device):

>V:1,C:173,@1.1.2.15#

If the Emergency Duration Test is pending, then the reply will be:

?V:1,C:173,@1.1.2.15=16#

174 - Query Emergency Battery Charge

Query the remaining charge of the emergency ballast battery.

Note: Emergency queries should only be sent to emergency ballasts, otherwise you will receive a 'Property does not exist' error message. See [Error / Diagnostic Messages](#).

Command

Send: Command (174), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Command (174), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255),
Emergency Battery Charge (0..100%)

ASCII Example

If you send the following Query Emergency Battery Charge command (including the full address of the emergency ballast):

>V:1,C:174,@1.1.2.15#

If the emergency ballast battery has 40% charge remaining, then the reply will be:

?V:1,C:174,@1.1.2.15=40#

175 - Query Emergency Battery Time

Query the current total running time of the emergency ballast battery.

Note: Emergency queries should only be sent to emergency ballasts, otherwise you will receive a 'Property does not exist' error message. See [Error / Diagnostic Messages](#).

Command

Send: Command (175), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Command (175), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255),
Emergency Battery Time (1 ... 255 hours)

ASCII Example

If you send the following Query Emergency Battery Time command (including the full address of the emergency ballast):

```
>V:1,C:175,@1.1.2.15#
```

If the emergency ballast battery running time has been 12 hours, then the reply will be:

```
?V:1,C:175,@1.1.2.15=12#
```

176 - Query Emergency Total Lamp Time

Query the current total lamp running time from any power source.

Note: Emergency queries should only be sent to emergency ballasts, otherwise you will receive a 'Property does not exist' error message. See [Error / Diagnostic Messages](#).

Command

Send: Command (176), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255)

Reply

Command (176), Cluster (1..253), Router (1..254), Subnet (1..4), Device (1..255),
Emergency Total Lamp Time (1 ... 1020 hours)

ASCII Example

If you send the following Query Emergency Total Lamp Time command (including the full address of the emergency ballast):

```
>V:1,C:176,@1.1.2.15#
```

If the emergency ballast total lamp running time has been 100 hours, then the reply will be:

```
?V:1,C:176,@1.1.2.15=100#
```

System Query Commands

185 - Query Time

Command

Send: Command (185)

Reply

Returns the local system time:

Command (185), Local System Time (hh:mm:ss dd-mmm-yyyy)

ASCII Example

If you send the following Query Time command:

>V:1,C:185#

If the time is 14:36:39 on 1st July 2009, then the reply will be:

?V:1,C:185=1245591399#

188 - Query Time Zone

Command

Send: Command (188)

Reply

Returns the timezone offset (difference in seconds, moving westward, between UTC and local time [GMT]):

Command (188), Time Difference (-12..12 hours)

ASCII Example: Central European Time [1 hour's time difference from GMT]

If you send the following Query Time Zone command:

>V:1,C:188#

If your location is in Central Europe at 1 hour ahead of Greenwich Mean time (GMT), then the reply will be:

??V:1,C:188=-3600#

ASCII Example: Central Time (US and Canada) [6 hours' time difference from GMT]

If you send the following Query Time Zone command:

>V:1,C:188#

If you are located at 6 hours offset from Greenwich Mean time (GMT), then the reply will be:

?V:1,C:188=21600#

189 - Query Daylight Saving Time

Command

Send: Command (189)

Reply

Returns the DST:

Command (189), DST (1=ON, 0=OFF)

ASCII Example

If you send the following Query DST command:

>V:1,C:189#

If Daylight Saving Time is enabled, then the reply will be:

?V:1,C:189=1#

190 - Query Software Version

Query the router firmware version.

Command

Send: Command (190)

Reply

Returns the software version:

Command (190), Software Version (e.g. 4.2.2)

ASCII Example

If you send the following Query Software Version command:

>V:1,C:190#

If the router firmware version is 4.2.2, then the reply will be:

?V:1,C:190=67240448#

191 - Query HelvarNet Version

Query the [HelvarNet](#) software version.

Command

Send: Command (191)

Reply

Returns the software version:

Command (191), HelvarNet Version (e.g. 1)

ASCII Example

If you send the following HelvarNet Software Version command:

>V:1,C:191#

If the HelvarNet version is 1, then the reply will be:

?V:1,C:191=1#

Query Command Table

Name	Command Number	Parameters
Query Lamp Running Hours	70	—
Query Ballast Running Hours	71	—
Query Maximum Voltage	72	—
Query Minimum Voltage	73	—
Query Maximum Temperature	74	—
Query Minimum Temperature	75	—
Query Clusters	101	—
Query Routers	102	Cluster: 1–253
Query LSIB	103	Group: 1–16383 Block: 1–8
Query Device Type	104	Cluster: 1–253 Router: 1–254

Name	Command Number	Parameters
Query Description Group	105	Subnet: 1–4 Device: 1–255 Group: 1–16383
Query Description Device	106	Cluster: 1–253 Router: 1–254 Subnet: 1–4 Device: 1–255
Query Device State	110	Cluster: 1–253 Router: 1–254 Subnet: 1–4 Device: 1–255
Query Device Is Disabled	111	Cluster: 1–253 Router: 1–254 Subnet: 1–4 Device: 1–255
Query Lamp Failure	112	Cluster: 1–253 Router: 1–254 Subnet: 1–4 Device: 1–255
Query Device Is Faulty	113	Cluster: 1–253 Router: 1–254 Subnet: 1–4 Device: 1–255
Query Device Is Missing	114	Cluster: 1–253 Router: 1–254 Subnet: 1–4 Device: 1–255
Query Emergency Battery Failure	129	Cluster: 1–253 Router: 1–254 Subnet: 1–4 Device: 1–255
Query Measurement	150	Cluster: 1–253 Router: 1–254 Subnet: 1–4 Device: 1–255 Subdevice: 0 or 1–16
Query Inputs	151	Cluster: 1–253 Router: 1–254 Subnet: 1–4 Device: 1–255 Subdevice: 0 or 1–16
Query Load Level	152	Cluster: 1–253 Router: 1–254

Name	Command Number	Parameters
		Subnet: 1–4 Device: 1–255 Cluster: 1–253 Router: 1–254
Query Power Consumption	160	Subnet: 1–4 Device: 1–255
Query Group Power Consumption	161	Group: 1–16383
Query Emergency Function Test Time	170	—
Query Emergency Function Test State	171	—
Query Emergency Duration Test Time	172	—
Query Emergency Duration Test State	173	—
Query Emergency Battery Charge	174	—
Query Emergency Battery Time	175	—
Query Emergency Total Lamp Time	176	—
Query Time	185	—
Query Time Zone	188	—
Query Daylight Saving Time	189	—
Query Software Version	190	—
Query HelvarNet Version	191	—

Word / Parameter Formats

Note: See [Control Command Word Formats](#) for Word formats not given here.

Cluster

ASCII Format

Cluster = 1..253

Block

ASCII Format

Block = 1..8

Subdevice

ASCII Format

Subdevice = 1..16

Query Replies Table

Cmd No	Name	Reply Description
101	Query Clusters	List of Cluster IDs
102	Query Routers	List of Router IDs
103	Query LSIB	LSIB, 1..16
104	Query Device Type	Device Type
105	Query Description Group	ASCII group description
106	Query Description Device	ASCII device description
110	Query Device State	Bitmask state value
111	Query Device Is Disabled	1 = Disabled, 0 = OK
112	Query Lamp Failure	1 = Failed, 0 = OK
113	Query Device Is Faulty	1 = Faulty, 0 = OK
114	Query Device Is Missing	1 = Missing, 0 = Present
129	Query Emergency Battery Failure	1 = Failed, 0 = OK
150	Query Measurement	0-200 or 1-100 (%)
151	Query Inputs	Input bitmask
152	Query Load Level	Load level 1-100 (%)
160	Query Power Consumption	Power (W)
161	Query Group Power Consumption	Power (W)
170	Query Emergency Function Test Time	Time (Epoch Seconds)
171	Query Emergency Function Test State	Bitmask test status
172	Query Emergency Duration Test Time	Time (Epoch Seconds)
173	Query Emergency Duration Test State	Bitmask test status
174	Query Emergency Battery Charge	0-100 (%)
175	Query Emergency Battery Time	0-255 hours
176	Query Emergency Total Lamp Time	Total time (decimal)
185	Query Time	Epoch time (seconds)
188	Query Time Zone	Seconds from GMT
189	Query Daylight Saving Time	1 = On, 0 = Off
190	Query Software Version	Hexadecimal breakdown
191	Query HelvarNet Version	Version string

GENERAL CONTEXT INFORMATION FROM VARIOUS PARTS

Workgroups

Within the context of a [lighting system](#) , a Workgroup is a collection of routers that work together and communicate with each other. Every lighting system must contain at least one Workgroup.

A lighting system is normally just a single Workgroup. However, on some sites there may be more than one Workgroup. For example, each building on a campus could be a separate Workgroup.

Addresses

An address is a number or sequence of numbers used to identify a [router](#) , [subnet](#) , [device](#) or subdevice in a [lighting system](#) . Each item has a unique address that is either defined automatically (by Designer or the router), or defined manually (by the user with Designer or at the physical device).

Address Structure for Items

Each address is made up of up to five numbers in the format:

Cluster ID.**Cluster Member ID**.**Subnet**.**Device**.**Subdevice**

Router Address Format

Routers have an address in the format of **Cluster ID**.*Cluster Member ID*

Subnet Address Format

Subnets have an address in the format of **Cluster ID**.*Cluster Member ID*.**Subnet**

Device Address Format

Devices have an address in the format of **Cluster ID**.*Cluster Member ID*.**Subnet**.**Device**

Subdevice Address Format

Subdevices have an address in the format of **Cluster ID**.*Cluster Member ID*.**Subnet**.**Device**.**Subdevice**

DALI Subnet

A DALI subnet is a collection of DALI devices, all connected on one cable, which are connected to a [router](#) . Each router can support two DALI subnets.

The DALI protocol is used to communicate between DALI devices on a DALI subnet. DALI [device](#) addresses are automatically set by the router system.

Up to 64 devices can be connected to each DALI subnet

SDIM Subnet

An SDIM subnet allows the Imagine 920 [Router](#) to drive [control gear](#) such as the Imagine range of dimmers, relay units and ballast controllers, or Digidim loads with SDIM capability. The router has one SDIM subnet which can support up to 128 SDIM devices, within the limits of 252 SDIM addresses. SDIM is an internal Helvar protocol used to communicate between SDIM devices (control gear) on an SDIM subnet. Unlike [DALI](#) devices, whose addresses are automatically set by the router system, SDIM addresses are set at the [device](#) by a [DIL](#) switch or menu selection. There can be one or more addresses, depending on how many channels the device has.

DMX Subnet

Note: Only the Imagine [920 Router](#) has a [DMX subnet](#) connector and can therefore support one DMX subnet

DMX (*Dimmer MultipleX*) is a communications protocol developed by USITT (United States Institute for Theatre Technology), commonly used to control stage lighting and effects.

The standard is intended for [lighting system](#) and entertainment system designers who want to integrate systems of lighting equipment and accessories, including dimmers, with controllers made by different manufacturers.

DMX Subnet Communication

DMX512 is designed to carry repetitive control data from a single controller to one or more receivers. This protocol is intended to be used to control dimmers, other lighting devices and related non-hazardous effects equipment.

Note: A [DMX](#) Lighting Control Console (or Lighting Desk) controls the levels of channels in the range from 0 to 255. When the DMX subnet is in DMX 'Out' operation, if you send a command to set a DMX [channel](#) to 100 % then the channel goes to 255 on the DMX [device](#) (all other levels are scaled proportionally). When in DMX 'In' operation, and you send a command to set a DMX [channel](#) to 100 %, the controlled [SDIM](#) channel goes to 100 %.

DMX 'In'

If the subnet is in this operation, then the SDIM and/or DALI devices are controlled channels (inputs) on their controlled SDIM and/or DALI subnets. These subnets can support up to 512 channels in from one DMX source.

DMX 'Out'

If the subnet is in this operation, then the DMX devices on the subnet operate as loads ([control gear](#)). This subnet can drive up to 512 DMX output channels.

Scenes

In its simplest sense, a [scene](#) is a set of levels. A scene can be assigned to a control panel [button](#) so that, when the [button](#) is pressed, the levels defined in the scene are set

Discovery

Before you configure the [router](#) 's network settings or lighting settings, the following is necessary:

- The client computer running Designer needs to be able to discover the routers.
- The routers need to discover one another.

This is achieved by the discovery mechanism, which involves the transmission of a discovery message.

Discovery message

The discovery message is transmitted via a [UDP](#) broadcast or UDP multicast. The ability to receive the message depends on the type of network on which the routers and client reside.

- If the network is a layer 2 network, the client and all routers will receive the UDP broadcast message.
- If the network is a layer 3 managed network, the UDP broadcast may not be sufficient for the client or all routers to receive the message. The reason is that UDP broadcasts are not always permitted to travel through managed switches due to concerns regarding network packet flooding. Therefore, the routers allow for the discovery message to be transmitted via a UDP multicast. The type of protocol used for transmitting the discovery message can be selected using the two properties 'Broadcast Discovery Message' and 'Multicast Discovery Message'. These allow each type to be enabled or disabled.

Note: When testing whether the multicast discovery message works, it can be helpful to use both UDP broadcast and UDP broadcast messages. If you have to use multicast discovery messages, enable them leaving the broadcast method enabled until you are satisfied that it is working properly. One of both methods needs to be enabled at any one time, because the router will not allow both the broadcast and multicast methods to be disabled.

Broadcast Discovery Address

In certain cases, it may be appropriate to change the broadcast address. This is an advanced topic and should only be carried out by someone with a good understanding of IP networks and IP subnetting. It is recommended to leave the default setting of 255.255.255.255 as it is.

Multicast Discovery Address

If you decide to adopt the multicast discovery mechanism, your network administrator will advise on the correct settings to use. The address must be in the range from 224.0.0.0 to 239.255.255.255.

Network Administration

If the network is a layer 3 managed network, it will be administered by an IT professional. Therefore, it is important to work closely with the administrator to determine:

- the course of action to take regarding the discovery mechanism; and
- what the IP addressing strategy will be.

In any case, the discovery message must be permitted to travel through the managed network unhindered

Names and Conventions

Router, Subnet and Device Names

Every [router](#) , [subnet](#) , [device](#) and subdevice has a default name (the item name), followed by the item's unique address.

It can be useful to rename important items to indicate their location or function in the system. This helps you to organise the workgroup design. For example, if a router controls the lighting for a restaurant, renaming it to **Restaurant** makes its function more obvious.

Names can be up to 43 characters long, and may contain any characters.

Scene Names

By default, each scene in a [lighting system](#) has a unique name, composed of the group to which it belongs and the scene block and scene number to which it relates. Scene names can be edited to make them easier for you to identify and remember their purpose in the lighting system. Names can be up to 43 characters long, and may contain any characters. See [Rename a Scene](#).

Naming Conventions

A variety of naming conventions are used in the lighting design. These vary from simple numbering of devices to using codes that identify a component, its location, power, and so on. If you are working with a lighting design that has been provided to you, it makes sense to use the chosen convention.

If you have the opportunity to choose a naming convention, we suggest you use an acronym or abbreviation for each item in the lighting system. For example, use the letter 'D' to indicate a **Downlight**, 'P' to indicate a **Panel**, and so on. By using such a code with a sequential numbered suffix for each item, you can identify items in a way that makes it easy to cross-reference your workgroup design with the various floor plans and specifications for the project.