

matpower-pip

pypi package

7.1.0.2.1.8

License

MIT

matpower-pip: A Python Package for Easy Access to MATPOWER Power System Simulation Package

This package is intended to make MATPOWER installable from PyPI. We did not change anything from MATPOWER package, instead we use a copy of MATPOWER (currently Version 8.0) and wrap it as `python package` published on PyPI. Use this package with `mypower` (the recommended way) or `oct2py` to run MATPOWER using octave client. `matlab.engine` is also supported. For the latest docs, read README on GitHub.

This project also listed on related links on matpower official website. Please visit that site to find other useful resources.

Installation

`matpower`


For downloading MATPOWER only (maybe you will run it using `matlab.engine` or any other method, or simply want an easy MATPOWER downloader):

```
pip install matpower
```

`oct2py` (Windows)

For callable `matpower` via `oct2py` (require octave on environment system PATH). You can follow the `oct2py` installation tutorial in `mypower` repository.

Usage

See [notebooks/](#) for complete examples. All examples should be compatible with Google Colab  [Open in Colab](#)

Running with engine (require `oct2py` or `matlab.engine`)

If `oct2py` or `matlab.engine` is installed, `matpower.start_instance` can be used to run octave or MATLAB with MATPOWER path added. Default engine is octave. You also can use `mypower` for added functionality as shown in `mypower` tutorial.

```
from matpower import start_instance
```

```
m = start_instance()
m.runpf()
```

```

from matpower import start_instance

m = start_instance()
mpc = m.eval('case9', verbose=False)
mpc = m.runpf(mpc)

from matpower import Matpower

with Matpower(engine='octave') as m: # run as context manager
    mpc = m.eval('case9', verbose=False)
    mpc = m.runpf(mpc)

```

```

print(m._engine is None) # engine cleanly terminated

```

```

from matpower import path_matpower

```

```

print(path_matpower) # matpower installation location

```

Since `mpc = m.runopf()` will make `mpc` contain unsupported `<object opf_model>`, we can avoid it by request maximum number of outputs using `nout='max_nout'` in octave.

```

from matpower import start_instance

```

```

m = start_instance()

```

```

mpc = m.loadcase('case9')

```

```

mpopt = m.mpopoption('verbose', 2)

```

```

[baseMVA, bus, gen, gencost, branch, f, success, et] = m.runopf(mpc, mpop, nout='max_nout')

```

Alternatively, it would be better to not parse back value that will not be use on python using `oct2py .eval` method. Use `;` to avoid octave print output on running the command.

```

# import start_instance to start matpower instance

```

```

from matpower import start_instance

```

```

# start instance

```

```

m = start_instance()

```

```

# use octave native to run some commands

```

```

m.eval("mpopt = mpopoption('verbose', 2);")

```

```

m.eval("mpc = loadcase('case9');")

```

```

m.eval("r1 = runopf(mpc, mpop);") # we avoid parse `r1` that contains unsupported `<object opf_model>`

```

```

# fetch data to python (.eval is used because .pull is not working in accessing field)

```

```

r1_mpc = {}

```

```

r1_mpc['baseMVA'] = m.eval('r1.baseMVA;')

```

```

r1_mpc['version'] = m.eval('r1.version;')

```

```

r1_mpc['bus'] = m.eval('r1.bus;')
r1_mpc['gen'] = m.eval('r1.gen;')
r1_mpc['branch'] = m.eval('r1.branch;')
r1_mpc['gencost'] = m.eval('r1.gencost;')

# modify variable if necessary
[GEN_BUS, PG, QG, QMAX, QMIN, VG, MBASE, GEN_STATUS, PMAX, PMIN, MU_PMAX,
 MU_PMIN, MU_QMAX, MU_QMIN, PC1, PC2, QC1MIN, QC1MAX, QC2MIN, QC2MAX,
 RAMP_AGC, RAMP_10, RAMP_30, RAMP_Q, APF] = m.idx_gen(nout='max_nout')
gen_index = 2 # index of generator to be changed
gen_index_ = int(gen_index - 1) # -1 due to python indexing start from 0
PMAX_ = int(PMAX - 1) # -1 due to python indexing start from 0
r1_mpc['gen'][gen_index_, PMAX_] = 110 # in this example, we modify PMAX to be 110

[PQ, PV, REF, NONE, BUS_I, BUS_TYPE, PD, QD, GS, BS,
 BUS_AREA, VM, VA, BASE_KV, ZONE, VMAX, VMIN, LAM_P,
 LAM_Q, MU_VMAX, MU_VMIN] = m.idx_bus(nout='max_nout')
bus_index = 7 # index of bus to be changed
bus_index_ = int(bus_index - 1) # -1 due to python indexing start from 0
PD_ = int(PD - 1) # -1 due to python indexing start from 0
r1_mpc['bus'][bus_index_, int(PD - 1)] = 80 # in this example, we modify PD to be 150

# push back value to octave client
m.push('mpc', r1_mpc) # push r1_mpc in python to mpc in octave

# test if we can retrieve pushed value
mpc = m.pull('mpc')

# test if our pushed variable can be used
m.eval("r1 = runopf(mpc, mpopt);")

Also support using matlab.engine.

from matpower import start_instance

m = start_instance(engine='matlab') # specify using `matlab.engine` instead of `oct2py`
mpc = m.runpf('case5', nargout=0)

```

Known engine issue

Octave

1. `m.runopf()` will make `mpc` contain unsupported `<object opf_model>`.
See: <https://github.com/MATPOWER/matpower/issues/134#issuecomment-1007798733>
Impacted case:

```

r1 = m.runopf(mpc)

Solution:

m.push('mpc', mpc)
m.eval("r1 = runopf(mpc, mpopt);")

r1_mpc = {}
r1_mpc['baseMVA'] = m.eval('r1.baseMVA;')
r1_mpc['version'] = m.eval('r1.version;')
r1_mpc['bus'] = m.eval('r1.bus;')
r1_mpc['gen'] = m.eval('r1.gen;')
r1_mpc['branch'] = m.eval('r1.branch;')
r1_mpc['gencost'] = m.eval('r1.gencost;')

```

Versioning

This package maintain MATPOWER version with added version mark, i.e. MATPOWER 7.1 become 7.1.0.x.x.x where .x.x.x come from `matpower-pip` versioning. The `matpower-pip` versioning is not released on pypi since `matpower-pip` is restricted for development only (and development should use git instead).

TODO

1. conda and docker installation that include octave-cli installation.

Authors

- **Muhammad Yasirroni** - yasirroni

Cite

We do request that publications derived from the use of `matpower-pip` explicitly acknowledge that fact by including all related MATPOWER publication and the following citation:

M. Yasirroni, Sarjiya, and L. M. Putranto, “matpower-pip: A Python Package for Easy Access to MATPOWER Power System Simulation Package,” [Online]. Available: <https://github.com/yasirroni/matpower-pip>.

```

@misc{matpower-pip,
  author = {Yasirroni, M. and Sarjiya and Putranto, L. M.},
  title = {matpower-pip: A Python Package for Easy Access to MATPOWER Power System Simulation Package},
  year = {2023},
  howpublished = {\url{https://github.com/yasirroni/matpower-pip}},
}

```

If a journal publication from the author to appear soon should be cited instead.

Contributing

See the CONTRIBUTING.md.

Acknowledgement

This repository was supported by the Faculty of Engineering, Universitas Gadjah Mada under the supervision of Mr. Sarjiya. If you use this package, we are very glad if you cite any relevant publication under Mr. Sarjiya's name that can be found on the semantic scholar or IEEE for the meantime, since publication related to this repository is ongoing. This work is also partly motivated after I found out that `oct2py` supports running `octave` client from `python`, but the only implementation for running `MATPOWER` that I know, that is `oct2pypower`, requires `docker` and is not newbie-friendly. Nevertheless, I would like to say thank you to all people who contributed to `oct2py`, `oct2pypower`, and more importantly `MATPOWER`.