



Your embedded solution partner.

[<< Reference Manual <<](#)

CANopen Stack



CANopen Library

2.6.7

Generated by Doxygen 1.8.11

Contents

1	CANopen Stack Reference Manual	1
1.1	Introduction	1
1.2	General	1
1.3	Using CANopen stack in an application	2
1.4	Indication functions	2
2	Data Structure Index	3
2.1	Data Structures	3
3	File Index	5
3.1	File List	5
4	Data Structure Documentation	9
4.1	CO_CAN_COB_T Struct Reference	9
4.1.1	Detailed Description	9
4.1.2	Field Documentation	9
4.1.2.1	canChan	9
4.1.2.2	canId	9
4.1.2.3	enabled	9
4.1.2.4	extended	10
4.1.2.5	ignore	10
4.1.2.6	rtr	10
4.2	CO_CAN_MSG_T Struct Reference	10
4.2.1	Detailed Description	10
4.2.2	Field Documentation	10

4.2.2.1	canCob	10
4.2.2.2	data	10
4.2.2.3	handle	10
4.2.2.4	len	11
4.3	CO_SERVICE_INIT_VAL_T Struct Reference	11
4.3.1	Detailed Description	11
4.4	CO_TIME_T Struct Reference	11
4.4.1	Detailed Description	11
4.4.2	Field Documentation	11
4.4.2.1	days	11
4.4.2.2	msec	11
4.5	co_timer Struct Reference	12
4.5.1	Detailed Description	12
4.5.2	Field Documentation	12
4.5.2.1	actTicks	12
4.5.2.2	attr	12
4.5.2.3	pData	12
4.5.2.4	pFct	12
4.5.2.5	pNext	12
4.5.2.6	ticks	12
4.6	PDO_REC_MAP_ENTRY_T Struct Reference	13
4.6.1	Detailed Description	13
4.6.2	Field Documentation	13
4.6.2.1	len	13
4.6.2.2	numeric	13
4.6.2.3	pVar	13
4.6.2.4	routePdo	13
4.6.2.5	val	13
4.7	PDO_REC_MAP_TABLE_T Struct Reference	14
4.7.1	Detailed Description	14

4.7.2	Field Documentation	14
4.7.2.1	mapCnt	14
4.7.2.2	mapEntry	14
4.8	PDO_TR_MAP_ENTRY_T Struct Reference	14
4.8.1	Detailed Description	14
4.8.2	Field Documentation	14
4.8.2.1	len	14
4.8.2.2	numeric	15
4.8.2.3	pVar	15
4.8.2.4	val	15
4.9	PDO_TR_MAP_TABLE_T Struct Reference	15
4.9.1	Detailed Description	15
4.9.2	Field Documentation	15
4.9.2.1	mapCnt	15
4.9.2.2	mapEntry	15
5	File Documentation	17
5.1	co_candebug.c File Reference	17
5.1.1	Detailed Description	17
5.2	co_candebug.h File Reference	17
5.2.1	Detailed Description	17
5.3	co_canopen.h File Reference	17
5.3.1	Detailed Description	18
5.3.2	Function Documentation	18
5.3.2.1	coCanOpenStackDeInit(void)	18
5.3.2.2	coCanOpenStackInit(CO_EVENT_STORE_T pLoadFunction)	18
5.3.2.3	coCanOpenStackInitPara(CO_EVENT_STORE_T pLoadFunction, CO_INIT_↔ OPTION_T *pCoOptions)	19
5.3.2.4	coCanOpenStackVarInit(CO_SERVICE_INIT_VAL_T *pServiceInitVals)	19
5.4	co_cfgman.c File Reference	19
5.4.1	Detailed Description	19

5.4.2	Function Documentation	20
5.4.2.1	coCfgConvToConsive(CHAR *pDcfData, UNSIGNED8 *pConsBuf, UNSIGNED32 *pConsBufLen)	20
5.4.2.2	coCfgStart(UNSIGNED8 sdoNr, UNSIGNED8 srvNodeId, UNSIGNED8 *pBuf, UNSIGNED32 bufLen, UNSIGNED32 sdoTimeOut)	20
5.4.2.3	coEventRegister_CFG_MANAGER(CO_EVENT_CFG_MANAGER_T pFunction)	20
5.5	co_cfgman.h File Reference	21
5.5.1	Detailed Description	21
5.5.2	Typedef Documentation	21
5.5.2.1	CO_EVENT_CFG_MANAGER_T	21
5.5.3	Enumeration Type Documentation	22
5.5.3.1	CO_CFG_TRANSFER_T	22
5.5.4	Function Documentation	22
5.5.4.1	coCfgConvToConsive(char *pDcfData, UNSIGNED8 *pConsBuf, UNSIGNED32 *pConsBufLen)	22
5.5.4.2	coCfgStart(UNSIGNED8 sdoNr, UNSIGNED8 srvNodeId, UNSIGNED8 *pBuf, UNSIGNED32 bufLen, UNSIGNED32 sdoTimeOut)	23
5.5.4.3	coEventRegister_CFG_MANAGER(CO_EVENT_CFG_MANAGER_T pFct)	23
5.6	co_cob.h File Reference	23
5.6.1	Detailed Description	24
5.6.2	Macro Definition Documentation	24
5.6.2.1	CO_COB_29BIT	24
5.6.2.2	CO_COB_29BIT_MASK	24
5.6.2.3	CO_COB_ID_MASK	24
5.6.2.4	CO_COB_INVALID	24
5.6.2.5	CO_COB_VALID_MASK	24
5.7	co_cobhandler.c File Reference	24
5.7.1	Detailed Description	24
5.8	co_commtask.c File Reference	25
5.8.1	Detailed Description	25
5.8.2	Function Documentation	25
5.8.2.1	coCommStateEvent(CO_COMM_STATE_EVENT_T newEvent)	25

5.8.2.2	coCommTask(void)	25
5.8.2.3	coEventRegister_CAN_STATE(CO_EVENT_CAN_STATE_T pFunction)	26
5.8.2.4	coEventRegister_COMM_EVENT(CO_EVENT_COMM_T pFunction)	26
5.9	co_commtask.h File Reference	27
5.9.1	Detailed Description	27
5.9.2	Typedef Documentation	27
5.9.2.1	CO_EVENT_CAN_STATE_T	27
5.9.2.2	CO_EVENT_COMM_T	28
5.9.3	Enumeration Type Documentation	28
5.9.3.1	CO_CAN_STATE_T	28
5.9.3.2	CO_COMM_STATE_EVENT_T	29
5.9.3.3	CO_COMMTASK_EVENT_T	29
5.9.4	Function Documentation	29
5.9.4.1	coCommStateEvent(CO_COMM_STATE_EVENT_T newEvent)	29
5.9.4.2	coCommTask(void)	29
5.9.4.3	coEventRegister_CAN_STATE(CO_EVENT_CAN_STATE_T pFunction)	30
5.9.4.4	coEventRegister_COMM_EVENT(CO_EVENT_COMM_T pFunction)	30
5.9.4.5	coQueueInit(void)	31
5.10	co_datatype.h File Reference	31
5.10.1	Detailed Description	31
5.10.2	Macro Definition Documentation	31
5.10.2.1	MSG_OVERWRITE	31
5.10.2.2	MSG_RET_INHIBIT	31
5.10.3	Enumeration Type Documentation	32
5.10.3.1	BOOL_T	32
5.10.3.2	RET_T	32
5.11	co_drv.h File Reference	33
5.11.1	Detailed Description	34
5.11.2	Function Documentation	34
5.11.2.1	codrvCanDisable(void)	34

5.11.2.2	<code>codrvCanDriverHandler(void)</code>	34
5.11.2.3	<code>codrvCanEnable(void)</code>	35
5.11.2.4	<code>codrvCanInit(UNSIGNED16 bitRate)</code>	35
5.11.2.5	<code>codrvCanReInit(UNSIGNED16 bitRate)</code>	35
5.11.2.6	<code>codrvCanSetBitRate(UNSIGNED16 bitRate)</code>	36
5.11.2.7	<code>codrvCanStartTransmission(void)</code>	36
5.11.2.8	<code>codrvHardwareInit(void)</code>	36
5.11.2.9	<code>codrvTimerSetup(UNSIGNED32 timerInterval)</code>	37
5.11.2.10	<code>coQueueGetNextTransmitMessage(void)</code>	37
5.11.2.11	<code>coQueueMsgTransmitted(const CO_CAN_MSG_T *pBuf)</code>	37
5.11.2.12	<code>coQueueReceiveMessageAvailable(void)</code>	38
5.12	<code>co_dynod.c</code> File Reference	38
5.12.1	Detailed Description	38
5.12.2	Function Documentation	38
5.12.2.1	<code>coDynOdAddIndex(UNSIGNED16 index, UNSIGNED8 nrOfSubs, CO_ODTYP↔ E_T odType)</code>	38
5.12.2.2	<code>coDynOdAddSubIndex(UNSIGNED16 index, UNSIGNED8 subIndex, CO_DAT↔ A_TYPE_T dataType, UNSIGNED16 attr, void *pVar)</code>	39
5.12.2.3	<code>coDynOdInit(UNSIGNED16 objCnt, UNSIGNED16 u8Cnt, UNSIGNED16 u16↔ Cnt, UNSIGNED16 u32Cnt, UNSIGNED16 i8Cnt, UNSIGNED16 i16Cnt, UNSI↔ GNED16 i32Cnt, UNSIGNED16 u64Cnt)</code>	39
5.12.2.4	<code>coDynOdRelease(void)</code>	40
5.12.2.5	<code>coDynOdSetSubIndexAddr(UNSIGNED16 index, UNSIGNED8 subIndex, CO_↔ DATA_TYPE_T dataType, void *pVar)</code>	40
5.13	<code>co_edsparse.c</code> File Reference	40
5.13.1	Detailed Description	41
5.13.2	Function Documentation	41
5.13.2.1	<code>coEdsparseAddEdsToRepository(char *edsFilePath)</code>	41
5.13.2.2	<code>coEdsparseDetectSlaveEds(UNSIGNED8 nodeId, UNSIGNED8 sdoClientNr, CO_DETECT_SLAVE_FCT_T finishFct)</code>	41
5.13.2.3	<code>coEdsparseGetIndexDesc(char *edsFileName, char *pSection, UNSIGNED16 edsIdx, UNSIGNED16 *pIndex, UNSIGNED8 *pNrOfSubs)</code>	42

5.13.2.4	coEdsparseGetObjectDesc(char *edsFileName, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 *pData Type, UNSIGNED16 *pAttr, char *pDefaultVal)	42
5.13.2.5	coEdsparseGetRPdoMapEntry(UNSIGNED16 mapIdx)	43
5.13.2.6	coEdsparseGetSupportedObjCnt(char *edsFileName, char *section)	43
5.13.2.7	coEdsparseGetTPdoMapEntry(UNSIGNED16 mapIdx)	43
5.13.2.8	coEdsparseReadEdsMapping(UNSIGNED8 nodeId, char *edsFileName)	44
5.14	co_emcy.c File Reference	44
5.14.1	Detailed Description	44
5.14.2	Function Documentation	45
5.14.2.1	coEmcyConsumerInit(UNSIGNED8 emcyCnt)	45
5.14.2.2	coEmcyProducerInit(void)	45
5.14.2.3	coEmcyWriteReq(UNSIGNED16 emcyErrCode, CO_CONST UNSIGNED8 pData[])	45
5.14.2.4	coEventRegister_EM CY(CO_EVENT_EM CY_T pFunction)	46
5.14.2.5	coEventRegister_EM CY_CONSUMER(CO_EVENT_EM CY_CONS_T pFunction)	46
5.15	co_emcy.h File Reference	46
5.15.1	Detailed Description	47
5.15.2	Macro Definition Documentation	47
5.15.2.1	CO_EM CY_ERRCODE_COMM_ERROR	47
5.15.2.2	CO_EM CY_ERRCODE_PDO_LEN	47
5.15.3	Typedef Documentation	47
5.15.3.1	CO_EVENT_EM CY_CONS_T	47
5.15.3.2	CO_EVENT_EM CY_T	47
5.15.4	Function Documentation	48
5.15.4.1	coEmcyConsumerInit(UNSIGNED8 emcyCnt)	48
5.15.4.2	coEmcyProducerInit(void)	48
5.15.4.3	coEventRegister_EM CY(CO_EVENT_EM CY_T pFunction)	48
5.15.4.4	coEventRegister_EM CY_CONSUMER(CO_EVENT_EM CY_CONS_T pFunction)	49
5.16	co_errctrl.c File Reference	49
5.16.1	Detailed Description	49
5.16.2	Function Documentation	49

5.16.2.1	<code>coErrorCtrlInit(UNSIGNED16 hbTime, UNSIGNED8 hbConsCnt)</code>	49
5.16.2.2	<code>coEventRegister_ERRCTRL(CO_EVENT_ERRCTRL_T pFunction)</code>	50
5.16.2.3	<code>coHbConsumerSet(UNSIGNED8 node, UNSIGNED16 hbTime)</code>	50
5.16.2.4	<code>coHbConsumerStart(UNSIGNED8 node)</code>	50
5.16.2.5	<code>coNmtGetRemoteNodeState(UNSIGNED8 nodeId)</code>	51
5.17	<code>co_event.c</code> File Reference	51
5.17.1	Detailed Description	51
5.17.2	Function Documentation	52
5.17.2.1	<code>icoEventInit(void)</code>	52
5.17.2.2	<code>icoEventIsActive(CO_CONST CO_EVENT_T *pEvent)</code>	52
5.17.2.3	<code>icoEventStart(CO_EVENT_T *pEvent, CO_EVENT_FCT_T ptrToFct, void *pData)</code>	52
5.18	<code>co_flyingmaster.h</code> File Reference	53
5.18.1	Detailed Description	53
5.18.2	Typedef Documentation	53
5.18.2.1	<code>CO_EVENT_FLYMA_T</code>	53
5.18.3	Enumeration Type Documentation	53
5.18.3.1	<code>CO_FLYMA_STATE_T</code>	53
5.19	<code>co_gfc.c</code> File Reference	54
5.19.1	Detailed Description	54
5.20	<code>co_gfc.h</code> File Reference	54
5.20.1	Detailed Description	54
5.20.2	Typedef Documentation	54
5.20.2.1	<code>CO_EVENT_GFC_T</code>	54
5.21	<code>co_guarding.c</code> File Reference	54
5.21.1	Detailed Description	55
5.21.2	Function Documentation	55
5.21.2.1	<code>coGuardingMasterStart(UNSIGNED8 node)</code>	55
5.21.2.2	<code>coGuardingMasterStop(UNSIGNED8 node)</code>	55
5.21.2.3	<code>icoGuardGetRemoteNodeState(UNSIGNED8 nodeId)</code>	56
5.22	<code>co_led.c</code> File Reference	56

5.22.1 Detailed Description	56
5.22.2 Function Documentation	57
5.22.2.1 coEventRegister_LED_GREEN(CO_EVENT_LED_T pFunction)	57
5.22.2.2 coEventRegister_LED_RED(CO_EVENT_LED_T pFunction)	57
5.22.2.3 coLedSetGreen(CO_LED_STATE_T newLedState)	57
5.22.2.4 coLedSetRed(CO_LED_STATE_T newLedState)	58
5.22.2.5 coLedSetState(CO_LED_STATE_T newState, BOOL_T on)	58
5.23 co_led.h File Reference	58
5.23.1 Detailed Description	59
5.23.2 Typedef Documentation	59
5.23.2.1 CO_EVENT_LED_T	59
5.23.3 Enumeration Type Documentation	59
5.23.3.1 CO_LED_STATE_T	59
5.23.4 Function Documentation	60
5.23.4.1 coEventRegister_LED_GREEN(CO_EVENT_LED_T pFunction)	60
5.23.4.2 coEventRegister_LED_RED(CO_EVENT_LED_T pFunction)	60
5.23.4.3 coLedSetGreen(CO_LED_STATE_T newLedState)	60
5.23.4.4 coLedSetRed(CO_LED_STATE_T newLedState)	61
5.23.4.5 coLedSetState(CO_LED_STATE_T newState, BOOL_T on)	61
5.24 co_iss.c File Reference	61
5.24.1 Detailed Description	62
5.24.2 Function Documentation	62
5.24.2.1 coEventRegister_LSS(CO_EVENT_LSS_T pFunction)	62
5.24.2.2 coLssInit(void)	62
5.24.2.3 coLssNonConfigSlave(void)	62
5.25 co_iss.h File Reference	63
5.25.1 Detailed Description	64
5.25.2 Typedef Documentation	64
5.25.2.1 CO_EVENT_LSS_MASTER_T	64
5.25.2.2 CO_EVENT_LSS_T	64

5.25.3 Enumeration Type Documentation	65
5.25.3.1 CO_LSS_MASTER_SERVICE_T	65
5.25.3.2 CO_LSS_SERVICE_T	66
5.25.3.3 CO_LSS_STATE_T	66
5.25.4 Function Documentation	66
5.25.4.1 coEventRegister_LSS(CO_EVENT_LSS_T pFunction)	66
5.25.4.2 coEventRegister_LSS_MASTER(CO_EVENT_LSS_MASTER_T pFunction)	66
5.25.4.3 coLssActivateBitrate(UNSIGNED16 switchDelay)	67
5.25.4.4 coLssFastScan(UNSIGNED16 timeOutVal)	67
5.25.4.5 coLssFastScanKnownDevice(UNSIGNED32 vendorId, UNSIGNED32 productCode, UNSIGNED32 versionNr, UNSIGNED32 serNr, UNSIGNED16 timeOutVal)	67
5.25.4.6 coLssIdentifyNonConfiguredSlaves(UNSIGNED16 timeOutVal, UNSIGNED16 interval)	68
5.25.4.7 coLssIdentifyRemoteSlaves(UNSIGNED32 vendor, UNSIGNED32 productCode, UNSIGNED32 revisionLow, UNSIGNED32 revisionHigh, UNSIGNED32 serialNumberLow, UNSIGNED32 serialNumberHigh, UNSIGNED16 timeOutVal)	68
5.25.4.8 coLssInit(void)	69
5.25.4.9 coLssInquireIdentity(UNSIGNED8 subIndex, UNSIGNED16 timeOutVal)	69
5.25.4.10 coLssInquireNodeId(UNSIGNED16 timeOutVal)	69
5.25.4.11 coLssMasterDisable(void)	69
5.25.4.12 coLssMasterEnable(void)	70
5.25.4.13 coLssMasterGetInquireData(void)	70
5.25.4.14 coLssMasterInit(void)	70
5.25.4.15 coLssNonConfigSlave(void)	70
5.25.4.16 coLssSetBitrate(UNSIGNED16 bitRate, UNSIGNED16 timeOutVal)	70
5.25.4.17 coLssSetBitrateTable(UNSIGNED8 tableSelector, UNSIGNED8 tableIndex, UNSIGNED16 timeOutVal)	71
5.25.4.18 coLssSetNodeId(UNSIGNED8 nodeId, UNSIGNED16 timeOutVal)	71
5.25.4.19 coLssStoreConfig(UNSIGNED16 timeOutVal)	71
5.25.4.20 coLssSwitchGlobal(CO_LSS_STATE_T mode)	72
5.25.4.21 coLssSwitchSelective(UNSIGNED32 vendorId, UNSIGNED32 productCode, UNSIGNED32 versionNr, UNSIGNED32 serNr, UNSIGNED16 timeOutVal)	72
5.26 co_issmaster.c File Reference	72

5.26.1 Detailed Description	73
5.26.2 Function Documentation	74
5.26.2.1 coEventRegister_LSS_MASTER(CO_EVENT_LSS_MASTER_T pFunction)	74
5.26.2.2 coLssActivateBitrate(UNSIGNED16 switchDelay)	74
5.26.2.3 coLssFastScan(UNSIGNED16 timeOutVal)	74
5.26.2.4 coLssFastScanKnownDevice(UNSIGNED32 vendorId, UNSIGNED32 product↔ Code, UNSIGNED32 versionNr, UNSIGNED32 serNr, UNSIGNED16 timeOutVal)	75
5.26.2.5 coLssIdentifyNonConfiguredSlaves(UNSIGNED16 timeOutVal, UNSIGNED16 in- terval)	75
5.26.2.6 coLssIdentifyRemoteSlaves(UNSIGNED32 vendorId, UNSIGNED32 product↔ Code, UNSIGNED32 revisionLow, UNSIGNED32 revisionHigh, UNSIGNED32 serialNumberLow, UNSIGNED32 serialNumberHigh, UNSIGNED16 timeOutVal)	75
5.26.2.7 coLssInquireIdentity(UNSIGNED8 subIndex, UNSIGNED16 timeOutVal)	76
5.26.2.8 coLssInquireNodeId(UNSIGNED16 timeOutVal)	76
5.26.2.9 coLssMasterDisable(void)	76
5.26.2.10 coLssMasterEnable(void)	77
5.26.2.11 coLssMasterGetInquireData(void)	77
5.26.2.12 coLssMasterInit(void)	77
5.26.2.13 coLssSetBitrate(UNSIGNED16 bitRate, UNSIGNED16 timeOutVal)	77
5.26.2.14 coLssSetBitrateTable(UNSIGNED8 tableSelector, UNSIGNED8 tableIndex, UN↔ SIGNED16 timeOutVal)	78
5.26.2.15 coLssSetNodeId(UNSIGNED8 nodeId, UNSIGNED16 timeOutVal)	78
5.26.2.16 coLssStoreConfig(UNSIGNED16 timeOutVal)	78
5.26.2.17 coLssSwitchGlobal(CO_LSS_STATE_T mode)	79
5.26.2.18 coLssSwitchSelective(UNSIGNED32 vendorId, UNSIGNED32 productCode, U↔ NSIGNED32 versionNr, UNSIGNED32 serNr, UNSIGNED16 timeOutVal)	79
5.27 co_manager.c File Reference	79
5.27.1 Detailed Description	80
5.27.2 Function Documentation	80
5.27.2.1 coEventRegister_MANAGER_BOOTUP(CO_EVENT_MANAGER_BOOTUP_T pFunction)	80
5.27.2.2 coManagerContinueConfigUpdate(UNSIGNED8 slave, RET_T result)	80
5.27.2.3 coManagerContinueOperational(void)	81

5.27.2.4	coManagerContinueSwUpdate(UNSIGNED8 slave, RET_T result)	81
5.27.2.5	coManagerStart(void)	81
5.28	co_manager.h File Reference	81
5.28.1	Detailed Description	82
5.28.2	Typedef Documentation	82
5.28.2.1	CO_EVENT_MANAGER_BOOTUP_T	82
5.28.3	Enumeration Type Documentation	82
5.28.3.1	CO_MANAGER_EVENT_T	82
5.28.4	Function Documentation	83
5.28.4.1	coEventRegister_MANAGER_BOOTUP(CO_EVENT_MANAGER_BOOTUP_T pFunction)	83
5.28.4.2	coManagerContinueConfigUpdate(UNSIGNED8 slave, RET_T result)	83
5.28.4.3	coManagerContinueOperational(void)	84
5.28.4.4	coManagerContinueSwUpdate(UNSIGNED8 slave, RET_T result)	84
5.28.4.5	coManagerStart(void)	84
5.29	co_mpdo.c File Reference	84
5.29.1	Detailed Description	84
5.30	co_network.c File Reference	84
5.30.1	Detailed Description	85
5.30.2	Function Documentation	85
5.30.2.1	coNetworkGet(UNSIGNED16 network, UNSIGNED8 *pNetworkIf, UNSIGNED8 *pRouterNode)	85
5.31	co_network.h File Reference	85
5.31.1	Detailed Description	86
5.31.2	Typedef Documentation	86
5.31.2.1	CO_EVENT_GW_SDOCLIENT_FCT_T	86
5.31.3	Function Documentation	86
5.31.3.1	coNetworkGet(UNSIGNED16 network, UNSIGNED8 *pNetworkIf, UNSIGNED8 *pRouterNode)	86
5.32	co_nmt.c File Reference	86
5.32.1	Detailed Description	87
5.32.2	Function Documentation	87

5.32.2.1	coEventRegister_NMT(CO_EVENT_NMT_T pFunction)	87
5.32.2.2	coNmtGetNodeId(void)	87
5.32.2.3	coNmtGetState(void)	87
5.32.2.4	coNmtInit(UNSIGNED8 master)	88
5.32.2.5	coNmtLocalStateReq(CO_NMT_STATE_T reqState)	88
5.33	co_nmt.h File Reference	88
5.33.1	Detailed Description	89
5.33.2	Typedef Documentation	89
5.33.2.1	CO_EVENT_ERRCTRL_T	89
5.33.2.2	CO_EVENT_NMT_T	90
5.33.2.3	CO_NODE_ID_T	90
5.33.3	Enumeration Type Documentation	90
5.33.3.1	CO_ERRCTRL_T	90
5.33.3.2	CO_NMT_REQ_STATE_T	91
5.33.3.3	CO_NMT_STATE_T	91
5.33.4	Function Documentation	91
5.33.4.1	coErrorCtrlInit(UNSIGNED16, UNSIGNED8)	91
5.33.4.2	coEventRegister_ERRCTRL(CO_EVENT_ERRCTRL_T pFunction)	92
5.33.4.3	coEventRegister_NMT(CO_EVENT_NMT_T pFunction)	92
5.33.4.4	coGuardingMasterStart(UNSIGNED8 node)	92
5.33.4.5	coGuardingMasterStop(UNSIGNED8 node)	93
5.33.4.6	coHbConsumerSet(UNSIGNED8 node, UNSIGNED16 hbTime)	93
5.33.4.7	coHbConsumerStart(UNSIGNED8 node)	94
5.33.4.8	coNmtGetNodeId(void)	94
5.33.4.9	coNmtGetRemoteNodeState(UNSIGNED8 nodeId)	94
5.33.4.10	coNmtGetState(void)	95
5.33.4.11	coNmtInhibitActive(void)	95
5.33.4.12	coNmtInit(UNSIGNED8)	95
5.33.4.13	coNmtLocalStateReq(CO_NMT_STATE_T reqState)	95
5.33.4.14	coNmtNodesIsMaster(void)	96

5.33.4.15 coNmtStateReq(UNSIGNED8 node, CO_NMT_STATE_T reqState, BOOL_↔ T master)	96
5.34 co_nmtmaster.c File Reference	96
5.34.1 Detailed Description	97
5.34.2 Function Documentation	97
5.34.2.1 coNmtInhibitActive(void)	97
5.34.2.2 coNmtNodeIsMaster(void)	97
5.34.2.3 coNmtStateReq(UNSIGNED8 node, CO_NMT_STATE_T reqState, BOOL_↔ T master)	97
5.35 co_nmtslave.c File Reference	98
5.35.1 Detailed Description	98
5.36 co_odaccess.c File Reference	98
5.36.1 Detailed Description	100
5.36.2 Function Documentation	100
5.36.2.1 coEventRegister_OBJECT_CHANGED(CO_EVENT_OBJECT_CHANGED_F↔ CT_T pFunction, UNSIGNED16 index, UNSIGNED8 subIndex)	100
5.36.2.2 coOdDomainAddrSet(UNSIGNED16 index, UNSIGNED8 subIndex, CO_DOM↔ AIN_PTR pAddr, UNSIGNED32 size)	100
5.36.2.3 coOdGetDefaultVal_u16(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIG↔ NED16 *pDefVal)	101
5.36.2.4 coOdGetDefaultVal_u32(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIG↔ NED32 *pDefVal)	101
5.36.2.5 coOdGetDefaultVal_u8(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGN↔ ED8 *pDefVal)	101
5.36.2.6 coOdGetObj_i16(UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER16 *pObj)	102
5.36.2.7 coOdGetObj_i32(UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER32 *pObj)	102
5.36.2.8 coOdGetObj_i8(UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER8 *pObj)	102
5.36.2.9 coOdGetObj_r32(UNSIGNED16 index, UNSIGNED8 subIndex, REAL32 *pObj) .	103
5.36.2.10 coOdGetObj_u16(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 *pObj)	103
5.36.2.11 coOdGetObj_u24(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED24 *pObj)	103
5.36.2.12 coOdGetObj_u32(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 *pObj)	104

5.36.2.13 coOdGetObj_u40(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED40 *pObj)	104
5.36.2.14 coOdGetObj_u48(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED48 *pObj)	104
5.36.2.15 coOdGetObj_u64(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED64 *pObj)	105
5.36.2.16 coOdGetObj_u8(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pObj)	105
5.36.2.17 coOdGetObjAddr(UNSIGNED16 index, UNSIGNED8 subIndex)	105
5.36.2.18 coOdGetObjAttribute(CO_CONST CO_OBJECT_DESC_T *pObjDesc)	106
5.36.2.19 coOdGetObjDescPtr(UNSIGNED16 index, UNSIGNED8 subIndex, CO_CONST CO_OBJECT_DESC_T **pDescPtr)	106
5.36.2.20 coOdGetObjSize(CO_CONST CO_OBJECT_DESC_T *pDesc)	106
5.36.2.21 coOdInitOdPtr(const CO_OD_ASSIGN_T *pOdAssing, UNSIGNED16 odCnt, const CO_OBJECT_DESC_T *pObjdesc, UNSIGNED16 descCnt, CO_EVENT_T OBJECT_CHANGED_FCT_T *pEventPtr, const CO_OD_DATA_VARIABLES_T *pOdVarPointers)	107
5.36.2.22 coOdPutObj_i16(UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER16 newVal)	107
5.36.2.23 coOdPutObj_i32(UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER32 newVal)	107
5.36.2.24 coOdPutObj_i8(UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER8 newVal)	108
5.36.2.25 coOdPutObj_r32(UNSIGNED16 index, UNSIGNED8 subIndex, REAL32 newVal)	108
5.36.2.26 coOdPutObj_u16(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 newVal)	108
5.36.2.27 coOdPutObj_u24(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED24 newVal)	109
5.36.2.28 coOdPutObj_u32(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 newVal)	109
5.36.2.29 coOdPutObj_u40(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED40 newVal)	109
5.36.2.30 coOdPutObj_u48(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED48 newVal)	110
5.36.2.31 coOdPutObj_u64(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED64 newVal)	110
5.36.2.32 coOdPutObj_u8(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 newVal)	110
5.36.2.33 coOdSetCobid(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 newCobId)	111

5.36.2.34	coOdVisStringSet(UNSIGNED16 index, UNSIGNED8 subIndex, VIS_STRIN↔ G pAddr, UNSIGNED32 size)	111
5.36.2.35	icoOdCheckObjAttr(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 checkAttr)	111
5.36.2.36	icoOdGetObjRecMapData(UNSIGNED16 index, UNSIGNED8 subIndex, void **pVar, UNSIGNED8 *pLen, BOOL_T *pNumeric)	112
5.36.2.37	icoOdGetObjTrMapData(UNSIGNED16 index, UNSIGNED8 subIndex, CO_CO↔ NST void **pVar, UNSIGNED8 *pLen, BOOL_T *pNumeric)	112
5.37	co_odaccess.h File Reference	112
5.37.1	Detailed Description	115
5.37.2	Macro Definition Documentation	115
5.37.2.1	CO_ATTR_DEFVAL	115
5.37.2.2	CO_ATTR_DYNOD	115
5.37.2.3	CO_ATTR_LIMIT	115
5.37.2.4	CO_ATTR_MAP	115
5.37.2.5	CO_ATTR_MAP_REC	115
5.37.2.6	CO_ATTR_MAP_TR	116
5.37.2.7	CO_ATTR_NUM	116
5.37.2.8	CO_ATTR_READ	116
5.37.2.9	CO_ATTR_STORE	116
5.37.2.10	CO_ATTR_WRITE	116
5.37.2.11	CO_OS_LOCK_OD	116
5.37.2.12	CO_OS_UNLOCK_OD	116
5.37.3	Typedef Documentation	116
5.37.3.1	CO_EVENT_OBJECT_CHANGED_FCT_T	116
5.37.4	Enumeration Type Documentation	117
5.37.4.1	CO_DATA_TYPE_T	117
5.37.4.2	CO_ODTYPE_T	117
5.37.5	Function Documentation	117
5.37.5.1	coDynOdAddIndex(UNSIGNED16 index, UNSIGNED8 nrOfSubs, CO_ODTYP↔ E_T odType)	117
5.37.5.2	coDynOdAddSubIndex(UNSIGNED16 index, UNSIGNED8 subIndex, CO_DAT↔ A_TYPE_T dataType, UNSIGNED16 attr, void *pVar)	117

5.37.5.3	coDynOdInit(UNSIGNED16 objCnt, UNSIGNED16 u8Cnt, UNSIGNED16 u16↔ Cnt, UNSIGNED16 u32Cnt, UNSIGNED16 i8Cnt, UNSIGNED16 i16Cnt, UNSI↔ GNED16 i32Cnt, UNSIGNED16 u64Cnt)	118
5.37.5.4	coDynOdRelease(void)	118
5.37.5.5	coDynOdSetSubIndexAddr(UNSIGNED16 index, UNSIGNED8 subIndex, CO_↔ DATA_TYPE_T dataType, void *pVar)	119
5.37.5.6	coEventRegister_OBJECT_CHANGED(CO_EVENT_OBJECT_CHANGED_F↔ CT_T, UNSIGNED16, UNSIGNED8)	119
5.37.5.7	coOdDomainAddrSet(UNSIGNED16 index, UNSIGNED8 subIndex, CO_DOM↔ AIN_PTR pAddr, UNSIGNED32 size)	119
5.37.5.8	coOdGetDefaultVal_u16(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIG↔ NED16 *pDefVal)	120
5.37.5.9	coOdGetDefaultVal_u32(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIG↔ NED32 *pDefVal)	120
5.37.5.10	coOdGetDefaultVal_u8(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGN↔ ED8 *pDefVal)	120
5.37.5.11	coOdGetObj_i16(UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER16 *pObj)	121
5.37.5.12	coOdGetObj_i32(UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER32 *pObj)	121
5.37.5.13	coOdGetObj_i8(UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER8 *pObj)	121
5.37.5.14	coOdGetObj_r32(UNSIGNED16 index, UNSIGNED8 subIndex, REAL32 *pObj) .	122
5.37.5.15	coOdGetObj_u16(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 *pObj)	122
5.37.5.16	coOdGetObj_u24(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED24 *pObj)	122
5.37.5.17	coOdGetObj_u32(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 *pObj)	123
5.37.5.18	coOdGetObj_u40(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED40 *pObj)	123
5.37.5.19	coOdGetObj_u48(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED48 *pObj)	123
5.37.5.20	coOdGetObj_u64(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED64 *pObj)	124
5.37.5.21	coOdGetObj_u8(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pObj)	124
5.37.5.22	coOdGetObjAddr(UNSIGNED16 index, UNSIGNED8 subIndex)	124
5.37.5.23	coOdGetObjAttribute(CO_CONST CO_OBJECT_DESC_T *pObjDesc)	125
5.37.5.24	coOdGetObjDescPtr(UNSIGNED16 index, UNSIGNED8 subIndex, CO_CONST CO_OBJECT_DESC_T **pDescPtr)	125

5.37.5.25 coOdGetObjSize(CO_CONST CO_OBJECT_DESC_T *pDesc)	125
5.37.5.26 coOdInitOdPtr(const CO_OD_ASSIGN_T *pOdAssing, UNSIGNED16 odCnt, const CO_OBJECT_DESC_T *pObjdesc, UNSIGNED16 descCnt, CO_EVENT↔ T_OBJECT_CHANGED_FCT_T *pEventPtr, const CO_OD_DATA_VARIABLE↔ ES_T *pOdVarPointers)	126
5.37.5.27 coOdPutObj_i16(UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER16 newVal)	126
5.37.5.28 coOdPutObj_i32(UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER32 newVal)	127
5.37.5.29 coOdPutObj_i8(UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER8 newVal)	127
5.37.5.30 coOdPutObj_r32(UNSIGNED16 index, UNSIGNED8 subIndex, REAL32 newVal)	127
5.37.5.31 coOdPutObj_u16(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 newVal)	128
5.37.5.32 coOdPutObj_u24(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED24 newVal)	128
5.37.5.33 coOdPutObj_u32(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 newVal)	128
5.37.5.34 coOdPutObj_u40(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED40 newVal)	129
5.37.5.35 coOdPutObj_u48(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED48 newVal)	129
5.37.5.36 coOdPutObj_u64(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED64 newVal)	129
5.37.5.37 coOdPutObj_u8(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 newVal)	130
5.37.5.38 coOdSetCobid(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 newCobId)	130
5.37.5.39 coOdVisStringSet(UNSIGNED16 index, UNSIGNED8 subIndex, VIS_STRIN↔ G pAddr, UNSIGNED32 size)	130
5.38 co_odindex.h File Reference	131
5.38.1 Detailed Description	131
5.39 co_pdo.c File Reference	131
5.39.1 Detailed Description	132
5.39.2 Function Documentation	132
5.39.2.1 coEventRegister_PDO(CO_EVENT_PDO_T pFunction)	132
5.39.2.2 coEventRegister_PDO_REC_EVENT(CO_EVENT_PDO_T pFunction)	132
5.39.2.3 coEventRegister_PDO_SYNC(CO_EVENT_PDO_T pFunction)	132

5.39.2.4	coPdoObjsMapped(UNSIGNED16 pdoNr, UNSIGNED16 index, UNSIGNED8 subIndex)	133
5.39.2.5	coPdoReceiveInit(UNSIGNED16 pdoNr, UNSIGNED8 transType, UNSIGNED16 inhibit, UNSIGNED16 eventTime, CO_CONST PDO_REC_MAP_TABLE_T *mapTable)	133
5.39.2.6	coPdoReqNr(UNSIGNED16 pdoNr, UNSIGNED8 flags)	134
5.39.2.7	coPdoReqObj(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 flags)	134
5.39.2.8	coPdoTransmitInit(UNSIGNED16 pdoNr, UNSIGNED8 transType, UNSIGNED16 inhibit, UNSIGNED16 eventTime, UNSIGNED8 syncStartVal, CO_CONST PDO_REC_MAP_TABLE_T *mapTable)	135
5.40	co_pdo.h File Reference	136
5.40.1	Detailed Description	136
5.40.2	Typedef Documentation	136
5.40.2.1	CO_EVENT_MPDO_T	136
5.40.2.2	CO_EVENT_PDO_T	137
5.40.3	Function Documentation	137
5.40.3.1	coEventRegister_PDO(CO_EVENT_PDO_T pFunction)	137
5.40.3.2	coEventRegister_PDO_REC_EVENT(CO_EVENT_PDO_T pFunction)	137
5.40.3.3	coEventRegister_PDO_SYNC(CO_EVENT_PDO_T pFunction)	138
5.40.3.4	coPdoObjsMapped(UNSIGNED16 pdoNr, UNSIGNED16 index, UNSIGNED8 subIndex)	138
5.40.3.5	coPdoReceiveInit(UNSIGNED16 pdoNr, UNSIGNED8 transType, UNSIGNED16 inhibit, UNSIGNED16 eventTime, CO_CONST PDO_REC_MAP_TABLE_T *mapTable)	139
5.40.3.6	coPdoReqNr(UNSIGNED16 pdoNr, UNSIGNED8 flags)	139
5.40.3.7	coPdoReqObj(UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 flags)	140
5.40.3.8	coPdoTransmitInit(UNSIGNED16 pdoNr, UNSIGNED8 transType, UNSIGNED16 inhibit, UNSIGNED16 eventTime, UNSIGNED8 syncStartVal, CO_CONST PDO_REC_MAP_TABLE_T *mapTable)	140
5.41	co_queue.c File Reference	141
5.41.1	Detailed Description	141
5.41.2	Function Documentation	141
5.41.2.1	coQueueGetNextTransmitMessage(void)	141
5.41.2.2	coQueueInit(void)	142
5.41.2.3	coQueueMsgTransmitted(const CO_CAN_MSG_T *pBuf)	142

5.41.2.4	coQueueReceiveMessageAvailable(void)	142
5.42	co_sdo.h File Reference	142
5.42.1	Detailed Description	144
5.42.2	Typedef Documentation	144
5.42.2.1	CO_EVENT_SDO_CLIENT_DOMAIN_WRITE_T	144
5.42.2.2	CO_EVENT_SDO_CLIENT_READ_T	144
5.42.2.3	CO_EVENT_SDO_CLIENT_WRITE_T	145
5.42.2.4	CO_EVENT_SDO_SERVER_CHECK_WRITE_T	145
5.42.2.5	CO_EVENT_SDO_SERVER_DOMAIN_WRITE_T	146
5.42.2.6	CO_EVENT_SDO_SERVER_T	146
5.42.3	Function Documentation	146
5.42.3.1	coEventRegister_SDO_CLIENT_READ(CO_EVENT_SDO_CLIENT_READ_T pFunction)	146
5.42.3.2	coEventRegister_SDO_CLIENT_WRITE(CO_EVENT_SDO_CLIENT_WRITE_T pFunction)	147
5.42.3.3	coEventRegister_SDO_SERVER_CHECK_WRITE(CO_EVENT_SDO_SERVER_CHECK_WRITE_T pFunction)	147
5.42.3.4	coEventRegister_SDO_SERVER_READ(CO_EVENT_SDO_SERVER_T pFunction)	147
5.42.3.5	coEventRegister_SDO_SERVER_WRITE(CO_EVENT_SDO_SERVER_T pFunction)	147
5.42.3.6	coEventUnregister_SDO_CLIENT_READ(CO_EVENT_SDO_CLIENT_READ_T pFunction)	148
5.42.3.7	coEventUnregister_SDO_CLIENT_WRITE(CO_EVENT_SDO_CLIENT_WRITE_T pFunction)	148
5.42.3.8	coSdoClientInit(UNSIGNED8)	148
5.42.3.9	coSdoNetworkRead(UNSIGNED8 sdoNr, UNSIGNED16 network, UNSIGNED8 node, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UN- SIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)	149
5.42.3.10	coSdoNetworkWrite(UNSIGNED8 sdoNr, UNSIGNED16 network, UNSIGNED8 node, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UN- SIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)	149
5.42.3.11	coSdoQueueAddTransfer(BOOL_T write, UNSIGNED8 sdoNr, UNSIGNED16 in- dex, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, C- O_SDO_QUEUE_IND_T pFct, void *pFctPara)	150

5.42.3.12 coSdoRead(UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)	151
5.42.3.13 coSdoReadSeg(UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)	151
5.42.3.14 coSdoServerInit(UNSIGNED8)	152
5.42.3.15 coSdoWrite(UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)	152
5.42.3.16 coSdoWriteSeg(UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)	153
5.43 co_sdoblockclient.c File Reference	153
5.43.1 Detailed Description	153
5.44 co_sdoblockserver.c File Reference	153
5.44.1 Detailed Description	154
5.45 co_sdoclient.c File Reference	154
5.45.1 Detailed Description	154
5.45.2 Function Documentation	154
5.45.2.1 coEventRegister_SDO_CLIENT_READ(CO_EVENT_SDO_CLIENT_READ_T pFunction)	154
5.45.2.2 coEventRegister_SDO_CLIENT_WRITE(CO_EVENT_SDO_CLIENT_WRITE_T pFunction)	155
5.45.2.3 coEventUnregister_SDO_CLIENT_READ(CO_EVENT_SDO_CLIENT_READ_T pFunction)	155
5.45.2.4 coEventUnregister_SDO_CLIENT_WRITE(CO_EVENT_SDO_CLIENT_WRITE_T pFunction)	155
5.45.2.5 coSdoClientInit(UNSIGNED8 clientNr)	156
5.45.2.6 coSdoRead(UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)	156
5.45.2.7 coSdoReadSeg(UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)	156
5.45.2.8 coSdoWrite(UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)	157

5.45.2.9	coSdoWriteSeg(UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)	158
5.46	co_sdonetwork.c File Reference	158
5.46.1	Detailed Description	158
5.46.2	Function Documentation	159
5.46.2.1	coSdoNetworkRead(UNSIGNED8 sdoNr, UNSIGNED16 network, UNSIGNED8 node, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)	159
5.46.2.2	coSdoNetworkWrite(UNSIGNED8 sdoNr, UNSIGNED16 network, UNSIGNED8 node, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)	159
5.47	co_sdoqueue.c File Reference	160
5.47.1	Detailed Description	160
5.47.2	Function Documentation	160
5.47.2.1	coSdoQueueAddTransfer(BOOL_T write, UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, CO_SDO_QUEUE_IND_T pFct, void *pFctPara)	160
5.48	co_sdoserv.c File Reference	161
5.48.1	Detailed Description	161
5.48.2	Function Documentation	161
5.48.2.1	coEventRegister_SDO_SERVER_CHECK_WRITE(CO_EVENT_SDO_SERVER_CHECK_WRITE_T pFunction)	161
5.48.2.2	coEventRegister_SDO_SERVER_READ(CO_EVENT_SDO_SERVER_T pFunction)	162
5.48.2.3	coEventRegister_SDO_SERVER_WRITE(CO_EVENT_SDO_SERVER_T pFunction)	162
5.48.2.4	coSdoServerInit(UNSIGNED8 sdoServerNr)	162
5.49	co_sleep.c File Reference	163
5.49.1	Detailed Description	163
5.49.2	Function Documentation	163
5.49.2.1	coEventRegister_SLEEP(CO_EVENT_SLEEP_T pFunction)	163
5.49.2.2	coSleepAwake(BOOL_T master, UNSIGNED8 status, UNSIGNED8 reason, UNSIGNED16 repeatTime)	163
5.49.2.3	coSleepModeActive(void)	164
5.49.2.4	coSleepModeStart(UNSIGNED16 waitTime)	164

5.49.2.5	coSleepRequestSleep(void)	164
5.49.2.6	coSleepWakeUp(BOOL_T master, UNSIGNED8 status, UNSIGNED8 reason, UNSIGNED16 repeatTime)	165
5.50	co_sleep.h File Reference	165
5.50.1	Detailed Description	166
5.50.2	Typedef Documentation	166
5.50.2.1	CO_EVENT_SLEEP_T	166
5.50.3	Enumeration Type Documentation	166
5.50.3.1	CO_SLEEP_MODE_T	166
5.50.4	Function Documentation	166
5.50.4.1	coEventRegister_SLEEP(CO_EVENT_SLEEP_T pFunction)	166
5.50.4.2	coSleepAwake(BOOL_T master, UNSIGNED8 status, UNSIGNED8 reason, UNSIGNED16 repeatTime)	167
5.50.4.3	coSleepModeActive(void)	167
5.50.4.4	coSleepModeStart(UNSIGNED16 waitTime)	167
5.50.4.5	coSleepRequestSleep(void)	168
5.50.4.6	coSleepWakeUp(BOOL_T master, UNSIGNED8 status, UNSIGNED8 reason, UNSIGNED16 repeatTime)	168
5.51	co_srd.c File Reference	168
5.51.1	Detailed Description	169
5.51.2	Function Documentation	169
5.51.2.1	coEventRegister_SRD(CO_EVENT_SRD_T pFunction)	169
5.51.2.2	coSrdInit(void)	169
5.51.2.3	coSrdReleaseConnection(UNSIGNED8 sdoClientChannel, UNSIGNED8 remoteNodeId, UNSIGNED32 timeOut)	169
5.51.2.4	coSrdRequestConnection(UNSIGNED8 sdoClientChannel, UNSIGNED8 remoteNodeId, UNSIGNED32 timeOut)	170
5.51.2.5	coSrdRequestRegister(CO_SRD_REQ_TYPE_T reqType, UNSIGNED8 sdoClientChannel, UNSIGNED32 timeOut)	170
5.51.2.6	icoSrdReset(void)	170
5.51.2.7	icoSrdVarInit(void)	171
5.52	co_srd.h File Reference	171
5.52.1	Detailed Description	171

5.52.2	Typedef Documentation	171
5.52.2.1	CO_EVENT_SRD_T	171
5.52.3	Enumeration Type Documentation	172
5.52.3.1	CO_SRD_REQ_TYPE_T	172
5.52.3.2	CO_SRD_RESULT_T	172
5.52.4	Function Documentation	172
5.52.4.1	coEventRegister_SRD(CO_EVENT_SRD_T pFunction)	172
5.52.4.2	coSrdInit(void)	173
5.52.4.3	coSrdReleaseConnection(UNSIGNED8 sdoClientChannel, UNSIGNED8 remoteNodeId, UNSIGNED32 timeOut)	173
5.52.4.4	coSrdRequestConnection(UNSIGNED8 sdoClientChannel, UNSIGNED8 remoteNodeId, UNSIGNED32 timeOut)	173
5.52.4.5	coSrdRequestRegister(CO_SRD_REQ_TYPE_T reqType, UNSIGNED8 sdoClientChannel, UNSIGNED32 timeOut)	173
5.53	co_srdo.c File Reference	174
5.53.1	Detailed Description	174
5.54	co_srdo.h File Reference	174
5.54.1	Detailed Description	174
5.55	co_stackinit.c File Reference	174
5.55.1	Detailed Description	175
5.55.2	Function Documentation	175
5.55.2.1	coCanOpenStackVarInit(CO_SERVICE_INIT_VAL_T *pServiceInitVals)	175
5.56	co_store.c File Reference	175
5.56.1	Detailed Description	175
5.57	co_store.h File Reference	175
5.57.1	Detailed Description	176
5.57.2	Macro Definition Documentation	176
5.57.2.1	CO_STORE_AREA_ALL	176
5.57.2.2	CO_STORE_SIGNATURE_LOAD	176
5.57.2.3	CO_STORE_SIGNATURE_SAVE	176
5.57.3	Typedef Documentation	176
5.57.3.1	CO_EVENT_STORE_T	176

5.58 co_sync.c File Reference	176
5.58.1 Detailed Description	177
5.58.2 Function Documentation	177
5.58.2.1 coEventRegister_SYNC(CO_EVENT_SYNC_T pFunction)	177
5.58.2.2 coEventRegister_SYNC_FINISHED(CO_EVENT_SYNC_FINISHED_T pFunction)	177
5.58.2.3 coSyncInit(UNSIGNED32 cobld)	178
5.59 co_sync.h File Reference	178
5.59.1 Detailed Description	178
5.59.2 Typedef Documentation	179
5.59.2.1 CO_EVENT_SYNC_FINISHED_T	179
5.59.2.2 CO_EVENT_SYNC_T	179
5.59.3 Function Documentation	179
5.59.3.1 coEventRegister_SYNC(CO_EVENT_SYNC_T pFunction)	179
5.59.3.2 coEventRegister_SYNC_FINISHED(CO_EVENT_SYNC_FINISHED_T pFunction)	180
5.59.3.3 coSyncInit(UNSIGNED32 cobld)	180
5.60 co_time.c File Reference	180
5.60.1 Detailed Description	181
5.60.2 Function Documentation	181
5.60.2.1 coEventRegister_TIME(CO_EVENT_TIME_T pFunction)	181
5.60.2.2 coTimeInit(BOOL_T producer, BOOL_T consumer)	181
5.60.2.3 coTimeWriteReq(const CO_TIME_T *pTimeData)	181
5.61 co_time.h File Reference	182
5.61.1 Detailed Description	182
5.61.2 Typedef Documentation	182
5.61.2.1 CO_EVENT_TIME_T	182
5.61.3 Function Documentation	183
5.61.3.1 coEventRegister_TIME(CO_EVENT_TIME_T pFunction)	183
5.61.3.2 coTimeInit(BOOL_T producer, BOOL_T consumer)	183
5.61.3.3 coTimeWriteReq(CO_TIME_T const *pTimeData)	183
5.62 co_timer.c File Reference	184

5.67.1 Detailed Description	191
5.67.2 Typedef Documentation	191
5.67.2.1 CO_EVENT_USER_T	191
5.68 codrv_can_generic.c File Reference	192
5.68.1 Detailed Description	192
5.68.2 Macro Definition Documentation	193
5.68.2.1 POLLING	193
5.68.3 Function Documentation	193
5.68.3.1 codrvCanDisable(void)	193
5.68.3.2 codrvCanDriverHandler(void)	194
5.68.3.3 codrvCanEnable(void)	194
5.68.3.4 codrvCanInit(UNSIGNED16 bitRate)	194
5.68.3.5 codrvCanReceiveInterrupt(void)	195
5.68.3.6 codrvCanReInit(UNSIGNED16 bitRate)	195
5.68.3.7 codrvCanSetBitRate(UNSIGNED16 bitRate)	195
5.68.3.8 codrvCanStartTransmission(void)	196
5.68.3.9 codrvCanTransmitInterrupt(void)	196
5.69 codrv_cpu_generic.c File Reference	196
5.69.1 Detailed Description	197
5.69.2 Function Documentation	197
5.69.2.1 codrvCanSetTxInterrupt(void)	197
5.69.2.2 codrvHardwareCanInit(void)	197
5.69.2.3 codrvHardwareInit(void)	197
5.69.2.4 codrvTimerISR(void)	198
5.69.2.5 codrvTimerSetup(UNSIGNED32 timerInterval)	198
5.70 codrv_error.c File Reference	198
5.70.1 Detailed Description	198
5.70.2 Function Documentation	199
5.70.2.1 codrvCanErrorGetFlags(void)	199
5.70.2.2 codrvCanErrorInformStack(void)	199

Chapter 1

CANopen Stack Reference Manual

1.1 Introduction

The CANopen Slave Stack of emtas is a software library that provides all communication services of the "CANopen Application Layer and Communication Profile" CiA 301 V4.2 and other profiles of CiA e.V. and EN50325-4.

The main features are:

- well-defined interface between driver and CANopen stack
- ANSI-C conform
- MISRA checked
- easy-to-handle Application Programming Interface
- static and dynamic object dictionary are possible
- LED CiA-303
- Layer Setting Services (CiA 305),
- configurable and scalable
- extensions for additional communication profiles such as
 - redundant communication (CiA 302),
 - safety relevant communication (CiA 304) as well as device profile implementations like
 - Generic I/O Modules (CiA 401)
 - EnergyBus Protokoll (CiA 454) are available.

This reference manual describes the functions for the API to evaluate the received data and to use the CANopen services in the network.

Configuration and features settings are supported by the graphical configuration tool CANopen DeviceDesigner.

1.2 General

The CANopen stack use strict data hiding, so access to internal data are only possible by functions. The same is valid for access to the communication segment of the object dictionary.

1.3 Using CANopen stack in an application

At startup, some initialization functions are necessary:

- `codrvHardwareInit()` - generic, CAN related hardware initialization
- `codrvCanInit()` - initialize CAN driver
- `coCanOpenStackInit()` - initialize CANopen functionality
- `codrvTimerSetup()` - initialize hardware timer
- `codrvCanEnable()` - start CAN communication

For the CANopen functionality, the central function `coCommTask()` has to be called in case of

- new CAN message was received
- timer period has been elapsed.

Therefore signal handlers should be used or a cyclic call of the function `coCommTask()` is necessary. For operating systems (like LINUX) the function `codrvWaitForEvent()` can be used to wait for events. All CANopen functionality is handled inside this function.

The start of CANopen services are also possible.

1.4 Indication functions

Indication functions inform application about CAN and CANopen service events.

To receive an indication, the application has to register a function by the appropriate service register function like `coEventRegister_PDO()`.

Every time the event occurs, the registered indication function is called.

Chapter 2

Data Structure Index

2.1 Data Structures

Here are the data structures with brief descriptions:

CO_CAN_COB_T	9
CO_CAN_MSG_T	10
CO_SERVICE_INIT_VAL_T	11
CO_TIME_T	11
co_timer	12
PDO_REC_MAP_ENTRY_T	13
PDO_REC_MAP_TABLE_T	14
PDO_TR_MAP_ENTRY_T	14
PDO_TR_MAP_TABLE_T	15

Chapter 3

File Index

3.1 File List

Here is a list of all documented files with brief descriptions:

co_candebug.c	CAN debug functionality	17
co_candebug.h	Defines for can debug	17
co_canopen.h	Defines for all services	17
co_cfgman.c	Config manager handling	19
co_cfgman.h	Defines for config manager services	21
co_cob.h	Cob defines	23
co_cobhandler.c	Functions for COB handling	24
co_commtask.c	Communication task routines	25
co_commtask.h	Defines for communication services	27
co_datatype.h	Data types	31
co_drv.h	Defines for driver	33
co_dynod.c	This file implements a dynamic object dictionary for objects => 0x2000	38
co_dynod.h	??
co_edsparse.c	EDS parser module	40
co_edsparse.h	??
co_emcy.c	Emergency handling	44
co_emcy.h	Defines for emcy services	46
co_errctrl.c	Error control handling (Heartbeat, Guarding)	49
co_event.c	Event routines	51

co_flyingmaster.h	Defines for nmt flying master services	53
co_gfc.c	Global failsafe command handling	54
co_gfc.h	Defines and the public API for the GFC modul	54
co_guarding.c	Gaurding Master services	54
co_led.c	LED handling according CiA 303-3	56
co_led.h	Defines for usage of LED CiA 303	58
co_iss.c	LSS slave handling	61
co_iss.h	Defines for Iss services	63
co_issmaster.c	LSS master handling	72
co_manager.c	Manager handling according to CiA 302-2	79
co_manager.h	Defines for bootup manager services	81
co_mpdo.c	MPDO handling	84
co_network.c	Multi level networking handling	84
co_network.h	Defines for network services	85
co_nmt.c	Network Managment(NMT) handler	86
co_nmt.h	Defines for nmt services	88
co_nmtmaster.c	NMT master services	96
co_nmtslave.c	NMT slave services	98
co_odaccess.c	Object dictionary access	98
co_odaccess.h	Defines for OD access	112
co_odindex.h	Defines for OD index	131
co_pdo.c	PDO transmission and reception routines	131
co_pdo.h	Defines for pdo service	136
co_queue.c	Queue handling	141
co_sdo.h	Defines for sdo service	142
co_sdoblockclient.c	Sdo block routines	153
co_sdoblockserver.c	Sdo block routines	153
co_sdoclient.c	Sdo client routines	154
co_sdonetwork.c	Sdo network routines	158

co_sdoqueue.c	SDO handling with queuing	160
co_sdoserv.c	SDO server routines	161
co_sleep.c	Sleep and Wakeup Handling	163
co_sleep.h	Defines for sleep services	165
co_srd.c	Service Request Device (SDO Manager Slave)	168
co_srd.h	Defines for srd services	171
co_srdo.c	Srdo handling	174
co_srdo.h	Defines for srdo services	174
co_stackinit.c	Functions for stack intialization handling	174
co_store.c	Stroe/Restore functionality	175
co_store.h	Defines for store services	175
co_sync.c	Sync handling	176
co_sync.h	Defines for sync services	178
co_time.c	Time handling	180
co_time.h	Defines for time services	182
co_timer.c	Timer routines	184
co_timer.h	Defines for timer	186
co_usdo.c	USDO routines	190
co_usdo.h		??
co_usdoserv.c	USDO server routines	190
co_user.c	User CAN functionality	191
co_user.h	Defines for time services	191
codrv_can_generic.c	Generic driver	192
codrv_cpu_generic.c	CPU specific routines	196
codrv_error.c	Error state handling	198

Chapter 4

Data Structure Documentation

4.1 CO_CAN_COB_T Struct Reference

Data Fields

- UNSIGNED32 [canId](#)
- UNSIGNED32 [ignore](#)
- UNSIGNED16 [canChan](#)
- [BOOL_T](#) [extended](#)
- [BOOL_T](#) [rtr](#)
- [BOOL_T](#) [enabled](#)

4.1.1 Detailed Description

CAN cob structure

4.1.2 Field Documentation

4.1.2.1 UNSIGNED16 canChan

reserved for driver

4.1.2.2 UNSIGNED32 canId

can identifier

4.1.2.3 BOOL_T enabled

cob enabled/disabled

4.1.2.4 **BOOL_T** extended

extended id

4.1.2.5 **UNSIGNED32** ignore

ignore mask for id

4.1.2.6 **BOOL_T** rtr

rtr

The documentation for this struct was generated from the following file:

- [co_drv.h](#)

4.2 **CO_CAN_MSG_T** Struct Reference

Data Fields

- **LIBDRV_HANDLE_T** [handle](#)
- **CO_CAN_COB_T** [canCob](#)
- **UNSIGNED8** [len](#)
- **UNSIGNED8** [data](#) [CO_CAN_MAX_DATA_LEN]

4.2.1 Detailed Description

CAN message structure

4.2.2 Field Documentation

4.2.2.1 **CO_CAN_COB_T** canCob

cob infos

4.2.2.2 **UNSIGNED8** data[CO_CAN_MAX_DATA_LEN]

data

4.2.2.3 **LIBDRV_HANDLE_T** handle

library internal handle

4.2.2.4 UNSIGNED8 len

msg len

The documentation for this struct was generated from the following file:

- [co_drv.h](#)

4.3 CO_SERVICE_INIT_VAL_T Struct Reference

4.3.1 Detailed Description

line parameter definition

defines number of line parameter for services

The documentation for this struct was generated from the following file:

- [co_canopen.h](#)

4.4 CO_TIME_T Struct Reference

Data Fields

- UNSIGNED32 [msec](#)
- UNSIGNED16 [days](#)

4.4.1 Detailed Description

TIME_OF_DAY structure

4.4.2 Field Documentation

4.4.2.1 UNSIGNED16 days

days after 1st january of 1984

4.4.2.2 UNSIGNED32 msec

milliseconds after midnight

The documentation for this struct was generated from the following file:

- [co_time.h](#)

4.5 co_timer Struct Reference

Data Fields

- struct [co_timer](#) * [pNext](#)
- UNSIGNED32 [actTicks](#)
- UNSIGNED32 [ticks](#)
- [CO_TIMER_FCT_T](#) [pFct](#)
- void * [pData](#)
- [CO_TIMER_ATTR_T](#) [attr](#)

4.5.1 Detailed Description

timer structure

4.5.2 Field Documentation

4.5.2.1 UNSIGNED32 actTicks

actual timer ticks

4.5.2.2 CO_TIMER_ATTR_T attr

timer attributes

4.5.2.3 void* pData

pointer for own data

4.5.2.4 CO_TIMER_FCT_T pFct

pointer to own function

4.5.2.5 struct co_timer* pNext

pointer to next timer

4.5.2.6 UNSIGNED32 ticks

calculated timer ticks

The documentation for this struct was generated from the following file:

- [co_timer.h](#)

4.6 PDO_REC_MAP_ENTRY_T Struct Reference

Data Fields

- void * [pVar](#)
- UNSIGNED8 [len](#)
- [BOOL_T](#) [numeric](#)
- UNSIGNED32 [val](#)
- UNSIGNED16 [routePdo](#) [1]

4.6.1 Detailed Description

PDO receive mapping entry (one mapping entry)

4.6.2 Field Documentation

4.6.2.1 UNSIGNED8 [len](#)

number of bytes for variable

4.6.2.2 [BOOL_T](#) [numeric](#)

numeric flag for byte swapping

4.6.2.3 void* [pVar](#)

pointer to variable

4.6.2.4 UNSIGNED16 [routePdo](#)[1]

route to other network

4.6.2.5 UNSIGNED32 [val](#)

OD value

The documentation for this struct was generated from the following file:

- [co_pdo.h](#)

4.7 PDO_REC_MAP_TABLE_T Struct Reference

Data Fields

- UNSIGNED8 [mapCnt](#)
- [PDO_REC_MAP_ENTRY_T](#) [mapEntry](#) [CO_MAX_MAP_ENTRIES]

4.7.1 Detailed Description

PDO mapping table (mapping entries for one receive PDO)

4.7.2 Field Documentation

4.7.2.1 UNSIGNED8 [mapCnt](#)

number of mapping entries

4.7.2.2 [PDO_REC_MAP_ENTRY_T](#) [mapEntry](#)[CO_MAX_MAP_ENTRIES]

Mapping entries

The documentation for this struct was generated from the following file:

- [co_pdo.h](#)

4.8 PDO_TR_MAP_ENTRY_T Struct Reference

Data Fields

- CO_CONST void * [pVar](#)
- UNSIGNED8 [len](#)
- [BOOL_T](#) [numeric](#)
- UNSIGNED32 [val](#)

4.8.1 Detailed Description

PDO transmit mapping entry (one mapping entry)

4.8.2 Field Documentation

4.8.2.1 UNSIGNED8 [len](#)

number of bytes for variable

4.8.2.2 BOOL_T numeric

numeric flag for byte swapping

4.8.2.3 CO_CONST void* pVar

pointer to variable

4.8.2.4 UNSIGNED32 val

OD value

The documentation for this struct was generated from the following file:

- [co_pdo.h](#)

4.9 PDO_TR_MAP_TABLE_T Struct Reference

Data Fields

- UNSIGNED8 [mapCnt](#)
- [PDO_TR_MAP_ENTRY_T](#) [mapEntry](#) [CO_MAX_MAP_ENTRIES]

4.9.1 Detailed Description

PDO mapping table (mapping entries for one transmit PDO)

4.9.2 Field Documentation

4.9.2.1 UNSIGNED8 mapCnt

number of mapping entries

4.9.2.2 PDO_TR_MAP_ENTRY_T mapEntry[CO_MAX_MAP_ENTRIES]

Mapping entries

The documentation for this struct was generated from the following file:

- [co_pdo.h](#)

Chapter 5

File Documentation

5.1 co_candebug.c File Reference

CAN debug functionality.

5.1.1 Detailed Description

CAN debug functionality.

Contain functions to send any data over CAN

5.2 co_candebug.h File Reference

defines for can debug

5.2.1 Detailed Description

defines for can debug

- contains defines for can debug services

5.3 co_canopen.h File Reference

defines for all services

Data Structures

- struct [CO_SERVICE_INIT_VAL_T](#)

Functions

- EXTERN_DECL [RET_T coCanOpenStackInit](#) ([CO_EVENT_STORE_T](#) pLoadFunction)
coCanOpenStackInit - init of CANopen stack
- EXTERN_DECL [RET_T coCanOpenStackInitPara](#) ([CO_EVENT_STORE_T](#) pLoadFunction, [CO_INIT_OPTION_T](#) *pCoOptions)
coCanOpenStackInit - init of CANopen stack This function is normally generated by the CANopen Device Designer and responsible for the initialization of the CANopen stack. In addition to coCanOpenStackInit some options for services can be added.
- EXTERN_DECL void [coCanOpenStackDeInit](#) (void)
coCanOpenStackDeInit - deinit of CANopen stack
- EXTERN_DECL void [coCanOpenStackVarInit](#) ([CO_SERVICE_INIT_VAL_T](#) *pServiceInitVals)
coCanOpenStackVarInit - init of variables of the stack

5.3.1 Detailed Description

defines for all services

- contains defines for all services

This header includes defines for all services of the CANopen library. It can be included instead of header files of each service.

5.3.2 Function Documentation

5.3.2.1 EXTERN_DECL void coCanOpenStackDeInit (void)

coCanOpenStackDeInit - deinit of CANopen stack

This function is normally generated by the CANopen Device Designer and responsible for the de-initialization of the CANopen stack.

Returns

void

5.3.2.2 EXTERN_DECL RET_T coCanOpenStackInit (CO_EVENT_STORE_T pLoadFunction)

coCanOpenStackInit - init of CANopen stack

This function is normally generated by the CANopen Device Designer and responsible for the initialization of the CANopen stack.

Returns

RET_T

5.3.2.3 EXTERN_DECL RET_T coCanOpenStackInitPara (CO_EVENT_STORE_T pLoadFunction, CO_INIT_OPTION_T * pCoOptions)

coCanOpenStackInit - init of CANopen stack This function is normally generated by the CANopen Device Designer and responsible for the initialization of the CANopen stack. In addition to coCanOpenStackInit some options for services can be added.

Returns

RET_T

5.3.2.4 EXTERN_DECL void coCanOpenStackVarInit (CO_SERVICE_INIT_VAL_T * pServiceInitVals)

coCanOpenStackVarInit - init of variables of the stack

This function initializes all global and local variables of the stack.

It can also be used to reinitialize the stack.

Returns

nothing

Parameters

<i>pServiceInitVals</i>	pointer to init vals
-------------------------	----------------------

5.4 co_cfgman.c File Reference

config manager handling

Functions

- [RET_T coCfgStart](#) (UNSIGNED8 sdoNr, UNSIGNED8 srvNodeId, UNSIGNED8 *pBuf, UNSIGNED32 bufLen, UNSIGNED32 sdoTimeOut)
co_cfgStart - start configuration
- [RET_T coCfgConvToConsive](#) (CHAR *pDcfData, UNSIGNED8 *pConsBuf, UNSIGNED32 *pConsBufLen)
co_convertToConsiceDcf - convert to consice DCF
- [RET_T coEventRegister_CFG_MANAGER](#) (CO_EVENT_CFG_MANAGER_T pFunction)
coEventRegister_CFG_MAN - register CFG_MAN event

5.4.1 Detailed Description

config manager handling

contains configuration manager handling

5.4.2 Function Documentation

5.4.2.1 RET_T coCfgConvToConsive (CHAR * *pDcfData*, UNSIGNED8 * *pConsBuf*, UNSIGNED32 * *pConsBufLen*)

co_convertToConsiceDcf - convert to consice DCF

This function convert the given data to the consive DCF. At function call the parameter pConsBufLen contains the maximal buffer length, and is updated with the real len of written buffer.

Returns

RET_T

Parameters

<i>pDcfData</i>	pointer to DCF data
<i>pConsBuf</i>	pointer to consive DCF buffer
<i>pConsBufLen</i>	max len of consive DCF buffer

5.4.2.2 RET_T coCfgStart (UNSIGNED8 *sdoNr*, UNSIGNED8 *srvNodeId*, UNSIGNED8 * *pBuf*, UNSIGNED32 *bufLen*, UNSIGNED32 *sdoTimeOut*)

co_cfgStart - start configuration

This function starts the SDO transfer to setup a node with a new configuration. Parameter are given as consive DCF buffer. For the SDO transfer, the client with sdoNr is used. If parameter srvNodeId != 0, then the sdo channel is automatically configured with the default server sdo cobs for the given nodeld.

If transfer is started successful, the function returns RET_OK. Finish of the whole transfer is indicated by the function configured by [coEventRegister_CFG_MANAGER\(\)](#).

Returns

RET_T

Parameters

<i>sdoNr</i>	use sdo number
<i>srvNodeId</i>	write to node n
<i>pBuf</i>	pointer to consive dcf buffer
<i>bufLen</i>	len of consive dcf buffer
<i>sdoTimeOut</i>	SDO timeout in msec

5.4.2.3 RET_T coEventRegister_CFG_MANAGER (CO_EVENT_CFG_MANAGER_T *pFunction*)

coEventRegister_CFG_MAN - register CFG_MAN event

This function registers an indication function for CFG_MAN events. The indication function is called after transfer to slave has been finished

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.5 co_cfgman.h File Reference

defines for config manager services

Typedefs

- typedef void(* [CO_EVENT_CFG_MANAGER_T](#)) ([CO_CFG_TRANSFER_T](#), UNSIGNED8, UNSIGNED16, UNSIGNED8, UNSIGNED32)
function pointer to SDO server event

Enumerations

Functions

- EXTERN_DECL [RET_T coCfgStart](#) (UNSIGNED8 sdoNr, UNSIGNED8 srvNodeId, UNSIGNED8 *pBuf, UNSIGNED32 bufLen, UNSIGNED32 sdoTimeOut)
co_cfgStart - start configuration
- EXTERN_DECL [RET_T coCfgConvToConsive](#) (char *pDcfData, UNSIGNED8 *pConsBuf, UNSIGNED32 *pConsBufLen)
co_convertToConsiceDcf - convert to consice DCF
- EXTERN_DECL [RET_T coEventRegister_CFG_MANAGER](#) ([CO_EVENT_CFG_MANAGER_T](#) pFct)
coEventRegister_CFG_MAN - register CFG_MAN event

5.5.1 Detailed Description

defines for config manager services

- contains defines for cfgman services

5.5.2 Typedef Documentation

- 5.5.2.1 typedef void(* [CO_EVENT_CFG_MANAGER_T](#)) ([CO_CFG_TRANSFER_T](#), UNSIGNED8, UNSIGNED16, UNSIGNED8, UNSIGNED32)

function pointer to SDO server event

Parameters

<i>type</i>	- result type
<i>sdoNr</i>	- sdo number
<i>index</i>	- object index
<i>subindex</i>	- object subindex
<i>reason</i>	- error reason

Returns

void

5.5.3 Enumeration Type Documentation

5.5.3.1 enum CO_CFG_TRANSFER_T

CO_CFG_TRANSFER_T state

Enumerator

CO_CFG_TRANSFER_FINISHED transfer finished ok
CO_CFG_TRANSFER_ABORT transfer abort by SDO server
CO_CFG_TRANSFER_ERROR transfer error by start SDO client

5.5.4 Function Documentation

5.5.4.1 EXTERN_DECL RET_T coCfgConvToConsive (CHAR * *pDcfData*, UNSIGNED8 * *pConsBuf*, UNSIGNED32 * *pConsBufLen*)

co_convertToConsiceDcf - convert to consice DCF

This function convert the given data to the consive DCF. At function call the parameter *pConsBufLen* contains the maximal buffer length, and is updated with the real len of written buffer.

Returns

RET_T

Parameters

<i>pDcfData</i>	pointer to DCF data
<i>pConsBuf</i>	pointer to consive DCF buffer
<i>pConsBufLen</i>	max len of consive DCF buffer

5.5.4.2 EXTERN_DECL RET_T coCfgStart (UNSIGNED8 *sdoNr*, UNSIGNED8 *srvNodeId*, UNSIGNED8 * *pBuf*, UNSIGNED32 *bufLen*, UNSIGNED32 *sdoTimeout*)

co_cfgStart - start configuration

This function starts the SDO transfer to setup a node with a new configuration. Parameter are given as consive DCF buffer. For the SDO transfer, the client with *sdoNr* is used. If parameter *srvNodeId* != 0, then the sdo channel is automatically configured with the default server sdo cobs for the given *nodeId*.

If transfer is started successful, the function returns RET_OK. Finish of the whole transfer is indicated by the function configured by [coEventRegister_CFG_MANAGER\(\)](#).

Returns

RET_T

Parameters

<i>sdoNr</i>	use sdo number
<i>srvNodeId</i>	write to node n
<i>pBuf</i>	pointer to consive dcf buffer
<i>bufLen</i>	len of consive dcf buffer
<i>sdoTimeout</i>	SDO timeout in msec

5.5.4.3 EXTERN_DECL RET_T coEventRegister_CFG_MANAGER (CO_EVENT_CFG_MANAGER_T *pFunction*)

coEventRegister_CFG_MAN - register CFG_MAN event

This function registers an indication function for CFG_MAN events. The indication function is called after transfer to slave has been finished

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.6 co_cob.h File Reference

cob defines

Macros

- #define [CO_COB_INVALID](#) 0x80000000UL

- `#define CO_COB_29BIT 0x20000000UL`
- `#define CO_COB_VALID_MASK 0x80000000UL`
- `#define CO_COB_29BIT_MASK 0x20000000UL`
- `#define CO_COB_ID_MASK 0x1FFFFFFFUL`

5.6.1 Detailed Description

cob defines

- contains defines for cobs

5.6.2 Macro Definition Documentation

5.6.2.1 `#define CO_COB_29BIT 0x20000000UL`

COB 29bit flag if this bit is set, the COB-ID is a 29-bit identifier

5.6.2.2 `#define CO_COB_29BIT_MASK 0x20000000UL`

COB 29bit mask With this mask, cobs can be checked for 29bit identifier

5.6.2.3 `#define CO_COB_ID_MASK 0x1FFFFFFFUL`

COB ID mask With this mask, only identifier bits are masked

5.6.2.4 `#define CO_COB_INVALID 0x80000000UL`

COB invalid if this bit is set, the COB-ID (and the service) is invalid

5.6.2.5 `#define CO_COB_VALID_MASK 0x80000000UL`

cob valid mask With this mask, cobs can be checked for valid

5.7 co_cobhandler.c File Reference

Functions for COB handling.

5.7.1 Detailed Description

Functions for COB handling.

contains functions for cob handling

5.8 co_commtask.c File Reference

communication task routines

Functions

- void [coCommTask](#) (void)
coCommTask - main communication task
- void [coCommStateEvent](#) ([CO_COMM_STATE_EVENT_T](#) newEvent)
coCommStateEvent - set a new communication state
- [RET_T](#) [coEventRegister_CAN_STATE](#) ([CO_EVENT_CAN_STATE_T](#) pFunction)
coEventRegister_CAN_STATE - register can state changes
- [RET_T](#) [coEventRegister_COMM_EVENT](#) ([CO_EVENT_COMM_T](#) pFunction)
coEventRegister_COMM_EVENT - register communication event changes

5.8.1 Detailed Description

communication task routines

contains communication task functions of canopen library

5.8.2 Function Documentation

5.8.2.1 void coCommStateEvent (CO_COMM_STATE_EVENT_T newEvent)

coCommStateEvent - set a new communication state

This function should be called, if a new communication state has been reached. It sets the LEDs and informs the application about the event.

Returns

void

Parameters

<i>newEvent</i>	new communication event
-----------------	-------------------------

5.8.2.2 void coCommTask (void)

coCommTask - main communication task

This is the main communication task for the CANopen stack. It has to be called cyclically by the application or signal driven after each received CAN message or timer event.

Returns

void

5.8.2.3 RET_T coEventRegister_CAN_STATE (CO_EVENT_CAN_STATE_T *pFunction*)

coEventRegister_CAN_STATE - register can state changes

With this function the application can register a function which is called, when the CAN state was changed.
CAN states are:

- BUS_OFF
- BUS_ON
- PASSIV
- UNCHANGED

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.8.2.4 RET_T coEventRegister_COMM_EVENT (CO_EVENT_COMM_T *pFunction*)

coEventRegister_COMM_EVENT - register communication event changes

With this function the application can register a function which is called, when the communication state has been changed.

- BUS OFF - no communication possible
- CAN OVERRUN - messages was lost
- Receice queue full - receive messages is full
- Receice queue overrun - receive messages was lost
- Transmit queue full - no more messages can be send
- Transmit queue overflow - transmit messages was lost
- Transmit queue empty - new transmit messages can be send

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.9 co_commtask.h File Reference

defines for communication services

Typedefs

- typedef void(* [CO_EVENT_CAN_STATE_T](#)) ([CO_CAN_STATE_T](#))
function pointer to CAN state indication function
- typedef void(* [CO_EVENT_COMM_T](#)) ([CO_COMM_STATE_EVENT_T](#))
function pointer to Communication state event indication function

Enumerations

Functions

- EXTERN_DECL void [coCommTask](#) (void)
coCommTask - main communication task
- EXTERN_DECL void [coCommStateEvent](#) ([CO_COMM_STATE_EVENT_T](#) newEvent)
coCommStateEvent - set a new communication state
- EXTERN_DECL [RET_T](#) [coEventRegister_COMM_EVENT](#) ([CO_EVENT_COMM_T](#) pFunction)
coEventRegister_COMM_EVENT - register communication event changes
- EXTERN_DECL [RET_T](#) [coEventRegister_CAN_STATE](#) ([CO_EVENT_CAN_STATE_T](#) pFunction)
coEventRegister_CAN_STATE - register can state changes
- EXTERN_DECL void [coQueueInit](#) (void)
coQueueInit - (re)init queues

5.9.1 Detailed Description

defines for communication services

- contains defines for communication services of the CANopen library

5.9.2 Typedef Documentation

5.9.2.1 typedef void(* [CO_EVENT_CAN_STATE_T](#)) ([CO_CAN_STATE_T](#))

function pointer to CAN state indication function

Parameters

<i>canState</i>	- new CAN state
-----------------	-----------------

Provides a new CAN controller state like Bus on, Bus off, error passive

Returns

void

5.9.2.2 typedef void(* CO_EVENT_COMM_T) (CO_COMM_STATE_EVENT_T)

function pointer to Communication state event indication function

Parameters

<i>commState</i>	- new communication state
------------------	---------------------------

Provides new communication states like buffer state, CAN working state CO_COMM_STATE_EVENT_REC_QUEUE_FULL CO_COMM_STATE_EVENT_REC_QUEUE_OVERFLOW CO_COMM_STATE_EVENT_REC_QUEUE_EMPTY CO_COMM_STATE_EVENT_TR_QUEUE_FULL CO_COMM_STATE_EVENT_TR_QUEUE_OVERFLOW CO_COMM_STATE_EVENT_TR_QUEUE_EMPTY CO_COMM_STATE_EVENT_CAN_OVERRUN
CAN controller states are only signaled by CO_EVENT_CAN_STATE_T

Returns

void

5.9.3 Enumeration Type Documentation**5.9.3.1 enum CO_CAN_STATE_T**

CAN states

Enumerator

CO_CAN_STATE_BUS_OFF CAN bus state is bus off

CO_CAN_STATE_BUS_ON CAN bus state is bus on

CO_CAN_STATE_PASSIVE CAN bus state is passive

CO_CAN_STATE_UNCHANGED CAN bus state is unchanged

5.9.3.2 enum CO_COMM_STATE_EVENT_T

Communication state events

Enumerator

CO_COMM_STATE_EVENT_NONE no event
CO_COMM_STATE_EVENT_BUS_OFF bus off
CO_COMM_STATE_EVENT_BUS_OFF_RECOVERY recovery from bus off
CO_COMM_STATE_EVENT_BUS_ON bus on
CO_COMM_STATE_EVENT_PASSIVE can passive
CO_COMM_STATE_EVENT_ACTIVE can active
CO_COMM_STATE_EVENT_CAN_OVERRUN can overrun
CO_COMM_STATE_EVENT_REC_QUEUE_FULL receive queue full
CO_COMM_STATE_EVENT_REC_QUEUE_OVERFLOW receive queue overflow
CO_COMM_STATE_EVENT_REC_QUEUE_EMPTY receive queue empty
CO_COMM_STATE_EVENT_TR_QUEUE_FULL transmit queue full
CO_COMM_STATE_EVENT_TR_QUEUE_OVERFLOW transmit queue overflow
CO_COMM_STATE_EVENT_TR_QUEUE_EMPTY transmit queue empty

5.9.3.3 enum CO_COMMTASK_EVENT_T

Communication task events

5.9.4 Function Documentation

5.9.4.1 EXTERN_DECL void coCommStateEvent (CO_COMM_STATE_EVENT_T newEvent)

coCommStateEvent - set a new communication state

This function should be called, if a new communication state has been reached. It sets the LEDs and informs the application about the event.

Returns

void

Parameters

<i>newEvent</i>	new communication event
-----------------	-------------------------

5.9.4.2 EXTERN_DECL void coCommTask (void)

coCommTask - main communication task

This is the main communication task for the CANopen stack. It has to be called cyclically by the application or signal driven after each received CAN message or timer event.

Returns

void

5.9.4.3 EXTERN_DECL RET_T coEventRegister_CAN_STATE (CO_EVENT_CAN_STATE_T *pFunction*)

coEventRegister_CAN_STATE - register can state changes

With this function the application can register a function which is called, when the CAN state was changed. CAN states are:

- BUS_OFF
- BUS_ON
- PASSIV
- UNCHANGED

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.9.4.4 EXTERN_DECL RET_T coEventRegister_COMM_EVENT (CO_EVENT_COMM_T *pFunction*)

coEventRegister_COMM_EVENT - register communication event changes

With this function the application can register a function which is called, when the communication state has been changed.

- BUS OFF - no communication possible
- CAN OVERRUN - messages was lost
- Receice queue full - receive messages is full
- Receice queue overrun - receive messages was lost
- Transmit queue full - no more messages can be send
- Transmit queue overflow - transmit messages was lost
- Transmit queue empty - new transmit messages can be send

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.9.4.5 EXTERN_DECL void coQueueInit (void)

coQueueInit - (re)init queues

This function clears the transmit and the receive queue

Returns

none

5.10 co_datatype.h File Reference

data types

Macros

- #define MSG_OVERWRITE 1u
- #define MSG_RET_INHIBIT 2u

Enumerations

5.10.1 Detailed Description

data types

- contains defines for data types

5.10.2 Macro Definition Documentation

5.10.2.1 #define MSG_OVERWRITE 1u

transmit message flags: if the last message is not transmitted yet, overwrite the last data with the new data

5.10.2.2 #define MSG_RET_INHIBIT 2u

return, if the inhibit time is not elapsed yet

5.10.3 Enumeration Type Documentation

5.10.3.1 enum **BOOL_T**

define for bool values

Enumerator

CO_FALSE false
CO_TRUE true

5.10.3.2 enum **RET_T**

Defines for **RET_T**

Enumerator

RET_OK all ok
RET_INVALID_PARAMETER error invalid parameter
RET_PARAMETER_INCOMPATIBLE error incompatible parameter
RET_NOT_INITIALIZED error function not initialized
RET_EVENT_NO_RESSOURCE error no ressource available
RET_INVALID_NMT_STATE error invalid NMT state
RET_INVALID_NODEID invalid node id
RET_ALREADY_INITIALIZED error already initialized
RET_IDX_NOT_FOUND error index not found
RET_SUBIDX_NOT_FOUND error subindex not found
RET_OD_ACCESS_ERROR error access at object dictionary
RET_NO_READ_PERM error no read permission
RET_NO_WRITE_PERM error no write permission
RET_SDO_UNKNOWN_CCS error unknown command specifier
RET_SDO_DATA_TYPE_NOT_MATCH error wrong data type
RET_SDO_INVALID_VALUE error invalid value
RET_SDO_TRANSFER_NOT_SUPPORTED error transfer not supported
RET_OUT_OF_MEMORY error out of memory
RET_DATA_TYPE_MISMATCH error data type mismatch
RET_TOGGLE_MISMATCH error toggle bit not alternate
RET_SDO_CRC_ERROR error CRC mismatch
RET_SDO_WRONG_BLOCKSIZE error wrong blocksize
RET_SDO_WRONG_SEQ_NR error wrong sequence number
RET_SDO_TIMEOUT error sdo timeout
RET_SDO_SPLIT_INDICATION SDO split indikation
RET_NO_COB_AVAILABLE error no cob available
RET_COB_DISABLED error cob-id is disabled
RET_DRV_WRONG_BITRATE error unknown bitrate
RET_DRV_ERROR error driver

RET_DRV_TRANS_BUFFER_FULL error transmit buffer full
RET_DRV_BUSY error driver is busy
RET_MAP_ERROR error map entry incorrect
RET_MAP_LEN_ERROR error mapping len incorrect
RET_INHIBIT_ACTIVE error inhibit is active
RET_INTERNAL_ERROR error internal
RET_HARDWARE_ERROR error hardware access
RET_ERROR_PRESENT_DEVICE_STATE error wrong device state
RET_VALUE_NOT_AVAILABLE error value not available
RET_ERROR_STORE error store data
RET_SERVICE_ALREADY_INITIALIZED service already initialized
RET_SERVICE_NOT_INITIALIZED service not initialized
RET_SERVICE_BUSY error service is busy
RET_CFG_CONVERT_ERROR cfg manager convert error
RET_NETWORK_ID_UNKNOWN network id unknown
RET_SDO_NODE_ID_UNKNOWN node id unknown
RET_SDO_CHANNEL_IN_USE channel already in use

5.11 co_drv.h File Reference

defines for driver

Data Structures

- struct [CO_CAN_COB_T](#)
- struct [CO_CAN_MSG_T](#)

Functions

- EXTERN_DECL void [codrvHardwareInit](#) (void)
codrvHardwareInit - hardware initialization
- EXTERN_DECL [RET_T](#) [codrvCanInit](#) (UNSIGNED16 bitRate)
codrvCanInit - init CAN controller
- EXTERN_DECL [RET_T](#) [codrvCanReInit](#) (UNSIGNED16 bitRate)
codrvCanReInit - reinit CAN controller
- EXTERN_DECL [RET_T](#) [codrvCanSetBitRate](#) (UNSIGNED16 bitRate)
codrvCanSetBitRate - set CAN Bitrate
- EXTERN_DECL [RET_T](#) [codrvCanStartTransmission](#) (void)
codrvCanStartTransmission - start can transmission if not active
- EXTERN_DECL void [codrvCanDriverHandler](#) (void)
codrvCanDriverHandler - can driver handler
- EXTERN_DECL [RET_T](#) [codrvCanEnable](#) (void)
codrvCanEnable - enable CAN controller
- EXTERN_DECL [RET_T](#) [codrvCanDisable](#) (void)
codrvCanDisable - disable CAN controller
- EXTERN_DECL void [coQueueMsgTransmitted](#) (const [CO_CAN_MSG_T](#) *pBuf)

- coQueueMsgTransmitted* - message was transmitted
- EXTERN_DECL [CO_CAN_MSG_T](#) * [coQueueGetNextTransmitMessage](#) (void)
 - coQueueGetNextTransmitMessage* - get next message to transmit
- EXTERN_DECL [BOOL_T](#) [coQueueReceiveMessageAvailable](#) (void)
 - coQueueReceiveMessageAvailable* - receive messages available
- EXTERN_DECL void [codrvCanEnableInterrupt](#) (void)
 - codrvCanEnableInterrupt* - enable the CAN interrupt
- EXTERN_DECL void [codrvCanDisableInterrupt](#) (void)
 - codrvCanDisableInterrupt* - disable the CAN interrupt
- EXTERN_DECL [RET_T](#) [codrvTimerSetup](#) (UNSIGNED32 timerInterval)
 - codrvTimerSetup* - init and configure the hardware Timer

5.11.1 Detailed Description

defines for driver

- contains defines for driver

5.11.2 Function Documentation

5.11.2.1 EXTERN_DECL RET_T codrvCanDisable (void)

codrvCanDisable - disable CAN controller

This function disables the CAN controller. The function waits for the CAN controller being disabled. Code calling this function typically expects that after returning the CAN controller is in Init mode.

But note, the time the CAN controller needs to enter the Init mode can be as long as the duration of one CAN frame.

Returns

[RET_T](#)

Return values

RET_OK	CAN controller is set to be disabled
------------------------	--------------------------------------

5.11.2.2 EXTERN_DECL void codrvCanDriverHandler (void)

codrvCanDriverHandler - can driver handler

This function is cyclically called from the CANopen stack to get the current CAN state (BUS_OFF, PASSIVE, ACTIVE).

If a bus off event has occurred, this function should try to get to bus on again (activate the CAN controller).

Returns

void

5.11.2.3 EXTERN_DECL RET_T codrvCanEnable (void)

codrvCanEnable - enable CAN controller

This function enables the CAN controller. At this point the enable bit is set. Typically the CAN controller requests 11 recessive bits to go in active mode. This will be checked later outside of this function.

Returns

RET_T

Return values

<i>RET_OK</i>	CAN controller, enabled was set
---------------	---------------------------------

5.11.2.4 EXTERN_DECL RET_T codrvCanInit (UNSIGNED16 *bitRate*)

codrvCanInit - init CAN controller

This function initializes the CAN controller and configures the bitrate. At the end of the function, the CAN controller should be in state disabled.

Returns

RET_T

Return values

<i>RET_OK</i>	initialization was OK
---------------	-----------------------

Parameters

<i>bitRate</i>	CAN bitrate
----------------	-------------

5.11.2.5 EXTERN_DECL RET_T codrvCanReInit (UNSIGNED16 *bitRate*)

codrvCanReInit - reinit CAN controller

This Function reinit the CAN controller after deactivation.

In Filter mode: After this function call all Filter are reset and must be reconfigured!

At the end of the function, the CAN controller should be in state disabled.

Parameters

<i>bitrate</i>	- CANopen bitrate RET_T
----------------	----------------------------

Parameters

<i>bitRate</i>	CAN bitrate
----------------	-------------

5.11.2.6 EXTERN_DECL RET_T codrvCanSetBitRate (UNSIGNED16 *bitRate*)

codrvCanSetBitRate - set CAN Bitrate

This function sets the CAN Bitrate to the given value. Changing the Bitrate is only allowed, if the CAN controller is in reset. The state at the start of the function is unknown, so the CAN controller should be switch to state reset.

At the end of the function the CAN controller should be stay in state reset.

Returns

RET_T

Return values

<i>RET_OK</i>	setting of Bitrate was OK
---------------	---------------------------

Parameters

<i>bitRate</i>	CAN Bitrate in kbit/s
----------------	-----------------------

5.11.2.7 EXTERN_DECL RET_T codrvCanStartTransmission (void)

codrvCanStartTransmission - start can transmission if not active

Transmission of CAN messages should be interrupt driven. If a message was sent, the Transmit Interrupt is called and the next message can be transmitted. To start the transmission of the first message, this function is called from the CANopen stack.

The easiest way to implement this function is to trigger the transmit interrupt, but only of the transmission is not already active.

Returns

RET_T

Return values

<i>RET_OK</i>	start transmission was successful
---------------	-----------------------------------

5.11.2.8 EXTERN_DECL void codrvHardwareInit (void)

codrvHardwareInit - hardware initialization

This function initializes the hardware, incl. clock and CAN hardware.

5.11.2.9 EXTERN_DECL RET_T codrvTimerSetup (UNSIGNED32 *timerInterval*)

codrvTimerSetup - init and configure the hardware Timer

This function starts a cyclic hardware timer to provide a timing interval for the CANopen library. Alternatively it can be derived from an other system timer with the timer interval given by the function parameter.

Returns

RET_T

Return values

<i>RET_OK</i>	initialization of the timer was ok
---------------	------------------------------------

Parameters

<i>timerInterval</i>	timer interval in usec
----------------------	------------------------

5.11.2.10 EXTERN_DECL CO_CAN_MSG_T* coQueueGetNextTransmitMessage (void)

coQueueGetNextTransmitMessage - get next message to transmit

This function returns the next available transmit message from the transmit queue. It increments also trBufferRdCnt.

Returns

CO_CAN_MSG_T* pointer to next tx message

Return values

<i>NULL</i>	pointer to transmit queue entry
<i>NULL</i>	no message available

5.11.2.11 EXTERN_DECL void coQueueMsgTransmitted (const CO_CAN_MSG_T * *pBuf*)

coQueueMsgTransmitted - message was transmitted

This function is called after a message was succesfull transmitted.

Returns

none

Parameters

<i>pBuf</i>	pointer to transmitted message
-------------	--------------------------------

5.11.2.12 EXTERN_DECL BOOL_T coQueueReceiveMessageAvailable (void)

coQueueReceiveMessageAvailable - receive messages available

This functions checks the receive queue for new messages. Are new messages available, return CO_TRUE. Otherwise CO_FALSE

Return values

CO_FALSE	no data available
CO_TRUE	data available

5.12 co_dynod.c File Reference

This file implements a dynamic object dictionary for objects => 0x2000.

Functions

- [RET_T coDynOdInit](#) (UNSIGNED16 objCnt, UNSIGNED16 u8Cnt, UNSIGNED16 u16Cnt, UNSIGNED16 u32Cnt, UNSIGNED16 i8Cnt, UNSIGNED16 i16Cnt, UNSIGNED16 i32Cnt, UNSIGNED16 u64Cnt)
coDynOdInit - init dynamic object dictionary
- [RET_T coDynOdRelease](#) (void)
coDynOdRelease - release dynamic object dictionary
- [RET_T coDynOdAddIndex](#) (UNSIGNED16 index, UNSIGNED8 nrOfSubs, CO_ODTYPE_T odType)
coDynOdAddIndex - add a new object index
- [RET_T coDynOdAddSubIndex](#) (UNSIGNED16 index, UNSIGNED8 subIndex, CO_DATA_TYPE_T dataType, UNSIGNED16 attr, void *pVar)
coDynOdAddSubIndex - add new subindex
- [RET_T coDynOdSetSubIndexAddr](#) (UNSIGNED16 index, UNSIGNED8 subIndex, CO_DATA_TYPE_T dataType, void *pVar)
coDynOdSetSubIndexAddr - set new pointer for subindex

5.12.1 Detailed Description

This file implements a dynamic object dictionary for objects => 0x2000.

5.12.2 Function Documentation

5.12.2.1 RET_T coDynOdAddIndex (UNSIGNED16 index, UNSIGNED8 nrOfSubs, CO_ODTYPE_T odType)

coDynOdAddIndex - add a new object index

Return values

<i>RET_IDX_NOT_FOUND</i>	index < 0x2000 are not allowed
<i>RET_INVALID_PARAMETER</i>	index already exist
<i>RET_EVENT_NO_RESSOURCE</i>	no resource available

Parameters

<i>index</i>	index
<i>nrOfSubs</i>	number of subindex
<i>odType</i>	variable, array, struct

5.12.2.2 **RET_T** coDynOdAddSubIndex (**UNSIGNED16** *index*, **UNSIGNED8** *subIndex*, **CO_DATA_TYPE_T** *dataType*, **UNSIGNED16** *attr*, void * *pVar*)

coDynOdAddSubIndex - add new subindex

no check for to many data or duplicate subindex

Return values

<i>RET_DATA_TYPE_MISMATCH</i>	data type not supported (only U8, U16, U32, I8, I16, I32 allowed)
<i>RET_IDX_NOT_FOUND</i>	index not found

Parameters

<i>index</i>	index
<i>subIndex</i>	number of subindex
<i>dataType</i>	data type
<i>attr</i>	attribute
<i>pVar</i>	pointer to variable

5.12.2.3 **RET_T** coDynOdInit (**UNSIGNED16** *objCnt*, **UNSIGNED16** *u8Cnt*, **UNSIGNED16** *u16Cnt*, **UNSIGNED16** *u32Cnt*, **UNSIGNED16** *i8Cnt*, **UNSIGNED16** *i16Cnt*, **UNSIGNED16** *i32Cnt*, **UNSIGNED16** *u64Cnt*)

coDynOdInit - init dynamic object dictionary

Return values

<i>RET_OK</i>	initialisation OK
<i>RET_EVENT_NO_RESSOURCE</i>	error at malloc()

Parameters

<i>objCnt</i>	number of new objects for can line
<i>u8Cnt</i>	number of U8 vars for can line
<i>u16Cnt</i>	number of U16 vars for can line

Parameters

<i>u32Cnt</i>	number of U32 vars for can line
<i>i8Cnt</i>	number of i8 vars for can line
<i>i16Cnt</i>	number of i16 vars for can line
<i>i32Cnt</i>	number of i32 vars for can line
<i>u64Cnt</i>	number of U64 vars for can line

5.12.2.4 RET_T coDynOdRelease (void)

coDynOdRelease - release dynamic object dictionary

Deinit dynamic object dictionary and release all requested memory

Return values

<i>RET_OK</i>	deinitialisation OK
---------------	---------------------

5.12.2.5 RET_T coDynOdSetSubIndexAddr (UNSIGNED16 index, UNSIGNED8 subIndex, CO_DATA_TYPE_T dataType, void * pVar)

coDynOdSetSubIndexAddr - set new pointer for subindex

set a new data pointer for a given sub index

Return values

<i>RET_DATA_TYPE_MISMATCH</i>	data type not supported (only U8, U16, U32, I8, I16, I32 allowed)
<i>RET_IDX_NOT_FOUND</i>	index not found

Parameters

<i>index</i>	index
<i>subIndex</i>	number of subindex
<i>dataType</i>	data type
<i>pVar</i>	pointer to variable

5.13 co_edsparse.c File Reference

EDS parser module.

Functions

- [RET_T coEdsparseAddEdsToRepository](#) (char *edsFilePath)

- coEdsparseAddEdsToRepository* - add file to eds repository
- [RET_T coEdsparseDetectSlaveEds](#) (UNSIGNED8 nodeId, UNSIGNED8 sdoClientNr, CO_DETECT_SLAVE_FCT_T finishFct)
 - detectSlaveEds* - detect slave EDS file
- [RET_T coEdsparseReadEdsMapping](#) (UNSIGNED8 nodeId, char *edsFileName)
 - coEdsparseReadEdsMapping* - read mapping from EDS file
- CO_EDS_MAP_TABLE_T * [coEdsparseGetRPdoMapEntry](#) (UNSIGNED16 mapIdx)
 - coEdsparseGetRPdoMapEntry* - get RPDO map entry from EDS table
- CO_EDS_MAP_TABLE_T * [coEdsparseGetTPdoMapEntry](#) (UNSIGNED16 mapIdx)
 - coEdsparseGetTPdoMapEntry* - get TPDO map entry from EDS table
- UNSIGNED16 [coEdsparseGetSupportedObjCnt](#) (char *edsFileName, char *section)
 - coEdsparseGetSupportedIndexCnt* - return number of supported index
- [RET_T coEdsparseGetIndexDesc](#) (char *edsFileName, char *pSection, UNSIGNED16 edsIdx, UNSIGNED16 *pIndex, UNSIGNED8 *pNrOfSubs)
 - coEdsparseGetIndexDesc* - return index description
- [RET_T coEdsparseGetObjectDesc](#) (char *edsFileName, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 *pDataType, UNSIGNED16 *pAttr, char *pDefaultVal)
 - coEdsparseGetObjectDesc* - get object description

5.13.1 Detailed Description

EDS parser module.

contains EDS parse routines

5.13.2 Function Documentation

5.13.2.1 RET_T coEdsparseAddEdsToRepository (char * edsFilePath)

coEdsparseAddEdsToRepository - add file to eds repository

This function add an EDS file to the internal repository and parse it for identity data

Returns

RET_T

Parameters

<i>edsFilePath</i>	eds file name
--------------------	---------------

5.13.2.2 RET_T coEdsparseDetectSlaveEds (UNSIGNED8 nodeId, UNSIGNED8 sdoClientNr, CO_DETECT_SLAVE_FCT_T finishFct)

detectSlaveEds - detect slave EDS file

This function read the identity from the given slave and checks it by available identity parameter from EDS repository. If it fit the identity from the device and the EDS given finishFct returns the fitting EDS file name.

If an error occurs, the finishFct returns without EDS file name but with the appropriate error.

Returns

RET_T

Parameters

<i>nodeId</i>	node id
<i>sdoClientNr</i>	SDO client number
<i>finishFct</i>	function for finish action

5.13.2.3 RET_T coEdsparseGetIndexDesc (char * edsFileName, char * pSection, UNSIGNED16 edsIdx, UNSIGNED16 * pIndex, UNSIGNED8 * pNrOfSubs)

coEdsparseGetIndexDesc - return index description

This function returns some information about the object index given by eds index. The maximum number of eds index can get by function [coEdsparseGetSupportedObjCnt\(\)](#)

section should be one of MandatoryObjects OptionalObjects ManufacturerObjects

Returns

RET_T

Parameters

<i>edsFileName</i>	eds file name
<i>pSection</i>	section name
<i>edsIdx</i>	index at eds file list
<i>pIndex</i>	object index
<i>pNrOfSubs</i>	number of subindex

5.13.2.4 RET_T coEdsparseGetObjectDesc (char * edsFileName, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 * pDataType, UNSIGNED16 * pAttr, char * pDefaultVal)

coEdsparseGetObjectDesc - get object description

This function returns object description from EDS for the given object index.

Returns

RET_T

Parameters

<i>edsFileName</i>	eds file name
--------------------	---------------

Parameters

<i>index</i>	object index
<i>subIndex</i>	object subindex
<i>pDataType</i>	pointer for data type
<i>pAttr</i>	pointer for object attributes
<i>pDefaultVal</i>	pointer for default val

5.13.2.5 CO_EDS_MAP_TABLE_T* coEdsparseGetRPdoMapEntry (UNSIGNED16 *mapIdx*)

coEdsparseGetRPdoMapEntry - get RPDO map entry from EDS table

This function returns a RPDO map entry from the EDS table

Returns

RET_T

Parameters

<i>mapIdx</i>	map index at table
---------------	--------------------

5.13.2.6 UNSIGNED16 coEdsparseGetSupportedObjCnt (char * *edsFileName*, char * *section*)

coEdsparseGetSupportedIndexCnt - return number of supported index

This function counts the supported index for the given section and return the number of supported index

section should be one of MandatoryObjects OptionalObjects ManufacturerObjects

Returns

number of supported index

Parameters

<i>edsFileName</i>	eds file name
<i>section</i>	section name

5.13.2.7 CO_EDS_MAP_TABLE_T* coEdsparseGetTPdoMapEntry (UNSIGNED16 *mapIdx*)

coEdsparseGetTPdoMapEntry - get TPDO map entry from EDS table

This function returns a TPDO map entry from the EDS table

Returns

RET_T

Parameters

<i>mapIdx</i>	map index at table
---------------	--------------------

5.13.2.8 RET_T coEdsparseReadEdsMapping (UNSIGNED8 nodeId, char * edsFileName)

coEdsparseReadEdsMapping - read mapping from EDS file

This function read the EDS file and save the values at the internal mapping tables.

Returns

RET_T

Parameters

<i>nodeId</i>	node id
<i>edsFileName</i>	eds file name

5.14 co_emcy.c File Reference

Emergency handling.

Functions

- [RET_T coEmcyWriteReq](#) (UNSIGNED16 emcyErrCode, CO_CONST UNSIGNED8 pData[])
coEmcyWriteReq - write an emergency message
- [RET_T coEventRegister_EMCY](#) (CO_EVENT_EMCY_T pFunction)
coEventRegister_EMCY - register emergency event function
- [RET_T coEventRegister_EMCY_CONSUMER](#) (CO_EVENT_EMCY_CONS_T pFunction)
coEventRegister_EMCY_CONSUMER - register emergency consumer event function
- [RET_T coEmcyProducerInit](#) (void)
coEmcyProducerInit - initialization for emergency producer
- [RET_T coEmcyConsumerInit](#) (UNSIGNED8 emcyCnt)
coEmcyConsumerInit - initialization for emergency consumer

5.14.1 Detailed Description

Emergency handling.

contains emcy routines

5.14.2 Function Documentation

5.14.2.1 RET_T coEmcyConsumerInit (UNSIGNED8 *emcyCnt*)

coEmcyConsumerInit - initialization for emergency consumer

This function initializes the emergency consumers.

Returns

RET_T

Parameters

<i>emcyCnt</i>	number of emergency consumers
----------------	-------------------------------

5.14.2.2 RET_T coEmcyProducerInit (void)

coEmcyProducerInit - initialization for emergency producer

This function initializes the emergency producer functionality.

Returns

RET_T

5.14.2.3 RET_T coEmcyWriteReq (UNSIGNED16 *emcyErrCode*, CO_CONST UNSIGNED8 *pData*[])

coEmcyWriteReq - write an emergency message

With this function, an emergency message can be send.

The message is automatically composed and transmitted by the given parameter and the error register value (index 0x1001:0). After that, the error history (index 0x1003:n) is updated with the new data.

The parameter *pData* can be NULL, if no application specific data should be sent.

The error register (index 0x1001:0) has to be updated by the application.

Returns

RET_T

Parameters

<i>emcyErrCode</i>	emergency error code
<i>pData</i>	pointer to additional 5 data bytes

5.14.2.4 RET_T coEventRegister_EMCY (CO_EVENT_EMCY_T pFunction)

coEventRegister_EMCY - register emergency event function

This function registers an emergency indication function.

Returns

RET_T

5.14.2.5 RET_T coEventRegister_EMCY_CONSUMER (CO_EVENT_EMCY_CONS_T pFunction)

coEventRegister_EMCY_CONSUMER - register emergency consumer event function

This function registers an emergency consumer indication function.

Returns

RET_T

5.15 co_emcy.h File Reference

defines for emcy services

Macros

- #define CO_EMCY_ERRCODE_PDO_LEN 0x8210u
- #define CO_EMCY_ERRCODE_COMM_ERROR 0x8130u

Typedefs

- typedef RET_T(* CO_EVENT_EMCY_T) (UNSIGNED16 errCode, const UNSIGNED8 *addErrorCode)
function pointer to emergency function
- typedef void(* CO_EVENT_EMCY_CONS_T) (UNSIGNED8 node, UNSIGNED16 errCode, UNSIGNED8 errorRegister, UNSIGNED8 const *addErrorCode)
function pointer to emergency consumer function

Functions

- EXTERN_DECL RET_T coEmcyProducerInit (void)
coEmcyProducerInit - initialization for emergency producer
- EXTERN_DECL RET_T coEmcyConsumerInit (UNSIGNED8 emcyCnt)
coEmcyConsumerInit - initialization for emergency consumer
- EXTERN_DECL RET_T coEventRegister_EMCY (CO_EVENT_EMCY_T pFunction)
coEventRegister_EMCY - register emergency event function
- EXTERN_DECL RET_T coEventRegister_EMCY_CONSUMER (CO_EVENT_EMCY_CONS_T pFunction)
coEventRegister_EMCY_CONSUMER - register emergency consumer event function

5.15.1 Detailed Description

defines for emcy services

- contains defines for emcy services

5.15.2 Macro Definition Documentation

5.15.2.1 `#define CO_EMCY_ERRCODE_COMM_ERROR 0x8130u`

define for Emergency Error Code communication error

5.15.2.2 `#define CO_EMCY_ERRCODE_PDO_LEN 0x8210u`

define for Emergency Error Code wrong PDO length

5.15.3 Typedef Documentation

5.15.3.1 `typedef void(* CO_EVENT_EMCY_CONS_T) (UNSIGNED8 node, UNSIGNED16 errCode, UNSIGNED8 errorRegister, UNSIGNED8 const *addErrorCode)`

function pointer to emergency consumer function

Parameters

<i>node</i>	- node id of received emergency
<i>errCode</i>	- emergency error code
<i>errorRegister</i>	- emergency error register
<i>addErrorCode</i>	- pointer to 5 bytes error code

Returns

none

5.15.3.2 `typedef RET_T(* CO_EVENT_EMCY_T) (UNSIGNED16 errCode, const UNSIGNED8 *addErrorCode)`

function pointer to emergency function

Parameters

<i>errCode</i>	- emergency error code
<i>addErrorCode</i>	- pointer to 5 bytes error code

Returns

RET_T

Return values

<i>RET_OK</i>	send emergency
<i>RET_xx</i>	don't send emergency

5.15.4 Function Documentation**5.15.4.1 EXTERN_DECL RET_T coEmcyConsumerInit (UNSIGNED8 *emcyCnt*)**

coEmcyConsumerInit - initialization for emergency consumer

This function initializes the emergency consumers.

Returns

RET_T

Parameters

<i>emcyCnt</i>	number of emergency consumers
----------------	-------------------------------

5.15.4.2 EXTERN_DECL RET_T coEmcyProducerInit (void)

coEmcyProducerInit - initialization for emergency producer

This function initializes the emergency producer functionality.

Returns

RET_T

5.15.4.3 EXTERN_DECL RET_T coEventRegister_EMCY (CO_EVENT_EMCY_T *pFunction*)

coEventRegister_EMCY - register emergency event function

This function registers an emergency indication function.

Returns

RET_T

5.15.4.4 EXTERN_DECL RET_T coEventRegister_EMCY_CONSUMER (CO_EVENT_EMCY_CONS_T pFunction)

coEventRegister_EMCY_CONSUMER - register emergency consumer event function

This function registers an emergency consumer indication function.

Returns

RET_T

5.16 co_errctrl.c File Reference

Error control handling (Heartbeat, Guarding)

Functions

- [RET_T coHbConsumerSet](#) (UNSIGNED8 node, UNSIGNED16 hbTime)
coHbConsumerSet - setup heartbeat consumer
- [RET_T coHbConsumerStart](#) (UNSIGNED8 node)
coHbConsumerStart - start heartbeat consumer monitoring
- [CO_NMT_STATE_T coNmtGetRemoteNodeState](#) (UNSIGNED8 nodeId)
coNmtGetRemoteNodeState - get remote node state
- [RET_T coEventRegister_ERRCTRL](#) (CO_EVENT_ERRCTRL_T pFunction)
coEventRegister_ERRCTRL - register error control event
- [RET_T coErrorCtrlInit](#) (UNSIGNED16 hbTime, UNSIGNED8 hbConsCnt)
coInitNmt - init error control

5.16.1 Detailed Description

Error control handling (Heartbeat, Guarding)

Contains error control routines to handle Heartbeat or Guarding.

5.16.2 Function Documentation

5.16.2.1 RET_T coErrorCtrlInit (UNSIGNED16 hbTime, UNSIGNED8 hbConsCnt)

coInitNmt - init error control

Setup error control handling for local node (transmit heartbeat) and remote node (heartbeat monitoring)

Returns

RET_T

Parameters

<i>hbTime</i>	heartbeat producer time
<i>hbConsCnt</i>	heartbeat consumer count

5.16.2.2 **RET_T** coEventRegister_ERRCTRL (**CO_EVENT_ERRCTRL_T** *pFunction*)

coEventRegister_ERRCTRL - register error control event

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.16.2.3 **RET_T** coHbConsumerSet (**UNSIGNED8** *node*, **UNSIGNED16** *hbTime*)

coHbConsumerSet - setup heartbeat consumer

This function configures a heartbeat consumer for the given node-id and the monitoring time. The data are automatically saved at the object dictionary. If an entry at the object dictionary already exist, then it will be overwritten. The parameter node have to be valid, otherwise the function returns an error.

Returns

RET_T

Return values

<i>RET_PARAMETER_INCOMPATIBLE</i>	invalid node id
-----------------------------------	-----------------

Parameters

<i>node</i>	node id
<i>hbTime</i>	heartbeat monitoring time

5.16.2.4 **RET_T** coHbConsumerStart (**UNSIGNED8** *node*)

coHbConsumerStart - start heartbeat consumer monitoring

This function starts a heartbeat consumer monitoring for the given node-id and the configured monitoring time from object dictionary.

Please note: The NMT state is set to unknown until next HB was received

Returns

RET_T

Return values

RET_PARAMETER_INCOMPATIBLE	invalid node id
----------------------------	-----------------

Parameters

node	node id
------	---------

5.16.2.5 CO_NMT_STATE_T coNmtGetRemoteNodeState (UNSIGNED8 nodeId)

coNmtGetRemoteNodeState - get remote node state

This function returns the NMT state of a remote node. If heartbeat monitoring of this node is disabled or has been failed, CO_NMT_STATE_UNKNOWN is returned.

Returns

CO_NMT_STATE_T

Parameters

node↔ Id	remote node id
-------------	----------------

5.17 co_event.c File Reference

event routines

Functions

- [RET_T icoEventStart](#) (CO_EVENT_T *pEvent, CO_EVENT_FCT_T ptrToFct, void *pData)
coEventStart - start a event
- [BOOL_T icoEventsActive](#) (CO_CONST CO_EVENT_T *pEvent)
coEventsActive - check if event is active
- void [icoEventInit](#) (void)
icoEventInit - init event interval

5.17.1 Detailed Description

event routines

contains event routines

5.17.2 Function Documentation

5.17.2.1 void icoEventInit (void)

icoEventInit - init event interval

This function initializes the internal event handling.

Returns

none

5.17.2.2 BOOL_T icoEventIsActive (CO_CONST CO_EVENT_T * *pEvent*)

coEventIsActive - check if event is active

With this function can be checked, if a event is currently in the event list.

Returns

BOOL_T

Return values

<i>CO_TRUE</i>	event is active
<i>CO_FALSE</i>	event is not active

Parameters

<i>pEvent</i>	pointer to event struct
---------------	-------------------------

5.17.2.3 RET_T icoEventStart (CO_EVENT_T * *pEvent*, CO_EVENT_FCT_T *ptrToFct*, void * *pData*)

coEventStart - start a event

This function add an event at end of the event list

Returns

RET_T

Parameters

<i>pEvent</i>	pointer to eventstruct
<i>ptrToFct</i>	function for event
<i>pData</i>	pointer for own data

5.18 co_flyingmaster.h File Reference

defines for nmt flying master services

Typedefs

- typedef void(* [CO_EVENT_FLYMA_T](#)) ([CO_FLYMA_STATE_T](#), UNSIGNED8, UNSIGNED8)
function pointer to NMT flying master event function

Enumerations

5.18.1 Detailed Description

defines for nmt flying master services

- contains defines for nmt flying master services

5.18.2 Typedef Documentation

5.18.2.1 typedef void(* [CO_EVENT_FLYMA_T](#)) ([CO_FLYMA_STATE_T](#), UNSIGNED8, UNSIGNED8)

function pointer to NMT flying master event function

Parameters

<i>nmtFlymaState</i>	- flying master event
<i>node</i>	- node id of actual master
<i>prior</i>	- priority of actual master

Returns

void

5.18.3 Enumeration Type Documentation

5.18.3.1 enum [CO_FLYMA_STATE_T](#)

NMT states

Enumerator

[CO_FLYMA_STATE_DETECT_NO_MASTERS](#) no master detected
[CO_FLYMA_STATE_MASTERS_AVAILABLE](#) master capable available
[CO_FLYMA_STATE_NO_ACTIVE_MASTER](#) no active master found
[CO_FLYMA_STATE_NEGOTIATION_STARTED](#) negotiation started
[CO_FLYMA_STATE_MASTER](#) we are master
[CO_FLYMA_STATE_SLAVE](#) we are slave

5.19 co_gfc.c File Reference

global failsafe command handling

5.19.1 Detailed Description

global failsafe command handling

Contains functions for the global failsafe services. The global failsafe service is not safety relevant, so there dynamic events possible for this service.

5.20 co_gfc.h File Reference

defines and the public API for the GFC modul.

Typedefs

- typedef void(* [CO_EVENT_GFC_T](#)) (void)
function pointer to gfc function

5.20.1 Detailed Description

defines and the public API for the GFC modul.

- contains defines for gfc services

5.20.2 Typedef Documentation

5.20.2.1 typedef void(* CO_EVENT_GFC_T) (void)

function pointer to gfc function

Returns

void

5.21 co_guarding.c File Reference

Gaurding Master services.

Functions

- [RET_T coGuardingMasterStart](#) (UNSIGNED8 node)
coGuardingMasterStart - start master node guarding
- [RET_T coGuardingMasterStop](#) (UNSIGNED8 node)
coGuardingMasterStop - stop master node guarding
- [CO_NMT_STATE_T icoGuardGetRemoteNodeState](#) (UNSIGNED8 nodeId)
coNmtGetRemoteNodeState - get remote node state

5.21.1 Detailed Description

Guarding Master services.

Contains guarding master routines.

5.21.2 Function Documentation

5.21.2.1 RET_T coGuardingMasterStart (UNSIGNED8 node)

coGuardingMasterStart - start master node guarding

This function starts the master node guarding monitoring for the given node-id and the configured monitoring time from object dictionary.

Please note: The NMT state is set to unknown until next guarding was received

Returns

RET_T

Return values

<i>RET_PARAMETER_INCOMPATIBLE</i>	invalid node id
-----------------------------------	-----------------

Parameters

<i>node</i>	node id
-------------	---------

5.21.2.2 RET_T coGuardingMasterStop (UNSIGNED8 node)

coGuardingMasterStop - stop master node guarding

This function stops the master node guarding monitoring for the given node-id

Returns

RET_T

Return values

<code>RET_PARAMETER_INCOMPATIBLE</code>	invalid node id
---	-----------------

Parameters

<code>node</code>	node id
-------------------	---------

5.21.2.3 `CO_NMT_STATE_T` `icoGuardGetRemoteNodeState (UNSIGNED8 nodeId)`

`coNmtGetRemoteNodeState` - get remote node state

This function returns the NMT state of a remote node. If guarding monitoring of this node is disabled or has been failed, `CO_NMT_STATE_UNKNOWN` is returned.

Returns

`CO_NMT_STATE_T`

Parameters

<code>nodeId</code>	remote node id
---------------------	----------------

5.22 `co_led.c` File Reference

LED handling according CiA 303-3.

Functions

- void `coLedSetGreen (CO_LED_STATE_T newLedState)`
coLedSetGreen - set green led to new state
- void `coLedSetRed (CO_LED_STATE_T newLedState)`
coLedSetRed - set red led to new state
- void `coLedSetState (CO_LED_STATE_T newState, BOOL_T on)`
coLedSetState - set led state
- `RET_T` `coEventRegister_LED_GREEN (CO_EVENT_LED_T pFunction)`
coEventRegister_LED_GREEN - register for green LED
- `RET_T` `coEventRegister_LED_RED (CO_EVENT_LED_T pFunction)`
coEventRegister_LED_RED - register for red LED

5.22.1 Detailed Description

LED handling according CiA 303-3.

contains LED handling according CiA 303-3

5.22.2 Function Documentation

5.22.2.1 RET_T coEventRegister_LED_GREEN (CO_EVENT_LED_T *pFunction*)

coEventRegister_LED_GREEN - register for green LED

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.22.2.2 RET_T coEventRegister_LED_RED (CO_EVENT_LED_T *pFunction*)

coEventRegister_LED_RED - register for red LED

Register application function for controlling of LED state

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.22.2.3 void coLedSetGreen (CO_LED_STATE_T *newLedState*)

coLedSetGreen - set green led to new state

Set green LED to one of the following state:

- OFF,
- FLICKERING,
- FLASH_1, FLASH_2, FLASH_3,
- BLINKING,
- ON

Returns

none

Parameters

<i>newLedState</i>	new led state
--------------------	---------------

5.22.2.4 void coLedSetRed (CO_LED_STATE_T *newLedState*)

coLedSetRed - set red led to new state

Set led LED to one of the following state: OFF, FLICKERING, FLASH_1, FLASH_2, FLASH_3, BLINKING, ON

Returns

none

Parameters

<i>newLedState</i>	new led state
--------------------	---------------

5.22.2.5 void coLedSetState (CO_LED_STATE_T *newState*, BOOL_T *on*)

coLedSetState - set led state

Set the error led to special state OFF, FLICKERING, FLASH_1, FLASH_2, FLASH_3, BLINKING, ON

All states are saved. Only the highest prior state is displayed. If the highest state is reset, the next state is displayed.

Returns

none

Parameters

<i>newState</i>	new state
<i>on</i>	set state to on/off

5.23 co_led.h File Reference

defines for usage of LED CiA 303

Typedefs

- typedef void(* [CO_EVENT_LED_T](#)) (BOOL_T)
function pointer to LED indication function

Enumerations

Functions

- EXTERN_DECL void [coLedSetGreen](#) ([CO_LED_STATE_T](#) newLedState)
coLedSetGreen - set green led to new state
- EXTERN_DECL void [coLedSetRed](#) ([CO_LED_STATE_T](#) newLedState)
coLedSetRed - set red led to new state
- EXTERN_DECL void [coLedSetState](#) ([CO_LED_STATE_T](#) newState, [BOOL_T](#) on)
coLedSetState - set led state
- EXTERN_DECL [RET_T](#) [coEventRegister_LED_GREEN](#) ([CO_EVENT_LED_T](#) pFunction)
coEventRegister_LED_GREEN - register for green LED
- EXTERN_DECL [RET_T](#) [coEventRegister_LED_RED](#) ([CO_EVENT_LED_T](#) pFunction)
coEventRegister_LED_RED - register for red LED

5.23.1 Detailed Description

defines for usage of LED CiA 303

- contains defines for usage of LED CiA 303

5.23.2 Typedef Documentation

5.23.2.1 typedef void(* CO_EVENT_LED_T) (BOOL_T)

function pointer to LED indication function

Parameters

<i>led_state</i>	- set led on/off
------------------	------------------

Returns

void

5.23.3 Enumeration Type Documentation

5.23.3.1 enum CO_LED_STATE_T

LED states

Enumerator

- CO_LED_STATE_OFF** led is off
- CO_LED_STATE_FLICKERING** led is flickering
- CO_LED_STATE_FLASH_1** led is flashing mode 1

CO_LED_STATE_FLASH_2 led is flashing mode 2
CO_LED_STATE_FLASH_3 led is flashing mode 3
CO_LED_STATE_BLINKING led is blinking
CO_LED_STATE_ON led is on

5.23.4 Function Documentation

5.23.4.1 EXTERN_DECL RET_T coEventRegister_LED_GREEN (CO_EVENT_LED_T *pFunction*)

coEventRegister_LED_GREEN - register for green LED

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.23.4.2 EXTERN_DECL RET_T coEventRegister_LED_RED (CO_EVENT_LED_T *pFunction*)

coEventRegister_LED_RED - register for red LED

Register application function for controlling of LED state

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.23.4.3 EXTERN_DECL void coLedSetGreen (CO_LED_STATE_T *newLedState*)

coLedSetGreen - set green led to new state

Set green LED to one of the following state:

- OFF,
- FLICKERING,
- FLASH_1, FLASH_2, FLASH_3,
- BLINKING,
- ON

Returns

none

Parameters

<i>newLedState</i>	new led state
--------------------	---------------

5.23.4.4 EXTERN_DECL void coLedSetRed (CO_LED_STATE_T *newLedState*)

coLedSetRed - set red led to new state

Set led LED to one of the following state: OFF, FLICKERING, FLASH_1, FLASH_2, FLASH_3, BLINKING, ON

Returns

none

Parameters

<i>newLedState</i>	new led state
--------------------	---------------

5.23.4.5 EXTERN_DECL void coLedSetState (CO_LED_STATE_T *newState*, BOOL_T *on*)

coLedSetState - set led state

Set the error led to special state OFF, FLICKERING, FLASH_1, FLASH_2, FLASH_3, BLINKING, ON

All states are saved. Only the highest prior state is displayed. If the highest state is reset, the next state is displayed.

Returns

none

Parameters

<i>newState</i>	new state
<i>on</i>	set state to on/off

5.24 co_iss.c File Reference

LSS slave handling.

Functions

- void [coLssNonConfigSlave](#) (void)

- coLssNonConfigSlave* - request for unconfigured slaves
- [RET_T coEventRegister_LSS](#) ([CO_EVENT_LSS_T](#) pFunction)
 - coEventRegister_LSS* - register LSS event
- [RET_T coLssInit](#) (void)
 - coLssInit* - init LSS functionality

5.24.1 Detailed Description

LSS slave handling.

contains LSS slave services

5.24.2 Function Documentation

5.24.2.1 [RET_T coEventRegister_LSS](#) ([CO_EVENT_LSS_T](#) pFunction)

coEventRegister_LSS - register LSS event

This function registers an indication function for LSS events.

Returns

[RET_T](#)

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.24.2.2 [RET_T coLssInit](#) (void)

coLssInit - init LSS functionality

This function initializes the LSS functionality, depending on the define `CO_LSS_SLAVE_SUPPORTED` or `CO_LSS_MASTER_SUPPORTED` as slave or master.

Returns

[RET_T](#)

5.24.2.3 [void coLssNonConfigSlave](#) (void)

coLssNonConfigSlave - request for unconfigured slaves

get answer, if node-id == 255

Returns

none

5.25 co_Iss.h File Reference

defines for Iss services

Typedefs

- typedef void(* [CO_EVENT_LSS_T](#)) ([CO_LSS_SERVICE_T](#) service, UNSIGNED16 bitrate, UNSIGNED8 *pErrCode, UNSIGNED8 *pErrSpec)
function pointer to LSS indication
- typedef void(* [CO_EVENT_LSS_MASTER_T](#)) ([CO_LSS_MASTER_SERVICE_T](#), UNSIGNED16 errorCode, UNSIGNED8 errorSpec, UNSIGNED32 *pIdentity)
function pointer to LSS master indication

Enumerations

Functions

- EXTERN_DECL [RET_T](#) [coLssInit](#) (void)
coLssInit - init LSS functionality
- EXTERN_DECL [RET_T](#) [coLssMasterInit](#) (void)
coLssMasterInit - init LSS functionality
- EXTERN_DECL [RET_T](#) [coEventRegister_LSS](#) ([CO_EVENT_LSS_T](#) pFunction)
coEventRegister_LSS - register LSS event
- EXTERN_DECL [RET_T](#) [coEventRegister_LSS_MASTER](#) ([CO_EVENT_LSS_MASTER_T](#) pFunction)
coEventRegister_LSS_MASTER - register LSS master event
- EXTERN_DECL [RET_T](#) [coLssIdentifyNonConfiguredSlaves](#) (UNSIGNED16 timeOutVal, UNSIGNED16 interval)
coLssIdentifyNonConfiguredSlaves - identify unconfigured remote slaves
- EXTERN_DECL void [coLssNonConfigSlave](#) (void)
coLssNonConfigSlave - request for unconfigured slaves
- EXTERN_DECL [RET_T](#) [coLssFastScan](#) (UNSIGNED16 timeOutVal)
coLssFastScan - start fastscan
- EXTERN_DECL [RET_T](#) [coLssFastScanKnownDevice](#) (UNSIGNED32 vendorId, UNSIGNED32 productCode, UNSIGNED32 versionNr, UNSIGNED32 serNr, UNSIGNED16 timeOutVal)
coLssFastScanKnownDevice - start fastscan for known device
- EXTERN_DECL [RET_T](#) [coLssSetNodeId](#) (UNSIGNED8 nodeId, UNSIGNED16 timeOutVal)
coLssSetNodeId - set node id for remote node
- EXTERN_DECL [RET_T](#) [coLssSetBitrate](#) (UNSIGNED16 bitRate, UNSIGNED16 timeOutVal)
coLssSetBitrate - set bitrate for remote nodes
- EXTERN_DECL [RET_T](#) [coLssSetBitrateTable](#) (UNSIGNED8 tableSelector, UNSIGNED8 tableIndex, UNSIGNED16 timeOutVal)
coLssSetBitrate - set bitrate for remote nodes
- EXTERN_DECL [RET_T](#) [coLssActivateBitrate](#) (UNSIGNED16 switchDelay)
coLssActivateBitrate - activate bitratenodes
- EXTERN_DECL [RET_T](#) [coLssSwitchGlobal](#) ([CO_LSS_STATE_T](#) mode)
coLssSwitchGlobal - send global switch command
- EXTERN_DECL [RET_T](#) [coLssSwitchSelective](#) (UNSIGNED32 vendorId, UNSIGNED32 productCode, UNSIGNED32 versionNr, UNSIGNED32 serNr, UNSIGNED16 timeOutVal)
coLssSwitchSelective - send Selective switch command

- EXTERN_DECL RET_T [coLssStoreConfig](#) (UNSIGNED16 timeOutVal)
coLssStoreConfig - store configuration
- EXTERN_DECL RET_T [coLssInquireNodeId](#) (UNSIGNED16 timeOutVal)
coLssInquireNodeId - inquire actual node ID
- EXTERN_DECL RET_T [coLssInquireIdentity](#) (UNSIGNED8 subIndex, UNSIGNED16 timeOutVal)
coLssInquireIdentity - inquire identity data
- EXTERN_DECL RET_T [coLssIdentifyRemoteSlaves](#) (UNSIGNED32 vendor, UNSIGNED32 productCode, UNSIGNED32 revisionLow, UNSIGNED32 revisionHigh, UNSIGNED32 serialNumberLow, UNSIGNED32 serialNumberHigh, UNSIGNED16 timeOutVal)
coLssIdentifyRemoteSlaves - identify remote slaves
- EXTERN_DECL void [coLssMasterDisable](#) (void)
coLssMasterDisable - disable LSS master services
- EXTERN_DECL void [coLssMasterEnable](#) (void)
coLssMasterEnable - enable LSS master services
- EXTERN_DECL UNSIGNED32 [coLssMasterGetInquireData](#) (void)
coLssMasterGetInquireData - get requested inquire data

5.25.1 Detailed Description

defines for lss services

- contains defines for lss services

5.25.2 Typedef Documentation

5.25.2.1 typedef void(* CO_EVENT_LSS_MASTER_T) (CO_LSS_MASTER_SERVICE_T, UNSIGNED16 errorCode, UNSIGNED8 errorSpec, UNSIGNED32 *pIdentity)

function pointer to LSS master indication

Parameters

<i>service</i>	- answer for service LSS_MASTER_SERVICE_XXX
<i>errorCode</i>	== 65535 - timeout
<i>errorCode</i>	== 1..255 - error code
<i>errorCode</i>	== 0 - ok
<i>errorSpec</i>	- error spec (if errorCode == 65365)
<i>pIdentity</i>	== NULL - no data available
<i>pIdentity</i>	!= NULL - pIdentity valid

Returns

void

5.25.2.2 typedef void(* CO_EVENT_LSS_T) (CO_LSS_SERVICE_T service, UNSIGNED16 bitrate, UNSIGNED8 *pErrCode, UNSIGNED8 *pErrSpec)

function pointer to LSS indication

Parameters

<i>service</i>	- answer for service LSS_SERVICE_XXX
<i>bitrate</i>	- new bitrate / pending node id (only for CO_LSS_SERVICE_STORE) 1000, 500, ... 10 standard bitrates 0 autobaud 0 table specific, values in pErrCode and pErrSpec)
<i>pErrCode</i>	- pointer to error code
<i>pErrSpec</i>	- pointer to error spec

Returns

UNSIGNED8

Return values

0	- success
1	- store not supported
2	- media access error
255	- implementation specific (value in parameter pErr)

5.25.3 Enumeration Type Documentation

5.25.3.1 enum CO_LSS_MASTER_SERVICE_T

LSS master services for indication functions.

Enumerator

CO_LSS_MASTER_SERVICE_NON_CONFIG_SLAVE LSS Master service non-config slave
CO_LSS_MASTER_SERVICE_SET_NODEID LSS Master service set node id
CO_LSS_MASTER_SERVICE_SET_BITRATE LSS Master service set bitrate
CO_LSS_MASTER_SERVICE_FASTSCAN LSS Master service fastscan
CO_LSS_MASTER_SERVICE_STORE LSS Master service store
CO_LSS_MASTER_SERVICE_INQUIRE_NODEID LSS Master service inquire node
CO_LSS_MASTER_SERVICE_INQUIRE_VENDOR LSS Master service inquire vendor
CO_LSS_MASTER_SERVICE_INQUIRE_PRODUCT LSS Master service inquire product
CO_LSS_MASTER_SERVICE_INQUIRE_REVISION LSS Master service inquire revision
CO_LSS_MASTER_SERVICE_INQUIRE_SERIAL LSS Master service inquire serial
CO_LSS_MASTER_SERVICE_BITRATE_OFF LSS Master service indication bitrate off
CO_LSS_MASTER_SERVICE_BITRATE_SET LSS Master service indication set new bitrate
CO_LSS_MASTER_SERVICE_BITRATE_ACTIVE LSS Master service indication bitrate active
CO_LSS_MASTER_SERVICE_SWITCH_SELECTIVE LSS Master service switch selective
CO_LSS_MASTER_SERVICE_IDENTITY LSS Master service identity
CO_LSS_MASTER_SERVICE_SWITCH_GLOBAL LSS Master switch global

5.25.3.2 enum CO_LSS_SERVICE_T

LSS slave services for indication functions.

Enumerator

CO_LSS_SERVICE_STORE LSS service indication store node id
CO_LSS_SERVICE_NEW_BITRATE LSS service indication new bitrate
CO_LSS_SERVICE_BITRATE_OFF LSS service indication bitrate off
CO_LSS_SERVICE_BITRATE_SET LSS service indication set new bitrate
CO_LSS_SERVICE_BITRATE_ACTIVE LSS service indication bitrate active
CO_LSS_SERVICE_NEW_NODE_ID LSS service indication new node-id

5.25.3.3 enum CO_LSS_STATE_T

LSS slave states.

Enumerator

CO_LSS_STATE_WAITING LSS state waiting
CO_LSS_STATE_CONFIGURATION LSS state configuration

5.25.4 Function Documentation

5.25.4.1 EXTERN_DECL RET_T coEventRegister_LSS (CO_EVENT_LSS_T *pFunction*)

coEventRegister_LSS - register LSS event

This function registers an indication function for LSS events.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.25.4.2 EXTERN_DECL RET_T coEventRegister_LSS_MASTER (CO_EVENT_LSS_MASTER_T *pFunction*)

coEventRegister_LSS_MASTER - register LSS master event

This function registers an indication function for LSS Master events.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.25.4.3 EXTERN_DECL RET_T coLssActivateBitrate (UNSIGNED16 *switchDelay*)

coLssActivateBitrate - activate bitratenodes

Start service activate bitrate for remote and local node. The function transmits the command to the remote slaves and start the timer for bitrate switch itself. After the time was elapsed, the indication is called.

Returns

RET_T

Parameters

<i>switchDelay</i>	switch delay time
--------------------	-------------------

5.25.4.4 EXTERN_DECL RET_T coLssFastScan (UNSIGNED16 *timeOutVal*)

coLssFastScan - start fastscan

start fastscan for the given parameter if no node was found, the indication will be return 0

Returns

RET_T

Parameters

<i>timeOutVal</i>	timeout value in msec
-------------------	-----------------------

5.25.4.5 EXTERN_DECL RET_T coLssFastScanKnownDevice (UNSIGNED32 *vendorId*, UNSIGNED32 *productCode*, UNSIGNED32 *versionNr*, UNSIGNED32 *serNr*, UNSIGNED16 *timeOutVal*)

coLssFastScanKnownDevice - start fastscan for known device

start fastscan for a well known device if no node was found, the indication will be return 0

Returns

RET_T

Parameters

<i>vendorId</i>	vendor number
<i>productCode</i>	product code
<i>versionNr</i>	version number
<i>serNr</i>	serial number
<i>timeOutVal</i>	timeout value in msec

5.25.4.6 EXTERN_DECL RET_T coLssIdentifyNonConfiguredSlaves (UNSIGNED16 *timeOutVal*, UNSIGNED16 *interval*)

coLssIdentifyNonConfiguredSlaves - identify unconfigured remote slaves

Identify unconfigured remote slaves by sending the LSS command. If no slave is available, the indication function is called after the time is up, given by the parameter timeoutvalue.

The LSS command is transmitted in a cycle of n seconds, given by parameter interval. If the parameter is 0, the LSS command is transmitted only once.

Returns

RET_T

Parameters

<i>timeOutVal</i>	timeout value in msec
<i>interval</i>	interval in seconds

5.25.4.7 EXTERN_DECL RET_T coLssIdentifyRemoteSlaves (UNSIGNED32 *vendorId*, UNSIGNED32 *productCode*, UNSIGNED32 *revisionLow*, UNSIGNED32 *revisionHigh*, UNSIGNED32 *serialNumberLow*, UNSIGNED32 *serialNumberHigh*, UNSIGNED16 *timeOutVal*)

coLssIdentifyRemoteSlaves - identify remote slaves

Identify remote slaves by sending the LSS command with the given identity parameter. If no slave is available, the indication function is called after the time is up, given by the parameter timeoutvalue.

Returns

RET_T

Parameters

<i>vendorId</i>	vendor id
<i>productCode</i>	product code
<i>revisionLow</i>	revision low
<i>revisionHigh</i>	revision high
<i>serialNumberLow</i>	serialNumber low
<i>serialNumberHigh</i>	serialNumber high
<i>timeOutVal</i>	timeout value in msec

5.25.4.8 EXTERN_DECL RET_T coLssInit (void)

coLssInit - init LSS functionality

This function initializes the LSS functionality, depending on the define CO_LSS_SLAVE_SUPPORTED or CO_LSS_MASTER_SUPPORTED as slave or master.

Returns

RET_T

5.25.4.9 EXTERN_DECL RET_T coLssInquireIdentity (UNSIGNED8 subIndex, UNSIGNED16 timeOutVal)

coLssInquireIdentity - inquire identity data

Send the inquire identity command

Please note - the indication function called after the request is finished only indicates an erroronous or error free execution of the request. It doesn't delivered the requested data. To get the requested data the function [coLssMasterGetInquireData\(\)](#) have to be used.

Returns

RET_T

Parameters

<i>subIndex</i>	subIndex of requested identity parameter (1..4)
<i>timeOutVal</i>	timeout value in msec

5.25.4.10 EXTERN_DECL RET_T coLssInquireNodeId (UNSIGNED16 timeOutVal)

coLssInquireNodeId - inquire actual node ID

Send the inquire node id command

Returns

RET_T

Parameters

<i>timeOutVal</i>	timeout value in msec
-------------------	-----------------------

5.25.4.11 EXTERN_DECL void coLssMasterDisable (void)

coLssMasterDisable - disable LSS master services

Returns

none

5.25.4.12 EXTERN_DECL void coLssMasterEnable (void)

coLssMasterEnable - enable LSS master services

(Re)enable LSS master services after the was disabled by [coLssMasterDisable\(\)](#)**Returns**

none

5.25.4.13 EXTERN_DECL UNSIGNED32 coLssMasterGetInquireData (void)

coLssMasterGetInquireData - get requested inquire data

This function returns the requested data for a inquire request started by [coLssInquireIdentity\(\)](#) before. The data are only valid, if the indication function with the parameter given to [coLssInquireIdentity\(\)](#) was indicated before without any error.

Returns

UNSIGNED32 identity value

5.25.4.14 EXTERN_DECL RET_T coLssMasterInit (void)

coLssMasterInit - init LSS functionality

This function initializes the LSS functionality, depending on the define CO_LSS_SLAVE_SUPPORTED or CO_LSS_MASTER_SUPPORTED as slave or master.

Returns

RET_T

5.25.4.15 EXTERN_DECL void coLssNonConfigSlave (void)

coLssNonConfigSlave - request for unconfigured slaves

get answer, if node-id == 255

Returns

none

5.25.4.16 EXTERN_DECL RET_T coLssSetBitrate (UNSIGNED16 *bitRate*, UNSIGNED16 *timeOutVal*)

coLssSetBitrate - set bitrate for remote nodes

Send a new bitrate to an remote slaves. Allowed bitrates are: 1000, 800, 500, 250, 125, 50, 20, 10, 0 (for autobaud)

The nodes have to be set before in configuration mode

Returns

RET_T

Parameters

<i>bitRate</i>	new bitrate
<i>timeOutVal</i>	timeout value in msec

5.25.4.17 EXTERN_DECL RET_T coLssSetBitrateTable (UNSIGNED8 *tableSelector*, UNSIGNED8 *tableIndex*, UNSIGNED16 *timeOutVal*)

coLssSetBitrate - set bitrate for remote nodes

Send a new bitrate to an remote slaves. Parameter are not checked! The nodes have to be set before in configuration mode

Returns

RET_T

Parameters

<i>tableSelector</i>	table selector
<i>tableIndex</i>	table index
<i>timeOutVal</i>	timeout value in msec

5.25.4.18 EXTERN_DECL RET_T coLssSetNodeId (UNSIGNED8 *nodeId*, UNSIGNED16 *timeOutVal*)

coLssNodeId - set node id for remote node

Send a new node id to an remote slave The node has to be set before in configuration mode

Returns

RET_T

Parameters

<i>nodeId</i>	new node id
<i>timeOutVal</i>	timeout value in msec

5.25.4.19 EXTERN_DECL RET_T coLssStoreConfig (UNSIGNED16 *timeOutVal*)

coLssStoreConfig - store configuration

Send the LSS store configuration command to a slave.

Returns

RET_T

Parameters

<i>timeOutVal</i>	timeout value in msec
-------------------	-----------------------

5.25.4.20 EXTERN_DECL RET_T coLssSwitchGlobal (CO_LSS_STATE_T *mode*)

coLssSwitchGlobal - send global switch command

Send the global switch command - no answer expected

Returns

RET_T

Parameters

<i>mode</i>	mode
-------------	------

5.25.4.21 EXTERN_DECL RET_T coLssSwitchSelective (UNSIGNED32 *vendorId*, UNSIGNED32 *productCode*, UNSIGNED32 *versionNr*, UNSIGNED32 *serNr*, UNSIGNED16 *timeOutVal*)

coLssSwitchSelective - send Selective switch command

Send the Selective switch command - the detected node should be answer and go into CONFIGURATION mode

Returns

RET_T

Parameters

<i>vendorId</i>	vendor number
<i>productCode</i>	product code
<i>versionNr</i>	version number
<i>serNr</i>	serial number
<i>timeOutVal</i>	timeout value in msec

5.26 co_Issmaster.c File Reference

LSS master handling.

Functions

- [RET_T coLssIdentifyNonConfiguredSlaves](#) (UNSIGNED16 timeOutVal, UNSIGNED16 interval)

- coLssIdentifyNonConfiguredSlaves - identify unconfigured remote slaves*
- [RET_T coLssIdentifyRemoteSlaves](#) (UNSIGNED32 vendorId, UNSIGNED32 productCode, UNSIGNED32 revisionLow, UNSIGNED32 revisionHigh, UNSIGNED32 serialNumberLow, UNSIGNED32 serialNumberHigh, UNSIGNED16 timeOutVal)
 - coLssIdentifyRemoteSlaves - identify remote slaves*
- [RET_T coLssFastScan](#) (UNSIGNED16 timeOutVal)
 - coLssFastScan - start fastscan*
- [RET_T coLssFastScanKnownDevice](#) (UNSIGNED32 vendorId, UNSIGNED32 productCode, UNSIGNED32 versionNr, UNSIGNED32 serNr, UNSIGNED16 timeOutVal)
 - coLssFastScanKnownDevice - start fastscan for known device*
- [RET_T coLssSetNodeId](#) (UNSIGNED8 nodeId, UNSIGNED16 timeOutVal)
 - coLssNodeId - set node id for remote node*
- [RET_T coLssSetBitrate](#) (UNSIGNED16 bitRate, UNSIGNED16 timeOutVal)
 - coLssSetBitrate - set bitrate for remote nodes*
- [RET_T coLssSetBitrateTable](#) (UNSIGNED8 tableSelector, UNSIGNED8 tableIndex, UNSIGNED16 timeOutVal)
 - coLssSetBitrate - set bitrate for remote nodes*
- [RET_T coLssActivateBitrate](#) (UNSIGNED16 switchDelay)
 - coLssActivateBitrate - activate bitratenodes*
- [RET_T coLssStoreConfig](#) (UNSIGNED16 timeOutVal)
 - coLssStoreConfig - store configuration*
- [RET_T coLssSwitchGlobal](#) ([CO_LSS_STATE_T](#) mode)
 - coLssSwitchGlobal - send global switch command*
- [RET_T coLssSwitchSelective](#) (UNSIGNED32 vendorId, UNSIGNED32 productCode, UNSIGNED32 versionNr, UNSIGNED32 serNr, UNSIGNED16 timeOutVal)
 - coLssSwitchSelective - send Selective switch command*
- [RET_T coLssInquireNodeId](#) (UNSIGNED16 timeOutVal)
 - coLssInquireNodeId - inquire actual node ID*
- [RET_T coLssInquireIdentity](#) (UNSIGNED8 subIndex, UNSIGNED16 timeOutVal)
 - coLssInquireIdentity - inquire identity data*
- [RET_T coEventRegister_LSS_MASTER](#) ([CO_EVENT_LSS_MASTER_T](#) pFunction)
 - coEventRegister_LSS_MASTER - register LSS master event*
- UNSIGNED32 [coLssMasterGetInquireData](#) (void)
 - coLssMasterGetInquireData - get requested inquire data*
- void [coLssMasterDisable](#) (void)
 - coLssMasterDisable - disable LSS master services*
- void [coLssMasterEnable](#) (void)
 - coLssMasterEnable - enable LSS master services*
- [RET_T coLssMasterInit](#) (void)
 - coLssMasterInit - init LSS functionality*

5.26.1 Detailed Description

LSS master handling.

contains LSS master services

5.26.2 Function Documentation

5.26.2.1 RET_T coEventRegister_LSS_MASTER (CO_EVENT_LSS_MASTER_T *pFunction*)

coEventRegister_LSS_MASTER - register LSS master event

This function registers an indication function for LSS Master events.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.26.2.2 RET_T coLssActivateBitrate (UNSIGNED16 *switchDelay*)

coLssActivateBitrate - activate bitratenodes

Start service activate bitrate for remote and local node. The function transmits the command to the remote slaves and start the timer for bitrate switch itself. After the time was elapsed, the indication is called.

Returns

RET_T

Parameters

<i>switchDelay</i>	switch delay time
--------------------	-------------------

5.26.2.3 RET_T coLssFastScan (UNSIGNED16 *timeOutVal*)

coLssFastScan - start fastscan

start fastscan for the given parameter if no node was found, the indication will be return 0

Returns

RET_T

Parameters

<i>timeOutVal</i>	timeout value in msec
-------------------	-----------------------

5.26.2.4 **RET_T** coLssFastScanKnownDevice (*UNSIGNED32 vendorId*, *UNSIGNED32 productCode*, *UNSIGNED32 versionNr*, *UNSIGNED32 serNr*, *UNSIGNED16 timeOutVal*)

coLssFastScanKnownDevice - start fastscan for known device

start fastscan for a well known device if no node was found, the indication will be return 0

Returns

RET_T

Parameters

<i>vendorId</i>	vendor number
<i>productCode</i>	product code
<i>versionNr</i>	version number
<i>serNr</i>	serial number
<i>timeOutVal</i>	timeout value in msec

5.26.2.5 **RET_T** coLssIdentifyNonConfiguredSlaves (*UNSIGNED16 timeOutVal*, *UNSIGNED16 interval*)

coLssIdentifyNonConfiguredSlaves - identify unconfigured remote slaves

Identify unconfigured remote slaves by sending the LSS command. If no slave is available, the indication function is called after the time is up, given by the parameter timeoutvalue.

The LSS command is transmitted in a cycle of n seconds, given by parameter interval. If the parameter is 0, the LSS command is transmitted only once.

Returns

RET_T

Parameters

<i>timeOutVal</i>	timeout value in msec
<i>interval</i>	interval in seconds

5.26.2.6 **RET_T** coLssIdentifyRemoteSlaves (*UNSIGNED32 vendorId*, *UNSIGNED32 productCode*, *UNSIGNED32 revisionLow*, *UNSIGNED32 revisionHigh*, *UNSIGNED32 serialNumberLow*, *UNSIGNED32 serialNumberHigh*, *UNSIGNED16 timeOutVal*)

coLssIdentifyRemoteSlaves - identify remote slaves

Identify remote slaves by sending the LSS command with the given identity parameter. If no slave is available, the indication function is called after the time is up, given by the parameter timeoutvalue.

Returns

RET_T

Parameters

<i>vendorId</i>	vendor id
<i>productCode</i>	product code
<i>revisionLow</i>	revision low
<i>revisionHigh</i>	revision high
<i>serialNumberLow</i>	serialNumber low
<i>serialNumberHigh</i>	serialNumber high
<i>timeOutVal</i>	timeout value in msec

5.26.2.7 **RET_T** `coLssInquireIdentity (UNSIGNED8 subIndex, UNSIGNED16 timeOutVal)`

`coLssInquireIdentity` - inquire identity data

Send the inquire identity command

Please note - the indication function called after the request is finished only indicates an erroronous or error free execution of the request. It doesn't delivered the requested data. To get the requested data the function [coLssMasterGetInquireData\(\)](#) have to be used.

Returns

RET_T

Parameters

<i>subIndex</i>	subIndex of requested identity parameter (1..4)
<i>timeOutVal</i>	timeout value in msec

5.26.2.8 **RET_T** `coLssInquireNodeId (UNSIGNED16 timeOutVal)`

`coLssInquireNodeId` - inquire actual node ID

Send the inquire node id command

Returns

RET_T

Parameters

<i>timeOutVal</i>	timeout value in msec
-------------------	-----------------------

5.26.2.9 **void** `coLssMasterDisable (void)`

`coLssMasterDisable` - disable LSS master services

Returns

none

5.26.2.10 void coLssMasterEnable (void)

coLssMasterEnable - enable LSS master services

(Re)enable LSS master services after the was disabled by [coLssMasterDisable\(\)](#)

Returns

none

5.26.2.11 UNSIGNED32 coLssMasterGetInquireData (void)

coLssMasterGetInquireData - get requested inquire data

This function returns the requested data for a inquire request started by [coLssInquireIdentity\(\)](#) before. The data are only valid, if the indication function with the parameter given to [coLssInquireIdentity\(\)](#) was indicated before without any error.

Returns

UNSIGNED32 identity value

5.26.2.12 RET_T coLssMasterInit (void)

coLssMasterInit - init LSS functionality

This function initializes the LSS functionality, depending on the define CO_LSS_SLAVE_SUPPORTED or CO_LSS_MASTER_SUPPORTED as slave or master.

Returns

RET_T

5.26.2.13 RET_T coLssSetBitrate (UNSIGNED16 *bitRate*, UNSIGNED16 *timeOutVal*)

coLssSetBitrate - set bitrate for remote nodes

Send a new bitrate to an remote slaves. Allowed bitrates are: 1000, 800, 500, 250, 125, 50, 20, 10, 0 (for autobaud)

The nodes have to be set before in configuration mode

Returns

RET_T

Parameters

<i>bitRate</i>	new bitrate
<i>timeOutVal</i>	timeout value in msec

5.26.2.14 **RET_T** `coLssSetBitrateTable (UNSIGNED8 tableSelector, UNSIGNED8 tableIndex, UNSIGNED16 timeOutVal)`

`coLssSetBitrate` - set bitrate for remote nodes

Send a new bitrate to an remote slaves. Parameter are not checked! The nodes have to be set before in configuration mode

Returns

RET_T

Parameters

<i>tableSelector</i>	table selector
<i>tableIndex</i>	table index
<i>timeOutVal</i>	timeout value in msec

5.26.2.15 **RET_T** `coLssSetNodeId (UNSIGNED8 nodeId, UNSIGNED16 timeOutVal)`

`coLssNodeId` - set node id for remote node

Send a new node id to an remote slave The node has to be set before in configuration mode

Returns

RET_T

Parameters

<i>nodeId</i>	new node id
<i>timeOutVal</i>	timeout value in msec

5.26.2.16 **RET_T** `coLssStoreConfig (UNSIGNED16 timeOutVal)`

`coLssStoreConfig` - store configuration

Send the LSS store configuration command to a slave.

Returns

RET_T

Parameters

<i>timeOutVal</i>	timeout value in msec
-------------------	-----------------------

5.26.2.17 RET_T coLssSwitchGlobal (CO_LSS_STATE_T mode)

coLssSwitchGlobal - send global switch command

Send the global switch command - no answer expected

Returns

RET_T

Parameters

<i>mode</i>	mode
-------------	------

5.26.2.18 RET_T coLssSwitchSelective (UNSIGNED32 vendorId, UNSIGNED32 productCode, UNSIGNED32 versionNr, UNSIGNED32 serNr, UNSIGNED16 timeOutVal)

coLssSwitchSelective - send Selective switch command

Send the Selective switch command - the detected node should be answer and go into CONFIGURATION mode

Returns

RET_T

Parameters

<i>vendorId</i>	vendor number
<i>productCode</i>	product code
<i>versionNr</i>	version number
<i>serNr</i>	serial number
<i>timeOutVal</i>	timeout value in msec

5.27 co_manager.c File Reference

Manager handling according to CiA 302-2.

Functions

- [RET_T coManagerStart](#) (void)

- coManagerStart*
- **RET_T coManagerContinueSwUpdate** (UNSIGNED8 slave, **RET_T** result)
coManagerContinueSwUpdate - continue after software update
- **RET_T coManagerContinueConfigUpdate** (UNSIGNED8 slave, **RET_T** result)
coManagerContinueConfigUpdate - continue configuration
- **RET_T coManagerContinueOperational** (void)
coManagerContinueOperational - continue to OPERATIONAL
- **RET_T coEventRegister_MANAGER_BOOTUP** (**CO_EVENT_MANAGER_BOOTUP_T** pFunction)
coEventRegister_MANAGER_BOOTUP - register *MANAGER_BOOTUP* event

5.27.1 Detailed Description

Manager handling according to CiA 302-2.

contains CANopen Manager handling according to CiA 302-2

5.27.2 Function Documentation

5.27.2.1 **RET_T coEventRegister_MANAGER_BOOTUP (CO_EVENT_MANAGER_BOOTUP_T pFunction)**

coEventRegister_MANAGER_BOOTUP - register *MANAGER_BOOTUP* event

register indication function for *MANAGER_BOOTUP* Procedure events

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.27.2.2 **RET_T coManagerContinueConfigUpdate (UNSIGNED8 slave, RET_T result)**

coManagerContinueConfigUpdate - continue configuration

This function has to be called from application after configuration for the given node was finished The result should be **RET_OK** or another error code.

If state of this node is not in correct state, the function returns **RET_INVALID_PARAMETER**

Parameters

<i>slave</i>	slave (1.. 127)
<i>result</i>	result of configuration process

5.27.2.3 RET_T coManagerContinueOperational (void)

coManagerContinueOperational - continue to OPERATIONAL

This function continues Bootup Procedure to state OPERATIONAL, if the start bit at 0x1f80 is not set. The application can start the nodes itself, or call this function to do that.

If state of this node is not in correct state, the function returns RET_INVALID_PARAMETER

5.27.2.4 RET_T coManagerContinueSwUpdate (UNSIGNED8 slave, RET_T result)

coManagerContinueSwUpdate - continue after software update

This function continues startup for the given node after software was updated by application

If state of this node is not in correct state, the function returns RET_INVALID_PARAMETER

Parameters

<i>slave</i>	slave
<i>result</i>	result of software update

5.27.2.5 RET_T coManagerStart (void)

coManagerStart

This function starts the CANopen manager process. All necessary parameter for mandatory and optional slaves has to be available at the object dictionary.

Returns

RET_T

5.28 co_manager.h File Reference

defines for bootup manager services

Typedefs

- typedef void(* [CO_EVENT_MANAGER_BOOTUP_T](#)) (UNSIGNED8, [CO_MANAGER_EVENT_T](#))
function pointer to NMT event function

Enumerations

Functions

- EXTERN_DECL [RET_T](#) [coEventRegister_MANAGER_BOOTUP](#) ([CO_EVENT_MANAGER_BOOTUP_T](#) pFunction)
coEventRegister_MANAGER_BOOTUP - register MANAGER_BOOTUP event
- EXTERN_DECL [RET_T](#) [coManagerStart](#) (void)
coManagerStart
- EXTERN_DECL [RET_T](#) [coManagerContinueSwUpdate](#) (UNSIGNED8 slave, [RET_T](#) result)
coManagerContinueSwUpdate - continue after software update
- EXTERN_DECL [RET_T](#) [coManagerContinueConfigUpdate](#) (UNSIGNED8 slave, [RET_T](#) result)
coManagerContinueConfigUpdate - continue configuration
- EXTERN_DECL [RET_T](#) [coManagerContinueOperational](#) (void)
coManagerContinueOperational - continue to OPERATIONAL

5.28.1 Detailed Description

defines for bootup manager services

- contains defines for bootup manager services

5.28.2 Typedef Documentation

5.28.2.1 typedef void(* CO_EVENT_MANAGER_BOOTUP_T) (UNSIGNED8, CO_MANAGER_EVENT_T)

function pointer to NMT event function

Parameters

<i>node</i>	- node id for event (0 = manager event)
<i>event</i>	- event type from CO_MANAGER_EVENT_T

Returns

void

5.28.3 Enumeration Type Documentation

5.28.3.1 enum CO_MANAGER_EVENT_T

manager bootup events

Enumerator

CO_MANAGER_EVENT_BOOT node x start boot

CO_MANAGER_EVENT_ERROR_B node x read 0x1000 failed
CO_MANAGER_EVENT_ERROR_C node x check device type failed
CO_MANAGER_EVENT_ERROR_D node x check vendor id type failed
CO_MANAGER_EVENT_ERROR_J node x check configuration failed
CO_MANAGER_EVENT_ERROR_G node x update configuration failed
CO_MANAGER_EVENT_ERROR_K node x start errctl failed
CO_MANAGER_EVENT_ERROR_M node x check product code failed
CO_MANAGER_EVENT_ERROR_N node x check version nr failed
CO_MANAGER_EVENT_ERROR_O node x check serial nr failed
CO_MANAGER_EVENT_UPDATE_SW node x software update necessary
CO_MANAGER_EVENT_UPDATE_CONFIG node x update config necessary
CO_MANAGER_EVENT_BOOTED node x boot successfully
CO_MANAGER_EVENT_ERROR_NODE node x failure heartbeat
CO_MANAGER_EVENT_RDY_OPERATIONAL manager ready for OPERATIONAL
CO_MANAGER_EVENT_FAILURE bootup failure about mandatory slave
CO_MANAGER_EVENT_FINISHED bootup finished without errors

5.28.4 Function Documentation

5.28.4.1 EXTERN_DECL RET_T coEventRegister_MANAGER_BOOTUP (CO_EVENT_MANAGER_BOOTUP_T pFunction)

coEventRegister_MANAGER_BOOTUP - register MANAGER_BOOTUP event

register indication function for MANAGER_BOOTUP Procedure events

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.28.4.2 EXTERN_DECL RET_T coManagerContinueConfigUpdate (UNSIGNED8 slave, RET_T result)

coManagerContinueConfigUpdate - continue configuration

This function has to be called from application after configuration for the given node was finished The result should be RET_OK or another error code.

If state of this node is not in correct state, the function returns RET_INVALID_PARAMETER

Parameters

<i>slave</i>	slave (1.. 127)
<i>result</i>	result of configuration process

5.28.4.3 EXTERN_DECL RET_T coManagerContinueOperational (void)

coManagerContinueOperational - continue to OPERATIONAL

This function continues Bootup Procedure to state OPERATIONAL, if the start bit at 0x1f80 is not set. The application can start the nodes itself, or call this function to do that.

If state of this node is not in correct state, the function returns RET_INVALID_PARAMETER

5.28.4.4 EXTERN_DECL RET_T coManagerContinueSwUpdate (UNSIGNED8 slave, RET_T result)

coManagerContinueSwUpdate - continue after software update

This function continues startup for the given node after software was updated by application

If state of this node is not in correct state, the function returns RET_INVALID_PARAMETER

Parameters

<i>slave</i>	slave
<i>result</i>	result of software update

5.28.4.5 EXTERN_DECL RET_T coManagerStart (void)

coManagerStart

This function starts the CANopen manager process. All necessary parameter for mandatory and optional slaves has to be available at the object dictionary.

Returns

RET_T

5.29 co_mpdo.c File Reference

MPDO handling.

5.29.1 Detailed Description

MPDO handling.

contains MPDO services

5.30 co_network.c File Reference

multi level networking handling

Functions

- [RET_T coNetworkGet](#) (UNSIGNED16 network, UNSIGNED8 *pNetworkIf, UNSIGNED8 *pRouterNode)
coNetworkGet - get network interface and router node
- UNSIGNED16 [icoNetworkLocalId](#) (void)
icoNetworkLocal - get local network id

5.30.1 Detailed Description

multi level networking handling

contains multi level network services

5.30.2 Function Documentation

5.30.2.1 **RET_T coNetworkGet** (UNSIGNED16 *network*, UNSIGNED8 * *pNetworkIf*, UNSIGNED8 * *pRouterNode*)

coNetworkGet - get network interface and router node

Get Network interface und router node for requested destination network from object 0x1f2c

Parameters

<i>network</i>	destination network
<i>pNetworkIf</i>	network interface number
<i>pRouterNode</i>	router node id

5.31 co_network.h File Reference

defines for network services

Typedefs

- typedef UNSIGNED8(* [CO_EVENT_GW_SDOCLIENT_FCT_T](#)) (UNSIGNED16 network, UNSIGNED8 node, UNSIGNED32 *pCobCISrv, UNSIGNED32 *pCobSrvCl)
function pointer to get sdo channel number

Functions

- EXTERN_DECL [RET_T coNetworkGet](#) (UNSIGNED16 network, UNSIGNED8 *pNetworkIf, UNSIGNED8 *pRouterNode)
coNetworkGet - get network interface and router node

5.31.1 Detailed Description

defines for network services

- contains defines for network services

5.31.2 Typedef Documentation

5.31.2.1 `typedef UNSIGNED8(* CO_EVENT_GW_SDOCLIENT_FCT_T) (UNSIGNED16 network, UNSIGNED8 node, UNSIGNED32 *pCobCSrv, UNSIGNED32 *pCobSrvCl)`

function pointer to get sdo channel number

Parameters

<i>network</i>	- target network
<i>node</i>	- target nodeid
<i>pCobCSrv</i>	- pointer for cob-id client server (0 - use default)
<i>pCobSrvCl</i>	- pointer for cob-id server client (0 - use default)

Returns

SDO channel

5.31.3 Function Documentation

5.31.3.1 `EXTERN_DECL RET_T coNetworkGet (UNSIGNED16 network, UNSIGNED8 * pNetworkIf, UNSIGNED8 * pRouterNode)`

coNetworkGet - get network interface and router node

Get Network interface und router node for requested destination network from object 0x1f2c

Parameters

<i>network</i>	destination network
<i>pNetworkIf</i>	network interface number
<i>pRouterNode</i>	router node id

5.32 co_nmt.c File Reference

Network Managment(NMT) handler.

Functions

- [RET_T coEventRegister_NMT](#) ([CO_EVENT_NMT_T](#) pFunction)
coEventRegister_NMT - register NMT event
- [UNSIGNED8 coNmtGetNodeId](#) (void)
coNmtGetNodeId - returns actual node id
- [CO_NMT_STATE_T coNmtGetState](#) (void)
coGetNmtState - returns current NMT state
- [RET_T coNmtLocalStateReq](#) ([CO_NMT_STATE_T](#) reqState)
coNmtLocalStateReq - request local NMT state change
- [RET_T coNmtInit](#) ([UNSIGNED8](#) master)
coInitNmt - init NMT functionality

5.32.1 Detailed Description

Network Managment(NMT) handler.

contains routines for NMT handling

5.32.2 Function Documentation

5.32.2.1 [RET_T coEventRegister_NMT](#) ([CO_EVENT_NMT_T](#) pFunction)

[coEventRegister_NMT](#) - register NMT event

register indication function for NMT events

Returns

[RET_T](#)

Parameters

pFunction	pointer to function
---------------------------	---------------------

5.32.2.2 [UNSIGNED8 coNmtGetNodeId](#) (void)

[coNmtGetNodeId](#) - returns actual node id

Returns

node-id

5.32.2.3 [CO_NMT_STATE_T coNmtGetState](#) (void)

[coGetNmtState](#) - returns current NMT state

This function returns the current NMT state of the local node.

Returns

NMT state

5.32.2.4 RET_T coNmtInit (UNSIGNED8 master)

coNmtInit - init NMT functionality

This function initializes the NMT functionality and calls an internal reset communication.

If parameter master is unequal 0 the node will be initialized as NMT master. If flying master is enabled, the decision for master/slave or flying master is done by check object 0x1f80. (parameter master is not used!) In this case, the node starts as slave and wait for the master negotiation.

Returns

RET_T

Parameters

<i>master</i>	master mode
---------------	-------------

5.32.2.5 RET_T coNmtLocalStateReq (CO_NMT_STATE_T reqState)

coNmtLocalStateReq - request local NMT state change

Be carful - NMT commands should be generated only by the master

Returns

RET_T

Parameters

<i>reqState</i>	new requested state
-----------------	---------------------

5.33 co_nmt.h File Reference

defines for nmt services

Typedefs

- typedef UNSIGNED8(* CO_NODE_ID_T) (void)
function pointer to get node id function This function shall get the node id for the device
- typedef void(* CO_EVENT_ERRCTRL_T) (UNSIGNED8, CO_ERRCTRL_T, CO_NMT_STATE_T)
function pointer to error control event function
- typedef RET_T(* CO_EVENT_NMT_T) (BOOL_T, CO_NMT_STATE_T)
function pointer to NMT event function

Enumerations

Functions

- EXTERN_DECL [RET_T coNmtInit](#) (UNSIGNED8)
coInitNmt - init NMT functionality
- EXTERN_DECL UNSIGNED8 [coNmtGetNodeId](#) (void)
coNmtGetNodeId - returns actual node id
- EXTERN_DECL [BOOL_T coNmtInhibitActive](#) (void)
icoNmtInhibitActive - check if inhibit is active
- EXTERN_DECL [RET_T coErrorCtrlInit](#) (UNSIGNED16, UNSIGNED8)
coInitNmt - init error control
- EXTERN_DECL [RET_T coEventRegister_ERRCTRL](#) ([CO_EVENT_ERRCTRL_T](#) pFunction)
coEventRegister_ERRCTRL - register error control event
- EXTERN_DECL [RET_T coEventRegister_NMT](#) ([CO_EVENT_NMT_T](#) pFunction)
coEventRegister_NMT - register NMT event
- EXTERN_DECL [CO_NMT_STATE_T coNmtGetState](#) (void)
coGetNmtState - returns current NMT state
- EXTERN_DECL [CO_NMT_STATE_T coNmtGetRemoteNodeState](#) (UNSIGNED8 nodeId)
coNmtGetRemoteNodeState - get remote node state
- EXTERN_DECL [RET_T coNmtStateReq](#) (UNSIGNED8 node, [CO_NMT_STATE_T](#) reqState, [BOOL_T](#) master)
coNmtStateReq - request NMT state change
- EXTERN_DECL [RET_T coNmtLocalStateReq](#) ([CO_NMT_STATE_T](#) reqState)
coNmtLocalStateReq - request local NMT state change
- EXTERN_DECL [BOOL_T coNmtNodesMaster](#) (void)
coNmtNodesMaster - detect if node is master
- EXTERN_DECL [RET_T coHbConsumerSet](#) (UNSIGNED8 node, UNSIGNED16 hbTime)
coHbConsumerSet - setup heartbeat consumer
- EXTERN_DECL [RET_T coHbConsumerStart](#) (UNSIGNED8 node)
coHbConsumerStart - start heartbeat consumer monitoring
- EXTERN_DECL [RET_T coGuardingMasterStart](#) (UNSIGNED8 node)
coGuardingMasterStart - start master node guarding
- EXTERN_DECL [RET_T coGuardingMasterStop](#) (UNSIGNED8 node)
coGuardingMasterStop - stop master node guarding

5.33.1 Detailed Description

defines for nmt services

- contains defines for nmt services

5.33.2 Typedef Documentation

5.33.2.1 typedef void(* CO_EVENT_ERRCTRL_T) (UNSIGNED8, CO_ERRCTRL_T, CO_NMT_STATE_T)

function pointer to error control event function

Parameters

<i>nodeId</i>	- node Id
<i>errCtrlState</i>	- error control state
<i>nmtState</i>	- actual NMT state

Returns

void

5.33.2.2 typedef RET_T(* CO_EVENT_NMT_T) (BOOL_T, CO_NMT_STATE_T)

function pointer to NMT event function

Parameters

<i>execute</i>	- execute status change y/n
<i>nmtState</i>	- new NMT state

Returns

RET_T

Return values

<i>RET_OK</i>	- state change allowed (only valid for OPERATIONAL)
<i>RET_</i>	- state change not allowed (only valid for OPERATIONAL)

5.33.2.3 typedef UNSIGNED8(* CO_NODE_ID_T) (void)

function pointer to get node id function This function shall get the node id for the device

Returns

node id

5.33.3 Enumeration Type Documentation**5.33.3.1 enum CO_ERRCTRL_T**

error control states

Enumerator**CO_ERRCTRL_BOOTUP** bootup**CO_ERRCTRL_NEW_STATE** NMT state changed

CO_ERRCTRL_HB_STARTED heartbeat started
CO_ERRCTRL_HB_FAILED heartbeat failed
CO_ERRCTRL_GUARD_FAILED Lifetime failure from master detected
CO_ERRCTRL_MGUARD_TOGGLE Master guarding toggle failure detected
CO_ERRCTRL_MGUARD_FAILED Master guarding failure detected
CO_ERRCTRL_BOOTUP_FAILURE error transmit bootup

5.33.3.2 enum CO_NMT_REQ_STATE_T

NMT REQ states

Enumerator

CO_NMT_REQ_STATE_STOPPED STOPPED
CO_NMT_REQ_STATE_OPERATIONAL OPERATIONAL
CO_NMT_REQ_STATE_RESET_NODE Reset NODE
CO_NMT_REQ_STATE_RESET_COMM Reset Communication
CO_NMT_REQ_STATE_PREOP PRE-OPERATIONAL

5.33.3.3 enum CO_NMT_STATE_T

NMT states

Enumerator

CO_NMT_STATE_UNKNOWN unknown
CO_NMT_STATE_OPERATIONAL OPERATIONAL
CO_NMT_STATE_STOPPED STOPPED
CO_NMT_STATE_PREOP PRE-OPERATIONAL
CO_NMT_STATE_RESET_NODE Reset NODE
CO_NMT_STATE_RESET_COMM Reset Communication

5.33.4 Function Documentation

5.33.4.1 EXTERN_DECL RET_T coErrorCtrlInit (UNSIGNED16 hbTime, UNSIGNED8 hbConsCnt)

colnitNmt - init error control

Setup error control handling for local node (transmit heartbeat) and remote node (heartbeat monitoring)

Returns

RET_T

Parameters

<i>hbTime</i>	heartbeat producer time
<i>hbConsCnt</i>	heartbeat consumer count

5.33.4.2 EXTERN_DECL RET_T coEventRegister_ERRCTRL (CO_EVENT_ERRCTRL_T *pFunction*)

coEventRegister_ERRCTRL - register error control event

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.33.4.3 EXTERN_DECL RET_T coEventRegister_NMT (CO_EVENT_NMT_T *pFunction*)

coEventRegister_NMT - register NMT event

register indication function for NMT events

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.33.4.4 EXTERN_DECL RET_T coGuardingMasterStart (UNSIGNED8 *node*)

coGuardingMasterStart - start master node guarding

This function starts the master node guarding monitoring for the given node-id and the configured monitoring time from object dictionary.

Please note: The NMT state is set to unknown until next guarding was received

Returns

RET_T

Return values

<i>RET_PARAMETER_INCOMPATIBLE</i>	invalid node id
-----------------------------------	-----------------

Parameters

<i>node</i>	node id
-------------	---------

5.33.4.5 EXTERN_DECL RET_T coGuardingMasterStop (UNSIGNED8 *node*)

coGuardingMasterStop - stop master node guarding

This function stops the master node guarding monitoring for the given node-id

Returns

RET_T

Return values

<i>RET_PARAMETER_INCOMPATIBLE</i>	invalid node id
-----------------------------------	-----------------

Parameters

<i>node</i>	node id
-------------	---------

5.33.4.6 EXTERN_DECL RET_T coHbConsumerSet (UNSIGNED8 *node*, UNSIGNED16 *hbTime*)

coHbConsumerSet - setup heartbeat consumer

This function configures a heartbeat consumer for the given node-id and the monitoring time. The data are automatically saved at the object dictionary. If an entry at the object dictionary already exist, then it will be overwritten. The parameter node have to be valid, otherwise the function returns an error.

Returns

RET_T

Return values

<i>RET_PARAMETER_INCOMPATIBLE</i>	invalid node id
-----------------------------------	-----------------

Parameters

<i>node</i>	node id
<i>hbTime</i>	heartbeat monitoring time

5.33.4.7 EXTERN_DECL RET_T coHbConsumerStart (UNSIGNED8 *node*)

coHbConsumerStart - start heartbeat consumer monitoring

This function starts a heartbeat consumer monitoring for the given node-id and the configured monitoring time from object dictionary.

Please note: The NMT state is set to unknown until next HB was received

Returns

RET_T

Return values

<i>RET_PARAMETER_INCOMPATIBLE</i>	invalid node id
-----------------------------------	-----------------

Parameters

<i>node</i>	node id
-------------	---------

5.33.4.8 EXTERN_DECL UNSIGNED8 coNmtGetNodeid (void)

coNmtGetNodeid - returns actual node id

Returns

node-id

5.33.4.9 EXTERN_DECL CO_NMT_STATE_T coNmtGetRemoteNodeState (UNSIGNED8 *nodeId*)

coNmtGetRemoteNodeState - get remote node state

This function returns the NMT state of a remote node. If heartbeat monitoring of this node is disabled or has been failed, CO_NMT_STATE_UNKNOWN is returned.

Returns

CO_NMT_STATE_T

Parameters

<i>node↔ Id</i>	remote node id
---------------------	----------------

5.33.4.10 EXTERN_DECL CO_NMT_STATE_T coNmtGetState (void)

coGetNmtState - returns current NMT state

This function returns the current NMT state of the local node.

Returns

NMT state

5.33.4.11 EXTERN_DECL BOOL_T coNmtInhibitActive (void)

icoNmtInhibitActive - check if inhibit is active

Returns

inhibit state

5.33.4.12 EXTERN_DECL RET_T coNmtInit (UNSIGNED8 *master*)

colnitNmt - init NMT functionality

This function initializes the NMT functionality and calls an internal reset communication.

If parameter master is unequal 0 the node will be initialized as NMT master. If flying master is enabled, the decision for master/slave or flying master is done by check object 0x1f80. (parameter master is not used!) In this case, the node starts as slave and wait for the master negotiation.

Returns

RET_T

Parameters

<i>master</i>	master mode
---------------	-------------

5.33.4.13 EXTERN_DECL RET_T coNmtLocalStateReq (CO_NMT_STATE_T *reqState*)

coNmtLocalStateReq - request local NMT state change

Be carful - NMT commands should be generated only by the master

Returns

RET_T

Parameters

<i>reqState</i>	new requested state
-----------------	---------------------

5.33.4.14 EXTERN_DECL BOOL_T coNmtNodesMaster (void)

coNmtNodesMaster - detect if node is master

CO_TRUE - node is master CO_FALSE - node is not master

5.33.4.15 EXTERN_DECL RET_T coNmtStateReq (UNSIGNED8 node, CO_NMT_STATE_T reqState, BOOL_T master)

coNmtStateReq - request NMT state change

Request NMT state change for the given node 1..127. If *node* == 0, the NMT request is sent to all nodes. If the NMT sending master should enter the same NMT state as the addressed node the *master* flag has to be set to CO_TRUE. This is true for *node* == 0 too.

If *node* == the masters own nodeId, the requested state is only valid for the own node.

If the inhibit time is set (see object 0x102a, NMT inhibit time), NMT command is not sent if time hasn't been elapsed.

Returns

RET_T

Parameters

<i>node</i>	node
<i>reqState</i>	new requested state
<i>master</i>	valid for master

5.34 co_nmtmaster.c File Reference

NMT master services.

Functions

- [RET_T coNmtStateReq](#) (UNSIGNED8 node, [CO_NMT_STATE_T reqState](#), [BOOL_T master](#))
coNmtStateReq - request NMT state change
- [BOOL_T coNmtInhibitActive](#) (void)
coNmtInhibitActive - check if inhibit is active
- [BOOL_T coNmtNodesMaster](#) (void)
coNmtNodesMaster - detect if node is master

5.34.1 Detailed Description

NMT master services.

contains NMT master services

5.34.2 Function Documentation

5.34.2.1 **BOOL_T** coNmtInhibitActive (void)

icoNmtInhibitActive - check if inhibit is active

Returns

inhibit state

5.34.2.2 **BOOL_T** coNmtNodeIsMaster (void)

coNmtNodeIsMaster - detect if node is master

CO_TRUE - node is master CO_FALSE - node is not master

5.34.2.3 **RET_T** coNmtStateReq (**UNSIGNED8** *node*, **CO_NMT_STATE_T** *reqState*, **BOOL_T** *master*)

coNmtStateReq - request NMT state change

Request NMT state change for the given node 1..127. If *node* == 0, the NMT request is sent to all nodes. If the NMT sending master should enter the same NMT state as the addressed node the *master* flag has to be set to CO_TRUE. This is true for *node* == 0 too.

If *node* == the masters own nodeId, the requested state is only valid for the own node.

If the inhibit time is set (see object 0x102a, NMT inhibit time), NMT command is not sent if time hasn't been elapsed.

Returns

RET_T

Parameters

<i>node</i>	node
<i>reqState</i>	new requested state
<i>master</i>	valid for master

5.35 co_nmtslave.c File Reference

NMT slave services.

5.35.1 Detailed Description

NMT slave services.

contains NMT slave services for self starting devices

5.36 co_odaccess.c File Reference

object dictionary access

Functions

- [RET_T coOdSetCobid](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 newCobId)
coOdSetCobid - set cob id
- void * [coOdGetObjAddr](#) (UNSIGNED16 index, UNSIGNED8 subIndex)
coOdGetObjAddr - get address of an object
- [RET_T coOdGetObj_u8](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pObj)
coOdGetObj_u8 - get UNSIGNED8 object
- [RET_T coOdGetObj_u16](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 *pObj)
coOdGetObj_u16 - get UNSIGNED16 object
- [RET_T coOdGetObj_u32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 *pObj)
coOdGetObj_u32 - get UNSIGNED32 object
- [RET_T coOdGetObj_u24](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED24 *pObj)
coOdGetObj_u24 - get UNSIGNED24 object
- [RET_T coOdGetObj_u40](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED40 *pObj)
coOdGetObj_u40 - get UNSIGNED40 object
- [RET_T coOdGetObj_u48](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED48 *pObj)
coOdGetObj_u48 - get UNSIGNED48 object
- [RET_T coOdGetObj_u64](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED64 *pObj)
coOdGetObj_u64 - get UNSIGNED64 object
- [RET_T coOdGetObj_i8](#) (UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER8 *pObj)
coOdGetObj_i8 - get INTEGER8 object
- [RET_T coOdGetObj_i16](#) (UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER16 *pObj)
coOdGetObj_i16 - get INTEGER16 object
- [RET_T coOdGetObj_i32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER32 *pObj)
coOdGetObj_i32 - get INTEGER32 object
- [RET_T coOdGetObj_r32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, REAL32 *pObj)
coOdGetObj_r32 - get REAL32 object
- [RET_T coOdPutObj_u8](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 newVal)
coOdPutObj_u8 - put UNSIGNED8 value to object
- [RET_T coOdPutObj_u16](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 newVal)
coOdPutObj_u16 - put UNSIGNED16 value to object
- [RET_T coOdPutObj_u32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 newVal)

- coOdPutObj_u32 - put UNSIGNED32 value to object*
- [RET_T coOdPutObj_i8](#) (UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER8 newVal)
coOdPutObj_i8 - Put INTEGER8 object
- [RET_T coOdPutObj_i16](#) (UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER16 newVal)
coOdPutObj_i16 - Put INTEGER16 object
- [RET_T coOdPutObj_i32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER32 newVal)
coOdPutObj_i32 - Put INTEGER32 object
- [RET_T coOdPutObj_r32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, REAL32 newVal)
coOdPutObj_r32 - Put REAL32 object
- [RET_T coOdPutObj_u24](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED24 newVal)
coOdPutObj_u24 - Put UNSIGNED24 Object
- [RET_T coOdPutObj_u40](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED40 newVal)
coOdPutObj_u40 - Put UNSIGNED40 Object
- [RET_T coOdPutObj_u48](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED48 newVal)
coOdPutObj_u48 - Put UNSIGNED48 Object
- [RET_T coOdPutObj_u64](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED64 newVal)
coOdPutObj_u64 - Put UNSIGNED64 Object
- UNSIGNED16 [coOdGetObjAttribute](#) (CO_CONST CO_OBJECT_DESC_T *pObjDesc)
coOdGetObjAttribute - get object attribute
- [RET_T coOdDomainAddrSet](#) (UNSIGNED16 index, UNSIGNED8 subIndex, CO_DOMAIN_PTR pAddr, U↔
UNSIGNED32 size)
coOdDomainAddrSet - set domain address
- [RET_T coOdVisStringSet](#) (UNSIGNED16 index, UNSIGNED8 subIndex, VIS_STRING pAddr, UNSIGNED32
size)
coOdVisStringSet - set address and len for visible string
- UNSIGNED32 [coOdGetObjSize](#) (CO_CONST CO_OBJECT_DESC_T *pDesc)
coOdGetObjSize - get object size
- [RET_T icoOdGetObjRecMapData](#) (UNSIGNED16 index, UNSIGNED8 subIndex, void **pVar, UNSIGNED8
*pLen, [BOOL_T](#) *pNumeric)
icoOdGetObjRecMapData - get data of receive mapping entry
- [RET_T icoOdGetObjTrMapData](#) (UNSIGNED16 index, UNSIGNED8 subIndex, CO_CONST void **pVar, U↔
UNSIGNED8 *pLen, [BOOL_T](#) *pNumeric)
icoOdGetObjTrMapData - get data of transmit mapping entry
- [RET_T icoOdCheckObjAttr](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 checkAttr)
icoOdCheckObjAttr - check object for given attributes
- [RET_T coOdGetDefaultVal_u8](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pDefVal)
coOdGetDefaultVal_u8 - get default value for specific object
- [RET_T coOdGetDefaultVal_u16](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 *pDefVal)
coOdGetDefaultVal_u16 - get default value for specific object
- [RET_T coOdGetDefaultVal_u32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 *pDefVal)
coOdGetDefaultVal_u32 - get default value for specific object
- [RET_T coOdGetObjDescPtr](#) (UNSIGNED16 index, UNSIGNED8 subIndex, CO_CONST CO_OBJECT_D↔
ESC_T **pDescPtr)
coOdGetObjDescPtr - get object description pointer
- [RET_T coEventRegister_OBJECT_CHANGED](#) (CO_EVENT_OBJECT_CHANGED_FCT_T pFunction, U↔
UNSIGNED16 index, UNSIGNED8 subIndex)
coEventRegister_OBJECT_CHANGED - register object changed function
- void [coOdInitOdPtr](#) (const CO_OD_ASSIGN_T *pOdAssing, UNSIGNED16 odCnt, const CO_OBJECT_↔
DESC_T *pObjdesc, UNSIGNED16 descCnt, CO_EVENT_OBJECT_CHANGED_FCT_T *pEventPtr, const
CO_OD_DATA_VARIABLES_T *pOdVarPointers)
coOdInitOdPtr - init all object dictionary and variable pointers

5.36.1 Detailed Description

object dictionary access

contains routines for object dictionary access

5.36.2 Function Documentation

5.36.2.1 **RET_T** coEventRegister_OBJECT_CHANGED (**CO_EVENT_OBJECT_CHANGED_FCT_T** *pFunction*, **UNSIGNED16** *index*, **UNSIGNED8** *subIndex*)

coEventRegister_OBJECT_CHANGED - register object changed function

This function registered a indication function for a given object. Each time, this object is changed by PDO, SDO or by coOdPutObj_xx() the given function is called.

If the subindex == 255, then the indication is called for each subindex.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
<i>index</i>	index
<i>subIndex</i>	subIndex

5.36.2.2 **RET_T** coOdDomainAddrSet (**UNSIGNED16** *index*, **UNSIGNED8** *subIndex*, **CO_DOMAIN_PTR** *pAddr*, **UNSIGNED32** *size*)

coOdDomainAddrSet - set domain address

This function sets the adress and the size of a domain.

At the initialization time, domains are not initialized at the object dictionary. This has to be done by this function.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pAddr</i>	pointer to domain
<i>size</i>	domain length

5.36.2.3 RET_T coOdGetDefaultVal_u16 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED16 * *pDefVal*)

coOdGetDefaultVal_u16 - get default value for specific object

This function returns the default value of an UNSIGNED16 object.

Returns

RET_T

Parameters

<i>index</i>	index
<i>subIndex</i>	sub index
<i>pDefVal</i>	pointer to default val

5.36.2.4 RET_T coOdGetDefaultVal_u32 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED32 * *pDefVal*)

coOdGetDefaultVal_u32 - get default value for specific object

This function returns the default value of an UNSIGNED32 object.

Returns

RET_T

Parameters

<i>index</i>	index
<i>subIndex</i>	sub index
<i>pDefVal</i>	pointer to default val

5.36.2.5 RET_T coOdGetDefaultVal_u8 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 * *pDefVal*)

coOdGetDefaultVal_u8 - get default value for specific object

This function returns the default value of an UNSIGNED8 object.

Returns

RET_T

Parameters

<i>index</i>	index
<i>subIndex</i>	sub index
<i>pDefVal</i>	pointer to default val

5.36.2.6 RET_T coOdGetObj_i16 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, INTEGER16 * *pObj*)

coOdGetObj_i16 - get INTEGER16 object

Get an object from the object dictionary from type INTEGER16.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.36.2.7 RET_T coOdGetObj_i32 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, INTEGER32 * *pObj*)

coOdGetObj_i32 - get INTEGER32 object

Get an object from the object dictionary from type INTEGER32.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.36.2.8 RET_T coOdGetObj_i8 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, INTEGER8 * *pObj*)

coOdGetObj_i8 - get INTEGER8 object

Get an object from the object dictionary from type INTEGER8.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.36.2.9 RET_T coOdGetObj_r32 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, REAL32 * *pObj*)

coOdGetObj_r32 - get REAL32 object

Get an object from the object dictionary from type REAL32.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.36.2.10 RET_T coOdGetObj_u16 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED16 * *pObj*)

coOdGetObj_u16 - get UNSIGNED16 object

Get an object from the object dictionary from type UNSIGNED16.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.36.2.11 RET_T coOdGetObj_u24 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED24 * *pObj*)

coOdGetObj_u24 - get UNSIGNED24 object

Get an object from the object dictionary from type UNSIGNED24.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.36.2.12 **RET_T** coOdGetObj_u32 (*UNSIGNED16 index*, *UNSIGNED8 subIndex*, *UNSIGNED32 * pObj*)

coOdGetObj_u32 - get UNSIGNED32 object

Get an object from the object dictionary from type UNSIGNED32.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.36.2.13 **RET_T** coOdGetObj_u40 (*UNSIGNED16 index*, *UNSIGNED8 subIndex*, *UNSIGNED40 * pObj*)

coOdGetObj_u40 - get UNSIGNED40 object

Get an object from the object dictionary from type UNSIGNED40

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.36.2.14 **RET_T** coOdGetObj_u48 (*UNSIGNED16 index*, *UNSIGNED8 subIndex*, *UNSIGNED48 * pObj*)

coOdGetObj_u48 - get UNSIGNED48 object

Get an object from the object dictionary from type UNSIGNED48

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.36.2.15 **RET_T** coOdGetObj_u64 (**UNSIGNED16** *index*, **UNSIGNED8** *subIndex*, **UNSIGNED64** * *pObj*)

coOdGetObj_u64 - get UNSIGNED64 object

Get an object from the object dictionary from type UNSIGNED64

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.36.2.16 **RET_T** coOdGetObj_u8 (**UNSIGNED16** *index*, **UNSIGNED8** *subIndex*, **UNSIGNED8** * *pObj*)

coOdGetObj_u8 - get UNSIGNED8 object

Get an object from the object dictionary from type UNSIGNED8.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.36.2.17 **void*** coOdGetObjAddr (**UNSIGNED16** *index*, **UNSIGNED8** *subIndex*)

coOdGetObjAddr - get address of an object

Get the address of an object from the object dictionary.

Returns

pointer to object address, NULL if object not found

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object

5.36.2.18 `UNSIGNED16 coOdGetObjAttribute (CO_CONST CO_OBJECT_DESC_T * pObjDesc)`

coOdGetObjAttribute - get object attribute

This function returns the attribute of the object from the given object description.

Returns

attribute

Parameters

<i>pObjDesc</i>	pointer to object description
-----------------	-------------------------------

5.36.2.19 `RET_T coOdGetObjDescPtr (UNSIGNED16 index, UNSIGNED8 subIndex, CO_CONST CO_OBJECT_DESC_T **
pDescPtr)`

coOdGetObjDescPtr - get object description pointer

This function returns a pointer to the object description of an object of the object dictionary.

Returns

RET_T

Parameters

<i>index</i>	index
<i>subIndex</i>	sub index
<i>pDescPtr</i>	pointer for description index

5.36.2.20 `UNSIGNED32 coOdGetObjSize (CO_CONST CO_OBJECT_DESC_T * pDesc)`

coOdGetObjSize - get object size

This function returns the size of an object (in bytes), given by the object description.

Returns

object size

Parameters

<i>pDesc</i>	pointer for description index
--------------	-------------------------------

5.36.2.21 void coOdInitOdPtr (const CO_OD_ASSIGN_T * *pOdAssing*, UNSIGNED16 *odCnt*, const CO_OBJECT_DESC_T * *pObjdesc*, UNSIGNED16 *descCnt*, CO_EVENT_OBJECT_CHANGED_FCT_T * *pEventPtr*, const CO_OD_DATA_VARIABLES_T * *pOdVarPointers*)

coOdInitOdPtr - init all object dictionary and variable pointers

This function initializes the object dictionary with all variables.

Returns

none

Parameters

<i>pOdAssing</i>	pointer to OD assign
<i>odCnt</i>	number of objects
<i>pObjdesc</i>	pointer to obj descr
<i>descCnt</i>	number of obj desc
<i>pEventPtr</i>	pointer to obj events
<i>pOdVarPointers</i>	pointer to variable types

5.36.2.22 RET_T coOdPutObj_i16 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, INTEGER16 *newVal*)

coOdPutObj_i16 - Put INTEGER16 object

Put value from type INTEGER16 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.36.2.23 RET_T coOdPutObj_i32 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, INTEGER32 *newVal*)

coOdPutObj_i32 - Put INTEGER32 object

Put value from type INTEGER32 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.36.2.24 **RET_T** coOdPutObj_i8 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, INTEGER8 *newVal*)

coOdPutObj_i8 - Put INTEGER8 object

Put value from type INTEGER8 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.36.2.25 **RET_T** coOdPutObj_r32 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, REAL32 *newVal*)

coOdPutObj_r32 - Put REAL32 object

Put value from type REAL32 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.36.2.26 **RET_T** coOdPutObj_u16 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED16 *newVal*)

coOdPutObj_u16 - put UNSIGNED16 value to object

Put value from type UNSIGNED16 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.36.2.27 **RET_T** coOdPutObj_u24 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED24 *newVal*)

coOdPutObj_u24 - Put UNSIGNED24 Object

Put value from type UNSIGNED24 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.36.2.28 **RET_T** coOdPutObj_u32 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED32 *newVal*)

coOdPutObj_u32 - put UNSIGNED32 value to object

Put value from type UNSIGNED32 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.36.2.29 **RET_T** coOdPutObj_u40 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED40 *newVal*)

coOdPutObj_u40 - Put UNSIGNED40 Object

Put value from type UNSIGNED24 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.36.2.30 **RET_T** coOdPutObj_u48 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED48 *newVal*)

coOdPutObj_u48 - Put UNSIGNED48 Object

Put value from type UNSIGNED24 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.36.2.31 **RET_T** coOdPutObj_u64 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED64 *newVal*)

coOdPutObj_u64 - Put UNSIGNED64 Object

Put value from type UNSIGNED24 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.36.2.32 **RET_T** coOdPutObj_u8 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 *newVal*)

coOdPutObj_u8 - put UNSIGNED8 value to object

Put value from type UNSIGNED8 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.36.2.33 **RET_T** coOdSetCobid (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED32 *newCobId*)

coOdSetCobid - set cob id

This function set the COB-Id for a service indicated by index and subindex.

According to the standard, the COB-ID is disabled first by this function, and then the new COB-ID is set.

Returns

RET_T

Parameters

<i>index</i>	index for the cob
<i>subIndex</i>	subIndex for the cob
<i>new↔ CobId</i>	new cob-id

5.36.2.34 **RET_T** coOdVisStringSet (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, VIS_STRING *pAddr*, UNSIGNED32 *size*)

coOdVisStringSet - set address and len for visible string

This function change the address and length if a visible string object. It can only be used for non-constant strings, defined as user variable.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pAddr</i>	pointer to string
<i>size</i>	string length

5.36.2.35 **RET_T** icoOdCheckObjAttr (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED16 *checkAttr*)

icoOdCheckObjAttr - check object for given attributes

internal

This function checks an object for the given attributes

Returns

RET_T

5.36.2.36 RET_T icoOdGetObjRecMapData (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, void ** *pVar*, UNSIGNED8 * *pLen*, BOOL_T * *pNumeric*)

icoOdGetObjRecMapData - get data of receive mapping entry

internal

This function returns data of mapping entry If index is not mapable, returns error

Returns

RET_T

5.36.2.37 RET_T icoOdGetObjTrMapData (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, CO_CONST void ** *pVar*, UNSIGNED8 * *pLen*, BOOL_T * *pNumeric*)

icoOdGetObjTrMapData - get data of transmit mapping entry

internal

This function returns data of mapping entry If index is not mapable, returns error

Returns

RET_T

5.37 co_odaccess.h File Reference

defines for OD access

Macros

- #define CO_OS_LOCK_OD()
- #define CO_OS_UNLOCK_OD()
- #define CO_ATTR_READ 0x0001u
- #define CO_ATTR_WRITE 0x0002u
- #define CO_ATTR_NUM 0x0004u
- #define CO_ATTR_MAP 0x0008u
- #define CO_ATTR_MAP_TR 0x0010u
- #define CO_ATTR_MAP_REC 0x0020u
- #define CO_ATTR_DEFVAL 0x0040u
- #define CO_ATTR_LIMIT 0x0080u
- #define CO_ATTR_DYNOD 0x0100u
- #define CO_ATTR_STORE 0x0200u

Typedefs

- typedef [RET_T](#)(* [CO_EVENT_OBJECT_CHANGED_FCT_T](#)) (UNSIGNED16, UNSIGNED8)
function pointer to object changed function

Enumerations

Functions

- void [coOdInitOdPtr](#) (const CO_OD_ASSIGN_T *pOdAssing, UNSIGNED16 odCnt, const CO_OBJECT_DESC_T *pObjdesc, UNSIGNED16 descCnt, [CO_EVENT_OBJECT_CHANGED_FCT_T](#) *pEventPtr, const CO_OD_DATA_VARIABLES_T *pOdVarPointers)
coOdInitOdPtr - init all object dictionary and variable pointers
- EXTERN_DECL [RET_T](#) [coOdGetObj_u32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 *pObj)
coOdGetObj_u32 - get UNSIGNED32 object
- EXTERN_DECL [RET_T](#) [coOdGetObj_u16](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 *pObj)
coOdGetObj_u16 - get UNSIGNED16 object
- EXTERN_DECL [RET_T](#) [coOdGetObj_u8](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pObj)
coOdGetObj_u8 - get UNSIGNED8 object
- EXTERN_DECL [RET_T](#) [coOdGetObj_i32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER32 *pObj)
coOdGetObj_i32 - get INTEGER32 object
- EXTERN_DECL [RET_T](#) [coOdGetObj_i16](#) (UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER16 *pObj)
coOdGetObj_i16 - get INTEGER16 object
- EXTERN_DECL [RET_T](#) [coOdGetObj_i8](#) (UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER8 *pObj)
coOdGetObj_i8 - get INTEGER8 object
- EXTERN_DECL [RET_T](#) [coOdGetObj_r32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, REAL32 *pObj)
coOdGetObj_r32 - get REAL32 object
- EXTERN_DECL [RET_T](#) [coOdGetObj_u24](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED24 *pObj)
coOdGetObj_u24 - get UNSIGNED24 object
- EXTERN_DECL [RET_T](#) [coOdGetObj_u40](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED40 *pObj)
coOdGetObj_u40 - get UNSIGNED40 object
- EXTERN_DECL [RET_T](#) [coOdGetObj_u48](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED48 *pObj)
coOdGetObj_u48 - get UNSIGNED48 object
- EXTERN_DECL [RET_T](#) [coOdGetObj_u64](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED64 *pObj)
coOdGetObj_u64 - get UNSIGNED64 object
- EXTERN_DECL UNSIGNED16 [coOdGetObjAttribute](#) (CO_CONST CO_OBJECT_DESC_T *pObjDesc)
coOdGetObjAttribute - get object attribute
- EXTERN_DECL [RET_T](#) [coOdGetObjDescPtr](#) (UNSIGNED16 index, UNSIGNED8 subIndex, CO_CONST CO_OBJECT_DESC_T **pDescPtr)
coOdGetObjDescPtr - get object description pointer
- EXTERN_DECL UNSIGNED32 [coOdGetObjSize](#) (CO_CONST CO_OBJECT_DESC_T *pDesc)
coOdGetObjSize - get object size
- EXTERN_DECL [RET_T](#) [coOdPutObj_u32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 newVal)
coOdPutObj_u32 - put UNSIGNED32 value to object

- EXTERN_DECL [RET_T coOdPutObj_u16](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 newVal)
coOdPutObj_u16 - put UNSIGNED16 value to object
- EXTERN_DECL [RET_T coOdPutObj_u8](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 newVal)
coOdPutObj_u8 - put UNSIGNED8 value to object
- EXTERN_DECL [RET_T coOdPutObj_i32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER32 newVal)
coOdPutObj_i32 - Put INTEGER32 object
- EXTERN_DECL [RET_T coOdPutObj_i16](#) (UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER16 newVal)
coOdPutObj_i16 - Put INTEGER16 object
- EXTERN_DECL [RET_T coOdPutObj_i8](#) (UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER8 newVal)
coOdPutObj_i8 - Put INTEGER8 object
- EXTERN_DECL [RET_T coOdPutObj_r32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, REAL32 newVal)
coOdPutObj_r32 - Put REAL32 object
- EXTERN_DECL [RET_T coOdPutObj_u24](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED24 newVal)
coOdPutObj_u24 - Put UNSIGNED24 Object
- EXTERN_DECL [RET_T coOdPutObj_u40](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED40 newVal)
coOdPutObj_u40 - Put UNSIGNED40 Object
- EXTERN_DECL [RET_T coOdPutObj_u48](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED48 newVal)
coOdPutObj_u48 - Put UNSIGNED48 Object
- EXTERN_DECL [RET_T coOdPutObj_u64](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED64 newVal)
coOdPutObj_u64 - Put UNSIGNED64 Object
- EXTERN_DECL void * [coOdGetObjAddr](#) (UNSIGNED16 index, UNSIGNED8 subIndex)
coOdGetObjAddr - get address of an object
- EXTERN_DECL [RET_T coOdGetDefaultVal_u32](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 *pDefVal)
coOdGetDefaultVal_u32 - get default value for specific object
- EXTERN_DECL [RET_T coOdGetDefaultVal_u16](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED16 *pDefVal)
coOdGetDefaultVal_u16 - get default value for specific object
- EXTERN_DECL [RET_T coOdGetDefaultVal_u8](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pDefVal)
coOdGetDefaultVal_u8 - get default value for specific object
- EXTERN_DECL [RET_T coOdSetCobid](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED32 newCobId)
coOdSetCobid - set cob id
- EXTERN_DECL [RET_T coOdDomainAddrSet](#) (UNSIGNED16 index, UNSIGNED8 subIndex, CO_DOMAIN_PTR pAddr, UNSIGNED32 size)
coOdDomainAddrSet - set domain address
- EXTERN_DECL [RET_T coOdVisStringSet](#) (UNSIGNED16 index, UNSIGNED8 subIndex, VIS_STRING_PTR pAddr, UNSIGNED32 size)
coOdVisStringSet - set address and len for visible string
- EXTERN_DECL [RET_T coEventRegister_OBJECT_CHANGED](#) (CO_EVENT_OBJECT_CHANGED_FCT_T, UNSIGNED16, UNSIGNED8)
coEventRegister_OBJECT_CHANGED - register object changed function

- EXTERN_DECL [RET_T coDynOdInit](#) (UNSIGNED16 objCnt, UNSIGNED16 u8Cnt, UNSIGNED16 u16Cnt, UNSIGNED16 u32Cnt, UNSIGNED16 i8Cnt, UNSIGNED16 i16Cnt, UNSIGNED16 i32Cnt, UNSIGNED16 u64Cnt)
coDynOdInit - init dynamic object dictionary
- EXTERN_DECL [RET_T coDynOdRelease](#) (void)
coDynOdRelease - release dynamic object dictionary
- EXTERN_DECL [RET_T coDynOdAddIndex](#) (UNSIGNED16 index, UNSIGNED8 nrOfSubs, [CO_ODTYPE_T](#) odType)
coDynOdAddIndex - add a new object index
- EXTERN_DECL [RET_T coDynOdAddSubIndex](#) (UNSIGNED16 index, UNSIGNED8 subIndex, [CO_DATA_TYPE_T](#) dataType, UNSIGNED16 attr, void *pVar)
coDynOdAddSubIndex - add new subindex
- EXTERN_DECL [RET_T coDynOdSetSubIndexAddr](#) (UNSIGNED16 index, UNSIGNED8 subIndex, [CO_DATA_TYPE_T](#) dataType, void *pVar)
coDynOdSetSubIndexAddr - set new pointer for subindex

5.37.1 Detailed Description

defines for OD access

- contains defines for object dictionary access

5.37.2 Macro Definition Documentation

5.37.2.1 #define CO_ATTR_DEFVAL 0x0040u

object has a default value

5.37.2.2 #define CO_ATTR_DYNOD 0x0100u

object is a dynamic created object

5.37.2.3 #define CO_ATTR_LIMIT 0x0080u

object has limits

5.37.2.4 #define CO_ATTR_MAP 0x0008u

object can be mapped into a PDO

5.37.2.5 #define CO_ATTR_MAP_REC 0x0020u

object can be mapped into a receive PDO

5.37.2.6 `#define CO_ATTR_MAP_TR 0x0010u`

object can be mapped into a transmit PDO

5.37.2.7 `#define CO_ATTR_NUM 0x0004u`

object is numeric

5.37.2.8 `#define CO_ATTR_READ 0x0001u`

object attributes object readable

5.37.2.9 `#define CO_ATTR_STORE 0x0200u`

object is supposed to be stored

5.37.2.10 `#define CO_ATTR_WRITE 0x0002u`

object writeable

5.37.2.11 `#define CO_OS_LOCK_OD()`

function call to lock object dictionary

5.37.2.12 `#define CO_OS_UNLOCK_OD()`

function call to unlock object dictionary

5.37.3 Typedef Documentation

5.37.3.1 `typedef RET_T(* CO_EVENT_OBJECT_CHANGED_FCT_T) (UNSIGNED16, UNSIGNED8)`

function pointer to object changed function

Parameters

<i>index</i>	- object index
<i>subindex</i>	- object subindex

Returns

RET_T

5.37.4 Enumeration Type Documentation

5.37.4.1 enum CO_DATA_TYPE_T

object datatypes

5.37.4.2 enum CO_ODTYPE_T

Object type

Enumerator

CO_ODTYPE_VAR variable**CO_ODTYPE_ARRAY** array**CO_ODTYPE_STRUCT** structure

5.37.5 Function Documentation

5.37.5.1 EXTERN_DECL RET_T coDynOdAddIndex (UNSIGNED16 *index*, UNSIGNED8 *nrOfSubs*, CO_ODTYPE_T *odType*)

coDynOdAddIndex - add a new object index

Return values

RET_IDX_NOT_FOUND	index < 0x2000 are not allowed
RET_INVALID_PARAMETER	index already exist
RET_EVENT_NO_RESSOURCE	no resource available

Parameters

<i>index</i>	index
<i>nrOfSubs</i>	number of subindex
<i>odType</i>	variable, array, struct

5.37.5.2 EXTERN_DECL RET_T coDynOdAddSubIndex (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, CO_DATA_TYPE_T *dataType*, UNSIGNED16 *attr*, void * *pVar*)

coDynOdAddSubIndex - add new subindex

no check for to many data or duplicate subindex

Return values

<i>RET_DATA_TYPE_MISMATCH</i>	data type not supported (only U8, U16, U32, I8, I16, I32 allowed)
<i>RET_IDX_NOT_FOUND</i>	index not found

Parameters

<i>index</i>	index
<i>subIndex</i>	number of subindex
<i>dataType</i>	data type
<i>attr</i>	attribute
<i>pVar</i>	pointer to variable

5.37.5.3 EXTERN_DECL RET_T coDynOdInit (UNSIGNED16 *objCnt*, UNSIGNED16 *u8Cnt*, UNSIGNED16 *u16Cnt*,
UNSIGNED16 *u32Cnt*, UNSIGNED16 *i8Cnt*, UNSIGNED16 *i16Cnt*, UNSIGNED16 *i32Cnt*, UNSIGNED16 *u64Cnt*)

coDynOdInit - init dynamic object dictionary

Return values

<i>RET_OK</i>	initialisation OK
<i>RET_EVENT_NO_RESSOURCE</i>	error at malloc()

Parameters

<i>objCnt</i>	number of new objects for can line
<i>u8Cnt</i>	number of U8 vars for can line
<i>u16Cnt</i>	number of U16 vars for can line
<i>u32Cnt</i>	number of U32 vars for can line
<i>i8Cnt</i>	number of i8 vars for can line
<i>i16Cnt</i>	number of i16 vars for can line
<i>i32Cnt</i>	number of i32 vars for can line
<i>u64Cnt</i>	number of U64 vars for can line

5.37.5.4 EXTERN_DECL RET_T coDynOdRelease (void)

coDynOdRelease - release dynamic object dictionary

Deinit dynamic object dictionary and release all requested memory

Return values

<i>RET_OK</i>	deinitialisation OK
---------------	---------------------

5.37.5.5 EXTERN_DECL RET_T coDynOdSetSubIndexAddr (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, CO_DATA_TYPE_T *dataType*, void * *pVar*)

coDynOdSetSubIndexAddr - set new pointer for subindex

set a new data pointer for a given sub index

Return values

<i>RET_DATA_TYPE_MISMATCH</i>	data type not supported (only U8, U16, U32, I8, I16, I32 allowed)
<i>RET_IDX_NOT_FOUND</i>	index not found

Parameters

<i>index</i>	index
<i>subIndex</i>	number of subindex
<i>dataType</i>	data type
<i>pVar</i>	pointer to variable

5.37.5.6 EXTERN_DECL RET_T coEventRegister_OBJECT_CHANGED (CO_EVENT_OBJECT_CHANGED_FCT_T *pFunction*, UNSIGNED16 *index*, UNSIGNED8 *subIndex*)

coEventRegister_OBJECT_CHANGED - register object changed function

This function registered a indication function for a given object. Each time, this object is changed by PDO, SDO or by coOdPutObj_xx() the given function is called.

If the subindex == 255, then the indication is called for each subindex.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
<i>index</i>	index
<i>subIndex</i>	subIndex

5.37.5.7 EXTERN_DECL RET_T coOdDomainAddrSet (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, CO_DOMAIN_PTR *pAddr*, UNSIGNED32 *size*)

coOdDomainAddrSet - set domain address

This function sets the adress and the size of a domain.

At the initialization time, domains are not initialized at the object dictionary. This has to be done by this function.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pAddr</i>	pointer to domain
<i>size</i>	domain length

5.37.5.8 **EXTERN_DECL RET_T** coOdGetDefaultVal_u16 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED16 * *pDefVal*)

coOdGetDefaultVal_u16 - get default value for specific object

This function returns the default value of an UNSIGNED16 object.

Returns

RET_T

Parameters

<i>index</i>	index
<i>subIndex</i>	sub index
<i>pDefVal</i>	pointer to default val

5.37.5.9 **EXTERN_DECL RET_T** coOdGetDefaultVal_u32 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED32 * *pDefVal*)

coOdGetDefaultVal_u32 - get default value for specific object

This function returns the default value of an UNSIGNED32 object.

Returns

RET_T

Parameters

<i>index</i>	index
<i>subIndex</i>	sub index
<i>pDefVal</i>	pointer to default val

5.37.5.10 **EXTERN_DECL RET_T** coOdGetDefaultVal_u8 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 * *pDefVal*)

coOdGetDefaultVal_u8 - get default value for specific object

This function returns the default value of an UNSIGNED8 object.

Returns

RET_T

Parameters

<i>index</i>	index
<i>subIndex</i>	sub index
<i>pDefVal</i>	pointer to default val

5.37.5.11 EXTERN_DECL RET_T coOdGetObj_i16 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, INTEGER16 * *pObj*)

coOdGetObj_i16 - get INTEGER16 object

Get an object from the object dictionary from type INTEGER16.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.37.5.12 EXTERN_DECL RET_T coOdGetObj_i32 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, INTEGER32 * *pObj*)

coOdGetObj_i32 - get INTEGER32 object

Get an object from the object dictionary from type INTEGER32.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.37.5.13 EXTERN_DECL RET_T coOdGetObj_i8 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, INTEGER8 * *pObj*)

coOdGetObj_i8 - get INTEGER8 object

Get an object from the object dictionary from type INTEGER8.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.37.5.14 EXTERN_DECL RET_T coOdGetObj_r32 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, REAL32 * *pObj*)

coOdGetObj_r32 - get REAL32 object

Get an object from the object dictionary from type REAL32.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.37.5.15 EXTERN_DECL RET_T coOdGetObj_u16 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED16 * *pObj*)

coOdGetObj_u16 - get UNSIGNED16 object

Get an object from the object dictionary from type UNSIGNED16.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.37.5.16 EXTERN_DECL RET_T coOdGetObj_u24 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED24 * *pObj*)

coOdGetObj_u24 - get UNSIGNED24 object

Get an object from the object dictionary from type UNSIGNED24.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.37.5.17 EXTERN_DECL RET_T coOdGetObj_u32 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED32 * *pObj*)

coOdGetObj_u32 - get UNSIGNED32 object

Get an object from the object dictionary from type UNSIGNED32.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.37.5.18 EXTERN_DECL RET_T coOdGetObj_u40 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED40 * *pObj*)

coOdGetObj_u40 - get UNSIGNED40 object

Get an object from the object dictionary from type UNSIGNED40

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.37.5.19 EXTERN_DECL RET_T coOdGetObj_u48 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED48 * *pObj*)

coOdGetObj_u48 - get UNSIGNED48 object

Get an object from the object dictionary from type UNSIGNED48

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.37.5.20 EXTERN_DECL RET_T coOdGetObj_u64 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED64 * *pObj*)

coOdGetObj_u64 - get UNSIGNED64 object

Get an object from the object dictionary from type UNSIGNED64

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.37.5.21 EXTERN_DECL RET_T coOdGetObj_u8 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 * *pObj*)

coOdGetObj_u8 - get UNSIGNED8 object

Get an object from the object dictionary from type UNSIGNED8.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pObj</i>	pointer to object

5.37.5.22 EXTERN_DECL void* coOdGetObjAddr (UNSIGNED16 *index*, UNSIGNED8 *subIndex*)

coOdGetObjAddr - get address of an object

Get the address of an object from the object dictionary.

Returns

pointer to object address, NULL if object not found

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object

5.37.5.23 EXTERN_DECL UNSIGNED16 coOdGetObjAttribute (CO_CONST CO_OBJECT_DESC_T * *pObjDesc*)

coOdGetObjAttribute - get object attribute

This function returns the attribute of the object from the given object description.

Returns

attribute

Parameters

<i>pObjDesc</i>	pointer to object description
-----------------	-------------------------------

5.37.5.24 EXTERN_DECL RET_T coOdGetObjDescPtr (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, CO_CONST CO_OBJECT_DESC_T ** *pDescPtr*)

coOdGetObjDescPtr - get object description pointer

This function returns a pointer to the object description of an object of the object dictionary.

Returns

RET_T

Parameters

<i>index</i>	index
<i>subIndex</i>	sub index
<i>pDescPtr</i>	pointer for description index

5.37.5.25 EXTERN_DECL UNSIGNED32 coOdGetObjSize (CO_CONST CO_OBJECT_DESC_T * *pDesc*)

coOdGetObjSize - get object size

This function returns the size of an object (in bytes), given by the object description.

Returns

object size

Parameters

<i>pDesc</i>	pointer for description index
--------------	-------------------------------

```
5.37.5.26 void coOdInitOdPtr ( const CO_OD_ASSIGN_T * pOdAssing, UNSIGNED16 odCnt, const CO_OBJECT_DESC_T
    * pObjdesc, UNSIGNED16 descCnt, CO_EVENT_OBJECT_CHANGED_FCT_T * pEventPtr, const
    CO_OD_DATA_VARIABLES_T * pOdVarPointers )
```

coOdInitOdPtr - init all object dictionary and variable pointers

This function initializes the object dictionary with all variables.

Returns

none

Parameters

<i>pOdAssing</i>	pointer to OD assign
<i>odCnt</i>	number of objects
<i>pObjdesc</i>	pointer to obj descr
<i>descCnt</i>	number of obj desc
<i>pEventPtr</i>	pointer to obj events
<i>pOdVarPointers</i>	pointer to variable types

```
5.37.5.27 EXTERN_DECL RET_T coOdPutObj_i16 ( UNSIGNED16 index, UNSIGNED8 subIndex, INTEGER16 newVal )
```

coOdPutObj_i16 - Put INTEGER16 object

Put value from type INTEGER16 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.37.5.28 EXTERN_DECL RET_T coOdPutObj_i32 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, INTEGER32 *newVal*)

coOdPutObj_i32 - Put INTEGER32 object

Put value from type INTEGER32 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.37.5.29 EXTERN_DECL RET_T coOdPutObj_i8 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, INTEGER8 *newVal*)

coOdPutObj_i8 - Put INTEGER8 object

Put value from type INTEGER8 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.37.5.30 EXTERN_DECL RET_T coOdPutObj_r32 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, REAL32 *newVal*)

coOdPutObj_r32 - Put REAL32 object

Put value from type REAL32 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.37.5.31 **EXTERN_DECL RET_T coOdPutObj_u16 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED16 *newVal*)**

coOdPutObj_u16 - put UNSIGNED16 value to object

Put value from type UNSIGNED16 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.37.5.32 **EXTERN_DECL RET_T coOdPutObj_u24 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED24 *newVal*)**

coOdPutObj_u24 - Put UNSIGNED24 Object

Put value from type UNSIGNED24 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.37.5.33 **EXTERN_DECL RET_T coOdPutObj_u32 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED32 *newVal*)**

coOdPutObj_u32 - put UNSIGNED32 value to object

Put value from type UNSIGNED32 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.37.5.34 **EXTERN_DECL RET_T** coOdPutObj_u40 (*UNSIGNED16 index*, *UNSIGNED8 subIndex*, *UNSIGNED40 newVal*)

coOdPutObj_u40 - Put UNSIGNED40 Object

Put value from type UNSIGNED24 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.37.5.35 **EXTERN_DECL RET_T** coOdPutObj_u48 (*UNSIGNED16 index*, *UNSIGNED8 subIndex*, *UNSIGNED48 newVal*)

coOdPutObj_u48 - Put UNSIGNED48 Object

Put value from type UNSIGNED24 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.37.5.36 **EXTERN_DECL RET_T** coOdPutObj_u64 (*UNSIGNED16 index*, *UNSIGNED8 subIndex*, *UNSIGNED64 newVal*)

coOdPutObj_u64 - Put UNSIGNED64 Object

Put value from type UNSIGNED24 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.37.5.37 EXTERN_DECL RET_T coOdPutObj_u8 (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 *newVal*)

coOdPutObj_u8 - put UNSIGNED8 value to object

Put value from type UNSIGNED8 to the object dictionary

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>newVal</i>	new value

5.37.5.38 EXTERN_DECL RET_T coOdSetCobid (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED32 *newCobId*)

coOdSetCobid - set cob id

This function set the COB-Id for a service indicated by index and subindex.

According to the standard, the COB-ID is disabled first by this function, and then the new COB-ID is set.

Returns

RET_T

Parameters

<i>index</i>	index for the cob
<i>subIndex</i>	subIndex for the cob
<i>new↔ CobId</i>	new cob-id

5.37.5.39 EXTERN_DECL RET_T coOdVisStringSet (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, VIS_STRING *pAddr*, UNSIGNED32 *size*)

coOdVisStringSet - set address and len for visible string

This function change the address and length if a visible string object. It can only be used for non-constant strings, defined as user variable.

Returns

RET_T

Parameters

<i>index</i>	index of object
<i>subIndex</i>	subindex of object
<i>pAddr</i>	pointer to string
<i>size</i>	string length

5.38 co_odindex.h File Reference

defines for OD index

5.38.1 Detailed Description

defines for OD index

- contains defines for OD index

5.39 co_pdo.c File Reference

PDO transmission and reception routines.

Functions

- [RET_T coPdoReqNr](#) (UNSIGNED16 pdoNr, UNSIGNED8 flags)
coPdoReqNr - request PDO transmission by PDO number
- [RET_T coPdoReqObj](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 flags)
coPdoReqObj - request PDO transmission by object
- [BOOL_T coPdoObjsMapped](#) (UNSIGNED16 pdoNr, UNSIGNED16 index, UNSIGNED8 subIndex)
coPdoObjsMapped - check, if object mapped to given PDO
- [RET_T coEventRegister_PDO](#) (CO_EVENT_PDO_T pFunction)
coEventRegister_PDO - register asynchronous PDO event
- [RET_T coEventRegister_PDO_REC_EVENT](#) (CO_EVENT_PDO_T pFunction)
coEventRegister_PDO_REC_EVENT - register receive PDO event
- [RET_T coEventRegister_PDO_SYNC](#) (CO_EVENT_PDO_T pFunction)
coEventRegister_PDO_SYNC - register PDO SYNC event
- void [icoPdoVarInit](#) (UNSIGNED16 *pTrCnt, UNSIGNED16 *pRecCnt)
icoPdoVarInit - init pdo variables
- [RET_T coPdoTransmitInit](#) (UNSIGNED16 pdoNr, UNSIGNED8 transType, UNSIGNED16 inhibit, UNSIGNED16 eventTime, UNSIGNED8 syncStartVal, CO_CONST [PDO_TR_MAP_TABLE_T](#) *mapTable)
coPdoTransmitInit - init transmit pdo functionality
- [RET_T coPdoReceiveInit](#) (UNSIGNED16 pdoNr, UNSIGNED8 transType, UNSIGNED16 inhibit, UNSIGNED16 eventTime, CO_CONST [PDO_REC_MAP_TABLE_T](#) *mapTable)
coPdoReceiveInit - init receive pdo functionality

5.39.1 Detailed Description

PDO transmission and reception routines.

contains PDO handling routines.

5.39.2 Function Documentation

5.39.2.1 RET_T coEventRegister_PDO (CO_EVENT_PDO_T *pFunction*)

coEventRegister_PDO - register asynchronous PDO event

Register an indication function for asynchronous PDOs.

After a PDO has been received, the data are stored in the object dictionary, and then the given indication function is called. This function is only valid for asynchronous PDOs.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.39.2.2 RET_T coEventRegister_PDO_REC_EVENT (CO_EVENT_PDO_T *pFunction*)

coEventRegister_PDO_REC_EVENT - register receive PDO event

Register an indication function for receive PDO event.

For monitoring of receive PDOs the event timer can be used. If the event timer value is unequal 0 then after the reception of a PDO the monitoring is started automatically. if no further PDO in the given time was received, the indication function given to this function is called.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.39.2.3 RET_T coEventRegister_PDO_SYNC (CO_EVENT_PDO_T *pFunction*)

coEventRegister_PDO_SYNC - register PDO SYNC event

Register an indication function for received synchronous PDOs.

After the SYNC was received, the received data are stored in the object dictionary, and then this given indication function is called.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.39.2.4 **BOOL_T** coPdoObjsMapped (UNSIGNED16 *pdoNr*, UNSIGNED16 *index*, UNSIGNED8 *subIndex*)

coPdoObjsMapped - check, if object mapped to given PDO

This function checks the PDO, if the given object is actual mapped to this PDO. (Only valid for receive PDOs)

Returns

BOOL_T

Return values

<i>CO_TRUE</i>	object is mapped
<i>CO_FALSE</i>	object is not mapped

Parameters

<i>pdoNr</i>	PDO number
<i>index</i>	index of mapped object
<i>subIndex</i>	subindex of mapped object

5.39.2.5 **RET_T** coPdoReceiveInit (UNSIGNED16 *pdoNr*, UNSIGNED8 *transType*, UNSIGNED16 *inhibit*, UNSIGNED16 *eventTime*, CO_CONST PDO_REC_MAP_TABLE_T * *mapTable*)

coPdoReceiveInit - init receive pdo functionality

This function initializes a receive PDO. The COB-ID is set at reset communication or at load parameter.

Note: All parameter are reset by their default values at reset communication.

Returns

RET_T

Parameters

<i>pdoNr</i>	PDO number
<i>transType</i>	transmission type
<i>inhibit</i>	inhibit time 100 usec
<i>eventTime</i>	event timer in msec
<i>mapTable</i>	pointer to mapping table

5.39.2.6 **RET_T** coPdoReqNr (UNSIGNED16 *pdoNr*, UNSIGNED8 *flags*)

coPdoReqNr - request PDO transmission by PDO number

This function requests the transmission of an PDO given by its number.

All mapped objects are automatically copied into the CAN message. If the inhibit time is not active, then the message is transmitted immediately.

If the inhibit time is not elapsed yet, the transmission depends on the parameter flags:

0 - PDO will be transmitted after inhibit is elapsed (if data are not changed, PDO will not be transmitted more than once!) MSG_OVERWRITE - if the last PDO is not transmitted yet, overwrite the last data with the new data MSG_RET_INHIBIT - return the function with RET_INHIBIT_ACTIVE, if the inhibit is not elapsed yet

with the same or

Returns

RET_T

Return values

<i>RET_INVALID_NMT_STATE</i>	invalid NMT state
<i>RET_INVALID_PARAMETER</i>	unknown PDO number
<i>RET_COB_DISABLED</i>	PDO is disabled
<i>RET_INHIBIT_ACTIVE</i>	inhibit time is not yet elapsed
<i>RET_OK</i>	all function are ok, but have not to be transmitted yet

Parameters

<i>pdoNr</i>	PDO number
<i>flags</i>	transmit flags

5.39.2.7 **RET_T** coPdoReqObj (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 *flags*)

coPdoReqObj - request PDO transmission by object

This function requests the transmission of the PDO, which the given object is mapped into.

All mapped objects are automatically copied into the CAN message. If the inhibit time is not active, then the message is transmitted immediately.

If the inhibit time is not elapsed yet, the transmission depends on the parameter flags:

0 - PDO will be transmitted after inhibit is elapsed MSG_OVERWRITE - if the last PDO is not transmitted yet, overwrite the last data with the new data MSG_RET_INHIBIT - return the function with RET_INHIBIT_ACTIVE, if the inhibit is not elapsed yet

Returns

RET_T

Return values

<i>RET_INVALID_NMT_STATE</i>	invalid NMT state
<i>RET_INVALID_PARAMETER</i>	unknown PDO number
<i>RET_COB_DISABLED</i>	PDO is disabled
<i>RET_INHIBIT_ACTIVE</i>	inhibit time is not yet elapsed
<i>RET_OK</i>	all function are ok, but have not to be transmitted yet

Parameters

<i>index</i>	index of mapped object
<i>subIndex</i>	subindex of mapped object
<i>flags</i>	transmit flags

5.39.2.8 RET_T coPdoTransmitInit (UNSIGNED16 pdoNr, UNSIGNED8 transType, UNSIGNED16 inhibit, UNSIGNED16 eventTime, UNSIGNED8 syncStartVal, CO_CONST PDO_TR_MAP_TABLE_T * mapTable)

coPdoTransmitInit - init transmit pdo functionality

This function initializes a transmit PDO. The COB-ID is set at reset communication or at load parameter.

Note: All parameters are reset to their default values at reset communication.

Returns

RET_T

Parameters

<i>pdoNr</i>	PDO number
<i>transType</i>	transmission type
<i>inhibit</i>	inhibit time 100 usec
<i>eventTime</i>	event timer in msec
<i>syncStartVal</i>	sync start value
<i>mapTable</i>	pointer to mapping table

5.40 co_pdo.h File Reference

defines for pdo service

Data Structures

- struct [PDO_TR_MAP_ENTRY_T](#)
- struct [PDO_REC_MAP_ENTRY_T](#)
- struct [PDO_TR_MAP_TABLE_T](#)
- struct [PDO_REC_MAP_TABLE_T](#)

Typedefs

- typedef void(* [CO_EVENT_PDO_T](#)) (UNSIGNED16)
function pointer to PDO indication
- typedef void(* [CO_EVENT_MPDO_T](#)) (UNSIGNED16, UNSIGNED16, UNSIGNED8)
function pointer to MPDO indication

Functions

- EXTERN_DECL [RET_T coPdoTransmitInit](#) (UNSIGNED16 pdoNr, UNSIGNED8 transType, UNSIGNED16 inhibit, UNSIGNED16 eventTime, UNSIGNED8 syncStartVal, CO_CONST [PDO_TR_MAP_TABLE_T](#) *mapTable)
coPdoTransmitInit - init transmit pdo functionality
- EXTERN_DECL [RET_T coPdoReceiveInit](#) (UNSIGNED16 pdoNr, UNSIGNED8 transType, UNSIGNED16 inhibit, UNSIGNED16 eventTime, CO_CONST [PDO_REC_MAP_TABLE_T](#) *mapTable)
coPdoReceiveInit - init receive pdo functionality
- EXTERN_DECL [RET_T coPdoReqNr](#) (UNSIGNED16 pdoNr, UNSIGNED8 flags)
coPdoReqNr - request PDO transmission by PDO number
- EXTERN_DECL [RET_T coPdoReqObj](#) (UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 flags)
coPdoReqObj - request PDO transmission by object
- EXTERN_DECL [BOOL_T coPdoObjsMapped](#) (UNSIGNED16 pdoNr, UNSIGNED16 index, UNSIGNED8 subIndex)
coPdoObjsMapped - check, if object mapped to given PDO
- EXTERN_DECL [RET_T coEventRegister_PDO](#) ([CO_EVENT_PDO_T](#) pFunction)
coEventRegister_PDO - register asynchronous PDO event
- EXTERN_DECL [RET_T coEventRegister_PDO_SYNC](#) ([CO_EVENT_PDO_T](#) pFunction)
coEventRegister_PDO_SYNC - register PDO SYNC event
- EXTERN_DECL [RET_T coEventRegister_PDO_REC_EVENT](#) ([CO_EVENT_PDO_T](#) pFunction)
coEventRegister_PDO_REC_EVENT - register receive PDO event

5.40.1 Detailed Description

defines for pdo service

- contains defines for pdo service

5.40.2 Typedef Documentation

5.40.2.1 typedef void(* CO_EVENT_MPDO_T) (UNSIGNED16, UNSIGNED16, UNSIGNED8)

function pointer to MPDO indication

Parameters

<i>pdoNr</i>	- PDO number
<i>index</i>	- Index
<i>subIndex</i>	- subIndex

Returns

void

5.40.2.2 typedef void(* CO_EVENT_PDO_T) (UNSIGNED16)

function pointer to PDO indication

Parameters

<i>pdoNr</i>	- PDO number
--------------	--------------

Returns

void

5.40.3 Function Documentation

5.40.3.1 EXTERN_DECL RET_T coEventRegister_PDO (CO_EVENT_PDO_T *pFunction*)

coEventRegister_PDO - register asynchronous PDO event

Register an indication function for asynchronous PDOs.

After a PDO has been received, the data are stored in the object dictionary, and then the given indication function is called. This function is only valid for asynchronous PDOs.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.40.3.2 EXTERN_DECL RET_T coEventRegister_PDO_REC_EVENT (CO_EVENT_PDO_T *pFunction*)

coEventRegister_PDO_REC_EVENT - register receive PDO event

Register an indication function for receive PDO event.

For monitoring of receive PDOs the event timer can be used. If the event timer value is unequal 0 then after the reception of a PDO the monitoring is started automatically. if no further PDO in the given time was received, the indication function given to this function is called.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.40.3.3 EXTERN_DECL RET_T coEventRegister_PDO_SYNC (CO_EVENT_PDO_T pFunction)

coEventRegister_PDO_SYNC - register PDO SYNC event

Register an indication function for received synchronous PDOs.

After the SYNC was received, the received data are stored in the object dictionary, and then this given indication function is called.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.40.3.4 EXTERN_DECL BOOL_T coPdoObjsMapped (UNSIGNED16 pdoNr, UNSIGNED16 index, UNSIGNED8 subIndex)

coPdoObjsMapped - check, if object mapped to given PDO

This function checks the PDO, if the given object is actual mapped to this PDO. (Only valid for receive PDOs)

Returns

BOOL_T

Return values

<i>CO_TRUE</i>	object is mapped
<i>CO_FALSE</i>	object is not mapped

Parameters

<i>pdoNr</i>	PDO number
<i>index</i>	index of mapped object

Parameters

<i>subIndex</i>	subindex of mapped object
-----------------	---------------------------

5.40.3.5 EXTERN_DECL RET_T coPdoReceiveInit (UNSIGNED16 *pdoNr*, UNSIGNED8 *transType*, UNSIGNED16 *inhibit*, UNSIGNED16 *eventTime*, CO_CONST PDO_REC_MAP_TABLE_T * *mapTable*)

coPdoReceiveInit - init receive pdo functionality

This function initializes a receive PDO. The COB-ID is set at reset communication or at load parameter.

Note: All parameter are reset by their default values at reset communication.

Returns

RET_T

Parameters

<i>pdoNr</i>	PDO number
<i>transType</i>	transmission type
<i>inhibit</i>	inhibit time 100 usec
<i>eventTime</i>	event timer in msec
<i>mapTable</i>	pointer to mapping table

5.40.3.6 EXTERN_DECL RET_T coPdoReqNr (UNSIGNED16 *pdoNr*, UNSIGNED8 *flags*)

coPdoReqNr - request PDO transmission by PDO number

This function requests the transmission of an PDO given by its number.

All mapped objects are automatically copied into the CAN message. If the inhibit time is not active, then the message is transmitted immediately.

If the inhibit time is not ellapsed yet, the transmission depends on the parameter flags:

0 - PDO will be transmitted after inhibit is ellapsed (if data are not changed, PDO will not be transmitted more than once!) MSG_OVERWRITE - if the last PDO is not transmitted yet, overwrite the last data with the new data MSG_RET_INHIBIT - return the function with RET_INHIBIT_ACTIVE, if the inhibit is not ellapsed yet

with the same or

Returns

RET_T

Return values

<i>RET_INVALID_NMT_STATE</i>	invalid NMT state
<i>RET_INVALID_PARAMETER</i>	unknown PDO number
<i>RET_COB_DISABLED</i>	PDO is disabled
<i>RET_INHIBIT_ACTIVE</i>	inhibit time is not yet ellapsed
<i>RET_OK</i>	all function are ok, but have not to be transmitted yet

Parameters

<i>pdoNr</i>	PDO number
<i>flags</i>	transmit flags

5.40.3.7 EXTERN_DECL RET_T coPdoReqObj (UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 *flags*)

coPdoReqObj - request PDO transmission by object

This function requests the transmission of the PDO, which the given object is mapped into. All mapped objects are automatically copied into the CAN message. If the inhibit time is not active, then the message is transmitted immediately.

If the inhibit time is not elapsed yet, the transmission depends on the parameter flags:

0 - PDO will be transmitted after inhibit is elapsed MSG_OVERWRITE - if the last PDO is not transmitted yet, overwrite the last data with the new data MSG_RET_INHIBIT - return the function with RET_INHIBIT_ACTIVE, if the inhibit is not elapsed yet

Returns

RET_T

Return values

<i>RET_INVALID_NMT_STATE</i>	invalid NMT state
<i>RET_INVALID_PARAMETER</i>	unknown PDO number
<i>RET_COB_DISABLED</i>	PDO is disabled
<i>RET_INHIBIT_ACTIVE</i>	inhibit time is not yet elapsed
<i>RET_OK</i>	all function are ok, but have not to be transmitted yet

Parameters

<i>index</i>	index of mapped object
<i>subIndex</i>	subindex of mapped object
<i>flags</i>	transmit flags

5.40.3.8 EXTERN_DECL RET_T coPdoTransmitInit (UNSIGNED16 *pdoNr*, UNSIGNED8 *transType*, UNSIGNED16 *inhibit*, UNSIGNED16 *eventTime*, UNSIGNED8 *syncStartVal*, CO_CONST PDO_TR_MAP_TABLE_T * *mapTable*)

coPdoTransmitInit - init transmit pdo functionality

This function initializes a transmit PDO. The COB-ID is set at reset communication or at load parameter.

Note: All parameters are reset to their default values at reset communication.

Returns

RET_T

Parameters

<i>pdoNr</i>	PDO number
<i>transType</i>	transmission type
<i>inhibit</i>	inhibit time 100 usec
<i>eventTime</i>	event timer in msec
<i>syncStartVal</i>	sync start value
<i>mapTable</i>	pointer to mapping table

5.41 co_queue.c File Reference

Queue handling.

Functions

- [BOOL_T coQueueReceiveMessageAvailable](#) (void)
coQueueReceiveMessageAvailable - receive messages available
- [CO_CAN_MSG_T * coQueueGetNextTransmitMessage](#) (void)
coQueueGetNextTransmitMessage - get next message to transmit
- void [coQueueMsgTransmitted](#) (const [CO_CAN_MSG_T](#) *pBuf)
coQueueMsgTransmitted - message was transmitted
- void [coQueueInit](#) (void)
coQueueInit - (re)init queues

5.41.1 Detailed Description

Queue handling.

contains functions for queue handling

5.41.2 Function Documentation

5.41.2.1 CO_CAN_MSG_T* coQueueGetNextTransmitMessage (void)

coQueueGetNextTransmitMessage - get next message to transmit

This function returns the next available transmit message from the transmit queue. It increments also trBufferRdCnt.

Returns

CO_CAN_MSG_T* pointer to next tx message

Return values

<i>NULL</i>	pointer to transmit queue entry
<i>NULL</i>	no message available

5.41.2.2 void coQueueInit (void)

coQueueInit - (re)init queues

This function clears the transmit and the receive queue

Returns

none

5.41.2.3 void coQueueMsgTransmitted (const CO_CAN_MSG_T * pBuf)

coQueueMsgTransmitted - message was transmitted

This function is called after a message was succesfull transmitted.

Returns

none

Parameters

<i>pBuf</i>	pointer to transmitted message
-------------	--------------------------------

5.41.2.4 BOOL_T coQueueReceiveMessageAvailable (void)

coQueueReceiveMessageAvailable - receive messages available

This functions checks the receive queue for new messages. Are new messages available, return CO_TRUE. Otherwise CO_FALSE

Return values

CO_FALSE	no data available
CO_TRUE	data available

5.42 co_sdo.h File Reference

defines for sdo service

Typedefs

- typedef RET_T(* CO_EVENT_SDO_SERVER_T) (BOOL_T, UNSIGNED8, UNSIGNED16, UNSIGNED8)
function pointer to SDO server event

- typedef [RET_T](#)(* [CO_EVENT_SDO_SERVER_CHECK_WRITE_T](#)) ([BOOL_T](#), [UNSIGNED8](#), [UNSIGNED16](#), [UNSIGNED8](#), const [UNSIGNED8](#) *)
function pointer to SDO server write check event
- typedef void(* [CO_EVENT_SDO_SERVER_DOMAIN_WRITE_T](#)) ([UNSIGNED16](#), [UNSIGNED8](#), [UNSIGNED32](#), [UNSIGNED32](#))
function pointer to SDO server write domain event
- typedef void(* [CO_EVENT_SDO_CLIENT_READ_T](#)) ([UNSIGNED8](#), [UNSIGNED16](#), [UNSIGNED8](#), [UNSIGNED32](#), [UNSIGNED32](#))
function pointer to SDO client read event
- typedef void(* [CO_EVENT_SDO_CLIENT_WRITE_T](#)) ([UNSIGNED8](#), [UNSIGNED16](#), [UNSIGNED8](#), [UNSIGNED32](#))
function pointer to SDO client write event
- typedef [RET_T](#)(* [CO_EVENT_SDO_CLIENT_DOMAIN_WRITE_T](#)) ([UNSIGNED8](#), [UNSIGNED16](#), [UNSIGNED8](#), [UNSIGNED32](#), void *)
function pointer to SDO client domain write event

Functions

- EXTERN_DECL [RET_T](#) [coSdoServerInit](#) ([UNSIGNED8](#))
coInitSdoServer - init sdo server functionality
- EXTERN_DECL [RET_T](#) [coEventRegister_SDO_SERVER_READ](#) ([CO_EVENT_SDO_SERVER_T](#) pFunction)
coEventRegister_SdoServer - register SDO server event
- EXTERN_DECL [RET_T](#) [coEventRegister_SDO_SERVER_WRITE](#) ([CO_EVENT_SDO_SERVER_T](#) pFunction)
coEventRegister_SdoServerWrite - register SDO server write event
- EXTERN_DECL [RET_T](#) [coEventRegister_SDO_SERVER_CHECK_WRITE](#) ([CO_EVENT_SDO_SERVER_CHECK_WRITE_T](#) pFunction)
coEventRegister_SdoServerCheckWrite - register SDO server write event
- EXTERN_DECL [RET_T](#) [coSdoClientInit](#) ([UNSIGNED8](#))
coInitSdoClient - init SDO client functionality
- EXTERN_DECL [RET_T](#) [coSdoRead](#) ([UNSIGNED8](#) sdoNr, [UNSIGNED16](#) index, [UNSIGNED8](#) subIndex, [UNSIGNED8](#) *pData, [UNSIGNED32](#) dataLen, [UNSIGNED16](#) numeric, [UNSIGNED32](#) timeout)
coSdoRead - read value by SDO
- EXTERN_DECL [RET_T](#) [coSdoWrite](#) ([UNSIGNED8](#) sdoNr, [UNSIGNED16](#) index, [UNSIGNED8](#) subIndex, [UNSIGNED8](#) *pData, [UNSIGNED32](#) dataLen, [UNSIGNED16](#) numeric, [UNSIGNED32](#) timeout)
coSdoWrite - Write value by SDO
- EXTERN_DECL [RET_T](#) [coSdoQueueAddTransfer](#) ([BOOL_T](#) write, [UNSIGNED8](#) sdoNr, [UNSIGNED16](#) index, [UNSIGNED8](#) subIndex, [UNSIGNED8](#) *pData, [UNSIGNED32](#) dataLen, [CO_SDO_QUEUE_IND_T](#) pFct, void *pFctPara)
coSdoQueueAddTransfer - add sdo transfer to sdo queue handler
- EXTERN_DECL [RET_T](#) [coSdoReadSeg](#) ([UNSIGNED8](#) sdoNr, [UNSIGNED16](#) index, [UNSIGNED8](#) subIndex, [UNSIGNED8](#) *pData, [UNSIGNED32](#) dataLen, [UNSIGNED16](#) numeric, [UNSIGNED32](#) timeout)
coSdoReadSeg - read value by segmented SDO
- EXTERN_DECL [RET_T](#) [coSdoWriteSeg](#) ([UNSIGNED8](#) sdoNr, [UNSIGNED16](#) index, [UNSIGNED8](#) subIndex, [UNSIGNED8](#) *pData, [UNSIGNED32](#) dataLen, [UNSIGNED16](#) numeric, [UNSIGNED32](#) timeout)
coSdoWriteSeg - Write value by segmented SDO
- EXTERN_DECL [RET_T](#) [coEventRegister_SDO_CLIENT_READ](#) ([CO_EVENT_SDO_CLIENT_READ_T](#) pFunction)
coEventRegister_SdoClientRead - register SDO client read event
- EXTERN_DECL [RET_T](#) [coEventRegister_SDO_CLIENT_WRITE](#) ([CO_EVENT_SDO_CLIENT_WRITE_T](#) pFunction)

- coEventRegister_SdoClientWrite* - register SDO client write event
- EXTERN_DECL [RET_T](#) [coEventUnregister_SDO_CLIENT_READ](#) ([CO_EVENT_SDO_CLIENT_READ_T](#) pFunction)
- coEventUnregister_SDO_CLIENT_READ* - unregister SDO client read event
- EXTERN_DECL [RET_T](#) [coEventUnregister_SDO_CLIENT_WRITE](#) ([CO_EVENT_SDO_CLIENT_WRITE_T](#) pFunction)
- coEventUnregister_SDO_CLIENT_WRITE* - unregister SDO client write event
- EXTERN_DECL [RET_T](#) [coSdoNetworkRead](#) (UNSIGNED8 sdoNr, UNSIGNED16 network, UNSIGNED8 node, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)
- coSdoNetworkRead* - read network value by SDO
- EXTERN_DECL [RET_T](#) [coSdoNetworkWrite](#) (UNSIGNED8 sdoNr, UNSIGNED16 network, UNSIGNED8 node, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)
- coSdoNetworkWrite* - Write value by SDO

5.42.1 Detailed Description

defines for sdo service

- contains defines for sdo service

5.42.2 Typedef Documentation

5.42.2.1 typedef [RET_T](#)(* [CO_EVENT_SDO_CLIENT_DOMAIN_WRITE_T](#)) (UNSIGNED8, UNSIGNED16, UNSIGNED8, UNSIGNED32, void *)

function pointer to SDO client domain write event

Parameters

<i>sdoNr</i>	- sdo number
<i>index</i>	- object index
<i>subindex</i>	- object subindex
<i>transferred</i>	- bytes transferred
<i>pointer</i>	- pointer to application data

Returns

[RET_T](#)

5.42.2.2 typedef void(* [CO_EVENT_SDO_CLIENT_READ_T](#)) (UNSIGNED8, UNSIGNED16, UNSIGNED8, UNSIGNED32, UNSIGNED32)

function pointer to SDO client read event

Parameters

<i>sdoNr</i>	- sdo number
<i>index</i>	- object index
<i>subindex</i>	- object subindex
<i>size</i>	- size of received data
<i>result</i>	- result of transfer

Returns

void

5.42.2.3 `typedef void(* CO_EVENT_SDO_CLIENT_WRITE_T)(UNSIGNED8, UNSIGNED16, UNSIGNED8, UNSIGNED32)`

function pointer to SDO client write event

Parameters

<i>sdoNr</i>	- sdo number
<i>index</i>	- object index
<i>subindex</i>	- object subindex
<i>result</i>	- result of transfer

Returns

void

5.42.2.4 `typedef RET_T(* CO_EVENT_SDO_SERVER_CHECK_WRITE_T)(BOOL_T, UNSIGNED8, UNSIGNED16, UNSIGNED8, const UNSIGNED8 *)`

function pointer to SDO server write check event

Parameters

<i>execute</i>	- execute or test only
<i>sdoNr</i>	- sdo number
<i>index</i>	- object index
<i>subindex</i>	- object subindex
<i>pData</i>	- pointer to receive buffer

Returns

RET_T

5.42.2.5 `typedef void(* CO_EVENT_SDO_SERVER_DOMAIN_WRITE_T) (UNSIGNED16, UNSIGNED8, UNSIGNED32, UNSIGNED32)`

function pointer to SDO server write domain event

Parameters

<i>index</i>	- object index
<i>subindex</i>	- object subindex
<i>domainBufSize</i>	- actual size at domain buffer
<i>transferSize</i>	- actual transfered size

Returns

RET_T

5.42.2.6 `typedef RET_T(* CO_EVENT_SDO_SERVER_T) (BOOL_T, UNSIGNED8, UNSIGNED16, UNSIGNED8)`

function pointer to SDO server event

Parameters

<i>execute</i>	- execute or test only
<i>sdoNr</i>	- sdo number
<i>index</i>	- object index
<i>subindex</i>	- object subindex

Returns

RET_T

5.42.3 Function Documentation

5.42.3.1 `EXTERN_DECL RET_T coEventRegister_SDO_CLIENT_READ (CO_EVENT_SDO_CLIENT_READ_T pFunction)`

coEventRegister_SdoClientRead - register SDO client read event

This function registers the sdo read indication function. It is called after a SDO read, started by [coSdoRead\(\)](#) was finished.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.42.3.2 EXTERN_DECL RET_T coEventRegister_SDO_CLIENT_WRITE (CO_EVENT_SDO_CLIENT_WRITE_T *pFunction*)

coEventRegister_SdoClientWrite - register SDO client write event

This function registers the sdo write indication function. It is called after a SDO write, started by [coSdoWrite\(\)](#) was finished.

Returns

RET_T

5.42.3.3 EXTERN_DECL RET_T coEventRegister_SDO_SERVER_CHECK_WRITE (CO_EVENT_SDO_SERVER_CHECK_WRITE_T *pFunction*)

coEventRegister_SdoServerCheckWrite - register SDO server write event

This function register a sdo server indication function, which is called before SDO write access is executed, so the application can reject an SDO write access.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.42.3.4 EXTERN_DECL RET_T coEventRegister_SDO_SERVER_READ (CO_EVENT_SDO_SERVER_T *pFunction*)

coEventRegister_SdoServer - register SDO server event

This function registers a sdo server indication function, which is called before a SDO read request is executed, so the application can update the data before the response is sent.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.42.3.5 EXTERN_DECL RET_T coEventRegister_SDO_SERVER_WRITE (CO_EVENT_SDO_SERVER_T *pFunction*)

coEventRegister_SdoServerWrite - register SDO server write event

This function registers a SDO server write indication function. It is called, after a SDO write access was finished.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.42.3.6 EXTERN_DECL RET_T coEventUnregister_SDO_CLIENT_READ (CO_EVENT_SDO_CLIENT_READ_T
pFunction)

coEventUnregister_SDO_CLIENT_READ - unregister SDO client read event

This function unregisters the sdo read indication function.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.42.3.7 EXTERN_DECL RET_T coEventUnregister_SDO_CLIENT_WRITE (CO_EVENT_SDO_CLIENT_WRITE_T
pFunction)

coEventUnregister_SDO_CLIENT_WRITE - unregister SDO client write event

This function unregisters the sdo write indication function.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.42.3.8 EXTERN_DECL RET_T coSdoClientInit (UNSIGNED8 *clientNr*)

coInitSdoClient - init SDO client functionality

This function initializes the SDO client with the given number.

Returns

RET_T

Parameters

<i>clientNr</i>	sdo client number
-----------------	-------------------

5.42.3.9 EXTERN_DECL RET_T coSdoNetworkRead (UNSIGNED8 *sdoNr*, UNSIGNED16 *network*, UNSIGNED8 *node*, UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 * *pData*, UNSIGNED32 *dataLen*, UNSIGNED16 *numeric*, UNSIGNED32 *timeout*)

coSdoNetworkRead - read network value by SDO

This function starts a sdo read transfer over a network to the given network/node and SDO parameters.

As first, the network connection to the router is established and than the normal SDO transfer ist started.

The result is given by the standard SDO client indication functions.

The data are stored at the given pointer *pData* with a maximal length of *dataLen*.

The timeout value given in msec is started with each message transmission.

The numeric flag is only valid for big-endian transfers. If this parameter is set, the data are changed to little endian format.

Before an SDO can be started, it has to be initialized. Initialization is done by setup the COB-Ids of this SDO at index 0x128x:1 and 0x128x:2

Returns

RET_T

Parameters

<i>sdoNr</i>	sdo number
<i>network</i>	network number
<i>node</i>	node number
<i>index</i>	index at server OD
<i>subIndex</i>	index at server OD
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	data len for transfer
<i>numeric</i>	numeric flag (only for big endian)
<i>timeout</i>	timeout in msec

5.42.3.10 EXTERN_DECL RET_T coSdoNetworkWrite (UNSIGNED8 *sdoNr*, UNSIGNED16 *network*, UNSIGNED8 *node*, UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 * *pData*, UNSIGNED32 *dataLen*, UNSIGNED16 *numeric*, UNSIGNED32 *timeout*)

coSdoNetworkWrite - Write value by SDO

This function starts a sdo read transfer over a network to the given network/node and SDO parameters.

As first, the network connection to the router is established and than the normal SDO transfer ist started.

The result is given by the standard SDO client indication functions.

The data are written from the given pointer *pData* and with a length of *dataLen*.

The timeout value given in msec is started with each message transmission.

The numeric flag is only valid for big-endian transfers. If this parameter is set, the data are changed to little endian format.

Before an SDO can be started, it has to be initialized. This is done by setup the COB-Ids of this SDO at index 0x128x:1 and 0x128x:2

If SDO block transfer is enabled, it will be used automatically if *dataLen* is larger than `CO_SDO_BLOCK_MIN_SIZE`. If the server doesn't support block transfer, segmented transfer will be used instead.

Returns

RET_T

Parameters

<i>sdoNr</i>	sdo number
<i>network</i>	network number
<i>node</i>	node number
<i>index</i>	index at server OD
<i>subIndex</i>	index at server OD
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	data len for transfer
<i>numeric</i>	numeric flag (only for big endian)
<i>timeout</i>	timeout in msec

5.42.3.11 EXTERN_DECL RET_T coSdoQueueAddTransfer (BOOL_T write, UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 * pData, UNSIGNED32 dataLen, CO_SDO_QUEUE_IND_T pFct, void * pFctPara)

coSdoQueueAddTransfer - add sdo transfer to sdo queue handler

This function can be used to add sdo transfers to a queue. If a transfer was finished, the next will start automatically. After each transfer, the given function with the parameter are called.

Please note: Only allowed for expedited transfers with initialized sdo channel. Transmit data are saved internally.

Returns

RET_T

Parameters

<i>write</i>	write/read access
<i>sdoNr</i>	sdo number
<i>index</i>	index
<i>subIndex</i>	subIndex
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	len of transfer data
<i>pFct</i>	pointer to finish function
<i>pFctPara</i>	pointer to data field for finish function

5.42.3.12 EXTERN_DECL RET_T coSdoRead (UNSIGNED8 *sdoNr*, UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 * *pData*, UNSIGNED32 *dataLen*, UNSIGNED16 *numeric*, UNSIGNED32 *timeout*)

coSdoRead - read value by SDO

This function starts a sdo transfer with the given parameters. The data are stored at the given pointer *pData* with a maximal length of *dataLen*.

The timeout value given in msec is started with each message transmission.

The numeric flag is only valid for big-endian transfers. If this parameter is set, the data are changed to little endian format.

Before an SDO can be started, it has to be initialized. Initialization is done by setup the COB-Ids of this SDO at index 0x128x:1 and 0x128x:2

If SDO block transfer is enabled, it will be used automatically if *dataLen* is larger than CO_SDO_BLOCK_MIN_SIZE. If the server doesn't support block transfer, segmented transfer will be used instead.

Returns

RET_T

Parameters

<i>sdoNr</i>	sdo number
<i>index</i>	index at server OD
<i>subIndex</i>	index at server OD
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	data len for transfer
<i>numeric</i>	numeric flag (only for big endian)
<i>timeout</i>	timeout in msec

5.42.3.13 EXTERN_DECL RET_T coSdoReadSeg (UNSIGNED8 *sdoNr*, UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 * *pData*, UNSIGNED32 *dataLen*, UNSIGNED16 *numeric*, UNSIGNED32 *timeout*)

coSdoReadSeg - read value by segmented SDO

This function starts a sdo transfer with the given parameters. The data are stored at the given pointer *pData* with a maximal length of *dataLen*.

The timeout value given in msec is started with each message transmission.

The numeric flag is only valid for big-endian transfers. If this parameter is set, the data are changed to little endian format.

Before an SDO can be started, it has to be initialized. Initialization is done by setup the COB-Ids of this SDO at index 0x128x:1 and 0x128x:2

The segmented transfer will be used.

Returns

RET_T

Parameters

<i>sdoNr</i>	sdo number
<i>index</i>	index at server OD
<i>subIndex</i>	index at server OD
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	data len for transfer
<i>numeric</i>	numeric flag (only for big endian)
<i>timeout</i>	timeout in msec

5.42.3.14 EXTERN_DECL RET_T coSdoServerInit (UNSIGNED8 *sdoServerNr*)

colnitSdoServer - init sdo server functionality

This function initializes the given sdo server. If the sdo number = 1, then the default COB-IDs are set for this SDO.

Returns

RET_T

Parameters

<i>sdoServerNr</i>	sdo server number
--------------------	-------------------

5.42.3.15 EXTERN_DECL RET_T coSdoWrite (UNSIGNED8 *sdoNr*, UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 * *pData*, UNSIGNED32 *dataLen*, UNSIGNED16 *numeric*, UNSIGNED32 *timeout*)

coSdoWrite - Write value by SDO

This function starts a sdo write transfer with the given parameter. The data are read from the given pointer *pData* and with a length of *dataLen*.

The timeout value given in msec is started with each message transmission.

The numeric flag is only valid for big-endian transfers. If this parameter is set, the data are changed to little endian format.

Before an SDO can be started, it has to be initialized. This is done by setup the COB-Ids of this SDO at index 0x128x:1 and 0x128x:2

If SDO block transfer is enabled, it will be used automatically if *dataLen* is larger than CO_SDO_BLOCK_MIN_SIZE. If the server doesn't support block transfer, segmented transfer will be used instead.

Returns

RET_T

Parameters

<i>sdoNr</i>	sdo number
<i>index</i>	index at server OD
<i>subIndex</i>	index at server OD
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	data len for transfer
<i>numeric</i>	numeric flag (only for big endian)
<i>timeout</i>	timeout in msec

5.42.3.16 EXTERN_DECL RET_T coSdoWriteSeg (UNSIGNED8 *sdoNr*, UNSIGNED16 *index*, UNSIGNED8 *subIndex*,
UNSIGNED8 * *pData*, UNSIGNED32 *dataLen*, UNSIGNED16 *numeric*, UNSIGNED32 *timeout*)

coSdoWriteSeg - Write value by segmented SDO

This function starts a sdo write transfer with the given parameter. The data are read from the given pointer pData and with a length of dataLen.

The timeout value given in msec is started with each message transmission.

The numeric flag is only valid for big-endian transfers. If this parameter is set, the data are changed to little endian format.

Before an SDO can be started, it has to be initialized. This is done by setup the COB-Ids of this SDO at index 0x128x:1 and 0x128x:2

The segmented transfer will be used.

Returns

RET_T

Parameters

<i>sdoNr</i>	sdo number
<i>index</i>	index at server OD
<i>subIndex</i>	index at server OD
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	data len for transfer
<i>numeric</i>	numeric flag (only for big endian)
<i>timeout</i>	timeout in msec

5.43 co_sdoblockclient.c File Reference

sdo block routines

5.43.1 Detailed Description

sdo block routines

contains sdo block transfer routines for client

5.44 co_sdoblockserver.c File Reference

sdo block routines

5.44.1 Detailed Description

sdo block routines

contains sdo block transfer routines for server

5.45 co_sdoclient.c File Reference

sdo client routines

Functions

- [RET_T coSdoRead](#) (UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)
coSdoRead - read value by SDO
- [RET_T coSdoReadSeg](#) (UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)
coSdoReadSeg - read value by segmented SDO
- [RET_T coSdoWrite](#) (UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)
coSdoWrite - Write value by SDO
- [RET_T coSdoWriteSeg](#) (UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 *pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)
coSdoWriteSeg - Write value by segmented SDO
- [RET_T coEventRegister_SDO_CLIENT_READ](#) (CO_EVENT_SDO_CLIENT_READ_T pFunction)
coEventRegister_SdoClientRead - register SDO client read event
- [RET_T coEventUnregister_SDO_CLIENT_READ](#) (CO_EVENT_SDO_CLIENT_READ_T pFunction)
coEventUnregister_SDO_CLIENT_READ - unregister SDO client read event
- [RET_T coEventRegister_SDO_CLIENT_WRITE](#) (CO_EVENT_SDO_CLIENT_WRITE_T pFunction)
coEventRegister_SdoClientWrite - register SDO client write event
- [RET_T coEventUnregister_SDO_CLIENT_WRITE](#) (CO_EVENT_SDO_CLIENT_WRITE_T pFunction)
coEventUnregister_SDO_CLIENT_WRITE - unregister SDO client write event
- [RET_T coSdoClientInit](#) (UNSIGNED8 clientNr)
coInitSdoClient - init SDO client functionality

5.45.1 Detailed Description

sdo client routines

contains sdo client routines

5.45.2 Function Documentation

5.45.2.1 RET_T coEventRegister_SDO_CLIENT_READ (CO_EVENT_SDO_CLIENT_READ_T pFunction)

coEventRegister_SdoClientRead - register SDO client read event

This function registers the sdo read indication function. It is called after a SDO read, started by [coSdoRead\(\)](#) was finished.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.45.2.2 RET_T coEventRegister_SDO_CLIENT_WRITE (CO_EVENT_SDO_CLIENT_WRITE_T *pFunction*)

coEventRegister_SdoClientWrite - register SDO client write event

This function registers the sdo write indication function. It is called after a SDO write, started by [coSdoWrite\(\)](#) was finished.

Returns

RET_T

5.45.2.3 RET_T coEventUnregister_SDO_CLIENT_READ (CO_EVENT_SDO_CLIENT_READ_T *pFunction*)

coEventUnregister_SDO_CLIENT_READ - unregister SDO client read event

This function unregisters the sdo read indication function.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.45.2.4 RET_T coEventUnregister_SDO_CLIENT_WRITE (CO_EVENT_SDO_CLIENT_WRITE_T *pFunction*)

coEventUnregister_SDO_CLIENT_WRITE - unregister SDO client write event

This function unregisters the sdo write indication function.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.45.2.5 RET_T coSdoClientInit (UNSIGNED8 *clientNr*)

coInitSdoClient - init SDO client functionality

This function initializes the SDO client with the given number.

Returns

RET_T

Parameters

<i>clientNr</i>	sdo client number
-----------------	-------------------

5.45.2.6 RET_T coSdoRead (UNSIGNED8 *sdoNr*, UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 * *pData*, UNSIGNED32 *dataLen*, UNSIGNED16 *numeric*, UNSIGNED32 *timeout*)

coSdoRead - read value by SDO

This function starts a sdo transfer with the given parameters. The data are stored at the given pointer pData with a maximal length of dataLen.

The timeout value given in msec is started with each message transmission.

The numeric flag is only valid for big-endian transfers. If this parameter is set, the data are changed to little endian format.

Before an SDO can be started, it has to be initialized. Initialization is done by setup the COB-Ids of this SDO at index 0x128x:1 and 0x128x:2

If SDO block transfer is enabled, it will be used automatically if dataLen is larger than CO_SDO_BLOCK_MIN_SIZE. If the server doesn't support block transfer, segmented transfer will be used instead.

Returns

RET_T

Parameters

<i>sdoNr</i>	sdo number
<i>index</i>	index at server OD
<i>subIndex</i>	index at server OD
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	data len for transfer
<i>numeric</i>	numeric flag (only for big endian)
<i>timeout</i>	timeout in msec

5.45.2.7 RET_T coSdoReadSeg (UNSIGNED8 *sdoNr*, UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 * *pData*, UNSIGNED32 *dataLen*, UNSIGNED16 *numeric*, UNSIGNED32 *timeout*)

coSdoReadSeg - read value by segmented SDO

This function starts a sdo transfer with the given parameters. The data are stored at the given pointer pData with a maximal length of dataLen.

The timeout value given in msec is started with each message transmission.

The numeric flag is only valid for big-endian transfers. If this parameter is set, the data are changed to little endian format.

Before an SDO can be started, it has to be initialized. Initialization is done by setup the COB-Ids of this SDO at index 0x128x:1 and 0x128x:2

The segmented transfer will be used.

Returns

RET_T

Parameters

<i>sdoNr</i>	sdo number
<i>index</i>	index at server OD
<i>subIndex</i>	index at server OD
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	data len for transfer
<i>numeric</i>	numeric flag (only for big endian)
<i>timeout</i>	timeout in msec

5.45.2.8 RET_T coSdoWrite (UNSIGNED8 sdoNr, UNSIGNED16 index, UNSIGNED8 subIndex, UNSIGNED8 * pData, UNSIGNED32 dataLen, UNSIGNED16 numeric, UNSIGNED32 timeout)

coSdoWrite - Write value by SDO

This function starts a sdo write transfer with the given parameter. The data are read from the given pointer pData and with a length of dataLen.

The timeout value given in msec is started with each message transmission.

The numeric flag is only valid for big-endian transfers. If this parameter is set, the data are changed to little endian format.

Before an SDO can be started, it has to be initialized. This is done by setup the COB-Ids of this SDO at index 0x128x:1 and 0x128x:2

If SDO block transfer is enabled, it will be used automatically if dataLen is larger than CO_SDO_BLOCK_MIN_SIZE. If the server doesn't support block transfer, segmented transfer will be used instead.

Returns

RET_T

Parameters

<i>sdoNr</i>	sdo number
<i>index</i>	index at server OD
<i>subIndex</i>	index at server OD
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	data len for transfer
<i>numeric</i>	numeric flag (only for big endian)
<i>timeout</i>	timeout in msec

5.45.2.9 **RET_T coSdoWriteSeg** (UNSIGNED8 *sdoNr*, UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 * *pData*, UNSIGNED32 *dataLen*, UNSIGNED16 *numeric*, UNSIGNED32 *timeout*)

coSdoWriteSeg - Write value by segmented SDO

This function starts a sdo write transfer with the given parameter. The data are read from the given pointer pData and with a length of dataLen.

The timeout value given in msec is started with each message transmission.

The numeric flag is only valid for big-endian transfers. If this parameter is set, the data are changed to little endian format.

Before an SDO can be started, it has to be initialized. This is done by setup the COB-Ids of this SDO at index 0x128x:1 and 0x128x:2

The segmented transfer will be used.

Returns

RET_T

Parameters

<i>sdoNr</i>	sdo number
<i>index</i>	index at server OD
<i>subIndex</i>	index at server OD
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	data len for transfer
<i>numeric</i>	numeric flag (only for big endian)
<i>timeout</i>	timeout in msec

5.46 co_sdonetwork.c File Reference

sdo network routines

Functions

- **RET_T coSdoNetworkRead** (UNSIGNED8 *sdoNr*, UNSIGNED16 *network*, UNSIGNED8 *node*, UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 **pData*, UNSIGNED32 *dataLen*, UNSIGNED16 *numeric*, UNSIGNED32 *timeout*)
coSdoNetworkRead - read network value by SDO
- **RET_T coSdoNetworkWrite** (UNSIGNED8 *sdoNr*, UNSIGNED16 *network*, UNSIGNED8 *node*, UNSIGNED16 *index*, UNSIGNED8 *subIndex*, UNSIGNED8 **pData*, UNSIGNED32 *dataLen*, UNSIGNED16 *numeric*, UNSIGNED32 *timeout*)
coSdoNetworkWrite - Write value by SDO

5.46.1 Detailed Description

sdo network routines

contains sdo network transfer routines for server

5.46.2 Function Documentation

5.46.2.1 **RET_T** coSdoNetworkRead (*UNSIGNED8 sdoNr*, *UNSIGNED16 network*, *UNSIGNED8 node*, *UNSIGNED16 index*, *UNSIGNED8 subIndex*, *UNSIGNED8 * pData*, *UNSIGNED32 dataLen*, *UNSIGNED16 numeric*, *UNSIGNED32 timeout*)

coSdoNetworkRead - read network value by SDO

This function starts a sdo read transfer over a network to the given network/node and SDO parameters.

As first, the network connection to the router is established and than the normal SDO transfer ist started.

The result is given by the standard SDO client indication functions.

The data are stored at the given pointer pData with a maximal length of dataLen.

The timeout value given in msec is started with each message transmission.

The numeric flag is only valid for big-endian transfers. If this parameter is set, the data are changed to little endian format.

Before an SDO can be started, it has to be initialized. Initialization is done by setup the COB-Ids of this SDO at index 0x128x:1 and 0x128x:2

Returns

RET_T

Parameters

<i>sdoNr</i>	sdo number
<i>network</i>	network number
<i>node</i>	node number
<i>index</i>	index at server OD
<i>subIndex</i>	index at server OD
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	data len for transfer
<i>numeric</i>	numeric flag (only for big endian)
<i>timeout</i>	timeout in msec

5.46.2.2 **RET_T** coSdoNetworkWrite (*UNSIGNED8 sdoNr*, *UNSIGNED16 network*, *UNSIGNED8 node*, *UNSIGNED16 index*, *UNSIGNED8 subIndex*, *UNSIGNED8 * pData*, *UNSIGNED32 dataLen*, *UNSIGNED16 numeric*, *UNSIGNED32 timeout*)

coSdoNetworkWrite - Write value by SDO

This function starts a sdo read transfer over a network to the given network/node and SDO parameters.

As first, the network connection to the router is established and than the normal SDO transfer ist started.

The result is given by the standard SDO client indication functions.

The data are written from the given pointer pData and with a length of dataLen.

The timeout value given in msec is started with each message transmission.

The numeric flag is only valid for big-endian transfers. If this parameter is set, the data are changed to little endian format.

Before an SDO can be started, it has to be initialized. This is done by setup the COB-Ids of this SDO at index 0x128x:1 and 0x128x:2

If SDO block transfer is enabled, it will be used automatically if dataLen is larger than CO_SDO_BLOCK_MIN_SIZE. If the server doesn't support block transfer, segmented transfer will be used instead.

Returns

RET_T

Parameters

<i>sdoNr</i>	sdo number
<i>network</i>	network number
<i>node</i>	node number
<i>index</i>	index at server OD
<i>subIndex</i>	index at server OD
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	data len for transfer
<i>numeric</i>	numeric flag (only for big endian)
<i>timeout</i>	timeout in msec

5.47 co_sdoqueue.c File Reference

SDO handling with queuing.

Functions

- [RET_T coSdoQueueAddTransfer](#) ([BOOL_T](#) write, [UNSIGNED8](#) sdoNr, [UNSIGNED16](#) index, [UNSIGNED8](#) subIndex, [UNSIGNED8](#) *pData, [UNSIGNED32](#) dataLen, [CO_SDO_QUEUE_IND_T](#) pFct, void *pFctPara)
coSdoQueueAddTransfer - add sdo transfer to sdo queue handler

5.47.1 Detailed Description

SDO handling with queuing.

5.47.2 Function Documentation

5.47.2.1 RET_T coSdoQueueAddTransfer ([BOOL_T](#) write, [UNSIGNED8](#) sdoNr, [UNSIGNED16](#) index, [UNSIGNED8](#) subIndex, [UNSIGNED8](#) * pData, [UNSIGNED32](#) dataLen, [CO_SDO_QUEUE_IND_T](#) pFct, void * pFctPara)

coSdoQueueAddTransfer - add sdo transfer to sdo queue handler

This function can be used to add sdo transfers to a queue. If a transfer was finished, the next will start automatically. After each transfer, the given function with the parameter are called.

Please note: Only allowed for expedited transfers with initialized sdo channel. Transmit data are saved internally.

Returns

RET_T

Parameters

<i>write</i>	write/read access
<i>sdoNr</i>	sdo number
<i>index</i>	index
<i>subIndex</i>	subIndex
<i>pData</i>	pointer to transfer data
<i>dataLen</i>	len of transfer data
<i>pFct</i>	pointer to finish function
<i>pFctPara</i>	pointer to data field for finish function

5.48 co_sdoserv.c File Reference

SDO server routines.

Functions

- [RET_T coEventRegister_SDO_SERVER_READ \(CO_EVENT_SDO_SERVER_T pFunction\)](#)
coEventRegister_SdoServer - register SDO server event
- [RET_T coEventRegister_SDO_SERVER_CHECK_WRITE \(CO_EVENT_SDO_SERVER_CHECK_WRITE_T pFunction\)](#)
coEventRegister_SdoServerCheckWrite - register SDO server write event
- [RET_T coEventRegister_SDO_SERVER_WRITE \(CO_EVENT_SDO_SERVER_T pFunction\)](#)
coEventRegister_SdoServerWrite - register SDO server write event
- [RET_T coSdoServerInit \(UNSIGNED8 sdoServerNr\)](#)
coInitSdoServer - init sdo server functionality

5.48.1 Detailed Description

SDO server routines.

contains sdo server routines

5.48.2 Function Documentation

5.48.2.1 RET_T coEventRegister_SDO_SERVER_CHECK_WRITE (CO_EVENT_SDO_SERVER_CHECK_WRITE_T pFunction)

coEventRegister_SdoServerCheckWrite - register SDO server write event

This function register a sdo server indication function, which is called before SDO write access is executed, so the application can reject an SDO write access.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.48.2.2 **RET_T** coEventRegister_SDO_SERVER_READ (**CO_EVENT_SDO_SERVER_T** *pFunction*)

coEventRegister_SdoServer - register SDO server event

This function registers a sdo server indication function, which is called before a SDO read request is executed, so the application can update the data before the response is sent.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.48.2.3 **RET_T** coEventRegister_SDO_SERVER_WRITE (**CO_EVENT_SDO_SERVER_T** *pFunction*)

coEventRegister_SdoServerWrite - register SDO server write event

This function registers a SDO server write indication function. It is called, after a SDO write access was finished.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.48.2.4 **RET_T** coSdoServerInit (**UNSIGNED8** *sdoServerNr*)

colnitSdoServer - init sdo server functionality

This function initializes the given sdo server. If the sdo number = 1, then the default COB-IDs are set for this SDO.

Returns

RET_T

Parameters

<i>sdoServerNr</i>	sdo server number
--------------------	-------------------

5.49 co_sleep.c File Reference

Sleep and Wakeup Handling.

Functions

- void [coSleepModeStart](#) (UNSIGNED16 waitTime)
coSleepModeStart - start sleep mode
- void [coSleepAwake](#) (BOOL_T master, UNSIGNED8 status, UNSIGNED8 reason, UNSIGNED16 repeatTime)
coSleepAwake - awake from sleep
- void [coSleepWakeUp](#) (BOOL_T master, UNSIGNED8 status, UNSIGNED8 reason, UNSIGNED16 repeatTime)
coSleepWakeUp - awake from sleep
- [BOOL_T coSleepModeActive](#) (void)
coSleepModeActive - check if sleep mode is active
- void [coSleepRequestSleep](#) (void)
coSleepRequestSleep - request sleep mode to master
- [RET_T coEventRegister_SLEEP](#) (CO_EVENT_SLEEP_T pFunction)
coEventRegister_SLEEP - register SLEEP event

5.49.1 Detailed Description

Sleep and Wakeup Handling.

contains routines for sleep/wakeup handling

5.49.2 Function Documentation

5.49.2.1 RET_T coEventRegister_SLEEP (CO_EVENT_SLEEP_T pFunction)

coEventRegister_SLEEP - register SLEEP event

register indication function for SLEEP events

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.49.2.2 void coSleepAwake (BOOL_T master, UNSIGNED8 status, UNSIGNED8 reason, UNSIGNED16 repeatTime)

coSleepAwake - awake from sleep

This function have to called after the processor is awaked. It transmit the wake up message, repeat it after the given repeatTime and reinitializes the communication handling.

Returns

none

Parameters

<i>master</i>	wake up master
<i>status</i>	wake up state (only for slaves)
<i>reason</i>	wake up reason
<i>repeatTime</i>	time interval for repeat wake up message

5.49.2.3 `BOOL_T coSleepModeActive (void)`

coSleepModeActive - check if sleep mode is active

Returns

none

5.49.2.4 `void coSleepModeStart (UNSIGNED16 waitTime)`

coSleepModeStart - start sleep mode

This function starts the sleep mode. First a timer is started, then the CAN traffic is stopped and the CPU is going to sleep.

Each step is indicated by the function registered by [coEventRegister_SLEEP\(\)](#).

Returns

none

Parameters

<i>waitTime</i>	wait time before stop CAN in ms
-----------------	---------------------------------

5.49.2.5 `void coSleepRequestSleep (void)`

coSleepRequestSleep - request sleep mode to master

Request sleep mode from master by sending sleep request.

Returns

none

5.49.2.6 void coSleepWakeUp (**BOOL_T** *master*, **UNSIGNED8** *status*, **UNSIGNED8** *reason*, **UNSIGNED16** *repeatTime*)

coSleepWakeUp - awake from sleep

This function can be called to send the wake up message independent from the actual sleep state. It transmits the wake up message, repeats it after the given repeatTime and reinitializes the communication handling.

Returns

none

Parameters

<i>master</i>	wake up master
<i>status</i>	wake up state (only for slaves)
<i>reason</i>	wake up reason
<i>repeatTime</i>	time interval for repeat wake up message

5.50 co_sleep.h File Reference

defines for sleep services

Typedefs

- typedef **UNSIGNED8**(* [CO_EVENT_SLEEP_T](#)) ([CO_SLEEP_MODE_T](#), **UNSIGNED8**)
function pointer to sleep event function

Enumerations

Functions

- **EXTERN_DECL** void [coSleepModeStart](#) (**UNSIGNED16** waitTime)
coSleepModeStart - start sleep mode
- **EXTERN_DECL** **RET_T** [coEventRegister_SLEEP](#) ([CO_EVENT_SLEEP_T](#) pFunction)
coEventRegister_SLEEP - register SLEEP event
- **EXTERN_DECL** **BOOL_T** [coSleepModeActive](#) (void)
coSleepModeActive - check if sleep mode is active
- **EXTERN_DECL** void [coSleepAwake](#) (**BOOL_T** master, **UNSIGNED8** status, **UNSIGNED8** reason, **UNSIGNED16** repeatTime)
coSleepAwake - awake from sleep
- **EXTERN_DECL** void [coSleepWakeUp](#) (**BOOL_T** master, **UNSIGNED8** status, **UNSIGNED8** reason, **UNSIGNED16** repeatTime)
coSleepWakeUp - awake from sleep
- **EXTERN_DECL** void [coSleepRequestSleep](#) (void)
coSleepRequestSleep - request sleep mode to master

5.50.1 Detailed Description

defines for sleep services

- contains defines for sleep services

5.50.2 Typedef Documentation

5.50.2.1 typedef UNSIGNED8(* CO_EVENT_SLEEP_T)(CO_SLEEP_MODE_T, UNSIGNED8)

function pointer to sleep event function

Parameters

<i>sleep</i>	mode
<i>node</i>	id

Return values

0	- ok
!=0	- error

5.50.3 Enumeration Type Documentation

5.50.3.1 enum CO_SLEEP_MODE_T

SLEEP states

Enumerator

CO_SLEEP_MODE_CHECK check if sleep mode is possible
CO_SLEEP_MODE OBJECTION slave has send an objection
CO_SLEEP_MODE_PREPARE automatic start sleep mode
CO_SLEEP_MODE_SILENT sleep mode silent
CO_SLEEP_MODE_DOZE sleep mode doze
CO_SLEEP_MODE_REQUEST_SLEEP sleep mode request sleep

5.50.4 Function Documentation

5.50.4.1 EXTERN_DECL RET_T coEventRegister_SLEEP (CO_EVENT_SLEEP_T pFunction)

coEventRegister_SLEEP - register SLEEP event

register indication function for SLEEP events

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.50.4.2 EXTERN_DECL void coSleepAwake (**BOOL_T** *master*, **UNSIGNED8** *status*, **UNSIGNED8** *reason*, **UNSIGNED16** *repeatTime*)

coSleepAwake - awake from sleep

This function have to called after the processor is awaked. It transmit the wake up message, repeat it after the given repeatTime and reinitializes the communication handling.

Returns

none

Parameters

<i>master</i>	wake up master
<i>status</i>	wake up state (only for slaves)
<i>reason</i>	wake up reason
<i>repeatTime</i>	time interval for repeat wake up message

5.50.4.3 EXTERN_DECL **BOOL_T** coSleepModeActive (void)

coSleepModeActive - check if sleep mode is active

Returns

none

5.50.4.4 EXTERN_DECL void coSleepModeStart (**UNSIGNED16** *waitTime*)

coSleepModeStart - start sleep mode

This function starts the sleep mode. First a timer is started, then the CAN traffic is stopped and the CPU is going to sleep.

Each step is indicated by the function registered by [coEventRegister_SLEEP\(\)](#).

Returns

none

Parameters

<i>waitTime</i>	wait time before stop CAN in ms
-----------------	---------------------------------

5.50.4.5 EXTERN_DECL void coSleepRequestSleep (void)

coSleepRequestSleep - request sleep mode to master

Request sleep mode from master by sending sleep request.

Returns

none

5.50.4.6 EXTERN_DECL void coSleepWakeUp (BOOL_T master, UNSIGNED8 status, UNSIGNED8 reason, UNSIGNED16 repeatTime)

coSleepWakeUp - awake from sleep

This function can be called to send the wake up message independent from the actual sleep state. It transmit the wake up message, repeat it after the given repeatTime and reinitializes the communication handling.

Returns

none

Parameters

<i>master</i>	wake up master
<i>status</i>	wake up state (only for slaves)
<i>reason</i>	wake up reason
<i>repeatTime</i>	time interval for repeat wake up message

5.51 co_srd.c File Reference

Service Request Device (SDO Manager Slave)

Functions

- [RET_T coSrdRequestRegister](#) (CO_SRD_REQ_TYPE_T reqType, UNSIGNED8 sdoClientChannel, UNSIGNED32 timeout)
coSrdRegister - register SRD at SDO manager
- [RET_T coSrdRequestConnection](#) (UNSIGNED8 sdoClientChannel, UNSIGNED8 remoteNodeId, UNSIGNED32 timeout)
coSrdRequestConnection - request connection to remote node
- [RET_T coSrdReleaseConnection](#) (UNSIGNED8 sdoClientChannel, UNSIGNED8 remoteNodeId, UNSIGNED32 timeout)
coSrdReleaseConnection - release connection to remote node
- [RET_T coEventRegister_SRD](#) (CO_EVENT_SRD_T pFunction)
coEventRegister_SRD - register SRD event

- void [icoSrdVarInit](#) (void)
- void [icoSrdReset](#) (void)
icoSrdReset
- [RET_T coSrdInit](#) (void)
colnitSrd - init Srd functionality

5.51.1 Detailed Description

Service Request Device (SDO Manager Slave)

contains routines for SRD slave handling

5.51.2 Function Documentation

5.51.2.1 [RET_T coEventRegister_SRD](#) ([CO_EVENT_SRD_T pFunction](#))

[coEventRegister_SRD](#) - register SRD event

register indication function for SRD events

Returns

[RET_T](#)

Parameters

pFunction	pointer to function
---------------------------	---------------------

5.51.2.2 [RET_T coSrdInit](#) (void)

[colnitSrd](#) - init Srd functionality

Returns

[RET_T](#)

5.51.2.3 [RET_T coSrdReleaseConnection](#) ([UNSIGNED8 sdoClientChannel](#), [UNSIGNED8 remoteNodeId](#), [UNSIGNED32 timeOut](#))

[coSrdReleaseConnection](#) - release connection to remote node

release SDO connection to remote node

If [sdoClientChannel](#) = 0, release all connections If [remoteNodeId](#) = 0 deregister at sdo manager

The answer will be done by calling function registered [coEventRegister_SRD\(\)](#)

Parameters

<i>sdoClientChannel</i>	sdo client channel to node
<i>remoteNodeId</i>	node id of remote node
<i>timeOut</i>	time out until service is aborted

5.51.2.4 RET_T coSrdRequestConnection (UNSIGNED8 *sdoClientChannel*, UNSIGNED8 *remoteNodeId*, UNSIGNED32 *timeOut*)

coSrdRequestConnection - request connection to remote node

Request SDO connection to remote node

The answer will be done by calling function registered [coEventRegister_SRD\(\)](#)

Parameters

<i>sdoClientChannel</i>	sdo client channel to node
<i>remoteNodeId</i>	node id of remote node
<i>timeOut</i>	time out until service is aborted

5.51.2.5 RET_T coSrdRequestRegister (CO_SRD_REQ_TYPE_T *reqType*, UNSIGNED8 *sdoClientChannel*, UNSIGNED32 *timeOut*)

coSrdRegister - register SRD at SDO manager

Request register as SRD at the SDO manager

If *reqType* == CO_SRD_REQ_TYPE_ALL_SDOS *sdoClientChannel* is ignored If *reqType* == CO_SRD_REQ_TYPE_NORMAL SDO client channel have to be from 1..128 (0x1280..0x12ff) This channel will be used as SDO client to the SDO manager.

The answer will be done by calling function registered by [coEventRegister_SRD\(\)](#)

Parameters

<i>reqType</i>	request type
<i>sdoClientChannel</i>	sdo client channel to SDO Manager
<i>timeOut</i>	time out until service is aborted in msec

5.51.2.6 void icoSrdReset (void)

icoSrdReset

Returns

none

5.51.2.7 void icoSrdVarInit (void)

Returns

none

5.52 co_srd.h File Reference

defines for srd services

Typedefs

- typedef void(* [CO_EVENT_SRD_T](#)) ([CO_SRD_RESULT_T](#) result, UNSIGNED8 errorCode)
function pointer to srd result function

Enumerations

Functions

- EXTERN_DECL [RET_T](#) [coSrdRequestRegister](#) ([CO_SRD_REQ_TYPE_T](#) reqType, UNSIGNED8 sdoClientChannel, UNSIGNED32 timeOut)
coSrdRegister - register SRD at SDO manager
- EXTERN_DECL [RET_T](#) [coSrdRequestConnection](#) (UNSIGNED8 sdoClientChannel, UNSIGNED8 remoteNodeId, UNSIGNED32 timeOut)
coSrdRequestConnection - request connection to remote node
- EXTERN_DECL [RET_T](#) [coSrdReleaseConnection](#) (UNSIGNED8 sdoClientChannel, UNSIGNED8 remoteNodeId, UNSIGNED32 timeOut)
coSrdReleaseConnection - release connection to remote node
- EXTERN_DECL [RET_T](#) [coEventRegister_SRD](#) ([CO_EVENT_SRD_T](#) pFunction)
coEventRegister_SRD - register SRD event
- EXTERN_DECL [RET_T](#) [coSrdInit](#) (void)
coInitSrd - init Srd functionality

5.52.1 Detailed Description

defines for srd services

- contains defines for srd services

5.52.2 Typedef Documentation

5.52.2.1 typedef void(* CO_EVENT_SRD_T) (CO_SRD_RESULT_T result, UNSIGNED8 errorCode)

function pointer to srd result function

Parameters

<i>result</i>	- result status of action
<i>errorcode</i>	- errorcode if

Returns

void

5.52.3 Enumeration Type Documentation

5.52.3.1 enum CO_SRD_REQ_TYPE_T

request type for SDO register

Enumerator

CO_SRD_REQ_TYPE_ALL_SDOS request all default Server SDOs

CO_SRD_REQ_TYPE_NORMAL request one SDO connection

5.52.3.2 enum CO_SRD_RESULT_T

result values for indication function

Enumerator

CO_SRD_RESULT_SUCCESS requested service ok

CO_SRD_RESULT_TIMEOUT time out occurred, fct aborted

CO_SRD_RESULT_ERROR error

CO_SRD_RESULT_ALL_REQUEST_SUCCESS request all sdos ok

CO_SRD_RESULT_NODE_REQUEST_SUCCESS request connection ok

5.52.4 Function Documentation

5.52.4.1 EXTERN_DECL RET_T coEventRegister_SRD (CO_EVENT_SRD_T *pFunction*)

coEventRegister_SRD - register SRD event

register indication function for SRD events

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.52.4.2 EXTERN_DECL RET_T coSrdInit (void)

coInitSrd - init Srd functionality

Returns

RET_T

5.52.4.3 EXTERN_DECL RET_T coSrdReleaseConnection (UNSIGNED8 *sdoClientChannel*, UNSIGNED8 *remoteNodeId*, UNSIGNED32 *timeOut*)

coSrdReleaseConnection - release connection to remote node

release SDO connection to remote node

If *sdoClientChannel* = 0, release all connections If *remoteNodeId* = 0 deregister at sdo manager

The answer will be done by calling function registered [coEventRegister_SRD\(\)](#)

Parameters

<i>sdoClientChannel</i>	sdo client channel to node
<i>remoteNodeId</i>	node id of remote node
<i>timeOut</i>	time out until service is aborted

5.52.4.4 EXTERN_DECL RET_T coSrdRequestConnection (UNSIGNED8 *sdoClientChannel*, UNSIGNED8 *remoteNodeId*, UNSIGNED32 *timeOut*)

coSrdRequestConnection - request connection to remote node

Request SDO connection to remote node

The answer will be done by calling function registered [coEventRegister_SRD\(\)](#)

Parameters

<i>sdoClientChannel</i>	sdo client channel to node
<i>remoteNodeId</i>	node id of remote node
<i>timeOut</i>	time out until service is aborted

5.52.4.5 EXTERN_DECL RET_T coSrdRequestRegister (CO_SRD_REQ_TYPE_T *reqType*, UNSIGNED8 *sdoClientChannel*, UNSIGNED32 *timeOut*)

coSrdRegister - register SRD at SDO manager

Request register as SRD at the SDO manager

If reqType == CO_SRD_REQ_TYPE_ALL_SDOs sdoClientChannel is ignored If reqType == CO_SRD_REQ_TYPE_NORMAL SDO client channel have to be from 1..128 (0x1280..0x12ff) This channel will be used as SDO client to the SDO manager.

The answer will be done by calling function registered by [coEventRegister_SRD\(\)](#)

Parameters

<i>reqType</i>	request type
<i>sdoClientChannel</i>	sdo client channel to SDO Manager
<i>timeOut</i>	time out until service is aborted in msec

5.53 co_srdo.c File Reference

srdo handling

5.53.1 Detailed Description

srdo handling

contains srdo services

5.54 co_srdo.h File Reference

defines for srdo services

5.54.1 Detailed Description

defines for srdo services

- contains defines for srdo services

5.55 co_stackinit.c File Reference

Functions for stack initialization handling.

Functions

- void [coCanOpenStackVarInit](#) ([CO_SERVICE_INIT_VAL_T](#) *pServiceInitVals)
coCanOpenStackVarInit - init of variables of the stack

5.55.1 Detailed Description

Functions for stack initialization handling.

contains functions for initialization handling

5.55.2 Function Documentation

5.55.2.1 void coCanOpenStackVarInit (CO_SERVICE_INIT_VAL_T * pServiceInitVals)

coCanOpenStackVarInit - init of variables of the stack

This function initializes all global and local variables of the stack.

It can also be used to reinitialize the stack.

Returns

nothing

Parameters

<i>pServiceInitVals</i>	pointer to init vals
-------------------------	----------------------

5.56 co_store.c File Reference

Stroe/Restore functionality.

5.56.1 Detailed Description

Stroe/Restore functionality.

contains routines for handling store/restore OD data

5.57 co_store.h File Reference

defines for store services

Macros

- #define [CO_STORE_AREA_ALL](#) 1u
- #define [CO_STORE_SIGNATURE_SAVE](#) 0x65766173ul
- #define [CO_STORE_SIGNATURE_LOAD](#) 0x64616f6cul

Typedefs

- typedef [RET_T](#)(* [CO_EVENT_STORE_T](#)) (UNSIGNED8 subIndex)
function pointer to save/load/clear function

5.57.1 Detailed Description

defines for store services

- contains defines for store services

5.57.2 Macro Definition Documentation

5.57.2.1 #define CO_STORE_AREA_ALL 1u

define for store/load/restore area all

5.57.2.2 #define CO_STORE_SIGNATURE_LOAD 0x64616f6cul

define for load command

5.57.2.3 #define CO_STORE_SIGNATURE_SAVE 0x65766173ul

define for save command

5.57.3 Typedef Documentation

5.57.3.1 typedef RET_T(* CO_EVENT_STORE_T) (UNSIGNED8 subIndex)

function pointer to save/load/clear function

Parameters

<i>subIndex</i>	- subindex parameter to point parameter area
-----------------	--

Returns

none

5.58 co_sync.c File Reference

sync handling

Functions

- [RET_T coEventRegister_SYNC](#) ([CO_EVENT_SYNC_T](#) pFunction)
coEventRegister_SYNC - register SYNC event
- [RET_T coEventRegister_SYNC_FINISHED](#) ([CO_EVENT_SYNC_FINISHED_T](#) pFunction)
coEventRegister_SYNC_FINISHED - register SYNC finished event
- [RET_T coSynclnit](#) (UNSIGNED32 cobId)
coSynclnit - init sync functionality

5.58.1 Detailed Description

sync handling

contains SYNC services

5.58.2 Function Documentation

5.58.2.1 [RET_T coEventRegister_SYNC](#) ([CO_EVENT_SYNC_T](#) pFunction)

[coEventRegister_SYNC](#) - register SYNC event

This function registers an indication function for SYNC events.

It is called every time a sync message was received or generated before PDOs are handled.

Returns

[RET_T](#)

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.58.2.2 [RET_T coEventRegister_SYNC_FINISHED](#) ([CO_EVENT_SYNC_FINISHED_T](#) pFunction)

[coEventRegister_SYNC_FINISHED](#) - register SYNC finished event

This function registers an indication function for finished SYNC handling.

It is called every time a sync message was received or generated and PDO handling is completed.

Returns

[RET_T](#)

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.58.2.3 RET_T coSyncInit (UNSIGNED32 cobId)

coSyncInit - init sync functionality

This function initializes the SYNC functionality.

If the node is a sync producer or a sync consumer depends on the value of the object dictionary index 0x1005. Sync counter value can also be set/reset by the value at the object dictionary at index 0x1019

Returns

RET_T

Parameters

<i>cobId</i>	sync cob-id
--------------	-------------

5.59 co_sync.h File Reference

defines for sync services

Typedefs

- typedef void(* [CO_EVENT_SYNC_T](#)) (UNSIGNED8)
function pointer to SYNC indication
- typedef void(* [CO_EVENT_SYNC_FINISHED_T](#)) (UNSIGNED8)
function pointer to SYNC Finished indication

Functions

- EXTERN_DECL [RET_T coSyncInit](#) (UNSIGNED32 cobId)
coSyncInit - init sync functionality
- EXTERN_DECL [RET_T coEventRegister_SYNC](#) ([CO_EVENT_SYNC_T](#) pFunction)
coEventRegister_SYNC - register SYNC event
- EXTERN_DECL [RET_T coEventRegister_SYNC_FINISHED](#) ([CO_EVENT_SYNC_FINISHED_T](#) pFunction)
coEventRegister_SYNC_FINISHED - register SYNC finished event

5.59.1 Detailed Description

defines for sync services

- contains defines for sync services

5.59.2 Typedef Documentation

5.59.2.1 typedef void(* CO_EVENT_SYNC_FINISHED_T) (UNSIGNED8)

function pointer to SYNC Finished indication

Parameters

<i>syncCounter</i>	- actual SYNC counter
--------------------	-----------------------

Returns

void

5.59.2.2 typedef void(* CO_EVENT_SYNC_T) (UNSIGNED8)

function pointer to SYNC indication

Parameters

<i>syncCounter</i>	- actual SYNC counter
--------------------	-----------------------

Returns

void

5.59.3 Function Documentation

5.59.3.1 EXTERN_DECL RET_T coEventRegister_SYNC (CO_EVENT_SYNC_T *pFunction*)

coEventRegister_SYNC - register SYNC event

This function registers an indication function for SYNC events.

It is called every time a sync message was received or generated before PDOs are handled.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.59.3.2 EXTERN_DECL RET_T coEventRegister_SYNC_FINISHED (CO_EVENT_SYNC_FINISHED_T *pFunction*)

coEventRegister_SYNC_FINISHED - register SYNC finished event

This function registers an indication function for finished SYNC handling.

It is called every time a sync message was received or generated and PDO handling is completed.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.59.3.3 EXTERN_DECL RET_T coSyncInit (UNSIGNED32 *cobId*)

coSyncInit - init sync functionality

This function initializes the SYNC functionality.

If the node is a sync producer or a sync consumer depends on the value of the object dictionary index 0x1005. Sync counter value can also be set/reset by the value at the object dictionary at index 0x1019

Returns

RET_T

Parameters

<i>cobId</i>	sync cob-id
--------------	-------------

5.60 co_time.c File Reference

time handling

Functions

- [RET_T coTimeWriteReq](#) (const [CO_TIME_T](#) *pTimeData)
coTimeWriteReq - write time request
- [RET_T coEventRegister_TIME](#) ([CO_EVENT_TIME_T](#) pFunction)
coEventRegister_TIME - register TIME event
- [RET_T coTimeInit](#) ([BOOL_T](#) producer, [BOOL_T](#) consumer)
coTimeInit - init time functionality

5.60.1 Detailed Description

time handling

contains TIME services

5.60.2 Function Documentation

5.60.2.1 RET_T coEventRegister_TIME (CO_EVENT_TIME_T *pFunction*)

coEventRegister_TIME - register TIME event

This function registers an indication function for TIME events.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.60.2.2 RET_T coTimeInit (BOOL_T *producer*, BOOL_T *consumer*)

coTimeInit - init time functionality

This function initializes the TIME functionality. The parameters give the possibilities to be producer and/or consumer, independ on the current value of the entry in the object dictionary.

Returns

RET_T

Parameters

<i>producer</i>	node can be time producer
<i>consumer</i>	node can be time consumer

5.60.2.3 RET_T coTimeWriteReq (const CO_TIME_T * *pTimeData*)

coTimeWriteReq - write time request

This function sends a time message to the bus.

Returns

RET_T

Parameters

<i>pTimeData</i>	time data to transmit
------------------	-----------------------

5.61 co_time.h File Reference

defines for time services

Data Structures

- struct [CO_TIME_T](#)

Typedefs

- typedef void(* [CO_EVENT_TIME_T](#)) ([CO_TIME_T](#) *pTime)
function pointer to time function

Functions

- EXTERN_DECL [RET_T](#) [coTimeWriteReq](#) ([CO_TIME_T](#) const *pTimeData)
coTimeWriteReq - write time request
- EXTERN_DECL [RET_T](#) [coTimeInit](#) ([BOOL_T](#) producer, [BOOL_T](#) consumer)
coTimeInit - init time functionality
- EXTERN_DECL [RET_T](#) [coEventRegister_TIME](#) ([CO_EVENT_TIME_T](#) pFunction)
coEventRegister_TIME - register TIME event

5.61.1 Detailed Description

defines for time services

- contains defines for time services

5.61.2 Typedef Documentation

5.61.2.1 typedef void(* CO_EVENT_TIME_T)(CO_TIME_T *pTime)

function pointer to time function

Parameters

<i>pTime</i>	- time of day structure
--------------	-------------------------

Returns

void

5.61.3 Function Documentation**5.61.3.1 EXTERN_DECL RET_T coEventRegister_TIME (CO_EVENT_TIME_T *pFunction*)**

coEventRegister_TIME - register TIME event

This function registers an indication function for TIME events.

Returns

RET_T

Parameters

<i>pFunction</i>	pointer to function
------------------	---------------------

5.61.3.2 EXTERN_DECL RET_T coTimeInit (BOOL_T *producer*, BOOL_T *consumer*)

coTimeInit - init time functionality

This function initializes the TIME functionality. The parameters give the possibilities to be producer and/or consumer, independ on the current value of the entry in the object dictionary.

Returns

RET_T

Parameters

<i>producer</i>	node can be time producer
<i>consumer</i>	node can be time consumer

5.61.3.3 EXTERN_DECL RET_T coTimeWriteReq (const CO_TIME_T * *pTimeData*)

coTimeWriteReq - write time request

This function sends a time message to the bus.

Returns

RET_T

Parameters

<i>pTimeData</i>	time data to transmit
------------------	-----------------------

5.62 co_timer.c File Reference

timer routines

Functions

- [RET_T coTimerStart](#) ([CO_TIMER_T](#) *pTimer, UNSIGNED32 timerTime, [CO_TIMER_FCT_T](#) pFct, void *p↵Data, [CO_TIMER_ATTR_T](#) timerAttributes)
coTimerStart - start a timer
- [RET_T coTimerStop](#) ([CO_CONST CO_TIMER_T](#) *pTimer)
coTimerStop - stop a timer
- [BOOL_T coTimerIsActive](#) ([CO_CONST CO_TIMER_T](#) *pTimer)
coTimerIsActive - check if timer is active
- void [coTimerAttrChange](#) ([CO_TIMER_T](#) *pTimer, [CO_TIMER_ATTR_T](#) timerAttributes)
coTimerAttrChange - change timer attribute
- void [coTimerTick](#) (void)
coTimerTick - timer tick elapsed
- void [coTimerInit](#) (UNSIGNED32 timerVal)
coTimerInit - init timer interval

5.62.1 Detailed Description

timer routines

contains timer routines

5.62.2 Function Documentation

5.62.2.1 void [coTimerAttrChange](#) ([CO_TIMER_T](#) * *pTimer*, [CO_TIMER_ATTR_T](#) *timerAttributes*)

[coTimerAttrChange](#) - change timer attribute

With this function timer attribute can be change.

Returns

none

Parameters

<i>pTimer</i>	pointer to timerstruct
<i>timerAttributes</i>	timer attributes

5.62.2.2 void coTimerInit (UNSIGNED32 *timerVal*)

coTimerInit - init timer interval

This function initializes the internal timer handling. It does nothing with the hardware timer and initializes only internal variables.

The given timer interval is used to calculate the timer period for timer depending functions started by [coTimerStart\(\)](#).

Returns

none

Parameters

<i>timerVal</i>	timer interval in μ sec
-----------------	-----------------------------

5.62.2.3 BOOL_T coTimerIsActive (CO_CONST CO_TIMER_T * *pTimer*)

coTimerIsActive - check if timer is active

With this function can be checked, if a timer is currently in the timer list.

Returns

BOOL_T

Return values

<i>CO_TRUE</i>	timer is active
<i>CO_FALSE</i>	timer is not active

Parameters

<i>pTimer</i>	pointer to timer struct
---------------	-------------------------

5.62.2.4 RET_T coTimerStart (CO_TIMER_T * *pTimer*, UNSIGNED32 *timerTime*, CO_TIMER_FCT_T *pFct*, void * *pData*, CO_TIMER_ATTR_T *timerAttributes*)

coTimerStart - start a timer

This function starts a timer with the given timer interval (in μ sec). If the timer is elapsed, the indication function pointed by ptrToFct() with the parameter pData is called.

Single-shot or cyclic timer can be defined using the CO_TIMER_ATTR_T attribute.

Returns

RET_T

Parameters

<i>pTimer</i>	pointer to timerstruct
<i>timerTime</i>	timer time in μ sec
<i>pFct</i>	function at timer elapsed
<i>pData</i>	pointer for own data
<i>timerAttributes</i>	timer attributes

5.62.2.5 **RET_T** coTimerStop (CO_CONST CO_TIMER_T * *pTimer*)

coTimerStop - stop a timer

This function stops the given timer.

Returns

RET_T

Return values

<i>RET_OK</i>	timer successful removed
<i>RET_INVALID_PARAMETER</i>	timer not in timer list

Parameters

<i>pTimer</i>	pointer to timerstruct
---------------	------------------------

5.62.2.6 **void** coTimerTick (void)

coTimerTick - timer tick elapsed

This function should be called, if the CANopen timer has been elapsed to signal a new timer interval to the stack.

It can be called at interrupt level.

Returns

none

5.63 **co_timer.h** File Reference

defines for timer

Data Structures

- struct [co_timer](#)

Typedefs

- typedef void(* [CO_TIMER_FCT_T](#)) (void *)
function pointer to Timer indication
- typedef struct [co_timer](#) xTimer

Enumerations

Functions

- EXTERN_DECL void [coTimerInit](#) (UNSIGNED32 timerVal)
coTimerInit - init timer interval
- EXTERN_DECL [RET_T](#) [coTimerStart](#) ([CO_TIMER_T](#) *pTimer, UNSIGNED32 timerTime, [CO_TIMER_FCT_T](#) pFct, void *pData, [CO_TIMER_ATTR_T](#) timerAttributes)
coTimerStart - start a timer
- EXTERN_DECL [RET_T](#) [coTimerStop](#) (CO_CONST [CO_TIMER_T](#) *pTimer)
coTimerStop - stop a timer
- EXTERN_DECL [BOOL_T](#) [coTimerIsActive](#) (CO_CONST [CO_TIMER_T](#) *pTimer)
coTimerIsActive - check if timer is active
- EXTERN_DECL void [coTimerTick](#) (void)
coTimerTick - timer tick elapsed
- EXTERN_DECL void [coTimerAttrChange](#) ([CO_TIMER_T](#) *pTimer, [CO_TIMER_ATTR_T](#) timerAttributes)
coTimerAttrChange - change timer attribute

5.63.1 Detailed Description

defines for timer

- contains defines for timer

5.63.2 Typedef Documentation

5.63.2.1 typedef void(* CO_TIMER_FCT_T) (void *)

function pointer to Timer indication

Parameters

<i>pFct</i>	- pointer to timer up function
-------------	--------------------------------

Returns

void

5.63.2.2 typedef struct co_timer xTimer

timer structure

5.63.3 Enumeration Type Documentation

5.63.3.1 enum CO_TIMER_ATTR_T

timer attributes

Enumerator

CO_TIMER_ATTR_ROUNDUP round up given timer value

CO_TIMER_ATTR_ROUNDUP_CYCLIC round up and start timer again

CO_TIMER_ATTR_ROUNDDOWN round down given timer value

CO_TIMER_ATTR_ROUNDDOWN_CYCLIC round down and start timer again

5.63.4 Function Documentation

5.63.4.1 EXTERN_DECL void coTimerAttrChange (CO_TIMER_T * *pTimer*, CO_TIMER_ATTR_T *timerAttributes*)

coTimerAttrChange - change timer attribute

With this function timer attribute can be change.

Returns

none

Parameters

<i>pTimer</i>	pointer to timerstruct
<i>timerAttributes</i>	timer attributes

5.63.4.2 EXTERN_DECL void coTimerInit (UNSIGNED32 *timerVal*)

coTimerInit - init timer interval

This function initializes the internal timer handling. It does nothing with the hardware timer and initializes only internal variables.

The given timer interval is used to calculate the timer period for timer depending functions started by [coTimerStart\(\)](#).

Returns

none

Parameters

<i>timerVal</i>	timer interval in µsec
-----------------	------------------------

5.63.4.3 EXTERN_DECL BOOL_T coTimerIsActive (CO_CONST CO_TIMER_T * *pTimer*)

coTimerIsActive - check if timer is active

With this function can be checked, if a timer is currently in the timer list.

Returns

BOOL_T

Return values

<i>CO_TRUE</i>	timer is active
<i>CO_FALSE</i>	timer is not active

Parameters

<i>pTimer</i>	pointer to timer struct
---------------	-------------------------

5.63.4.4 EXTERN_DECL RET_T coTimerStart (CO_TIMER_T * *pTimer*, UNSIGNED32 *timerTime*, CO_TIMER_FCT_T *pFct*, void * *pData*, CO_TIMER_ATTR_T *timerAttributes*)

coTimerStart - start a timer

This function starts a timer with the given timer interval (in μ sec). If the timer is elapsed, the indication function pointed by ptrToFct() with the parameter pData is called.

Single-shot or cyclic timer can be defined using the CO_TIMER_ATTR_T attribute.

Returns

RET_T

Parameters

<i>pTimer</i>	pointer to timerstruct
<i>timerTime</i>	timer time in μ sec
<i>pFct</i>	function at timer elapsed
<i>pData</i>	pointer for own data
<i>timerAttributes</i>	timer attributes

5.63.4.5 EXTERN_DECL RET_T coTimerStop (CO_CONST CO_TIMER_T * *pTimer*)

coTimerStop - stop a timer

This function stops the given timer.

Returns

RET_T

Return values

<i>RET_OK</i>	timer successful removed
<i>RET_INVALID_PARAMETER</i>	timer not in timer list

Parameters

<i>pTimer</i>	pointer to timerstruct
---------------	------------------------

5.63.4.6 EXTERN_DECL void coTimerTick (void)

coTimerTick - timer tick elapsed

This function should be called, if the CANopen timer has been elapsed to signal a new timer interval to the stack.

It can be called at interrupt level.

Returns

none

5.64 co_usdo.c File Reference

USDO routines.

5.64.1 Detailed Description

USDO routines.

contains usdo server routines

5.65 co_usdoserv.c File Reference

USDO server routines.

5.65.1 Detailed Description

USDO server routines.

contains usdo server routines

5.66 co_user.c File Reference

User CAN functionality.

5.66.1 Detailed Description

User CAN functionality.

Contain functions to send other data over CAN

5.67 co_user.h File Reference

defines for time services

Typedefs

- typedef void(* [CO_EVENT_USER_T](#)) (CO_CONST UNSIGNED16 msgNr, CO_CONST UNSIGNED8 dataLen, CO_CONST UNSIGNED8 *pRecData)
function pointer to user function

5.67.1 Detailed Description

defines for time services

- contains defines for time services

5.67.2 Typedef Documentation

5.67.2.1 typedef void(* [CO_EVENT_USER_T](#)) (CO_CONST UNSIGNED16 msgNr, CO_CONST UNSIGNED8 dataLen, CO_CONST UNSIGNED8 *pRecData)

function pointer to user function

Parameters

<i>msgNr</i>	- message number
<i>dataLen</i>	- received data len
<i>precData</i>	- received data

Returns

void

5.68 codrv_can_generic.c File Reference

generic driver

Macros

- `#define POLLING 1`

Functions

- `RET_T codrvCanInit` (UNSIGNED16 bitRate)
codrvCanInit - init CAN controller
- `RET_T codrvCanReInit` (UNSIGNED16 bitRate)
codrvCanReInit - reinit CAN controller
- `RET_T codrvCanSetBitRate` (UNSIGNED16 bitRate)
codrvCanSetBitRate - set CAN Bitrate
- `RET_T codrvCanEnable` (void)
codrvCanEnable - enable CAN controller
- `RET_T codrvCanDisable` (void)
codrvCanDisable - disable CAN controller
- `RET_T codrvCanStartTransmission` (void)
codrvCanStartTransmission - start can transmission if not active
- `void codrvCanTransmitInterrupt` (void)
codrvCanDriverTransmitInterrupt - can driver transmit interrupt
- `void codrvCanReceiveInterrupt` (void)
codrvCanReceiveInterrupt - can driver receive interrupt
- `void codrvCanDriverHandler` (void)
codrvCanDriverHandler - can driver handler

5.68.1 Detailed Description

generic driver

- generic driver for basic CAN

Author

emtas GmbH

This module contains a skeleton for a basic can driver. It can be use to implement a new driver for CANopen library of emtas.

The official small API for Filter usage is contained. But it is not required for a basic CAN driver.

5.68.2 Macro Definition Documentation

5.68.2.1 #define POLLING 1

CO_DRV_FILTER This setting activates the filter functionality. But note, you need a lot of filter to use it effectively. For a slave for example for the following services:

- NMT
- SDO Request
- n RPDOs optionally a slave can receive other nodes
- Heart Beat (as consumer)
- EMCY (as consumer) Typical the CAN controller is called FullCAN controller if it has for each filtered out CAN frame Id a own hardware storage (message object).

It can also be a sophisticated CAN receiver, preferred with a hardware FIFO, with a sophisticated acceptance filter mechanism.

You have to set this define in gen_define.h! CO_DRV_GROUP_FILTER The group filter mechanism is a additional feature for the general filter mechanism. The most filter can set an acceptance mask. A often used mask enable a group for all NodeIds of a specific command group, e.g. heartbeat consumer. In this case only one filter is required for 128 message identifiers.

You have to set this define in gen_define.h! POLLING Often used driver internal define, e.g. during the development. In case this define is set, the driver don't use interrupts.

You have to use it driver internal, only. CODRV_DEBUG Often used driver internal define to activate the printf() output for debugging. A completely correct functionality is not ensured, if this define is set. Please deactivate it! DEBUG_SEND_TESTMESSAGE Often used driver internal #define to send a transmit CAN frame during the initialization. For measurement purpose the message ID is 0x555 and the data byte 0x01..0x8. If no other CAN node is connected, the CAN controller will send this frame endless. This can be used to measure the bit time using an oscilloscope. Please deactivate it in production code!

5.68.3 Function Documentation

5.68.3.1 RET_T codrvCanDisable (void)

codrvCanDisable - disable CAN controller

This function disables the CAN controller. The function waits for the CAN controller being disabled. Code calling this function typically expects that after returning the CAN controller is in Init mode.

But note, the time the CAN controller needs to enter the Init mode can be as long as the duration of one CAN frame.

Returns

RET_T

Return values

<i>RET_OK</i>	CAN controller is set to be disabled
---------------	--------------------------------------

5.68.3.2 void codrvCanDriverHandler (void)

codrvCanDriverHandler - can driver handler

This function is cyclically called from the CANopen stack to get the current CAN state (BUS_OFF, PASSIVE, ACTIVE).

If a bus off event has occurred, this function should try to get to bus on again (activate the CAN controller).

Returns

void

5.68.3.3 RET_T codrvCanEnable (void)

codrvCanEnable - enable CAN controller

This function enables the CAN controller. At this point the enable bit is set. Typically the CAN controller requests 11 recessive bits to go in active mode. This will be checked later outside of this function.

Returns

RET_T

Return values

<i>RET_OK</i>	CAN controller, enabled was set
---------------	---------------------------------

5.68.3.4 RET_T codrvCanInit (UNSIGNED16 *bitRate*)

codrvCanInit - init CAN controller

This function initializes the CAN controller and configures the bitrate. At the end of the function, the CAN controller should be in state disabled.

Returns

RET_T

Return values

<i>RET_OK</i>	initialization was OK
---------------	-----------------------

Parameters

<i>bitRate</i>	CAN bitrate
----------------	-------------

5.68.3.5 void codrvCanReceiveInterrupt (void)

codrvCanReceiveInterrupt - can driver receive interrupt

This function is called, if a new message was received. As first get the pointer to the receive buffer and save the message there. Then set the buffer as filled and inform the lib about new data.

Returns

void

5.68.3.6 RET_T codrvCanReInit (UNSIGNED16 *bitRate*)

codrvCanReInit - reinit CAN controller

This Function reinit the CAN controller after deactivation.

In Filter mode: After this function call all Filter are reset and must be reconfigured!

At the end of the function, the CAN controller should be in state disabled.

Parameters

<i>bitrate</i>	- CANopen bitrate RET_T
----------------	----------------------------

Parameters

<i>bitRate</i>	CAN bitrate
----------------	-------------

5.68.3.7 RET_T codrvCanSetBitRate (UNSIGNED16 *bitRate*)

codrvCanSetBitRate - set CAN Bitrate

This function sets the CAN Bitrate to the given value. Changing the Bitrate is only allowed, if the CAN controller is in reset. The state at the start of the function is unknown, so the CAN controller should be switch to state reset.

At the end of the function the CAN controller should be stay in state reset.

Returns

RET_T

Return values

<i>RET_OK</i>	setting of Bitrate was OK
---------------	---------------------------

Parameters

<i>bitRate</i>	CAN Bitrate in kbit/s
----------------	-----------------------

5.68.3.8 **RET_T** `codrvCanStartTransmission (void)`

`codrvCanStartTransmission` - start can transmission if not active

Transmission of CAN messages should be interrupt driven. If a message was sent, the Transmit Interrupt is called and the next message can be transmitted. To start the transmission of the first message, this function is called from the CANopen stack.

The easiest way to implement this function is to trigger the transmit interrupt, but only if the transmission is not already active.

Returns

RET_T

Return values

<i>RET_OK</i>	start transmission was successful
---------------	-----------------------------------

5.68.3.9 **void** `codrvCanTransmitInterrupt (void)`

`codrvCanDriverTransmitInterrupt` - can driver transmit interrupt

This function is called, after a message was transmitted.

As first, inform stack about message transmission. Get the next message from the transmit buffer, write it to the CAN controller and transmit it.

Returns

void

5.69 **codrv_cpu_generic.c** File Reference

CPU specific routines.

Functions

- void [codrvHardwareInit](#) (void)
codrvHardwareInit - hardware initialization
- void [codrvHardwareCanInit](#) (void)
codrvInitCanHW - CAN related hardware initialization
- void [codrvCanEnableInterrupt](#) (void)
codrvCanEnableInterrupt - enable the CAN interrupt
- void [codrvCanDisableInterrupt](#) (void)
codrvCanDisableInterrupt - disable the CAN interrupt
- void [codrvCanSetTxInterrupt](#) (void)
codrvCanSetTxInterrupt - set pending bit of the Transmit interrupt
- [RET_T codrvTimerSetup](#) (UNSIGNED32 timerInterval)
codrvTimerSetup - init and configure the hardware Timer
- void [codrvTimerISR](#) (void)
codrvTimerISR - Timer interrupt service routine

5.69.1 Detailed Description

CPU specific routines.

cpu specific routines

This module contains the cpu specific routines for initialization and timer handling.

Author

emtas GmbH

5.69.2 Function Documentation

5.69.2.1 void codrvCanSetTxInterrupt (void)

codrvCanSetTxInterrupt - set pending bit of the Transmit interrupt

This function set the interrupt pending bit. In case of the NVIC enable interrupt and the CAN specific enable TX Interrupt mask the CAN interrupt handler is calling.

5.69.2.2 void codrvHardwareCanInit (void)

codrvInitCanHW - CAN related hardware initialization

Within this function you find the CAN only hardware part. Goal of it is, that you can have your own hardware initialization like [codrvHardwareInit\(\)](#), but you can add our tested CAN initialization.

5.69.2.3 void codrvHardwareInit (void)

codrvHardwareInit - hardware initialization

This function initializes the hardware, incl. clock and CAN hardware.

5.69.2.4 void codrvTimerISR (void)

codrvTimerISR - Timer interrupt service routine

This function is normally called from timer interrupt or from an other system timer. It has to call the timer handling function at the library.

Returns

void

5.69.2.5 RET_T codrvTimerSetup (UNSIGNED32 timerInterval)

codrvTimerSetup - init and configure the hardware Timer

This function starts a cyclic hardware timer to provide a timing interval for the CANopen library. Alternatively it can be derived from an other system timer with the timer interval given by the function parameter.

Returns

RET_T

Return values

<i>RET_OK</i>	intialization of the timer was ok
---------------	-----------------------------------

Parameters

<i>timerInterval</i>	timer interval in usec
----------------------	------------------------

5.70 codrv_error.c File Reference

error state handling

Functions

- CAN_ERROR_FLAGS_T * [codrvCanErrorGetFlags](#) (void)
codrvCanErrorgetFlags - Reference to the error flags
- void [codrvCanErrorInit](#) (void)
codrvCanErrorInit - init Error variables
- RET_T [codrvCanErrorInformStack](#) (void)

5.70.1 Detailed Description

error state handling

5.70.2 Function Documentation

5.70.2.1 CAN_ERROR_FLAGS_T* codrvCanErrorGetFlags (void)

codrvCanErrorgetFlags - Reference to the error flags

Return values

<i>pointer</i>	to error flags
----------------	----------------

5.70.2.2 RET_T codrvCanErrorInformStack (void)

codrvCanErrorInformStack - inform the stack about changes

Call outside of interrupts! Typical call in [codrvCanDriverHandler\(\)](#).

Index

actTicks
 co_timer, [12](#)

attr
 co_timer, [12](#)

BOOL_T
 co_datatype.h, [32](#)

CO_ATTR_DEFVAL
 co_odaccess.h, [115](#)

CO_ATTR_DYNOD
 co_odaccess.h, [115](#)

CO_ATTR_LIMIT
 co_odaccess.h, [115](#)

CO_ATTR_MAP_REC
 co_odaccess.h, [115](#)

CO_ATTR_MAP_TR
 co_odaccess.h, [115](#)

CO_ATTR_MAP
 co_odaccess.h, [115](#)

CO_ATTR_NUM
 co_odaccess.h, [116](#)

CO_ATTR_READ
 co_odaccess.h, [116](#)

CO_ATTR_STORE
 co_odaccess.h, [116](#)

CO_ATTR_WRITE
 co_odaccess.h, [116](#)

CO_CAN_COB_T, [9](#)
 canChan, [9](#)
 canId, [9](#)
 enabled, [9](#)
 extended, [9](#)
 ignore, [10](#)
 rtr, [10](#)

CO_CAN_MSG_T, [10](#)
 canCob, [10](#)
 data, [10](#)
 handle, [10](#)
 len, [10](#)

CO_CAN_STATE_BUS_OFF
 co_commtask.h, [28](#)

CO_CAN_STATE_BUS_ON
 co_commtask.h, [28](#)

CO_CAN_STATE_PASSIVE
 co_commtask.h, [28](#)

CO_CAN_STATE_UNCHANGED
 co_commtask.h, [28](#)

CO_CAN_STATE_T
 co_commtask.h, [28](#)

CO_CFG_TRANSFER_ABORT
 co_cfgman.h, [22](#)

CO_CFG_TRANSFER_ERROR
 co_cfgman.h, [22](#)

CO_CFG_TRANSFER_FINISHED
 co_cfgman.h, [22](#)

CO_CFG_TRANSFER_T
 co_cfgman.h, [22](#)

CO_COB_29BIT_MASK
 co_cob.h, [24](#)

CO_COB_29BIT
 co_cob.h, [24](#)

CO_COB_ID_MASK
 co_cob.h, [24](#)

CO_COB_INVALID
 co_cob.h, [24](#)

CO_COB_VALID_MASK
 co_cob.h, [24](#)

CO_COMM_STATE_EVENT_ACTIVE
 co_commtask.h, [29](#)

CO_COMM_STATE_EVENT_BUS_OFF_RECOVERY
 co_commtask.h, [29](#)

CO_COMM_STATE_EVENT_BUS_OFF
 co_commtask.h, [29](#)

CO_COMM_STATE_EVENT_BUS_ON
 co_commtask.h, [29](#)

CO_COMM_STATE_EVENT_CAN_OVERRUN
 co_commtask.h, [29](#)

CO_COMM_STATE_EVENT_NONE
 co_commtask.h, [29](#)

CO_COMM_STATE_EVENT_PASSIVE
 co_commtask.h, [29](#)

CO_COMM_STATE_EVENT_REC_QUEUE_EMPTY
 co_commtask.h, [29](#)

CO_COMM_STATE_EVENT_REC_QUEUE_FULL
 co_commtask.h, [29](#)

CO_COMM_STATE_EVENT_REC_QUEUE_OVERFLOW
 LOW
 co_commtask.h, [29](#)

CO_COMM_STATE_EVENT_TR_QUEUE_EMPTY
 co_commtask.h, [29](#)

CO_COMM_STATE_EVENT_TR_QUEUE_FULL
 co_commtask.h, [29](#)

CO_COMM_STATE_EVENT_TR_QUEUE_OVERFLOW
 OW
 co_commtask.h, [29](#)

CO_COMM_STATE_EVENT_T
 co_commtask.h, [28](#)

CO_COMMTASK_EVENT_T

co_commtask.h, [29](#)
 CO_DATA_TYPE_T
 co_odaccess.h, [117](#)
 CO_EMCY_ERRCODE_COMM_ERROR
 co_emcy.h, [47](#)
 CO_EMCY_ERRCODE_PDO_LEN
 co_emcy.h, [47](#)
 CO_ERRCTRL_BOOTUP_FAILURE
 co_nmt.h, [91](#)
 CO_ERRCTRL_BOOTUP
 co_nmt.h, [90](#)
 CO_ERRCTRL_GUARD_FAILED
 co_nmt.h, [91](#)
 CO_ERRCTRL_HB_FAILED
 co_nmt.h, [91](#)
 CO_ERRCTRL_HB_STARTED
 co_nmt.h, [90](#)
 CO_ERRCTRL_MGUARD_FAILED
 co_nmt.h, [91](#)
 CO_ERRCTRL_MGUARD_TOGGLE
 co_nmt.h, [91](#)
 CO_ERRCTRL_NEW_STATE
 co_nmt.h, [90](#)
 CO_ERRCTRL_T
 co_nmt.h, [90](#)
 CO_EVENT_CAN_STATE_T
 co_commtask.h, [27](#)
 CO_EVENT_CFG_MANAGER_T
 co_cfgman.h, [21](#)
 CO_EVENT_COMM_T
 co_commtask.h, [28](#)
 CO_EVENT_EMCY_CONS_T
 co_emcy.h, [47](#)
 CO_EVENT_EMCY_T
 co_emcy.h, [47](#)
 CO_EVENT_ERRCTRL_T
 co_nmt.h, [89](#)
 CO_EVENT_FLYMA_T
 co_flyingmaster.h, [53](#)
 CO_EVENT_GFC_T
 co_gfc.h, [54](#)
 CO_EVENT_GW_SDOCLIENT_FCT_T
 co_network.h, [86](#)
 CO_EVENT_LED_T
 co_led.h, [59](#)
 CO_EVENT_LSS_MASTER_T
 co_lss.h, [64](#)
 CO_EVENT_LSS_T
 co_lss.h, [64](#)
 CO_EVENT_MANAGER_BOOTUP_T
 co_manager.h, [82](#)
 CO_EVENT_MPDO_T
 co_pdo.h, [136](#)
 CO_EVENT_NMT_T
 co_nmt.h, [90](#)
 CO_EVENT_OBJECT_CHANGED_FCT_T
 co_odaccess.h, [116](#)
 CO_EVENT_PDO_T
 co_pdo.h, [137](#)
 CO_EVENT_SDO_CLIENT_DOMAIN_WRITE_T
 co_sdo.h, [144](#)
 CO_EVENT_SDO_CLIENT_READ_T
 co_sdo.h, [144](#)
 CO_EVENT_SDO_CLIENT_WRITE_T
 co_sdo.h, [145](#)
 CO_EVENT_SDO_SERVER_CHECK_WRITE_T
 co_sdo.h, [145](#)
 CO_EVENT_SDO_SERVER_DOMAIN_WRITE_T
 co_sdo.h, [145](#)
 CO_EVENT_SDO_SERVER_T
 co_sdo.h, [146](#)
 CO_EVENT_SLEEP_T
 co_sleep.h, [166](#)
 CO_EVENT_SRD_T
 co_srd.h, [171](#)
 CO_EVENT_STORE_T
 co_store.h, [176](#)
 CO_EVENT_SYNC_FINISHED_T
 co_sync.h, [179](#)
 CO_EVENT_SYNC_T
 co_sync.h, [179](#)
 CO_EVENT_TIME_T
 co_time.h, [182](#)
 CO_EVENT_USER_T
 co_user.h, [191](#)
 CO_FALSE
 co_datatype.h, [32](#)
 CO_FLYMA_STATE_DETECT_NO_MASTERS
 co_flyingmaster.h, [53](#)
 CO_FLYMA_STATE_MASTERS_AVAILABLE
 co_flyingmaster.h, [53](#)
 CO_FLYMA_STATE_MASTER
 co_flyingmaster.h, [53](#)
 CO_FLYMA_STATE_NEGOTIATION_STARTED
 co_flyingmaster.h, [53](#)
 CO_FLYMA_STATE_NO_ACTIVE_MASTER
 co_flyingmaster.h, [53](#)
 CO_FLYMA_STATE_SLAVE
 co_flyingmaster.h, [53](#)
 CO_FLYMA_STATE_T
 co_flyingmaster.h, [53](#)
 CO_LED_STATE_BLINKING
 co_led.h, [60](#)
 CO_LED_STATE_FLASH_1
 co_led.h, [59](#)
 CO_LED_STATE_FLASH_2
 co_led.h, [59](#)
 CO_LED_STATE_FLASH_3
 co_led.h, [60](#)
 CO_LED_STATE_FLICKERING
 co_led.h, [59](#)
 CO_LED_STATE_OFF
 co_led.h, [59](#)
 CO_LED_STATE_ON
 co_led.h, [60](#)
 CO_LED_STATE_T

co_led.h, [59](#)
CO_LSS_MASTER_SERVICE_BITRATE_ACTIVE
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_BITRATE_OFF
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_BITRATE_SET
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_FASTSCAN
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_IDENTITY
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_INQUIRE_NODEID
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_INQUIRE_PRODUCT
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_INQUIRE_REVISION
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_INQUIRE_SERIAL
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_INQUIRE_VENDOR
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_NON_CONFIG_SLAVE
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_SET_BITRATE
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_SET_NODEID
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_STORE
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_SWITCH_GLOBAL
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_SWITCH_SELECTIVE
co_iss.h, [65](#)
CO_LSS_MASTER_SERVICE_T
co_iss.h, [65](#)
CO_LSS_SERVICE_BITRATE_ACTIVE
co_iss.h, [66](#)
CO_LSS_SERVICE_BITRATE_OFF
co_iss.h, [66](#)
CO_LSS_SERVICE_BITRATE_SET
co_iss.h, [66](#)
CO_LSS_SERVICE_NEW_BITRATE
co_iss.h, [66](#)
CO_LSS_SERVICE_NEW_NODE_ID
co_iss.h, [66](#)
CO_LSS_SERVICE_STORE
co_iss.h, [66](#)
CO_LSS_SERVICE_T
co_iss.h, [65](#)
CO_LSS_STATE_CONFIGURATION
co_iss.h, [66](#)
CO_LSS_STATE_WAITING
co_iss.h, [66](#)
CO_LSS_STATE_T
co_iss.h, [66](#)
CO_MANAGER_EVENT_BOOTED
co_manager.h, [83](#)
CO_MANAGER_EVENT_BOOT
co_manager.h, [82](#)
CO_MANAGER_EVENT_ERROR_NODE
co_manager.h, [83](#)
CO_MANAGER_EVENT_ERROR_B
co_manager.h, [82](#)
CO_MANAGER_EVENT_ERROR_C
co_manager.h, [83](#)
CO_MANAGER_EVENT_ERROR_D
co_manager.h, [83](#)
CO_MANAGER_EVENT_ERROR_G
co_manager.h, [83](#)
CO_MANAGER_EVENT_ERROR_J
co_manager.h, [83](#)
CO_MANAGER_EVENT_ERROR_K
co_manager.h, [83](#)
CO_MANAGER_EVENT_ERROR_M
co_manager.h, [83](#)
CO_MANAGER_EVENT_ERROR_N
co_manager.h, [83](#)
CO_MANAGER_EVENT_ERROR_O
co_manager.h, [83](#)
CO_MANAGER_EVENT_FAILURE
co_manager.h, [83](#)
CO_MANAGER_EVENT_FINISHED
co_manager.h, [83](#)
CO_MANAGER_EVENT_RDY_OPERATIONAL
co_manager.h, [83](#)
CO_MANAGER_EVENT_UPDATE_CONFIG
co_manager.h, [83](#)
CO_MANAGER_EVENT_UPDATE_SW
co_manager.h, [83](#)
CO_MANAGER_EVENT_T
co_manager.h, [82](#)
CO_NMT_REQ_STATE_OPERATIONAL
co_nmt.h, [91](#)
CO_NMT_REQ_STATE_PREOP
co_nmt.h, [91](#)
CO_NMT_REQ_STATE_RESET_COMM
co_nmt.h, [91](#)
CO_NMT_REQ_STATE_RESET_NODE
co_nmt.h, [91](#)
CO_NMT_REQ_STATE_STOPPED
co_nmt.h, [91](#)
CO_NMT_REQ_STATE_T
co_nmt.h, [91](#)
CO_NMT_STATE_OPERATIONAL
co_nmt.h, [91](#)
CO_NMT_STATE_PREOP
co_nmt.h, [91](#)
CO_NMT_STATE_RESET_COMM
co_nmt.h, [91](#)
CO_NMT_STATE_RESET_NODE
co_nmt.h, [91](#)
CO_NMT_STATE_STOPPED
co_nmt.h, [91](#)
CO_NMT_STATE_UNKNOWN
co_nmt.h, [91](#)
CO_NMT_STATE_T

- co_nmt.h, 91
- CO_NODE_ID_T
 - co_nmt.h, 90
- CO_ODTYPE_ARRAY
 - co_odaccess.h, 117
- CO_ODTYPE_STRUCT
 - co_odaccess.h, 117
- CO_ODTYPE_VAR
 - co_odaccess.h, 117
- CO_ODTYPE_T
 - co_odaccess.h, 117
- CO_OS_LOCK_OD
 - co_odaccess.h, 116
- CO_OS_UNLOCK_OD
 - co_odaccess.h, 116
- CO_SERVICE_INIT_VAL_T, 11
- CO_SLEEP_MODE_CHECK
 - co_sleep.h, 166
- CO_SLEEP_MODE_DOZE
 - co_sleep.h, 166
- CO_SLEEP_MODE_OBJECTION
 - co_sleep.h, 166
- CO_SLEEP_MODE_PREPARE
 - co_sleep.h, 166
- CO_SLEEP_MODE_REQUEST_SLEEP
 - co_sleep.h, 166
- CO_SLEEP_MODE_SILENT
 - co_sleep.h, 166
- CO_SLEEP_MODE_T
 - co_sleep.h, 166
- CO_SRD_REQ_TYPE_ALL_SDOS
 - co_srd.h, 172
- CO_SRD_REQ_TYPE_NORMAL
 - co_srd.h, 172
- CO_SRD_REQ_TYPE_T
 - co_srd.h, 172
- CO_SRD_RESULT_ALL_REQUEST_SUCCESS
 - co_srd.h, 172
- CO_SRD_RESULT_ERROR
 - co_srd.h, 172
- CO_SRD_RESULT_NODE_REQUEST_SUCCESS
 - co_srd.h, 172
- CO_SRD_RESULT_SUCCESS
 - co_srd.h, 172
- CO_SRD_RESULT_TIMEOUT
 - co_srd.h, 172
- CO_SRD_RESULT_T
 - co_srd.h, 172
- CO_STORE_AREA_ALL
 - co_store.h, 176
- CO_STORE_SIGNATURE_LOAD
 - co_store.h, 176
- CO_STORE_SIGNATURE_SAVE
 - co_store.h, 176
- CO_TIME_T, 11
 - days, 11
 - msec, 11
- CO_TIMER_ATTR_ROUNDDOWN_CYCLIC
 - co_timer.h, 188
- CO_TIMER_ATTR_ROUNDDOWN
 - co_timer.h, 188
- CO_TIMER_ATTR_ROUNDUP_CYCLIC
 - co_timer.h, 188
- CO_TIMER_ATTR_ROUNDUP
 - co_timer.h, 188
- CO_TIMER_ATTR_T
 - co_timer.h, 188
- CO_TIMER_FCT_T
 - co_timer.h, 187
- CO_TRUE
 - co_datatype.h, 32
- canChan
 - CO_CAN_COB_T, 9
- canCob
 - CO_CAN_MSG_T, 10
- canId
 - CO_CAN_COB_T, 9
- co_candebug.c, 17
- co_candebug.h, 17
- co_canopen.h, 17
 - coCanOpenStackDelnit, 18
 - coCanOpenStackInit, 18
 - coCanOpenStackInitPara, 18
 - coCanOpenStackVarInit, 19
- co_cfgman.c, 19
 - coCfgConvToConsive, 20
 - coCfgStart, 20
 - coEventRegister_CFG_MANAGER, 20
- co_cfgman.h, 21
 - CO_CFG_TRANSFER_ABORT, 22
 - CO_CFG_TRANSFER_ERROR, 22
 - CO_CFG_TRANSFER_FINISHED, 22
 - CO_CFG_TRANSFER_T, 22
 - CO_EVENT_CFG_MANAGER_T, 21
 - coCfgConvToConsive, 22
 - coCfgStart, 22
 - coEventRegister_CFG_MANAGER, 23
- co_cob.h, 23
 - CO_COB_29BIT_MASK, 24
 - CO_COB_29BIT, 24
 - CO_COB_ID_MASK, 24
 - CO_COB_INVALID, 24
 - CO_COB_VALID_MASK, 24
- co_cobhandler.c, 24
- co_commtask.c, 25
 - coCommStateEvent, 25
 - coCommTask, 25
 - coEventRegister_CAN_STATE, 26
 - coEventRegister_COMM_EVENT, 26
- co_commtask.h, 27
 - CO_CAN_STATE_BUS_OFF, 28
 - CO_CAN_STATE_BUS_ON, 28
 - CO_CAN_STATE_PASSIVE, 28
 - CO_CAN_STATE_UNCHANGED, 28
 - CO_CAN_STATE_T, 28
 - CO_COMM_STATE_EVENT_ACTIVE, 29

- CO_COMM_STATE_EVENT_BUS_OFF_RECOVER, 29
- CO_COMM_STATE_EVENT_BUS_OFF, 29
- CO_COMM_STATE_EVENT_BUS_ON, 29
- CO_COMM_STATE_EVENT_CAN_OVERRUN, 29
- CO_COMM_STATE_EVENT_NONE, 29
- CO_COMM_STATE_EVENT_PASSIVE, 29
- CO_COMM_STATE_EVENT_REC_QUEUE_EMPTY, 29
- CO_COMM_STATE_EVENT_REC_QUEUE_FULL, 29
- CO_COMM_STATE_EVENT_REC_QUEUE_OVERFLOW, 29
- CO_COMM_STATE_EVENT_TR_QUEUE_EMPTY, 29
- CO_COMM_STATE_EVENT_TR_QUEUE_FULL, 29
- CO_COMM_STATE_EVENT_TR_QUEUE_OVERFLOW, 29
- CO_COMM_STATE_EVENT_T, 28
- CO_COMMTASK_EVENT_T, 29
- CO_EVENT_CAN_STATE_T, 27
- CO_EVENT_COMM_T, 28
- coCommStateEvent, 29
- coCommTask, 29
- coEventRegister_CAN_STATE, 30
- coEventRegister_COMM_EVENT, 30
- coQueueInit, 31
- co_datatype.h, 31
 - BOOL_T, 32
 - CO_FALSE, 32
 - CO_TRUE, 32
 - MSG_OVERWRITE, 31
 - MSG_RET_INHIBIT, 31
 - RET_ALREADY_INITIALIZED, 32
 - RET_CFG_CONVERT_ERROR, 33
 - RET_COB_DISABLED, 32
 - RET_DATA_TYPE_MISMATCH, 32
 - RET_DRV_BUSY, 33
 - RET_DRV_ERROR, 32
 - RET_DRV_TRANS_BUFFER_FULL, 32
 - RET_DRV_WRONG_BITRATE, 32
 - RET_ERROR_PRESENT_DEVICE_STATE, 33
 - RET_ERROR_STORE, 33
 - RET_EVENT_NO_RESSOURCE, 32
 - RET_HARDWARE_ERROR, 33
 - RET_IDX_NOT_FOUND, 32
 - RET_INHIBIT_ACTIVE, 33
 - RET_INTERNAL_ERROR, 33
 - RET_INVALID_NMT_STATE, 32
 - RET_INVALID_NODEID, 32
 - RET_INVALID_PARAMETER, 32
 - RET_MAP_ERROR, 33
 - RET_MAP_LEN_ERROR, 33
 - RET_NETWORK_ID_UNKNOWN, 33
 - RET_NO_COB_AVAILABLE, 32
 - RET_NO_READ_PERM, 32
 - RET_NO_WRITE_PERM, 32
 - RET_NOT_INITIALIZED, 32
 - RET_OD_ACCESS_ERROR, 32
 - RET_OUT_OF_MEMORY, 32
 - RET_OK, 32
 - RET_PARAMETER_INCOMPATIBLE, 32
 - RET_SDO_CHANNEL_IN_USE, 33
 - RET_SDO_CRC_ERROR, 32
 - RET_SDO_DATA_TYPE_NOT_MATCH, 32
 - RET_SDO_INVALID_VALUE, 32
 - RET_SDO_NODE_ID_UNKNOWN, 33
 - RET_SDO_SPLIT_INDICATION, 32
 - RET_SDO_TIMEOUT, 32
 - RET_SDO_TRANSFER_NOT_SUPPORTED, 32
 - RET_SDO_UNKNOWN_CCS, 32
 - RET_SDO_WRONG_BLOCKSIZE, 32
 - RET_SDO_WRONG_SEQ_NR, 32
 - RET_SERVICE_ALREADY_INITIALIZED, 33
 - RET_SERVICE_BUSY, 33
 - RET_SERVICE_NOT_INITIALIZED, 33
 - RET_SUBIDX_NOT_FOUND, 32
 - RET_TOGGLE_MISMATCH, 32
 - RET_VALUE_NOT_AVAILABLE, 33
 - RET_T, 32
- co_drv.h, 33
 - coQueueGetNextTransmitMessage, 37
 - coQueueMsgTransmitted, 37
 - coQueueReceiveMessageAvailable, 38
 - codrvCanDisable, 34
 - codrvCanDriverHandler, 34
 - codrvCanEnable, 34
 - codrvCanInit, 35
 - codrvCanReInit, 35
 - codrvCanSetBitRate, 36
 - codrvCanStartTransmission, 36
 - codrvHardwareInit, 36
 - codrvTimerSetup, 37
- co_dynod.c, 38
 - coDynOdAddIndex, 38
 - coDynOdAddSubIndex, 39
 - coDynOdInit, 39
 - coDynOdRelease, 40
 - coDynOdSetSubIndexAddr, 40
- co_edsparse.c, 40
 - coEdsparseAddEdsToRepository, 41
 - coEdsparseDetectSlaveEds, 41
 - coEdsparseGetIndexDesc, 42
 - coEdsparseGetObjectDesc, 42
 - coEdsparseGetRPdoMapEntry, 43
 - coEdsparseGetSupportedObjCnt, 43
 - coEdsparseGetTPdoMapEntry, 43
 - coEdsparseReadEdsMapping, 44
- co_emcy.c, 44
 - coEmcyConsumerInit, 45
 - coEmcyProducerInit, 45
 - coEmcyWriteReq, 45
 - coEventRegister_EMCY_CONSUMER, 46
 - coEventRegister_EMCY, 45

- co_emcy.h, 46
 - CO_EMCY_ERRCODE_COMM_ERROR, 47
 - CO_EMCY_ERRCODE_PDO_LEN, 47
 - CO_EVENT_EMCY_CONS_T, 47
 - CO_EVENT_EMCY_T, 47
 - coEmcyConsumerInit, 48
 - coEmcyProducerInit, 48
 - coEventRegister_EMCY_CONSUMER, 48
 - coEventRegister_EMCY, 48
- co_errctrl.c, 49
 - coErrorCtrlInit, 49
 - coEventRegister_ERRCTRL, 50
 - coHbConsumerSet, 50
 - coHbConsumerStart, 50
 - coNmtGetRemoteNodeState, 51
- co_event.c, 51
 - icoEventInit, 52
 - icoEventsActive, 52
 - icoEventStart, 52
- co_flyingmaster.h, 53
 - CO_EVENT_FLYMA_T, 53
 - CO_FLYMA_STATE_DETECT_NO_MASTERS, 53
 - CO_FLYMA_STATE_MASTERS_AVAILABLE, 53
 - CO_FLYMA_STATE_MASTER, 53
 - CO_FLYMA_STATE_NEGOTIATION_STARTED, 53
 - CO_FLYMA_STATE_NO_ACTIVE_MASTER, 53
 - CO_FLYMA_STATE_SLAVE, 53
 - CO_FLYMA_STATE_T, 53
- co_gfc.c, 54
- co_gfc.h, 54
 - CO_EVENT_GFC_T, 54
- co_guarding.c, 54
 - coGuardingMasterStart, 55
 - coGuardingMasterStop, 55
 - icoGuardGetRemoteNodeState, 56
- co_led.c, 56
 - coEventRegister_LED_GREEN, 57
 - coEventRegister_LED_RED, 57
 - coLedSetGreen, 57
 - coLedSetRed, 58
 - coLedSetState, 58
- co_led.h, 58
 - CO_EVENT_LED_T, 59
 - CO_LED_STATE_BLINKING, 60
 - CO_LED_STATE_FLASH_1, 59
 - CO_LED_STATE_FLASH_2, 59
 - CO_LED_STATE_FLASH_3, 60
 - CO_LED_STATE_FLICKERING, 59
 - CO_LED_STATE_OFF, 59
 - CO_LED_STATE_ON, 60
 - CO_LED_STATE_T, 59
 - coEventRegister_LED_GREEN, 60
 - coEventRegister_LED_RED, 60
 - coLedSetGreen, 60
 - coLedSetRed, 61
 - coLedSetState, 61
- co_iss.c, 61
 - coEventRegister_LSS, 62
 - coLssInit, 62
 - coLssNonConfigSlave, 62
- co_iss.h, 63
 - CO_EVENT_LSS_MASTER_T, 64
 - CO_EVENT_LSS_T, 64
 - CO_LSS_MASTER_SERVICE_BITRATE_ACTI↔VE, 65
 - CO_LSS_MASTER_SERVICE_BITRATE_OFF, 65
 - CO_LSS_MASTER_SERVICE_BITRATE_SET, 65
 - CO_LSS_MASTER_SERVICE_FASTSCAN, 65
 - CO_LSS_MASTER_SERVICE_IDENTITY, 65
 - CO_LSS_MASTER_SERVICE_INQUIRE_NOD↔EID, 65
 - CO_LSS_MASTER_SERVICE_INQUIRE_PRO↔DUCT, 65
 - CO_LSS_MASTER_SERVICE_INQUIRE_REVI↔SION, 65
 - CO_LSS_MASTER_SERVICE_INQUIRE_SERI↔AL, 65
 - CO_LSS_MASTER_SERVICE_INQUIRE_VEN↔DOR, 65
 - CO_LSS_MASTER_SERVICE_NON_CONFIG↔SLAVE, 65
 - CO_LSS_MASTER_SERVICE_SET_BITRATE, 65
 - CO_LSS_MASTER_SERVICE_SET_NODEID, 65
 - CO_LSS_MASTER_SERVICE_STORE, 65
 - CO_LSS_MASTER_SERVICE_SWITCH_GLOB↔AL, 65
 - CO_LSS_MASTER_SERVICE_SWITCH_SELE↔CTIVE, 65
 - CO_LSS_MASTER_SERVICE_T, 65
 - CO_LSS_SERVICE_BITRATE_ACTIVE, 66
 - CO_LSS_SERVICE_BITRATE_OFF, 66
 - CO_LSS_SERVICE_BITRATE_SET, 66
 - CO_LSS_SERVICE_NEW_BITRATE, 66
 - CO_LSS_SERVICE_NEW_NODE_ID, 66
 - CO_LSS_SERVICE_STORE, 66
 - CO_LSS_SERVICE_T, 65
 - CO_LSS_STATE_CONFIGURATION, 66
 - CO_LSS_STATE_WAITING, 66
 - CO_LSS_STATE_T, 66
 - coEventRegister_LSS_MASTER, 66
 - coEventRegister_LSS, 66
 - coLssActivateBtrate, 67
 - coLssFastScan, 67
 - coLssFastScanKnownDevice, 67
 - coLssIdentifyNonConfiguredSlaves, 68
 - coLssIdentifyRemoteSlaves, 68
 - coLssInit, 69
 - coLssInquireIdentity, 69
 - coLssInquireNodeId, 69
 - coLssMasterDisable, 69
 - coLssMasterEnable, 70
 - coLssMasterGetInquireData, 70
 - coLssMasterInit, 70

- coLssNonConfigSlave, 70
- coLssSetBitrate, 70
- coLssSetBitrateTable, 71
- coLssSetNodeId, 71
- coLssStoreConfig, 71
- coLssSwitchGlobal, 72
- coLssSwitchSelective, 72
- co_issmaster.c, 72
 - coEventRegister_LSS_MASTER, 74
 - coLssActivateBitrate, 74
 - coLssFastScan, 74
 - coLssFastScanKnownDevice, 74
 - coLssIdentifyNonConfiguredSlaves, 75
 - coLssIdentifyRemoteSlaves, 75
 - coLssInquireIdentity, 76
 - coLssInquireNodeId, 76
 - coLssMasterDisable, 76
 - coLssMasterEnable, 77
 - coLssMasterGetInquireData, 77
 - coLssMasterInit, 77
 - coLssSetBitrate, 77
 - coLssSetBitrateTable, 78
 - coLssSetNodeId, 78
 - coLssStoreConfig, 78
 - coLssSwitchGlobal, 79
 - coLssSwitchSelective, 79
- co_manager.c, 79
 - coEventRegister_MANAGER_BOOTUP, 80
 - coManagerContinueConfigUpdate, 80
 - coManagerContinueOperational, 80
 - coManagerContinueSwUpdate, 81
 - coManagerStart, 81
- co_manager.h, 81
 - CO_EVENT_MANAGER_BOOTUP_T, 82
 - CO_MANAGER_EVENT_BOOTED, 83
 - CO_MANAGER_EVENT_BOOT, 82
 - CO_MANAGER_EVENT_ERROR_NODE, 83
 - CO_MANAGER_EVENT_ERROR_B, 82
 - CO_MANAGER_EVENT_ERROR_C, 83
 - CO_MANAGER_EVENT_ERROR_D, 83
 - CO_MANAGER_EVENT_ERROR_G, 83
 - CO_MANAGER_EVENT_ERROR_J, 83
 - CO_MANAGER_EVENT_ERROR_K, 83
 - CO_MANAGER_EVENT_ERROR_M, 83
 - CO_MANAGER_EVENT_ERROR_N, 83
 - CO_MANAGER_EVENT_ERROR_O, 83
 - CO_MANAGER_EVENT_FAILURE, 83
 - CO_MANAGER_EVENT_FINISHED, 83
 - CO_MANAGER_EVENT_RDY_OPERATIONAL, 83
 - CO_MANAGER_EVENT_UPDATE_CONFIG, 83
 - CO_MANAGER_EVENT_UPDATE_SW, 83
 - CO_MANAGER_EVENT_T, 82
 - coEventRegister_MANAGER_BOOTUP, 83
 - coManagerContinueConfigUpdate, 83
 - coManagerContinueOperational, 84
 - coManagerContinueSwUpdate, 84
 - coManagerStart, 84
- co_mpdo.c, 84
- co_network.c, 84
 - coNetworkGet, 85
- co_network.h, 85
 - CO_EVENT_GW_SDOCLIENT_FCT_T, 86
 - coNetworkGet, 86
- co_nmt.c, 86
 - coEventRegister_NMT, 87
 - coNmtGetNodeId, 87
 - coNmtGetState, 87
 - coNmtInit, 88
 - coNmtLocalStateReq, 88
- co_nmt.h, 88
 - CO_ERRCTRL_BOOTUP_FAILURE, 91
 - CO_ERRCTRL_BOOTUP, 90
 - CO_ERRCTRL_GUARD_FAILED, 91
 - CO_ERRCTRL_HB_FAILED, 91
 - CO_ERRCTRL_HB_STARTED, 90
 - CO_ERRCTRL_MGUARD_FAILED, 91
 - CO_ERRCTRL_MGUARD_TOGGLE, 91
 - CO_ERRCTRL_NEW_STATE, 90
 - CO_ERRCTRL_T, 90
 - CO_EVENT_ERRCTRL_T, 89
 - CO_EVENT_NMT_T, 90
 - CO_NMT_REQ_STATE_OPERATIONAL, 91
 - CO_NMT_REQ_STATE_PREOP, 91
 - CO_NMT_REQ_STATE_RESET_COMM, 91
 - CO_NMT_REQ_STATE_RESET_NODE, 91
 - CO_NMT_REQ_STATE_STOPPED, 91
 - CO_NMT_REQ_STATE_T, 91
 - CO_NMT_STATE_OPERATIONAL, 91
 - CO_NMT_STATE_PREOP, 91
 - CO_NMT_STATE_RESET_COMM, 91
 - CO_NMT_STATE_RESET_NODE, 91
 - CO_NMT_STATE_STOPPED, 91
 - CO_NMT_STATE_UNKNOWN, 91
 - CO_NMT_STATE_T, 91
 - CO_NODE_ID_T, 90
 - coErrorCtrlInit, 91
 - coEventRegister_ERRCTRL, 92
 - coEventRegister_NMT, 92
 - coGuardingMasterStart, 92
 - coGuardingMasterStop, 93
 - coHbConsumerSet, 93
 - coHbConsumerStart, 94
 - coNmtGetNodeId, 94
 - coNmtGetRemoteNodeState, 94
 - coNmtGetState, 94
 - coNmtInhibitActive, 95
 - coNmtInit, 95
 - coNmtLocalStateReq, 95
 - coNmtNodeIsMaster, 96
 - coNmtStateReq, 96
- co_nmtmaster.c, 96
 - coNmtInhibitActive, 97
 - coNmtNodeIsMaster, 97
 - coNmtStateReq, 97
- co_nmtslave.c, 98

- co_odaccess.c, 98
 - coEventRegister_OBJECT_CHANGED, 100
 - coOdDomainAddrSet, 100
 - coOdGetDefaultVal_u16, 100
 - coOdGetDefaultVal_u32, 101
 - coOdGetDefaultVal_u8, 101
 - coOdGetObj_i16, 102
 - coOdGetObj_i32, 102
 - coOdGetObj_i8, 102
 - coOdGetObj_r32, 103
 - coOdGetObj_u16, 103
 - coOdGetObj_u24, 103
 - coOdGetObj_u32, 104
 - coOdGetObj_u40, 104
 - coOdGetObj_u48, 104
 - coOdGetObj_u64, 105
 - coOdGetObj_u8, 105
 - coOdGetObjAddr, 105
 - coOdGetObjAttribute, 105
 - coOdGetObjDescPtr, 106
 - coOdGetObjSize, 106
 - coOdInitOdPtr, 106
 - coOdPutObj_i16, 107
 - coOdPutObj_i32, 107
 - coOdPutObj_i8, 108
 - coOdPutObj_r32, 108
 - coOdPutObj_u16, 108
 - coOdPutObj_u24, 109
 - coOdPutObj_u32, 109
 - coOdPutObj_u40, 109
 - coOdPutObj_u48, 110
 - coOdPutObj_u64, 110
 - coOdPutObj_u8, 110
 - coOdSetCobid, 111
 - coOdVisStringSet, 111
 - icoOdCheckObjAttr, 111
 - icoOdGetObjRecMapData, 112
 - icoOdGetObjTrMapData, 112
- co_odaccess.h, 112
 - CO_ATTR_DEFVAL, 115
 - CO_ATTR_DYNOD, 115
 - CO_ATTR_LIMIT, 115
 - CO_ATTR_MAP_REC, 115
 - CO_ATTR_MAP_TR, 115
 - CO_ATTR_MAP, 115
 - CO_ATTR_NUM, 116
 - CO_ATTR_READ, 116
 - CO_ATTR_STORE, 116
 - CO_ATTR_WRITE, 116
 - CO_DATA_TYPE_T, 117
 - CO_EVENT_OBJECT_CHANGED_FCT_T, 116
 - CO_ODTYPE_ARRAY, 117
 - CO_ODTYPE_STRUCT, 117
 - CO_ODTYPE_VAR, 117
 - CO_ODTYPE_T, 117
 - CO_OS_LOCK_OD, 116
 - CO_OS_UNLOCK_OD, 116
 - coDynOdAddIndex, 117
 - coDynOdAddSubIndex, 117
 - coDynOdInit, 118
 - coDynOdRelease, 118
 - coDynOdSetSubIndexAddr, 118
 - coEventRegister_OBJECT_CHANGED, 119
 - coOdDomainAddrSet, 119
 - coOdGetDefaultVal_u16, 120
 - coOdGetDefaultVal_u32, 120
 - coOdGetDefaultVal_u8, 120
 - coOdGetObj_i16, 121
 - coOdGetObj_i32, 121
 - coOdGetObj_i8, 121
 - coOdGetObj_r32, 122
 - coOdGetObj_u16, 122
 - coOdGetObj_u24, 122
 - coOdGetObj_u32, 123
 - coOdGetObj_u40, 123
 - coOdGetObj_u48, 123
 - coOdGetObj_u64, 124
 - coOdGetObj_u8, 124
 - coOdGetObjAddr, 124
 - coOdGetObjAttribute, 125
 - coOdGetObjDescPtr, 125
 - coOdGetObjSize, 125
 - coOdInitOdPtr, 126
 - coOdPutObj_i16, 126
 - coOdPutObj_i32, 126
 - coOdPutObj_i8, 127
 - coOdPutObj_r32, 127
 - coOdPutObj_u16, 128
 - coOdPutObj_u24, 128
 - coOdPutObj_u32, 128
 - coOdPutObj_u40, 129
 - coOdPutObj_u48, 129
 - coOdPutObj_u64, 129
 - coOdPutObj_u8, 130
 - coOdSetCobid, 130
 - coOdVisStringSet, 130
- co_odindex.h, 131
- co_pdo.c, 131
 - coEventRegister_PDO_REC_EVENT, 132
 - coEventRegister_PDO_SYNC, 132
 - coEventRegister_PDO, 132
 - coPdoObjsMapped, 133
 - coPdoReceiveInit, 133
 - coPdoReqNr, 134
 - coPdoReqObj, 134
 - coPdoTransmitInit, 135
- co_pdo.h, 136
 - CO_EVENT_MPDO_T, 136
 - CO_EVENT_PDO_T, 137
 - coEventRegister_PDO_REC_EVENT, 137
 - coEventRegister_PDO_SYNC, 138
 - coEventRegister_PDO, 137
 - coPdoObjsMapped, 138
 - coPdoReceiveInit, 139
 - coPdoReqNr, 139
 - coPdoReqObj, 140

- coPdoTransmitInit, 140
- co_queue.c, 141
 - coQueueGetNextTransmitMessage, 141
 - coQueueInit, 142
 - coQueueMsgTransmitted, 142
 - coQueueReceiveMessageAvailable, 142
- co_sdo.h, 142
 - CO_EVENT_SDO_CLIENT_DOMAIN_WRITE_T, 144
 - CO_EVENT_SDO_CLIENT_READ_T, 144
 - CO_EVENT_SDO_CLIENT_WRITE_T, 145
 - CO_EVENT_SDO_SERVER_CHECK_WRITE_T, 145
 - CO_EVENT_SDO_SERVER_DOMAIN_WRITE_T, 145
 - CO_EVENT_SDO_SERVER_T, 146
 - coEventRegister_SDO_CLIENT_READ, 146
 - coEventRegister_SDO_CLIENT_WRITE, 147
 - coEventRegister_SDO_SERVER_CHECK_WRITE, 147
 - coEventRegister_SDO_SERVER_READ, 147
 - coEventRegister_SDO_SERVER_WRITE, 147
 - coEventUnregister_SDO_CLIENT_READ, 148
 - coEventUnregister_SDO_CLIENT_WRITE, 148
 - coSdoClientInit, 148
 - coSdoNetworkRead, 149
 - coSdoNetworkWrite, 149
 - coSdoQueueAddTransfer, 150
 - coSdoRead, 151
 - coSdoReadSeg, 151
 - coSdoServerInit, 152
 - coSdoWrite, 152
 - coSdoWriteSeg, 153
- co_sdoblockclient.c, 153
- co_sdoblockserver.c, 153
- co_sdoclient.c, 154
 - coEventRegister_SDO_CLIENT_READ, 154
 - coEventRegister_SDO_CLIENT_WRITE, 155
 - coEventUnregister_SDO_CLIENT_READ, 155
 - coEventUnregister_SDO_CLIENT_WRITE, 155
 - coSdoClientInit, 155
 - coSdoRead, 156
 - coSdoReadSeg, 156
 - coSdoWrite, 157
 - coSdoWriteSeg, 158
- co_sdonetwork.c, 158
 - coSdoNetworkRead, 159
 - coSdoNetworkWrite, 159
- co_sdoqueue.c, 160
 - coSdoQueueAddTransfer, 160
- co_sdoserv.c, 161
 - coEventRegister_SDO_SERVER_CHECK_WRITE, 161
 - coEventRegister_SDO_SERVER_READ, 162
 - coEventRegister_SDO_SERVER_WRITE, 162
 - coSdoServerInit, 162
- co_sleep.c, 163
 - coEventRegister_SLEEP, 163
- coSleepAwake, 163
- coSleepModeActive, 164
- coSleepModeStart, 164
- coSleepRequestSleep, 164
- coSleepWakeUp, 164
- co_sleep.h, 165
 - CO_EVENT_SLEEP_T, 166
 - CO_SLEEP_MODE_CHECK, 166
 - CO_SLEEP_MODE_DOZE, 166
 - CO_SLEEP_MODE OBJECTION, 166
 - CO_SLEEP_MODE_PREPARE, 166
 - CO_SLEEP_MODE_REQUEST_SLEEP, 166
 - CO_SLEEP_MODE_SILENT, 166
 - CO_SLEEP_MODE_T, 166
 - coEventRegister_SLEEP, 166
 - coSleepAwake, 167
 - coSleepModeActive, 167
 - coSleepModeStart, 167
 - coSleepRequestSleep, 168
 - coSleepWakeUp, 168
- co_srd.c, 168
 - coEventRegister_SRD, 169
 - coSrdInit, 169
 - coSrdReleaseConnection, 169
 - coSrdRequestConnection, 170
 - coSrdRequestRegister, 170
 - icoSrdReset, 170
 - icoSrdVarInit, 170
- co_srd.h, 171
 - CO_EVENT_SRD_T, 171
 - CO_SRD_REQ_TYPE_ALL_SDOS, 172
 - CO_SRD_REQ_TYPE_NORMAL, 172
 - CO_SRD_REQ_TYPE_T, 172
 - CO_SRD_RESULT_ALL_REQUEST_SUCCESS, 172
 - CO_SRD_RESULT_ERROR, 172
 - CO_SRD_RESULT_NODE_REQUEST_SUCCESS, 172
 - CO_SRD_RESULT_SUCCESS, 172
 - CO_SRD_RESULT_TIMEOUT, 172
 - CO_SRD_RESULT_T, 172
 - coEventRegister_SRD, 172
 - coSrdInit, 173
 - coSrdReleaseConnection, 173
 - coSrdRequestConnection, 173
 - coSrdRequestRegister, 173
- co_srdo.c, 174
- co_srdo.h, 174
- co_stackinit.c, 174
 - coCanOpenStackVarInit, 175
- co_store.c, 175
- co_store.h, 175
 - CO_EVENT_STORE_T, 176
 - CO_STORE_AREA_ALL, 176
 - CO_STORE_SIGNATURE_LOAD, 176
 - CO_STORE_SIGNATURE_SAVE, 176
- co_sync.c, 176
 - coEventRegister_SYNC_FINISHED, 177

- coEventRegister_SYNC, 177
- coSynclnit, 178
- co_sync.h, 178
 - CO_EVENT_SYNC_FINISHED_T, 179
 - CO_EVENT_SYNC_T, 179
 - coEventRegister_SYNC_FINISHED, 179
 - coEventRegister_SYNC, 179
 - coSynclnit, 180
- co_time.c, 180
 - coEventRegister_TIME, 181
 - coTimeInit, 181
 - coTimeWriteReq, 181
- co_time.h, 182
 - CO_EVENT_TIME_T, 182
 - coEventRegister_TIME, 183
 - coTimeInit, 183
 - coTimeWriteReq, 183
- co_timer, 12
 - actTicks, 12
 - attr, 12
 - pData, 12
 - pFct, 12
 - pNext, 12
 - ticks, 12
- co_timer.c, 184
 - coTimerAttrChange, 184
 - coTimerInit, 185
 - coTimerIsActive, 185
 - coTimerStart, 185
 - coTimerStop, 186
 - coTimerTick, 186
- co_timer.h, 186
 - CO_TIMER_ATTR_ROUNDDOWN_CYCLIC, 188
 - CO_TIMER_ATTR_ROUNDDOWN, 188
 - CO_TIMER_ATTR_ROUNDUP_CYCLIC, 188
 - CO_TIMER_ATTR_ROUNDUP, 188
 - CO_TIMER_ATTR_T, 188
 - CO_TIMER_FCT_T, 187
 - coTimerAttrChange, 188
 - coTimerInit, 188
 - coTimerIsActive, 188
 - coTimerStart, 189
 - coTimerStop, 189
 - coTimerTick, 190
 - xTimer, 187
- co_usdo.c, 190
- co_usdoserv.c, 190
- co_user.c, 191
- co_user.h, 191
 - CO_EVENT_USER_T, 191
- coCanOpenStackDelnit
 - co_canopen.h, 18
- coCanOpenStackInit
 - co_canopen.h, 18
- coCanOpenStackInitPara
 - co_canopen.h, 18
- coCanOpenStackVarInit
 - co_canopen.h, 19
- co_stackinit.c, 175
- coCfgConvToConserve
 - co_cfgman.c, 20
 - co_cfgman.h, 22
- coCfgStart
 - co_cfgman.c, 20
 - co_cfgman.h, 22
- coCommStateEvent
 - co_commtask.c, 25
 - co_commtask.h, 29
- coCommTask
 - co_commtask.c, 25
 - co_commtask.h, 29
- coDynOdAddIndex
 - co_dynod.c, 38
 - co_odaccess.h, 117
- coDynOdAddSubIndex
 - co_dynod.c, 39
 - co_odaccess.h, 117
- coDynOdInit
 - co_dynod.c, 39
 - co_odaccess.h, 118
- coDynOdRelease
 - co_dynod.c, 40
 - co_odaccess.h, 118
- coDynOdSetSubIndexAddr
 - co_dynod.c, 40
 - co_odaccess.h, 118
- coEdsparseAddEdsToRepository
 - co_edsparse.c, 41
- coEdsparseDetectSlaveEds
 - co_edsparse.c, 41
- coEdsparseGetIndexDesc
 - co_edsparse.c, 42
- coEdsparseGetObjectDesc
 - co_edsparse.c, 42
- coEdsparseGetRPdoMapEntry
 - co_edsparse.c, 43
- coEdsparseGetSupportedObjCnt
 - co_edsparse.c, 43
- coEdsparseGetTPdoMapEntry
 - co_edsparse.c, 43
- coEdsparseReadEdsMapping
 - co_edsparse.c, 44
- coEmcyConsumerInit
 - co_emcy.c, 45
 - co_emcy.h, 48
- coEmcyProducerInit
 - co_emcy.c, 45
 - co_emcy.h, 48
- coEmcyWriteReq
 - co_emcy.c, 45
- coErrorCtrlInit
 - co_errctrl.c, 49
 - co_nmt.h, 91
- coEventRegister_CAN_STATE
 - co_commtask.c, 26
 - co_commtask.h, 30

- coEventRegister_CFG_MANAGER
 - co_cfgman.c, [20](#)
 - co_cfgman.h, [23](#)
- coEventRegister_COMM_EVENT
 - co_commtask.c, [26](#)
 - co_commtask.h, [30](#)
- coEventRegister_EMCY_CONSUMER
 - co_emcy.c, [46](#)
 - co_emcy.h, [48](#)
- coEventRegister_EMCY
 - co_emcy.c, [45](#)
 - co_emcy.h, [48](#)
- coEventRegister_ERRCTRL
 - co_errctrl.c, [50](#)
 - co_nmt.h, [92](#)
- coEventRegister_LED_GREEN
 - co_led.c, [57](#)
 - co_led.h, [60](#)
- coEventRegister_LED_RED
 - co_led.c, [57](#)
 - co_led.h, [60](#)
- coEventRegister_LSS_MASTER
 - co_iss.h, [66](#)
 - co_issmaster.c, [74](#)
- coEventRegister_LSS
 - co_iss.c, [62](#)
 - co_iss.h, [66](#)
- coEventRegister_MANAGER_BOOTUP
 - co_manager.c, [80](#)
 - co_manager.h, [83](#)
- coEventRegister_NMT
 - co_nmt.c, [87](#)
 - co_nmt.h, [92](#)
- coEventRegister_OBJECT_CHANGED
 - co_odaccess.c, [100](#)
 - co_odaccess.h, [119](#)
- coEventRegister_PDO_REC_EVENT
 - co_pdo.c, [132](#)
 - co_pdo.h, [137](#)
- coEventRegister_PDO_SYNC
 - co_pdo.c, [132](#)
 - co_pdo.h, [138](#)
- coEventRegister_PDO
 - co_pdo.c, [132](#)
 - co_pdo.h, [137](#)
- coEventRegister_SDO_CLIENT_READ
 - co_sdo.h, [146](#)
 - co_sdoclient.c, [154](#)
- coEventRegister_SDO_CLIENT_WRITE
 - co_sdo.h, [147](#)
 - co_sdoclient.c, [155](#)
- coEventRegister_SDO_SERVER_CHECK_WRITE
 - co_sdo.h, [147](#)
 - co_sdoserv.c, [161](#)
- coEventRegister_SDO_SERVER_READ
 - co_sdo.h, [147](#)
 - co_sdoserv.c, [162](#)
- coEventRegister_SDO_SERVER_WRITE
 - co_sdo.h, [147](#)
 - co_sdoserv.c, [162](#)
- coEventRegister_SLEEP
 - co_sleep.c, [163](#)
 - co_sleep.h, [166](#)
- coEventRegister_SRD
 - co_srd.c, [169](#)
 - co_srd.h, [172](#)
- coEventRegister_SYNC_FINISHED
 - co_sync.c, [177](#)
 - co_sync.h, [179](#)
- coEventRegister_SYNC
 - co_sync.c, [177](#)
 - co_sync.h, [179](#)
- coEventRegister_TIME
 - co_time.c, [181](#)
 - co_time.h, [183](#)
- coEventUnregister_SDO_CLIENT_READ
 - co_sdo.h, [148](#)
 - co_sdoclient.c, [155](#)
- coEventUnregister_SDO_CLIENT_WRITE
 - co_sdo.h, [148](#)
 - co_sdoclient.c, [155](#)
- coGuardingMasterStart
 - co_guarding.c, [55](#)
 - co_nmt.h, [92](#)
- coGuardingMasterStop
 - co_guarding.c, [55](#)
 - co_nmt.h, [93](#)
- coHbConsumerSet
 - co_errctrl.c, [50](#)
 - co_nmt.h, [93](#)
- coHbConsumerStart
 - co_errctrl.c, [50](#)
 - co_nmt.h, [94](#)
- coLedSetGreen
 - co_led.c, [57](#)
 - co_led.h, [60](#)
- coLedSetRed
 - co_led.c, [58](#)
 - co_led.h, [61](#)
- coLedSetState
 - co_led.c, [58](#)
 - co_led.h, [61](#)
- coLssActivateBitrate
 - co_iss.h, [67](#)
 - co_issmaster.c, [74](#)
- coLssFastScan
 - co_iss.h, [67](#)
 - co_issmaster.c, [74](#)
- coLssFastScanKnownDevice
 - co_iss.h, [67](#)
 - co_issmaster.c, [74](#)
- coLssIdentifyNonConfiguredSlaves
 - co_iss.h, [68](#)
 - co_issmaster.c, [75](#)
- coLssIdentifyRemoteSlaves
 - co_iss.h, [68](#)

- co_issmaster.c, 75
- coLssInit
 - co_iss.c, 62
 - co_iss.h, 69
- coLssInquireIdentity
 - co_iss.h, 69
 - co_issmaster.c, 76
- coLssInquireNodeId
 - co_iss.h, 69
 - co_issmaster.c, 76
- coLssMasterDisable
 - co_iss.h, 69
 - co_issmaster.c, 76
- coLssMasterEnable
 - co_iss.h, 70
 - co_issmaster.c, 77
- coLssMasterGetInquireData
 - co_iss.h, 70
 - co_issmaster.c, 77
- coLssMasterInit
 - co_iss.h, 70
 - co_issmaster.c, 77
- coLssNonConfigSlave
 - co_iss.c, 62
 - co_iss.h, 70
- coLssSetBitrate
 - co_iss.h, 70
 - co_issmaster.c, 77
- coLssSetBitrateTable
 - co_iss.h, 71
 - co_issmaster.c, 78
- coLssSetNodeId
 - co_iss.h, 71
 - co_issmaster.c, 78
- coLssStoreConfig
 - co_iss.h, 71
 - co_issmaster.c, 78
- coLssSwitchGlobal
 - co_iss.h, 72
 - co_issmaster.c, 79
- coLssSwitchSelective
 - co_iss.h, 72
 - co_issmaster.c, 79
- coManagerContinueConfigUpdate
 - co_manager.c, 80
 - co_manager.h, 83
- coManagerContinueOperational
 - co_manager.c, 80
 - co_manager.h, 84
- coManagerContinueSwUpdate
 - co_manager.c, 81
 - co_manager.h, 84
- coManagerStart
 - co_manager.c, 81
 - co_manager.h, 84
- coNetworkGet
 - co_network.c, 85
 - co_network.h, 86
- coNmtGetNodeId
 - co_nmt.c, 87
 - co_nmt.h, 94
- coNmtGetRemoteNodeState
 - co_errctrl.c, 51
 - co_nmt.h, 94
- coNmtGetState
 - co_nmt.c, 87
 - co_nmt.h, 94
- coNmtInhibitActive
 - co_nmt.h, 95
 - co_nmtmaster.c, 97
- coNmtInit
 - co_nmt.c, 88
 - co_nmt.h, 95
- coNmtLocalStateReq
 - co_nmt.c, 88
 - co_nmt.h, 95
- coNmtNodesMaster
 - co_nmt.h, 96
 - co_nmtmaster.c, 97
- coNmtStateReq
 - co_nmt.h, 96
 - co_nmtmaster.c, 97
- coOdDomainAddrSet
 - co_odaccess.c, 100
 - co_odaccess.h, 119
- coOdGetDefaultVal_u16
 - co_odaccess.c, 100
 - co_odaccess.h, 120
- coOdGetDefaultVal_u32
 - co_odaccess.c, 101
 - co_odaccess.h, 120
- coOdGetDefaultVal_u8
 - co_odaccess.c, 101
 - co_odaccess.h, 120
- coOdGetObj_i16
 - co_odaccess.c, 102
 - co_odaccess.h, 121
- coOdGetObj_i32
 - co_odaccess.c, 102
 - co_odaccess.h, 121
- coOdGetObj_i8
 - co_odaccess.c, 102
 - co_odaccess.h, 121
- coOdGetObj_r32
 - co_odaccess.c, 103
 - co_odaccess.h, 122
- coOdGetObj_u16
 - co_odaccess.c, 103
 - co_odaccess.h, 122
- coOdGetObj_u24
 - co_odaccess.c, 103
 - co_odaccess.h, 122
- coOdGetObj_u32
 - co_odaccess.c, 104
 - co_odaccess.h, 123
- coOdGetObj_u40

- co_odaccess.c, [104](#)
- co_odaccess.h, [123](#)
- coOdGetObj_u48
 - co_odaccess.c, [104](#)
 - co_odaccess.h, [123](#)
- coOdGetObj_u64
 - co_odaccess.c, [105](#)
 - co_odaccess.h, [124](#)
- coOdGetObj_u8
 - co_odaccess.c, [105](#)
 - co_odaccess.h, [124](#)
- coOdGetObjAddr
 - co_odaccess.c, [105](#)
 - co_odaccess.h, [124](#)
- coOdGetObjAttribute
 - co_odaccess.c, [105](#)
 - co_odaccess.h, [125](#)
- coOdGetObjDescPtr
 - co_odaccess.c, [106](#)
 - co_odaccess.h, [125](#)
- coOdGetObjSize
 - co_odaccess.c, [106](#)
 - co_odaccess.h, [125](#)
- coOdInitOdPtr
 - co_odaccess.c, [106](#)
 - co_odaccess.h, [126](#)
- coOdPutObj_i16
 - co_odaccess.c, [107](#)
 - co_odaccess.h, [126](#)
- coOdPutObj_i32
 - co_odaccess.c, [107](#)
 - co_odaccess.h, [126](#)
- coOdPutObj_i8
 - co_odaccess.c, [108](#)
 - co_odaccess.h, [127](#)
- coOdPutObj_r32
 - co_odaccess.c, [108](#)
 - co_odaccess.h, [127](#)
- coOdPutObj_u16
 - co_odaccess.c, [108](#)
 - co_odaccess.h, [128](#)
- coOdPutObj_u24
 - co_odaccess.c, [109](#)
 - co_odaccess.h, [128](#)
- coOdPutObj_u32
 - co_odaccess.c, [109](#)
 - co_odaccess.h, [128](#)
- coOdPutObj_u40
 - co_odaccess.c, [109](#)
 - co_odaccess.h, [129](#)
- coOdPutObj_u48
 - co_odaccess.c, [110](#)
 - co_odaccess.h, [129](#)
- coOdPutObj_u64
 - co_odaccess.c, [110](#)
 - co_odaccess.h, [129](#)
- coOdPutObj_u8
 - co_odaccess.c, [110](#)
- co_odaccess.h, [130](#)
- coOdSetCobid
 - co_odaccess.c, [111](#)
 - co_odaccess.h, [130](#)
- coOdVisStringSet
 - co_odaccess.c, [111](#)
 - co_odaccess.h, [130](#)
- coPdoObjsMapped
 - co_pdo.c, [133](#)
 - co_pdo.h, [138](#)
- coPdoReceiveInit
 - co_pdo.c, [133](#)
 - co_pdo.h, [139](#)
- coPdoReqNr
 - co_pdo.c, [134](#)
 - co_pdo.h, [139](#)
- coPdoReqObj
 - co_pdo.c, [134](#)
 - co_pdo.h, [140](#)
- coPdoTransmitInit
 - co_pdo.c, [135](#)
 - co_pdo.h, [140](#)
- coQueueGetNextTransmitMessage
 - co_drv.h, [37](#)
 - co_queue.c, [141](#)
- coQueueInit
 - co_commtask.h, [31](#)
 - co_queue.c, [142](#)
- coQueueMsgTransmitted
 - co_drv.h, [37](#)
 - co_queue.c, [142](#)
- coQueueReceiveMessageAvailable
 - co_drv.h, [38](#)
 - co_queue.c, [142](#)
- coSdoClientInit
 - co_sdo.h, [148](#)
 - co_sdoclient.c, [155](#)
- coSdoNetworkRead
 - co_sdo.h, [149](#)
 - co_sdonetwork.c, [159](#)
- coSdoNetworkWrite
 - co_sdo.h, [149](#)
 - co_sdonetwork.c, [159](#)
- coSdoQueueAddTransfer
 - co_sdo.h, [150](#)
 - co_sdoqueue.c, [160](#)
- coSdoRead
 - co_sdo.h, [151](#)
 - co_sdoclient.c, [156](#)
- coSdoReadSeg
 - co_sdo.h, [151](#)
 - co_sdoclient.c, [156](#)
- coSdoServerInit
 - co_sdo.h, [152](#)
 - co_sdoserv.c, [162](#)
- coSdoWrite
 - co_sdo.h, [152](#)
 - co_sdoclient.c, [157](#)

- coSdoWriteSeg
 - co_sdo.h, 153
 - co_sdoclient.c, 158
- coSleepAwake
 - co_sleep.c, 163
 - co_sleep.h, 167
- coSleepModeActive
 - co_sleep.c, 164
 - co_sleep.h, 167
- coSleepModeStart
 - co_sleep.c, 164
 - co_sleep.h, 167
- coSleepRequestSleep
 - co_sleep.c, 164
 - co_sleep.h, 168
- coSleepWakeUp
 - co_sleep.c, 164
 - co_sleep.h, 168
- coSrdInit
 - co_srd.c, 169
 - co_srd.h, 173
- coSrdReleaseConnection
 - co_srd.c, 169
 - co_srd.h, 173
- coSrdRequestConnection
 - co_srd.c, 170
 - co_srd.h, 173
- coSrdRequestRegister
 - co_srd.c, 170
 - co_srd.h, 173
- coSyncInit
 - co_sync.c, 178
 - co_sync.h, 180
- coTimeInit
 - co_time.c, 181
 - co_time.h, 183
- coTimeWriteReq
 - co_time.c, 181
 - co_time.h, 183
- coTimerAttrChange
 - co_timer.c, 184
 - co_timer.h, 188
- coTimerInit
 - co_timer.c, 185
 - co_timer.h, 188
- coTimerIsActive
 - co_timer.c, 185
 - co_timer.h, 188
- coTimerStart
 - co_timer.c, 185
 - co_timer.h, 189
- coTimerStop
 - co_timer.c, 186
 - co_timer.h, 189
- coTimerTick
 - co_timer.c, 186
 - co_timer.h, 190
- codrv_can_generic.c, 192
- codrvCanDisable, 193
- codrvCanDriverHandler, 194
- codrvCanEnable, 194
- codrvCanInit, 194
- codrvCanReInit, 195
- codrvCanReceiveInterrupt, 195
- codrvCanSetBitRate, 195
- codrvCanStartTransmission, 196
- codrvCanTransmitInterrupt, 196
- POLLING, 193
- codrv_cpu_generic.c, 196
- codrvCanSetTxInterrupt, 197
- codrvHardwareCanInit, 197
- codrvHardwareInit, 197
- codrvTimerISR, 197
- codrvTimerSetup, 198
- codrv_error.c, 198
- codrvCanErrorGetFlags, 199
- codrvCanErrorInformStack, 199
- codrvCanDisable
 - co_drv.h, 34
 - codrv_can_generic.c, 193
- codrvCanDriverHandler
 - co_drv.h, 34
 - codrv_can_generic.c, 194
- codrvCanEnable
 - co_drv.h, 34
 - codrv_can_generic.c, 194
- codrvCanErrorGetFlags
 - codrv_error.c, 199
- codrvCanErrorInformStack
 - codrv_error.c, 199
- codrvCanInit
 - co_drv.h, 35
 - codrv_can_generic.c, 194
- codrvCanReInit
 - co_drv.h, 35
 - codrv_can_generic.c, 195
- codrvCanReceiveInterrupt
 - codrv_can_generic.c, 195
- codrvCanSetBitRate
 - co_drv.h, 36
 - codrv_can_generic.c, 195
- codrvCanSetTxInterrupt
 - codrv_cpu_generic.c, 197
- codrvCanStartTransmission
 - co_drv.h, 36
 - codrv_can_generic.c, 196
- codrvCanTransmitInterrupt
 - codrv_can_generic.c, 196
- codrvHardwareCanInit
 - codrv_cpu_generic.c, 197
- codrvHardwareInit
 - co_drv.h, 36
 - codrv_cpu_generic.c, 197
- codrvTimerISR
 - codrv_cpu_generic.c, 197
- codrvTimerSetup

- co_drv.h, 37
- codrv_cpu_generic.c, 198
- data
 - CO_CAN_MSG_T, 10
- days
 - CO_TIME_T, 11
- enabled
 - CO_CAN_COB_T, 9
- extended
 - CO_CAN_COB_T, 9
- handle
 - CO_CAN_MSG_T, 10
- icoEventInit
 - co_event.c, 52
- icoEventIsActive
 - co_event.c, 52
- icoEventStart
 - co_event.c, 52
- icoGuardGetRemoteNodeState
 - co_guarding.c, 56
- icoOdCheckObjAttr
 - co_odaccess.c, 111
- icoOdGetObjRecMapData
 - co_odaccess.c, 112
- icoOdGetObjTrMapData
 - co_odaccess.c, 112
- icoSrdReset
 - co_srd.c, 170
- icoSrdVarInit
 - co_srd.c, 170
- ignore
 - CO_CAN_COB_T, 10
- len
 - CO_CAN_MSG_T, 10
 - PDO_REC_MAP_ENTRY_T, 13
 - PDO_TR_MAP_ENTRY_T, 14
- MSG_OVERWRITE
 - co_datatype.h, 31
- MSG_RET_INHIBIT
 - co_datatype.h, 31
- mapCnt
 - PDO_REC_MAP_TABLE_T, 14
 - PDO_TR_MAP_TABLE_T, 15
- mapEntry
 - PDO_REC_MAP_TABLE_T, 14
 - PDO_TR_MAP_TABLE_T, 15
- msec
 - CO_TIME_T, 11
- numeric
 - PDO_REC_MAP_ENTRY_T, 13
 - PDO_TR_MAP_ENTRY_T, 14
- PDO_REC_MAP_ENTRY_T, 13
 - len, 13
 - numeric, 13
 - pVar, 13
 - routePdo, 13
 - val, 13
- PDO_REC_MAP_TABLE_T, 14
 - mapCnt, 14
 - mapEntry, 14
- PDO_TR_MAP_ENTRY_T, 14
 - len, 14
 - numeric, 14
 - pVar, 15
 - val, 15
- PDO_TR_MAP_TABLE_T, 15
 - mapCnt, 15
 - mapEntry, 15
- pData
 - co_timer, 12
- pFct
 - co_timer, 12
- pNext
 - co_timer, 12
- POLLING
 - codrv_can_generic.c, 193
- pVar
 - PDO_REC_MAP_ENTRY_T, 13
 - PDO_TR_MAP_ENTRY_T, 15
- RET_ALREADY_INITIALIZED
 - co_datatype.h, 32
- RET_CFG_CONVERT_ERROR
 - co_datatype.h, 33
- RET_COB_DISABLED
 - co_datatype.h, 32
- RET_DATA_TYPE_MISMATCH
 - co_datatype.h, 32
- RET_DRV_BUSY
 - co_datatype.h, 33
- RET_DRV_ERROR
 - co_datatype.h, 32
- RET_DRV_TRANS_BUFFER_FULL
 - co_datatype.h, 32
- RET_DRV_WRONG_BITRATE
 - co_datatype.h, 32
- RET_ERROR_PRESENT_DEVICE_STATE
 - co_datatype.h, 33
- RET_ERROR_STORE
 - co_datatype.h, 33
- RET_EVENT_NO_RESSOURCE
 - co_datatype.h, 32
- RET_HARDWARE_ERROR
 - co_datatype.h, 33
- RET_IDX_NOT_FOUND
 - co_datatype.h, 32
- RET_INHIBIT_ACTIVE
 - co_datatype.h, 33
- RET_INTERNAL_ERROR
 - co_datatype.h, 33
- RET_INVALID_NMT_STATE

co_datatype.h, [32](#)
RET_INVALID_NODEID
co_datatype.h, [32](#)
RET_INVALID_PARAMETER
co_datatype.h, [32](#)
RET_MAP_ERROR
co_datatype.h, [33](#)
RET_MAP_LEN_ERROR
co_datatype.h, [33](#)
RET_NETWORK_ID_UNKNOWN
co_datatype.h, [33](#)
RET_NO_COB_AVAILABLE
co_datatype.h, [32](#)
RET_NO_READ_PERM
co_datatype.h, [32](#)
RET_NO_WRITE_PERM
co_datatype.h, [32](#)
RET_NOT_INITIALIZED
co_datatype.h, [32](#)
RET_OD_ACCESS_ERROR
co_datatype.h, [32](#)
RET_OUT_OF_MEMORY
co_datatype.h, [32](#)
RET_OK
co_datatype.h, [32](#)
RET_PARAMETER_INCOMPATIBLE
co_datatype.h, [32](#)
RET_SDO_CHANNEL_IN_USE
co_datatype.h, [33](#)
RET_SDO_CRC_ERROR
co_datatype.h, [32](#)
RET_SDO_DATA_TYPE_NOT_MATCH
co_datatype.h, [32](#)
RET_SDO_INVALID_VALUE
co_datatype.h, [32](#)
RET_SDO_NODE_ID_UNKNOWN
co_datatype.h, [33](#)
RET_SDO_SPLIT_INDICATION
co_datatype.h, [32](#)
RET_SDO_TIMEOUT
co_datatype.h, [32](#)
RET_SDO_TRANSFER_NOT_SUPPORTED
co_datatype.h, [32](#)
RET_SDO_UNKNOWN_CCS
co_datatype.h, [32](#)
RET_SDO_WRONG_BLOCKSIZE
co_datatype.h, [32](#)
RET_SDO_WRONG_SEQ_NR
co_datatype.h, [32](#)
RET_SERVICE_ALREADY_INITIALIZED
co_datatype.h, [33](#)
RET_SERVICE_BUSY
co_datatype.h, [33](#)
RET_SERVICE_NOT_INITIALIZED
co_datatype.h, [33](#)
RET_SUBIDX_NOT_FOUND
co_datatype.h, [32](#)
RET_TOGGLE_MISMATCH
co_datatype.h, [32](#)
RET_VALUE_NOT_AVAILABLE
co_datatype.h, [33](#)
RET_T
co_datatype.h, [32](#)
routePdo
PDO_REC_MAP_ENTRY_T, [13](#)
rtr
CO_CAN_COB_T, [10](#)
ticks
co_timer, [12](#)
val
PDO_REC_MAP_ENTRY_T, [13](#)
PDO_TR_MAP_ENTRY_T, [15](#)
xTimer
co_timer.h, [187](#)