

INSERT THIS SIDE UP, THIS END FIRST. USE BLACK
FELT-TIPPED INK, FILL OVALS COMPLETELY

		↑				↑	
		<input type="radio"/>		<input type="radio"/>		<input type="radio"/>	
		<input type="radio"/> Pulse/ Serial		<input type="radio"/> \$1/\$5 Credit Lines		<div>section 1</div> <div>Select only one Interface Type</div>	
		<input type="radio"/> MDB		<input type="radio"/> \$1-20 Credit Lines			
		<input type="radio"/> RS-232		<input type="radio"/> Always Enabled			
		<input type="radio"/> Parallel		<input type="radio"/> Hi			
		<input type="radio"/> Special 1		<input type="radio"/> Special 2			
<div>section 2</div> <div>Pulses per Dollar (sum of selected values)</div>		<input type="radio"/> 64		<input type="radio"/> 4		<div>Example: For 50 ppd, fill in the ovals for 32, 16, and 2, (32+16+2 = 50)</div>	
		<input type="radio"/> 32		<input type="radio"/> 2			
		<input type="radio"/> 16		<input type="radio"/> 1			
		<input type="radio"/> 8		<input type="radio"/> None			
		<input type="radio"/> 4		<input type="radio"/> 1			
		Pulse Speed: <input type="radio"/> Slow		<input type="radio"/> Fast		<div>section 3</div>	
		Lighted Bezel: <input type="radio"/> Solid On		<input type="radio"/> Flashing			
<div>section 4</div> <div>Select Bills to Enable</div>		<input type="radio"/> Bill 1 (\$1)		<input type="radio"/> Bill 2 (\$5)		<div>Example: To accept USA \$1, \$5, and \$10, fill in the ovals for Bill 1, Bill 2, and Bill 3.</div>	
		<input type="radio"/> Bill 3 (\$10)		<input type="radio"/> Bill 4 (\$20)			
		<input type="radio"/> Bill 5 (\$50)		<input type="radio"/> Bill 6 (\$100)			
		<input type="radio"/> Bill 7		<input type="radio"/> Bill 8			
		<input type="radio"/> Bill 9		<input type="radio"/> Bill 10			
		<input type="radio"/> Bill 11		<input type="radio"/> Bill 12			
		<input type="radio"/> Bill 13		<input type="radio"/> Bill 14			
		Security Level: <input type="radio"/> High		<input type="radio"/> Low		<div>section 5</div>	
		Insert Direction: <input type="radio"/> Face up, Left 1st		<input type="radio"/> All 4 Ways			
		<input type="radio"/>		<input type="radio"/>			

This Configuration Card should be printed on standard copy paper, measuring 6.0 x 2.6 inches (152 x 66 mm).

If printing from a .PDF file, turn off the "shrink to fit" option in your printer settings for proper scale.



PYRAMID TECHNOLOGIES, INC.

CURRENCY VALIDATION EXPERTS