

Modified: Programming Barcodes for DS9208

Configuration name in Utility :	Modified
Last Modified :	09-Feb-21
Windows Filename :	Config File_DS9208_Modified_2021.02.09.scncfg
Plug-in Name :	DS9208-COMMON SR MODELS-025
Report Type :	Only parameters changed from defaults shown



Modified: Programming Barcodes for DS9208

Configuration name in Utility : Modified
Last Modified : 09-Feb-21
Windows Filename : Config File_DS9208_Modified_2021.02.09.scncfg
Plug-in Name : DS9208-COMMON SR MODELS-025
Report Type : Only parameters changed from defaults shown



Set Factory Defaults

Cable Connection Settings

USB

USB Device Type	Default (HID Keyboard Emulation)
Emulate Keypad	Enable
Emulate Keypad with Leading Zero	Enable
Quick Keypad Emulation	Enable

Modify Data- Advanced Data Formatting

Erase All Rules

Begin New Rule

PDF417

String to match at position[1] : %

1. Send ASCII Key <¶>

2. Send All that remains

Save Rule

Begin New Rule

PDF417

String to match at position[1] : @

1. Move To All Patterns and Replace <<RS>> with <[RS]>

Modified: Programming Barcodes for DS9208

Configuration name in Utility : Modified
Last Modified : 09-Feb-21
Windows Filename : Config File_DS9208_Modified_2021.02.09.scncfg
Plug-in Name : DS9208-COMMON SR MODELS-025
Report Type : Only parameters changed from defaults shown



<RS>

End of Message

[

R

S

]

End of Message

2. Skip To Start

3. Move To All Patterns and Replace <<Enter>> with <[CR]>

<Enter>

End of Message

[

C

R

]

End of Message

4. Skip To Start

5. Move To All Patterns and Replace <<LF>> with <[LF]>

<LF>

End of Message

[

Modified: Programming Barcodes for DS9208

Configuration name in Utility : Modified
Last Modified : 09-Feb-21
Windows Filename : Config File_DS9208_Modified_2021.02.09.scncfg
Plug-in Name : DS9208-COMMON SR MODELS-025
Report Type : Only parameters changed from defaults shown



L
F
]
End of Message
6. Skip To Start
7. Send ASCII Key <¶>
8. Send All that remains
Save Rule

General Parameter Settings

System

Country Code Page	UTF-8
Presentation Aiming Pattern	Enable on PDF
PDF Prioritization	Enable PDF Prioritization
Motion Detect Range	Medium Range

Beeper

Beeper Volume	Low
Suppress Power Up Beeps	Suppress Power-Up Beeps
Configuration File	Modified

Firmware:

CAAASS00-007-R02

Modified: Programming Barcodes for DS9208

Configuration name in Utility :	Modified
Last Modified :	09-Feb-21
Windows Filename :	Config File_DS9208_Modified_2021.02.09.scncfg
Plug-in Name :	DS9208-COMMON SR MODELS-025
Report Type :	Only parameters changed from defaults shown



Supported Scanner Models for Plug-in :

2356-9208-0000
DS9208-SR00004CNWW
DS9208-SR00004NNWW
DS9208-SR00004NNY
DS9208-SR0000WCNWW
DS9208-SR0000WNNWW
DS9208-SR00214NNWW
DS9208-SR00254NNWW
DS9208-SR4NNU21ZY