

Rig ID test — which light is which

Finds every fixture on the rig, confirms its type, position and DMX address, and catches missing or mis-addressed units. About 30 minutes, two people: one at the Mac (QLab) and desk, one on stage with this sheet.

Set up	Mantra: import Plantagenet_Players_Base_2026_r1.mtr (Home > Tools > Import Show). QLab: open Plantagenet_Players_Base_2026_r1.qlab5 and check the MANTRA network patch reaches the desk. House and work lights off. GO E2 (all off).
Part 1 · types	GO I1-I4 one at a time. Every fixture of that type comes on together. On stage: count them, check where they are and that they look like the description. GO I5 to clear.
Part 2 · one by one	GO T1 to T40. Each GO lights one fixture and turns off the one before. Call the cue number; on stage tick the three boxes or write what happened. T41 turns the last one off.
Anything wrong	Write it in Notes, carry on, then fix from the fault table on the last page and repeat that cue.

Part 1 · find each type

GO	Type	How to recognise it	Expect	Where they hang now	Counted	OK
I1	C42	Lightsky 8800-C42 LED profile: long body, lens barrel and shutters. Hard-edged beam you can shape.	12	FOH: #1-12		☐
I2	ZOOM	Tour Pro Zoom wash: lens with a zoom, usually barn doors. Soft beam that changes width with zoom.	10	LX1: #13-22		☐
I3	COB	TourCOB PAR: short round can with one big LED chip on the front. Wide soft beam, no zoom.	11	LX2: #23-28 LX1: #29-32 LX2 wall: #39		☐
I4	PIX	PixBar: long thin batten with a row of LED cells.	6	pelmet/LX2: #33-38		☐

The hazer (#40) is not in the sweep: test it on its own with T40. Hazer on the floor upstage. Its test runs it at 50 % - haze, not light. Confirm #38 (PIX) and #39 (COB) are on the rig — if a count is one short, it is probably one of these.

Reading Part 2 (next page)

Line: U1 = desk DMX XLR out; U2 = Art-Net / sACN → node 2.0.0.10 → FOH bar. Address on fixture: the start address the fixture's own display should show, on its line. Mode: the DMX channel mode the fixture must be set to. Lit alone: only this one came on. Right place: it hangs where 'Hangs' says (as installed; C42s are fixed on the FOH bar, #1 at the stage-right end). Right type: it matches the description above.

Part 2 · one fixture at a time

GO	#	Type	Hangs	Fader	Line	Address on fixture	Mode	Lit alone	Right place	Right type	Notes
T1	1	C42	FOH 1	Console 1	U2	A101	11 ch	☐	☐	☐	
T2	2	C42	FOH 2	Console 2	U2	A112	11 ch	☐	☐	☐	
T3	3	C42	FOH 3	Console 3	U2	A123	11 ch	☐	☐	☐	
T4	4	C42	FOH 4	Console 4	U2	A134	11 ch	☐	☐	☐	
T5	5	C42	FOH 5	Console 5	U2	A145	11 ch	☐	☐	☐	
T6	6	C42	FOH 6	Console 6	U2	A156	11 ch	☐	☐	☐	
T7	7	C42	FOH 7	Console 7	U2	A167	11 ch	☐	☐	☐	
T8	8	C42	FOH 8	Console 8	U2	A178	11 ch	☐	☐	☐	
T9	9	C42	FOH 9	Console 9	U2	A189	11 ch	☐	☐	☐	
T10	10	C42	FOH 10	Console 10	U2	A200	11 ch	☐	☐	☐	
T11	11	C42	FOH 11	Console 11	U2	A211	11 ch	☐	☐	☐	
T12	12	C42	FOH 12	Console 12	U2	A222	11 ch	☐	☐	☐	
T13	13	ZOOM	LX1	Console 13	U1	A301	12 ch	☐	☐	☐	
T14	14	ZOOM	LX1	Console 14	U1	A313	12 ch	☐	☐	☐	
T15	15	ZOOM	LX1	Console 15	U1	A325	12 ch	☐	☐	☐	
T16	16	ZOOM	LX1	Console 16	U1	A337	12 ch	☐	☐	☐	
T17	17	ZOOM	LX1	Console 17	U1	A349	12 ch	☐	☐	☐	
T18	18	ZOOM	LX1	Console 18	U1	A361	12 ch	☐	☐	☐	
T19	19	ZOOM	LX1	Console 19	U1	A373	12 ch	☐	☐	☐	
T20	20	ZOOM	LX1	Console 20	U1	A385	12 ch	☐	☐	☐	
T21	21	ZOOM	LX1	Console 21	U1	A397	12 ch	☐	☐	☐	
T22	22	ZOOM	LX1	Console 22	U1	A409	12 ch	☐	☐	☐	
T23	23	COB	LX2	Console 23	U1	A421	6 ch	☐	☐	☐	
T24	24	COB	LX2	Console 24	U1	A427	6 ch	☐	☐	☐	
T25	25	COB	LX2	Wing 1 · 25	U1	A433	6 ch	☐	☐	☐	
T26	26	COB	LX2	Wing 1 · 26	U1	A439	6 ch	☐	☐	☐	
T27	27	COB	LX2	Wing 1 · 27	U1	A445	6 ch	☐	☐	☐	
T28	28	COB	LX2	Wing 1 · 28	U1	A451	6 ch	☐	☐	☐	
T29	29	COB	LX1	Wing 1 · 29	U1	A457	6 ch	☐	☐	☐	
T30	30	COB	LX1	Wing 1 · 30	U1	A463	6 ch	☐	☐	☐	
T31	31	COB	LX1	Wing 1 · 31	U1	A469	6 ch	☐	☐	☐	
T32	32	COB	LX1	Wing 1 · 32	U1	A475	6 ch	☐	☐	☐	
T33	33	PIX	pelmet/LX2	Wing 1 · 33	U1	A001	6 ch	☐	☐	☐	
T34	34	PIX	pelmet/LX2	Wing 1 · 34	U1	A007	6 ch	☐	☐	☐	
T35	35	PIX	pelmet/LX2	Wing 1 · 35	U1	A013	6 ch	☐	☐	☐	
T36	36	PIX	pelmet/LX2	Wing 1 · 36	U1	A019	6 ch	☐	☐	☐	
T37	37	PIX	pelmet/LX2	Wing 2 · 37	U1	A025	6 ch	☐	☐	☐	
T38	38	PIX	pelmet/LX2	Wing 2 · 38	U1	A031	6 ch	☐	☐	☐	
T39	39	COB	LX2 wall	Wing 2 · 39	U1	A481	6 ch	☐	☐	☐	
T40	40	HAZE	floor US	Wing 2 · 40	U1	A487	2 ch	☐	☐	☐	

Fault finding

What you see	Likely cause	Fix
Nothing lights	No power; no DMX on that line; wrong address or mode; desk output cleared or blacked out	Check the fixture has power and shows an address. Check the DMX cable into it. For U2 check the node (2.0.0.10) and that the desk sends the protocol it uses (Art-Net or sACN). On the desk: A L, then GO again.
A different fixture lights	That fixture is set to this fixture's address	Note which one lit. Set each fixture's display to the address in Part 2.
Two fixtures light	Two fixtures share one address	Find the one that is not at 'Hangs' and give it its own address from Part 2.
Right fixture, wrong colour, flicker, strobe or movement	Wrong DMX mode on the fixture	Set the mode in Part 2 (C42 11 ch · Zoom 12 ch · COB 6 ch · PixBar 6 ch · hazer 2 ch).
Everything after one fixture is dead	Broken DMX cable, bad through-port or missing terminator	Swap the cable after the last working fixture; terminate the last fixture on the line.
A sweep count is short	A fixture is missing, off, or on the wrong address	Run that type's fixtures in Part 2 to find which number doesn't light.
Lit, but in the wrong place	Fixture hung in a different position	Note it. C42s cannot be moved: give the unit at each FOH position the address for that position in Part 2. Other types: move it, or note it — the fader label and link map go by fixture number, not position.

Sign-off

Tested by _____ Date _____ All 40 fixtures OK ☐