

TRUSS ADAPTOR

Technical data / extra information sheet

Mechanical Theatre Equipment Compliance Portal

Purpose of this sheet

A technical record template for this equipment. Complete and review it using the actual manufacturer instructions, installation design, inspection records and site assessment. It does not certify an asset or assign a load rating.

1. Equipment identification

Field	Details
Equipment name	Truss Adaptor
Equipment category	Aluminium Truss
Manufacturer / supplier	To be confirmed for the actual asset.
Model / product variant	To be confirmed; include part number and version.
Asset / serial / batch ID	To be completed; attach a photograph of identification markings.
Site / location	To be completed.
Owner / responsible person	To be completed.
Status / record date	Generic template - asset details and approval outstanding. Date: _____

2. Description and typical use

An interface between truss and a stand, hoist, bracket or other support. The adaptor must match the truss geometry and transfer forces through approved contact/attachment locations.

- Identify the actual adaptor and both connected systems.
- Use the approved orientation and restraint; assess the whole connection, not just the adaptor label.

3. Technical data to confirm

Enter confirmed values and the document/drawing reference in the asset record. WLL means working load limit. No numerical load rating is assigned by this sheet.

Parameter	Required confirmation
Adaptor identity	Record manufacturer, model, material and purpose of the interface.
Truss fit	Confirm exact truss series, chord diameter/spacing and permitted attachment nodes.
Other interface	Record stand spigot, hoist point or support connection and its locking arrangement.
Capacity/direction	Confirm load limit, moment/offset allowance and permitted load directions.
Contact/retention	Record saddles, clamps, bolts and anti-lift/anti-rotation features.
Assembly reference	Attach maker instructions or approved connection drawing and fastener settings.
Operating limits	Record all manufacturer/designer restrictions and the approved load arrangement.
Inspection / maintenance	Record pre-use checks, periodic inspections and servicing responsibilities; use the exact product instructions.
Documents / traceability	Attach applicable instructions, drawings, certificates and inspection/examination reports. Record reference and revision.

Important limitation

An adaptor does not make incompatible truss series interchangeable or increase the rating of a stand, hoist or truss.

4. Regulatory and good practice context

Topic	Application to record
Work equipment	Apply relevant PUWER duties for suitability, maintenance, inspection and safe use.
Lifting equipment	Assess the actual role in any lifting system. A fixed support or structural component should not be classified solely from its name or portal category.
Standards / instructions	Identify relevant product/structural standards and any BS EN 17206 machinery interface. Confirm applicable editions and scope; use maker/designer limits.

5. Pre-use and periodic inspection

Use competent personnel and a safe inspection method. These checks support the asset-specific regime; they do not replace maintenance or a statutory thorough examination. Record Pass / Fail / N/A and findings.

Check	What to confirm	Result / notes
Identification/records	Asset and configuration identifiable; instructions and previous defect actions available.	
Fit and seating	Correct contact with truss; no forced fit, packing or local crushing.	
Clamps and retainers	All approved parts fitted and securely locked.	
Adaptor body	No bending, cracked welds, damaged holes or corrosion affecting strength.	
Connected systems	Support and truss are compatible and within the recorded arrangement.	
Change or damage history	Check for overload, impact, modification, repair or changed environment since last assessment.	
Safe function check	Where applicable, verify intended operation using an authorised safe procedure; do not improvise a proof-load test.	
Outcome/actions	Record defects, restrictions and actions; confirm who authorises return to use.	

6. Removal from service triggers

- Distorted adaptor, missing retention, insecure fit or damage at the truss contact.
- Unapproved truss/support combination or a load direction without confirmed capacity.
- Damage, wear, corrosion or malfunction beyond the manufacturer/designer acceptance criteria, or uncertainty about safe condition.
- Suspected overload, significant impact or an unapproved modification: isolate the affected asset pending competent assessment.
- Tag and prevent use of unsafe equipment; record the defect and authorised repair/replacement and reinspection before return.

Inspection planning

Where LOLER applies, record the correct examination interval or a competent person's written scheme. Do not assume that an annual visual check is sufficient for every asset. Include examinations after relevant exceptional events.

7. Site-specific notes and limitations

Topic	Site entry / supporting document reference
Permitted loads / uses	
Prohibited uses / limits	
Location / environment	
Inspection / servicing plan	
Related assets / drawings	

8. Inspection and document record

Date	Check / document	Completed by	Outcome / action

Asset details verified by: _____ Date: _____

Release / approval reference: _____

Reference guidance

[Prolyte - current manuals and product documents \(example brand\)](#)

[HSE - PUWER overview](#)

[HSE - LOLER overview](#)

[HSE - thorough examinations](#)

References reviewed 9 October 2026. Example-brand documents do not identify the asset or approve another manufacturer's product. Keep the exact product manual and installation evidence with the portal record.

Portal document note

Suggested portal path: documents/truss_adaptor_technical_datasheet.pdf. Uploading the file only makes it available; the equipment record must link to this exact filename.