



Annual Haul Out Checklist

Freedom to enjoy



BEFORE HAULING – TRIAL RUN

- ☐ TAKE READINGS AT 500 RPM, INCREMENTS, FIVE-MINUTE INTERVALS.
- ☐ RUN FOR 30 MINUTES AT 80% LOAD (OR 10% BELOW MAXIMUM RPM).
- ☐ RUN AT WIDE OPEN THROTTLE (WOT) FOR 10 MINUTES AND CHECK TEMPS, SMOKE, VIBRATION
- ☐ CHECK SHAFT-SEAL DRIP RATE. IF CONVENTIONAL STUFFING BOX, TAKE TEMP OF HOUSING AT CRUISE. (SHOULD NOT BE HIGHER THAN 20 DEGREES ABOVE SEAWATER TEMP OR 130 MAX.)
- ☐ FOR ALL SEALS, PULL INJECTION HOSE OFF AND CHECK FOR GOOD FLOW OF WATER.

IMMEDIATELY AFTER HAUL OUT – STRUCTURAL

- ☐ SIGHT BOTTOM FOR BLISTERS WHILE PAINT IS WET. IF BLISTERS ARE PRESENT, CHECK BOTTOM WITH MOISTURE METER.
- ☐ LOOK FOR AREAS THAT REMAIN DAMP AFTER SURROUNDING AREAS HAVE DRIED (CAN INDICATE A PROBLEM IN THE LAMINATE)

WHILE ON LAND – BELOW THE WATERLINE

INSPECT BOTTOM PAINT:

- ☐ IF FLAKING, CONSIDER SODA BLASTING.
- ☐ IF SODA BLASTING, GOOD TIME TO APPLY A BARRIER COAT.

APPLYING ABLATIVE PAINT:

- ☐ IF EXISTING, BUILD UP THIN SPOTS WITH 2-3 COATS BEFORE PAINTING BOTTOM
- ☐ IF NEW, FIRST COAT SHOULD BE A DIFFERENT COLOR TO INDICATE WHEN GETTING THIN.

INSPECT THRU-HULLS AND SEACOCKS:

- ☐ COUNT HOLES IN BOTTOM AND ACCOUNT FOR SAME NUMBER OF SEACOCKS INSIDE THE BOAT
- ☐ OPEN AND CLOSE EACH SEACOCK WHILE ON LAND AND SERVICE ANY FROZEN ONES..
- ☐ EXERCISE ALL SEACOCKS 3-4 TIMES PER YEAR.
- ☐ BRONZE SHOULD HAVE A GOLDEN HUE. IF PINK, THERE IS A CORROSION PROBLEM. PINK = WEAKENED. > IF PINK, HAVE A MARINE ELECTRICIAN CHECK EFFECTIVENESS OF SACRIFICIAL ANODES AND FOR STRAY CURRENT (DC)
- ☐ CHECK FOR PITTING OF THE HARDWARE - POINTS TO STRAY CURRENT CORROSION (DC).
- ☐ LOOK FOR "HALOS" AROUND THRU-HULLS (DISTORTIONS IN THE PAINT) INDICATIVE OF EXCESSIVE SACRIFICIAL ANODES OR AC STRAY CURRENT

INSPECT POWER TRAIN: PROP

- ☐ THIN NUT BELONGS AGAINST THE PROP
- ☐ PROP COLOR – GOLDEN HUE, NO PINK

m: 0439 748 387

e: yachtsupport@marinehq.com.au

w: www.marinehq.com.au

Freedom to enjoy





Annual Haul Out Checklist

Freedom to enjoy



BELOW THE WATERLINE (CONT'D.)

- ☐ CHECK CLEARANCE OF BLADES USING A GUIDE CLAMPED TO RUDDER. IF ENGINE HAD VIBRATION DURING TRIAL RUN, CONSIDER PROP SCAN
- ☐ PROPELLER SHOULD ROTATE EASILY (IF NOT, ALIGNMENT OR BEARING PROBLEM) .
- ☐ NO MORE THAN ONE SHAFT DIAMETER DISTANCE BETWEEN FORWARD END OF PROP HUB AND AFT END OF CLOSEST BEARING

CHECK CUTLASS BEARINGS:

- ☐ NO SIDE-TO-SIDE MOVEMENT OF SHAFT
- ☐ LOOK FOR DRIED OR CRACKED RUBBER. CHECK SHAFT SEALS.
- ☐ CONVENTIONAL STUFFING BOX

REPACK IF TEMPS AND DRIP RATE WERE UNACCEPTABLE DURING TRIAL RUN.

- ☐ CHECK FACE SEAL (PSS).

- IF INJECTION NIPPLE IS NYLON, REPLACE WITH STAINLESS.
- REPLACE HOSE EVERY SIX YEARS OR IF CRACKED.
- INSPECT AND CLEAN BETWEEN SEAL AND ROTOR.

SACRIFICIAL ANODES:

- ☐ INSPECT FOR REMAINING METAL. IF ZINC AND NOT EATEN AWAY, CONSIDER CHANGING TO ALUMINUM
 - ZINC: ONLY EFFECTIVE IN SALT WATER. TRACE METALS HARMFUL TO ENVIRONMENT
 - ALUMINUM: EFFECTIVE IN SALT OR BRACKISH AND BETTER FOR ENVIRONMENT
 - MAGNESIUM: USE ONLY IN FRESH WATER
 - DON'T MIX TYPES ON ONE BOAT
 - OK TO HAVE ALUMINUM ON HULL AND ZINCS FOR INTERNAL ENGINE COMPONENTS

- ☐ CINSTALL A GALVANIC ISOLATOR TO PROTECT YOUR ANODES FROM OTHER BOATS IN A MARINA.

HULL, ABOVE THE WATERLINE

- ☐ HULL, ABOVE THE WATERLINE

PROTECT GELCOAT

- ☐ CLEAN AND WAX ANNUALLY.
- ☐ KEEP COMPOUNDING TO A MINIMUM (SANDS AWAY THE GELCOAT).
- ☐ CORED HULLS: MOISTURE-METER CHECK EVERY THREE YEARS

DECK AND CABIN

PROTECT GELCOAT

- ☐ CCHECK WITH MOISTURE METER EVERY THREE YEARS. > RENEW HARDWARE BEDDING EVERY 7-10 YEARS OR AS INDICATED BY MOISTURE CHECK.

AFTER LAUNCHING

- ☐ CHECK ALL SEACOCKS FOR LEAKS AND EASE OF MOVEMENT.
- ☐ FOR DRIPLESS SHAFT SEALS W/BELLOW HOSE, COMPRESS BELLOW TO RELEASE ENTRAPPED AIR.
- ☐ REPEAT WIDE-OPEN-THROTTLE TEST AND RECORD RESULTS.

m: 0439 748 387

e: yachtsupport@marinehq.com.au

w: www.marinahq.com.au

Freedom to enjoy

