

Kabel-ID	Kleur	ESP(Model)/PIN
hallSensorExitStation-1	green	5V
hallSensorExitStation-2	white	GND
hallSensorExitStation-3	red	GIOP 35
hallSensorStartPosition-1	green	5V
hallSensorStartPosition-2	white	GND
hallSensorStartPosition-3	red	GIOP 32
hallSensorEnterStation-1	green	5V
hallSensorEnterStation-2	white	GND
hallSensorEnterStation-3	red	GIOP 34
stationGateServo-oe	red	5V
stationGateServo-rd	blue	GND
stationGateServo-bn	yellow	GIOP 15
hallSensorBottomLifthill-1	green	5V
hallSensorBottomLifthill-2	white	GND
hallSensorBottomLifthill-3	red	GIOP 25
ledExitStation	red	5V
ledExitStation	green	GIOP 21
ledExitStation	blue	GND

mac address: **F8:B3:B7:33:41:FC** **192.168.0.50**

Kabel-ID	Kleur	Driver	ESP(Model)/PIN
stationStepper-be	connector	LN1	GIOP 18
stationStepper-pk-we-pk	connector	LN2	GIOP 19
stationStepper-yw	connector	LN3	GIOP 22
stationStepper-oe-gn-oe	connector	LN4	GIOP 23
stationStepper-rd	connector		
lifthillStepper	driver-Enable	/	GIOP 14
lifthillStepper	driver-Step	/	GIOP 27
lifthillStepper	driver-Direction	/	GIOP 26
enterServo-oe	purple	GPIO 25	
enterServo-rd	brown	5V	
enter-bn	white	GND	

Kabel-ID	Kleur	ESP(Model)/PIN
hallSensorOnTiltdrop-1	black	5V
hallSensorOnTiltdrop-2	white	GND
hallSensorOnTiltdrop-3	yellow	GIOP 34
hallSensorTiltdropClosed-1	black	5V
hallSensorTiltdropClosed-2	white	GND
hallSensorTiltdropClosed-3	red	GIOP 26
hallSensorOffTiltdrop-1	black	5V
hallSensorOffTiltdrop-2	white	GND
hallSensorOffTiltdrop-3	blue	GIOP 27
hallSensorTiltdropOpen-1	black	5V
hallSensorTiltdropOpen-2	white	GND
hallSensorTiltdropOpen-3	green	GIOP 32
ledLifthillTower	red	5V
ledLifthillTower	green	GIOP 14
ledLifthillTower	blue	GND
ledTilt	red	5V
ledTilt	green	GIOP 13
ledTilt	blue	GND
ledDrop	red	5V
ledDrop	green	GIOP 12
ledDrop	blue	GND

Kabel-ID	Kleur	Driver	ESP(Model)/PIN
tiltdropStepper-be	connector	LN1	GIOP 18
tiltdropStepper-pk-we-pk	connector	LN2	GIOP 19
tiltdropStepper-yw	connector	LN3	GIOP 22
tiltdropStepper-oe-gn-oe	connector	LN4	GIOP 23
tiltdropStepper-rd	connector		
releaseServo-oe	yellow	GPIO 33	
releaseServo-rd	red	5V	
releaseServo-bn	black	GND	

mac address ESP2/Tilt_Drop **E8:31:CD:AE:87:4C** **192.168.0.51**

Kabel-ID	Kleur	ESP(Model)/PIN
hallSensorStationConnect-1	black	5V
hallSensorStationConnect-2	blue	GND
hallSensorStationConnect-3	green	GIOP 27
hallSensorBrakeConnect-1	yellow	5V
hallSensorBrakeConnect-2	blue	GND
hallSensorBrakeConnect-3	white/grey	GIOP 26
brakesServo-oe	yellow	GPIO 25
brakesServo-rd	red	5V
brakesServo-bn	black	GND

Kabel-ID	Kleur	ESP(Model)/PIN
hallSensorStationConnect-1	black	5V
hallSensorStationConnect-2	blue	GND
hallSensorStationConnect-3	green	GIOP 27
hallSensorBrakeConnect-1	yellow	5V
hallSensorBrakeConnect-2	blue	GND
hallSensorBrakeConnect-3	white/grey	GIOP 26
hallSensorMiddle-1	black	5V
hallSensorMiddle-2	blue	GND
hallSensorMiddle-3	green	GIOP 25
hallSensorOnSwitchtrack-1	black	5V
hallSensorOnSwitchtrack-2	blue	GND
hallSensorOnSwitchtrack-3	green	GIOP 32
releaseServo-oe	yellow	GPIO 33
releaseServo-rd	black	5V
releaseServo-bn	white	GND

Kabel-ID	Kleur	Driver	ESP(Model)/PIN
RotatingStepper-be	connector	LN1	GIOP 19
RotatingStepper-pk-bk-pk	connector	LN2	GIOP 21
RotatingStepper-yw	connector	LN3	GIOP 22
RotatingStepper-oe-gn-oe	connector	LN4	GIOP 23
RotatingStepper-rd	connector		
TiltingStepper-be	connector	LN1	GIOP 14
TiltingStepper-pk-bk-pk	connector	LN2	GIOP 13
TiltingStepper-yw	connector	LN3	GIOP 15
TiltingStepper-oe-gn-oe	connector	LN4	GIOP 18
TiltingStepper-rd	connector		