H40.50:PC Command

JOG Entry Decision

0 (0/0)

MB00000F — Debug | STORE | [WLFQD]Src 00000 | [WLFQD]Dest MW02020 ---

[MW02020]
.../0022w .../0031 .../0043
.../0092 .../0132 H40.60/0003w
H40.60/0008w H40.60/0017 H40.60/0030
H40.60/0120 GANTRY2/0030 GANTRY2/0065
GANTRY2/0100 GANTRY2/0135 GANTRY2/0170
GANTRY2/0205 GANTRY2/0240 GANTRY2/0275

Button Tag IN

1 (2/5)

FOR | [W]Var DW00020 --- | [W]Init 00000 | [W]Max 00111 | [W]Step 00001

2 (3/9)

NL 2 — EXPRESSION
'I' = 'DW00020'
I = DW00020;

3 (4/11)

NL 2 — MB200220i — [PCTAG]JOG On Signal AX1 | MB200120 — [PCTAG]PC JOG | MB200129 — [PCTAG]PC JOG CW/CCW | MB900000i — Jog Enable(+) | MB101000i — #1 Jog Running

MB200129 — [PCTAG]PC JOG CW/CCW | MB900080i — ---

[MB101000]
.../0018i

4 (11/18)

NL 2 — MB101000i — #1 Jog Running

EXPRESSION
'MW02020' = 'DW00020' + 1
MW02020 = DW00020 + 1;

5 (13/24)

END_FOR

6 (14/25)

!= | [WLFQD]SrcA ML20000 [PCTAG]PC Command Code | [WLFQD]SrcB 00000 | DB000000 — pls | DB000010 — PC Command Pls

[DB000010]
.../0060 .../0070 .../0080

7 (17/31)

!= | [WLFQD]SrcA MW02020 --- | [WLFQD]SrcB 00000 | DB000001 — pls | DB000011 — PC Command Pls(JOG)

[DB000011]
.../0061 .../0071 .../0088
.../0107

8 (20/37)

MB027009 — MCCommandExecCmp | MB02700A — MotionCommandresponseCode(0C- | MB00005A — Running PC Command Exec | TON[10ms] | [W]Set 00003 | [W]Count DW00004 --- | DB000012 — M Command Stop

[DB000012]
.../0053

9 (25/46)

MB00006B — Pls:Stop | DB000013 — Stop

!= | [WLFQD]SrcA MW02020 --- | [WLFQD]SrcB 00000 | DB000002 — pls

[DB000013]
.../0051

10 (29/50)

MB00005A — Running PC Command Exec | DB000013 — Stop | MB000050 — All Servo OFF | GB010101 --- | MB000001 — Stopping | DB000014 — PC Command Stopping

DB000014 — PC Command Stopping | DB000012 — M Command Stop | DB000003 — pls | DB00000B — PC Command Stop Cmp

[DB000014]
.../0052 .../0152 .../0180
.../0196
[DB00000B]
.../0065

11 (39/60)

DB000010 — PC Command Pls | MB00003D — PC COMMAND Cmp | MB000050 — All Servo OFF | DB00000B — PC Command Stop Cmp | MB00000A — Alarm | MB000009 — Alarm Code Check | GB010101 ---

DB000011 — PC Command Pls(JOG)

MB00005A — Running PC Command Exec

MB00005A — Running PC Command Exec

[MB00005A]
.../0039 .../0050 .../0062
.../0109 .../0116 .../0123
.../0130 .../0151 .../0160
.../0195 H20.02/0012 H20.02/0022
H20.02/0024 H20.02/0026 H20.02/0028
H20.02/0030 H20.02/0033 H20.02/0039
H40.10/0004 H40.51/0025 H40.60/0026
H40.60/0037 H40.60/0049 H40.60/0056w
H40.60/0097 H40.60/0104 H40.60/0111
H40.60/0118 H40.60/0132 H40.60/0141
H40.60/0176 H50.10/0015 H70.10/0037
L40.40/0014 L40.41/0007

12 (49/70)

DB000010 — PC Command Pls | SETW | [W]Dest MW02600 --- | [W]Data 00000 | [W]Width 00190

DB000011 — PC Command Pls(JOG) | SETW | [W]Dest MW02200 --- | [W]Data 00000 | [W]Width 00190

[MW02600]
H40.60/0060w
[MW02200]
H40.60/0066w

13 (53/80)

DB000010 — PC Command Pls | COPYW | [W]Src MW20000 [PCTAG]PC Command Code | [W]Dest MW02780 --- | [W]Width 00012

STORE | [WLFQD]Src 00000 | [WLFQD]Dest MW02000 ---

[MW02780]
.../0091w .../0111 .../0118
.../0125 H40.60/0073w H40.60/0081w
H40.60/0099 H40.60/0106 H40.60/0113
[MW02000]
H40.60/0063w

14 (56/88)

DB000011 — PC Command Pls(JOG)

EXPRESSION
```
'MW02780' = 4
MW02780 = 4;
'Axis Index' = 'MW02020'
MW02782 = MW02020;
'Set Torque Over' = '[PCTAG]PCJOG High Speed'
MB027840 = MB200128;
'Jog' = '[PCTAG]PCJOG CW/CCW'
MB027841 = MB200129;
'JOG 0:CW 1:CCW' = 0
MB027842 = 0;
'SyncroMode' = 0
MB027843 = 0;
'ML02786' = 'CW00200'
ML02786 = CW00200;
```

[MW02782]
.../0200 .../0211 .../0215
.../0219 .../0226 H20.04/0048
H20.04/0051 H20.04/0057w H40.60/0083w
H40.60/0180 H40.60/0190 H40.60/0194
H40.60/0201 H50.12/0243 H50.12/0246
H50.14/0072 H50.14/0075 GANTRY1/0001
[MB027840]
H40.60/0085w
[MB027841]
H10.11/0218 H10.11/0335 H10.12/0516
H10.12/0782 H10.13/0544 H10.13/0824
H10.14/0594 H10.14/0899 H10.15/0608
H10.15/0920 H10.16/0600 H10.16/0908
H10.17/0583 H10.17/0889 H10.18/0206
H10.18/0317 H10.19/0629 H10.19/0952
H40.60/0087w H50.42/2753 H50.42/2755
H50.42/2809 H50.42/2811 H50.43/1400
H50.43/1440 H50.43/1489 H50.43/1491
H50.43/1549 H50.44/1438 H50.47/1412
H50.47/1449 H50.47/1486 H50.47/1525
H50.48/1410 H50.48/1443 H50.48/1478
[MB027842]
H40.60/0090w
[MB027843]
.../0147 H40.60/0093w
[ML02786]
H40.60/0095w

15 (58/107)

DB000011 — PC Command Pls(JOG) → DB000088 (S) ---

16 (60/109)

MB00005A — Running PC Command Exec → MB00003D (R) PC COMMAND Cmp

[MB00003D]
.../0063 H40.60/0050 H40.60/0098w

17 (62/111)

== [WLFQD]SrcA MW02780 --- [WLFQD]SrcB 00001 → MB00005C Running ABS Seach
MB00005A Running PC Command Exec
MB00005C Running ABS Seach

[MB00005C]
.../0115 H10.11/0216 H10.11/0333
H10.12/0514 H10.12/0780 H10.13/0542
H10.13/0822 H10.14/0592 H10.14/0897
H10.15/0606 H10.15/0918 H10.16/0598
H10.16/0906 H10.17/0581 H10.17/0887
H10.18/0204 H10.18/0315 H10.19/0627
H10.19/0950 H40.60/0103 H40.60/0105w
H50.12/0256 H50.14/0086

18 (66/118)

== [WLFQD]SrcA MW02780 --- [WLFQD]SrcB 00002 → MB00005D Running Step
MB00005A Running PC Command Exec
MB00005D Running Step

[MB00005D]
.../0122 H40.60/0110 H40.60/0112w
H50.10/0018 H50.12/0251 H50.14/0080

19 (70/125)

== [WLFQD]SrcA MW02780 --- [WLFQD]SrcB 00003 → MB00005E Running Positioning
MB00005A Running PC Command Exec
MB00005E Running Positioning

[MB00005E]
.../0129 .../0143 H40.60/0117
H40.60/0119w H40.60/0128 CNV_JOG/0039
CNV_JOG/0081 CNV_JOG/0123 CNV_JOG/0165
CNV_JOG/0207 CNV_JOG/0249 CNV_JOG/0291
CNV_JOG/0333 CNV_JOG/0379 CNV_JOG/0421

20 (74/132)

!= [WLFQD]SrcA MW02020 --- [WLFQD]SrcB 00000 → MB000059 Jog Driving
MB030951 EQUIP Smoke Detect Sensor 18 Inp- — MB020120 ---

[MB000059]
.../0139 .../0141 .../0145
.../0148 H10.11/0217 H10.11/0219
H10.11/0334 H10.11/0336 H10.12/0515
H10.12/0517 H10.12/0781 H10.12/0783
H10.13/0543 H10.13/0545 H10.13/0823
H10.13/0825 H10.14/0593 H10.14/0595
H10.14/0898 H10.14/0900 H10.15/0607
H10.15/0609 H10.15/0919 H10.15/0921
H10.16/0599 H10.16/0601 H10.16/0907
H10.16/0909 H10.17/0582 H10.17/0584
H10.17/0888 H10.17/0890 H10.18/0205
H10.18/0207 H10.18/0316 H10.18/0318
H10.19/0628 H10.19/0630 H10.19/0951
H10.19/0953 H40.60/0014 H40.60/0021
H40.60/0126w H50.10/0016 H50.12/0252
H50.14/0081 H70.10/0036 L40.40/0015

Syncronized Mode

21 (78/139)

MB000059 Jog Driving — MB200042 ---
MB000059 Jog Driving — MB200136 [PCTAG]Link Mode
MB00005E Running Positioning → MB000021 SyncroMode

[MB000021]
H40.60/0129w

Gantry Single Axis Mode

22 (84/148)

MB000059 Jog Driving — MB200043 ---
MB027843 SyncroMode
MB000059 Jog Driving — MB200137 [PCTAG]Gantry Axis Single Mode
→ MB000022 GantryOneAxisMode

[MB000022]
H40.60/0131w CNV_JOG/0038 CNV_JOG/0080
CNV_JOG/0122 CNV_JOG/0164 CNV_JOG/0206
CNV_JOG/0248 CNV_JOG/0290 CNV_JOG/0332
CNV_JOG/0378 CNV_JOG/0420

MSEE Control

23 (90/151)
MB00005A Running PC Command Exec
DB000014 PC Command Stopping
MB00000A Alarm
MB000002 All Servo On
→ DB000100 ---
[DB000100] .../0165

24 (95/156)
MB032108 ---
MB03210E ---
MB03210F ---
→ MB032140 MP Alarm Occurred
[MB032140] .../0166 H40.60/0140w H40.60/0147

25 (99/160)
MB00005A Running PC Command Exec
DB000004 pls
→ MB032110 ---
[MB032110] H40.60/0143w

26 (102/163)
SB000004 Always ON
→ MB032111 ---
[MB032111] H40.60/0145w

27 (104/165)
DB000100 ---
MB032140 MP Alarm Occurred
→ MB032112 ---
[MB032112] H40.60/0148w

28 (107/168)
MB00006F Pls:Reset
MB032102 ---
→ MB032115 ---
[MB032115] H40.60/0151w

29 (110/171)
SB000004 Always ON
→ MB03211D ---
[MB03211D] H40.60/0153w

30 (112/173)
Interpolated Override

EXPRESSION
```
'MB03211E' = 1
MB03211E = 1;      // MPM00xInterpolation Override
'Machine Override / MPM011 Work Register 3'  = '[PCTAG]EQP Override(%)'
MW03212  = MW20032; // Machine Override
```

[MB03211E] H40.60/0156w
[MW03212] H40.60/0158w

31 (113/178)
Origin Return
MSEE | [W]Program No 00011 | [A]Data MA03210 Call Motion Program

Axis Control

32 (114/180)
DB000014 PC Command Stopping

EXPRESSION
```
'MW02610' = 0
MW02610 = 0; // Motion command
'MW02611' = 0
MW02611 = 0; // Motion sub command

'MW02010' = 0
MW02010 = 0; // Motion command
'MW02011' = 0
MW02011 = 0; // Motion sub command

'MW02210' = 0
MW02210 = 0; // Motion command
'MW02211' = 0
MW02211 = 0; // Motion sub command
```

[MW02611]
H40.60/0166w CPY_PCMD/0098 CPY_PCMD/0133
CPY_PCMD/0174 CPY_PCMD/0209 CPY_PCMD/0244
CPY_PCMD/0279 CPY_PCMD/0314 CPY_PCMD/0349
GANTRY1/0038 GANTRY1/0073 GANTRY1/0114
GANTRY1/0149 GANTRY1/0184 GANTRY1/0219
GANTRY1/0254 GANTRY1/0289 GANTRY3/0283
[MW02010]
H40.60/0168w GANTRY2/0036 GANTRY2/0071
GANTRY2/0106 GANTRY2/0141 GANTRY2/0176
GANTRY2/0211 GANTRY2/0246 GANTRY2/0281
[MW02011]
H40.60/0170w GANTRY2/0038 GANTRY2/0073
GANTRY2/0108 GANTRY2/0143 GANTRY2/0178
GANTRY2/0213 GANTRY2/0248 GANTRY2/0283
[MW02210]
H40.60/0172w GANTRY3/0036 GANTRY3/0071
GANTRY3/0106 GANTRY3/0141 GANTRY3/0176
GANTRY3/0211 GANTRY3/0246
[MW02211]
H40.60/0174w GANTRY3/0038 GANTRY3/0073
GANTRY3/0108 GANTRY3/0143 GANTRY3/0178
GANTRY3/0213 GANTRY3/0248

33 (116/198)
MB00005A Running PC Command Exec
DB000014 PC Command Stopping
MB02600E ABS Runing Panrameter Change
CPY PCMD Copy PC Command Area
[W]AxisIdx MW02782 Axis Index | [B]B-VAL DB000008 Endbit

34 (120/204)
MB000001 Stopping
DB000005 pls
→ MB02600E ABS Runing Panrameter Change
→ MB02600F ABS 실행중(Gantry)
[MB02600E] .../0197
[MB02600F] .../0208 .../0223 H40.60/0186w
H40.60/0187 H40.60/0198 CPY_PCMD/0028
CPY_PCMD/0038 CPY_PCMD/0053 CPY_PCMD/1112

35
124/208

MB02600F
ABS 실행중(Gantry)

GANTRY1
Gantry1 ABS Sensor Search

[W]B-VAL	[B]B-VAL
MW02782 Axis Index	DB00000D ---

GANTRY2
Gantry2 ABS Sensor Search

[W]B-VAL	[B]Endbit
MW02782 Axis Index	DB000009 Endbit

GANTRY3
Gantry3 ABS Sensor Search

[W]B-VAL	[B]Endbit
MW02782 Axis Index	DB00000C ---

36
128/223

MB02600F
ABS 실행중(Gantry)

GET IR
Get Abs Search Sensor

[W]AxisIdx	[B]EndBit
MW02782 Axis Index	DB00000A Endbit
	[B]Sensor1 MB027010 ABS Sensor 1
	[B]Sensor2 MB027011 ABS Sensor 2
	[B]Sensor1 MB027017 ABS Sensor 1(Gantry)
	[B]Sensor2 MB027018 ABS Sensor 2(Gantry)
	[B]Sensor1 MB027019 ABS Sensor 1(Gantry)
	[B]Sensor2 MB02701A ABS Sensor 2(Gantry)

[MB027010] H40.60/0205w	CPY_PCMD/1119w
[MB027011] H40.60/0207w	CPY_PCMD/1121w
[MB027017] H40.60/0209w	CPY_PCMD/1123w
[MB027018] H40.60/0211w	CPY_PCMD/1125w
[MB027019] H40.60/0213w	CPY_PCMD/1127w
[MB02701A] H40.60/0215w	CPY_PCMD/1129w

37
130/242

END