

H40.10: ServoAlarm											
0	0/0	SB000001	TON[1s]	[W]Set 00005	[W]Count DW00044			MB000033	[MB000033] .../0289 .../0312 H40.20/0001	.../0294 .../0317	.../0301 .../0323
		After High S can Start, O nly 1 Scan -						Err.Detec.Va lid			
1	3/4	MB00005A	DB000000					DB00000E	[DB00000E] .../0320	.../0326	
		Running PC Command E xec	Pls					Pls:Running PC Comman d Exec			
2	6/7	FOR	[W]Var DW00025	[W]Init 00000	[W]Max 00111	[W]Step 00001					
3	7/11	NL 2							[DW00020] .../0019		
								EXPRESSION 'I' = 'DW00025' I = DW00025; 'DW00020' = 'DW00025' + 1 DW00020 = DW00025 + 1;			
4	8/16	NL 2	IF	'MB100000i' == true MB100000i == true;							
5	9/18	NL 3						CNV AXIS Convert Axis Index to Line Axis [W]AxisIdx DW00020 --- [B]Endbit DB00000F --- [W]LineNo DW00021 --- [W]AxisNo DW00022 ---	[DW00021] .../0030 .../0084 .../0138 .../0220 .../0240 .../0270 [DW00022] .../0026 .../0215	.../0048 .../0102 .../0120 .../0220 .../0250 .../0260	.../0066 .../0120 .../0230 .../0260
6	10/24	NL 3									
								EXPRESSION 'I' = 'DW00025' I = DW00025; 'J' = (DW00022-1) * 0x80 J = (DW00022-1) * 0x80;			
7	11/30	NL 3	==	[WLFQD]SrcA DW00021	[WLFQD]SrcB 00001				[DW00032] .../0056w .../0110w .../0156 [DW00033] .../0058w .../0112w .../0185 [DW00034] .../0060w .../0114w .../0188 [DL00040] .../0062w .../0116w .../0161 [DL00042] .../0064w .../0118w .../0173	.../0074w .../0128w .../0180 .../0076w .../0130w .../0094w .../0148w .../0078w .../0132w .../0150w .../0080w .../0134w .../0100w .../0154w	.../0092w .../0146w .../0096w .../0150w .../0098w .../0152w .../0100w .../0154w
								EXPRESSION 'DW00030' = 'IW8000j' DW00030 = IW8000j; 'Servo alarm code' = 'IW802Dj' DW00032 = IW802Dj; 'DW00033' = 'IW8008j' DW00033 = IW8008j; 'DW00034' = 'OW8008j' DW00034 = OW8008j; 'Warning' = 'IL8002j' DL00040 = IL8002j; 'Alarm' = 'IL8004j' DL00042 = IL8004j;			
8	13/48	NL 3	==	[WLFQD]SrcA DW00021	[WLFQD]SrcB 00002				[DW00032] .../0038w .../0110w .../0156 [DW00033] .../0040w .../0112w .../0185 [DW00034] .../0042w .../0114w .../0188 [DL00040] .../0044w .../0116w .../0161 [DL00042] .../0046w .../0118w .../0173	.../0074w .../0128w .../0180 .../0076w .../0130w .../0094w .../0148w .../0078w .../0132w .../0150w .../0080w .../0134w .../0100w .../0154w	.../0092w .../0146w .../0096w .../0150w .../0098w .../0152w .../0100w .../0154w
								EXPRESSION 'DW00030' = 'IW8800j' DW00030 = IW8800j; 'Servo alarm code' = 'STR1Y1~Servo alarm code' DW00032 = IW882Dj; 'DW00033' = 'STR1Y1~Motion command response code' DW00033 = IW8808j; 'DW00034' = 'STR1Y1~Motion command' DW00034 = OW8808j; 'Warning' = 'STR1Y1~Warning' DL00040 = IL8802j; 'Alarm' = 'STR1Y1~Alarm' DL00042 = IL8804j;			
9	15/68	NL 3	==	[WLFQD]SrcA DW00021	[WLFQD]SrcB 00005				[DW00032] .../0038w .../0110w .../0156 [DW00033] .../0040w .../0112w .../0185 [DW00034] .../0042w .../0114w .../0188 [DL00040] .../0044w .../0116w .../0161 [DL00042] .../0046w .../0118w .../0173	.../0056w .../0128w .../0180 .../0058w .../0130w .../0060w .../0132w .../0062w .../0134w .../0064w .../0136w	.../0092w .../0146w .../0094w .../0148w .../0096w .../0150w .../0098w .../0152w .../0100w .../0154w
								EXPRESSION 'DW00030' = 'IWA000j' DW00030 = IWA000j; 'Servo alarm code' = 'CX~Servo alarm code' DW00032 = IWA02Dj; 'DW00033' = 'CX~Motion command response code' DW00033 = IWA008j; 'DW00034' = 'CX~Motion command' DW00034 = OWA008j; 'Warning' = 'CX~Warning' DL00040 = ILA002j; 'Alarm' = 'CX~Alarm' DL00042 = ILA004j;			

10	NL 3	==	[WLFQD]SrcA DW00021 ---	[WLFQD]SrcB 00006	EXPRESSION 'DW00030' = 'IWA800j' DW00030 = IWA800j; 'Servo alarm code' = 'SCHY1~Servo alarm code' DW00032 = IWA82Dj; 'DW00033' = 'SCHY1~Motion command response code' DW00033 = IWA808j; 'DW00034' = 'SCHY1~Motion command' DW00034 = OWA808j; 'Warning' = 'SCHY1~Warning' DL00040 = ILA802j; 'Alarm' = 'SCHY1~Alarm' DL00042 = ILA804j;		[DW00032] .../0038w .../0110w .../0156 .../0180 [DW00033] .../0040w .../0112w .../0185 [DW00034] .../0042w .../0114w .../0188 [DL00040] .../0044w .../0116w .../0161 [DL00042] .../0046w .../0118w .../0173	.../0056w .../0128w .../0146w .../0058w .../0130w .../0076w .../0148w .../0060w .../0132w .../0078w .../0150w .../0062w .../0134w .../0080w .../0152w .../0064w .../0136w .../0082w .../0154w			
11	NL 3	==	[WLFQD]SrcA DW00021 ---	[WLFQD]SrcB 00007	EXPRESSION 'DW00030' = 'IWB000j' DW00030 = IWB000j; 'Servo alarm code' = 'BKPBY1~Servo alarm code' DW00032 = IWB02Dj; 'DW00033' = 'BKPBY1~Motion command response code' DW00033 = IWB008j; 'DW00034' = 'BKPBY1~Motion command' DW00034 = OWB008j; 'Warning' = 'BKPBY1~Warning' DL00040 = ILB002j; 'Alarm' = 'BKPBY1~Alarm' DL00042 = ILB004j;		[DW00032] .../0038w .../0092w .../0156 .../0180 [DW00033] .../0040w .../0094w .../0130w .../0185 [DW00034] .../0042w .../0096w .../0132w .../0188 [DL00040] .../0044w .../0098w .../0134w .../0161 [DL00042] .../0046w .../0100w .../0136w .../0173	.../0056w .../0128w .../0146w .../0058w .../0130w .../0076w .../0148w .../0060w .../0132w .../0078w .../0150w .../0062w .../0134w .../0080w .../0152w .../0064w .../0136w .../0082w .../0154w			
12	NL 3	==	[WLFQD]SrcA DW00021 ---	[WLFQD]SrcB 00008	EXPRESSION 'DW00030' = 'IWB800j' DW00030 = IWB800j; 'Servo alarm code' = 'IWB82Dj' DW00032 = IWB82Dj; 'DW00033' = 'IWB808j' DW00033 = IWB808j; 'DW00034' = 'OWB808j' DW00034 = OWB808j; 'Warning' = 'ILB802j' DL00040 = ILB802j; 'Alarm' = 'ILB804j' DL00042 = ILB804j;		[DW00032] .../0038w .../0092w .../0156 .../0180 [DW00033] .../0040w .../0094w .../0112w .../0185 [DW00034] .../0042w .../0096w .../0114w .../0188 [DL00040] .../0044w .../0098w .../0116w .../0161 [DL00042] .../0046w .../0100w .../0118w .../0173	.../0056w .../0110w .../0180 .../0058w .../0112w .../0076w .../0148w .../0060w .../0114w .../0078w .../0150w .../0062w .../0116w .../0080w .../0152w .../0064w .../0118w .../0154w			
13	NL 3	==	[WLFQD]SrcA DW00021 ---	[WLFQD]SrcB 00009	EXPRESSION 'DW00030' = 'IWC000j' DW00030 = IWC000j; 'Servo alarm code' = 'IWC02Dj' DW00032 = IWC02Dj; 'DW00033' = 'IWC008j' DW00033 = IWC008j; 'DW00034' = 'OWC008j' DW00034 = OWC008j; 'Warning' = 'ILC002j' DL00040 = ILC002j; 'Alarm' = 'ILC004j' DL00042 = ILC004j;		[DW00032] .../0038w .../0092w .../0156 .../0180 [DW00033] .../0040w .../0094w .../0112w .../0185 [DW00034] .../0042w .../0096w .../0114w .../0188 [DL00040] .../0044w .../0098w .../0116w .../0161 [DL00042] .../0046w .../0100w .../0118w .../0173	.../0056w .../0110w .../0180 .../0058w .../0112w .../0076w .../0130w .../0060w .../0114w .../0078w .../0132w .../0062w .../0116w .../0080w .../0134w .../0064w .../0118w .../0136w			
14	NL 3	RCHK	[WLFQD]In DW00032 Servo alarm code	[WLFQD]Lower H0090	[WLFQD]Upper H0099	DB000500i Servo Warni ng	[DB000500] .../0183i .../0201i .../0300i				
15	NL 3	!=	[WLFQD]SrcA 00000	[WLFQD]SrcB DL00040 Warning		DB000600i Servo Alarm- 1	[DB000600] .../0196i				
16	NL 3	!=	[WLFQD]SrcA 00000	[WLFQD]SrcB DL00042 Alarm	DB000423 Positive soft limit	DB000424 Negative sof t limit	DB000700i Servo Alarm- 2	[DB000700] .../0197i			
17	NL 3	!=	[WLFQD]SrcA 00000	[WLFQD]SrcB DW00032 Servo alarm code	DB000500i Servo Warni ng		DB000800i Servo Alarm- 3	[DB000800] .../0198i			
18	NL 3		DB000423 Positive soft limit	DB000424 Negative sof t limit	!=	[WLFQD]SrcA DW00033 ---	[WLFQD]SrcB 00009	!=	[WLFQD]SrcA DW00034 ---	[WLFQD]SrcB 00009	[DB000900] .../0203i .../0293i
							DB000900i Soft Limit Al arm				



