

H10.56:IO Management_Unit6									

* DL Register Area - 120Word									
* DW00000 - DW00009 (Pls Use)									
* DW00010 - DW00039 (BIT Use)									
* DW00040 - DW00089 (Word Use)									
* DW00090 - DW00119 (Timer)									

# Program Name : IO Management_Unit6									
#									
# Function :									
#									
# Call Program : H10									
#									
# Sub Program :									
#									
# Func Program :									

Command Bit Operation									
Vaccum									
0	U/U	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00015	[W]Step 00001			
1	1/4	NL				EXPRESSION			
		2				'I' = 'DW00040' I = DW00040;			
2	2/8	NL	MB065840i UNLOADER C ELL TRANSFE R VACUUM -	DB000000i Pls			MB065850i (R)	[MB065850] ../0009i L10.66/0158i	H30.50/0393w L10.66/0199i H50.46/0798 L20.46/0261
3	3/9	NL	MB065850i UNLOADER C ELL TRANSFE R VACUUM -	DB000010i Pls			MB065840i (R)	[MB065840] ../0006i L10.66/0201i	H50.46/0622 L20.46/0257 L10.66/0156i
4	8/12	NL	MB066920i ---	DB000020i Pls			MB066930i ---	[MB066930] ../0015i	L20.46/0389
5	11/18	NL	MB066930i ---	DB000030i Pls			MB066920i (R)	[MB066920] ../0012i	L20.46/0385
6	14/18		END_FOR						
Blow									
7	15/19	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00015	[W]Step 00001			
8	18/23	NL				EXPRESSION			
		2				'I' = 'DW00040' I = DW00040;			
9	17/25	NL	MB065860i Cell Transfer V acuum Break 1 ~3 On	DB000040i Pls			MB065870i (R)	[MB065870] ../0028i L10.66/0244i	H50.46/1134 L10.66/0285i L10.16/0451i L20.46/0517
10	20/28	NL	MB065870i Cell Transfer V acuum Break 1 ~3 Off	DB000050i Pls			MB065860i (R)	[MB065860] ../0025i L10.66/0242i	H50.46/0974 L10.66/0287i L10.16/0390i L20.46/0513
11	23/31	NL	MB066940i ---	DB000060i Pls			MB066950i (R)	[MB066950] ../0034i	L20.46/0645
12	26/34	NL	MB066950i ---	DB000070i Pls			MB066940i (R)	[MB066940] ../0031i	L20.46/0641
13	29/37		END_FOR						
Cylinder									
14	30/38	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00031	[W]Step 00001			
15	31/42	NL				EXPRESSION			
		2				'I' = 'DW00040' I = DW00040;			
16	32/44	NL	MB065800i Unit6 Cylinder 1 Forward (Sol)	DB000080i Pls			MB065820i (R)	[MB065820] ../0047i L10.66/0081i	H50.46/0333 L20.46/0005 L10.66/0008i
17	35/47	NL	MB065820i Unit6 Cylinder 1 Backward (S ol)	DB000090i Pls			MB065800i (R)	[MB065800] ../0044i L10.66/0083i	H50.46/0045 L20.46/0001 L10.66/0006i
18	38/50		END_FOR						
19	39/51				END				