

H10.57-IO Management_Unit7									

* DL Register Area - 120Word									
* DW00000 - DW00009 (Pls Use)									
* DW00010 - DW00039 (BIT Use)									
* DW00040 - DW00089 (Word Use)									
* DW00090 - DW00119 (Timer)									

# Program Name : IO Management_Unit7									
#									
# Function :									
#									
# Call Program : H10									
#									
# Sub Program :									
#									
# Func Program :									

Command Bit Operation									
Vaccum									
0	U/U	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00015	[W]Step 00001			
1	1/4	NL				EXPRESSION			
		2				'I' = 'DW00040' I = DW00040;			
2	2/8	NL	MB070840i	DB000000i			MB070850i	[MB070850]	
		2	Unit7 Vacuum 1 On (Sol) MT R Area1 Vacu-	Pls			Reverse Top V acuum Area 1 Off	.../0009i	H30.50/0400w L10.67/0158i
								H50.47/0813 L20.47/0261	H50.17/0162w L10.67/0199i
3	5/9	NL	MB070850i	DB000010i			MB070840i	[MB070840]	
		2	Reverse Top V acuum Area 1 Off	Pls			Unit7 Vacuum 1 On (Sol) MT R Area1 Vacu-	.../0006i	H50.17/0148w L10.67/0201i
								L10.67/0156i	H50.47/0637 L20.47/0257
4	8/12	NL	MB071920i	DB000020i			MB071930i	[MB071930]	
		2		Pls				.../0015i	L20.47/0389
5	11/18	NL	MB071930i	DB000030i			MB071920i	[MB071920]	
		2		Pls				.../0012i	L20.47/0385
6	14/18		END_FOR						
Blow									
7	15/18	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00015	[W]Step 00001			
8	18/23	NL				EXPRESSION			
		2				'I' = 'DW00040' I = DW00040;			
9	17/25	NL	MB070860i	DB000040i			MB070870i	[MB070870]	
		2	[Sol] MTR Vac uum Break On	Pls			[Sol] MTR Vac uum Break Off	.../0028i	H50.17/0179w L10.67/0244i
								L10.17/0433i L20.47/0517	H50.47/1151 L10.67/0285i
10	20/28	NL	MB070870i	DB000050i			MB070860i	[MB070860]	
		2	[Sol] MTR Vac uum Break Off	Pls			[Sol] MTR Vac uum Break On	.../0025i	H50.17/0175w L10.67/0242i
								L10.17/0375i L20.47/0513	H50.47/0990 L10.67/0287i
11	23/31	NL	MB071940i	DB000060i			MB071950i	[MB071950]	
		2		Pls				.../0034i	L20.47/0645
12	26/34	NL	MB071950i	DB000070i			MB071940i	[MB071940]	
		2		Pls				.../0031i	L20.47/0641
13	29/37		END_FOR						
Cylinder									
14	30/38	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00031	[W]Step 00001			
15	31/42	NL				EXPRESSION			
		2				'I' = 'DW00040' I = DW00040;			
16	32/43	NL	MB070800i	DB000080i			MB070820i	[MB070820]	
		2	Unit7 Cylinder 1 Forward (Sol)	Pls			Unit7 Cylinder 1 Backward (S ol)	.../0047i	H50.47/0349 L20.47/0005
								L10.67/0081i	L10.67/0008i
17	35/47	NL	MB070820i	DB000090i			MB070800i	[MB070800]	
		2	Unit7 Cylinder 1 Backward (S ol)	Pls			Unit7 Cylinder 1 Forward (Sol)	.../0044i	H50.47/0061 L20.47/0001
								L10.67/0083i	L10.67/0006i
18	38/50		END_FOR						
19	39/51					END			