

H10.58:IO Management_Unit8									

* DL Register Area - 120Word									
* DW00000 - DW00009 (Pls Use)									
* DW00010 - DW00039 (BIT Use)									
* DW00040 - DW00089 (Word Use)									
* DW00090 - DW00119 (Timer)									

# Program Name : IO Management_Unit8									
#									
# Function :									
#									
# Call Program : H10									
#									
# Sub Program :									
#									
# Func Program :									

Command Bit Operation									
Vaccum									
0	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00015	[W]Step 00001				
1	NL				EXPRESSION				
					'I' = 'DW00040'				
					I = DW00040;				
2	NL	MB075840i	DB000000i			MB075850i	[MB075850]		
		(Sol) STR1 Va	Pls			(Sol) STR1 Are	.../0009i	H50.18/0063	H50.18/0082w
		cuum 1 On				a1 Vacuum Off	H50.48/0813	L10.68/0158i	L10.68/0238i
							L20.48/0263	L20.48/1935	
3	NL	MB075850i	DB000010i			MB075840i	[MB075840]		
		(Sol) STR1 Are	Pls			(Sol) STR1 Va	.../0006i	H50.18/0053	H50.18/0071w
		a1 Vacuum Off				cuum 1 On	H50.18/0091	H50.48/0637	L10.68/0156i
							L10.68/0240i	L20.48/0259	L20.48/1931
4	NL	MB076920i	DB000020i			MB076930i	[MB076930]		
		(Sol) STR1 Are	Pls			(Sol) STR1 Are	.../0015i	L20.48/0391	L20.48/2063
		a All Vacuum				a All Vacuum			
		On				Off			
5	NL	MB076930i	DB000030i			MB076920i	[MB076920]		
		(Sol) STR1 Are	Pls			(Sol) STR1 Are	.../0012i	L20.48/0387	L20.48/2059
		a All Vacuum				a All Vacuum			
		Off				On			
6	END_FOR								
7	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00015	[W]Step 00001				
8	NL				EXPRESSION				
					'I' = 'DW00040'				
					I = DW00040;				
9	NL	MB075860i	DB000040i			MB075870i	[MB075870]		
		(Sol) STR1 Va	Pls			(Sol) STR1 Va	.../0028i	H50.18/0104w	H50.48/1149
		cuum Break O				cuum Break Of	L10.68/0322i	L10.68/0402i	L20.48/0519
		n				f	L20.48/2191		
10	NL	MB075870i	DB000050i			MB075860i	[MB075860]		
		(Sol) STR1 Va	Pls			(Sol) STR1 Va	.../0025i	H50.18/0099w	H50.48/0989
		cuum Break Of				cuum Break O	L10.18/0580i	L10.68/0320i	L10.68/0404i
		f				n	L20.48/0515	L20.48/2187	
11	NL	MB076940i	DB000060i			MB076950i	[MB076950]		
		---	Pls			---	.../0034i	L20.48/0647	L20.48/2319
12	NL	MB076950i	DB000070i			MB076940i	[MB076940]		
		---	Pls			---	.../0031i	L20.48/0643	L20.48/2315
13	END_FOR								
14	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00031	[W]Step 00001				
15	NL				EXPRESSION				
					'I' = 'DW00040'				
					I = DW00040;				
16	NL	MB075800i	DB000080i			MB075820i	[MB075820]		
		---	Pls			---	.../0047i	H50.48/0349	L10.68/0008i
							L10.68/0081i	L20.48/0007	L20.48/1679
17	NL	MB075820i	DB000090i			MB075800i	[MB075800]		
		---	Pls			---	.../0044i	H50.48/0061	L10.68/0006i
							L10.68/0083i	L20.48/0003	L20.48/1675
18	END_FOR								
19	END								