

H10.58:IO Management_Unit9									

* DL Register Area - 120Word									
* DW00000 - DW00009 (Pls Use)									
* DW00010 - DW00039 (BIT Use)									
* DW00040 - DW00089 (Word Use)									
* DW00090 - DW00119 (Timer)									

# Program Name : IO Management_Unit9									
#									
# Function :									
#									
# Call Program : H10									
#									
# Sub Program :									
#									
# Func Program :									

Command Bit Operation									
Vacuum									
0	U/U	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00015	[W]Step 00001			
1	1/4	NL				EXPRESSION			
		2				'I' = 'DW00040' I = DW00040;			
2	2/8	NL	MB080840i (Sol) SBT Area 1 Vacuum On	DB000000i Pls			MB080850i (R) (Sol) SBT Area 1 Vacuum Off	[MB080850] ../0009i L10.69/0158i	H50.19/0075w L10.69/0199i H50.49/0810 L20.49/0005
3	5/9	NL	MB080850i (Sol) SBT Area 1 Vacuum Off	DB000010i Pls			MB080840i (R) (Sol) SBT Area 1 Vacuum On	[MB080840] ../0006i L10.69/0156i	H50.19/0062w L10.69/0201i H50.49/0633 L20.49/0001
4	8/12	NL	MB081920i Unit9 Vacuum 17 On (Sol)	DB000020i Pls			MB081930i (R) Unit9 Vacuum 17 Off (Sol)	[MB081930] ../0015i	L20.49/0133
5	11/15	NL	MB081930i Unit9 Vacuum 17 Off (Sol)	DB000030i Pls			MB081920i (R) Unit9 Vacuum 17 On (Sol)	[MB081920] ../0012i	L20.49/0129
6	14/18		END_FOR						
Blow									
7	15/19	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00015	[W]Step 00001			
8	18/23	NL				EXPRESSION			
		2				'I' = 'DW00040' I = DW00040;			
9	17/25	NL	MB080860i (Sol) SBT Vac uum Break On	DB000040i Pls			MB080870i (R) (Sol) SBT Vac uum Break Off	[MB080870] ../0028i L10.69/0244i	H50.19/0094w L10.69/0285i H50.49/1148 L20.49/0261
10	20/28	NL	MB080870i (Sol) SBT Vac uum Break Off	DB000050i Pls			MB080860i (R) (Sol) SBT Vac uum Break On	[MB080860] ../0025i L10.69/0242i	H50.19/0089w L10.69/0287i H50.49/0987 L20.49/0257
11	23/31	NL	MB081940i ---	DB000060i Pls			MB081950i (R) ---	[MB081950] ../0034i	L20.49/0389
12	26/34	NL	MB081950i ---	DB000070i Pls			MB081940i (R) ---	[MB081940] ../0031i	L20.49/0385
13	29/37		END_FOR						
Cylinder									
14	30/38	FOR	[W]Var DW00040 ---	[W]Init 00000	[W]Max 00031	[W]Step 00001			
15	31/42	NL				EXPRESSION			
		2				'I' = 'DW00040' I = DW00040;			
16	32/44	NL	MB080800i Unit9 Cylinder 1 Forward (Sol)) SBT Brush -	DB000080i Pls			MB080820i (R) Unit9 Cylinder 1 Backward (Sol)) SBT Brush-	[MB080820] ../0047i L10.69/0008i	H50.49/0345 L10.69/0081i H99.02/2074 L20.49/0513
17	35/47	NL	MB080820i Unit9 Cylinder 1 Backward (Sol)) SBT Brush-	DB000100i Pls			MB080800i (R) Unit9 Cylinder 1 Forward (Sol)) SBT Brush -	[MB080800] ../0044i L10.69/0006i	H50.49/0057 L10.69/0083i H99.02/2055 L20.49/0517
18	38/50		END_FOR						
19	39/51				END				