

L30.02:MC Condition									
Input									
0						COPYW	[W]Src IW0000 ---	[W]Dest MW32000 ---	[W]Width 00004
1						COPYW	[W]Src IW0100 ---	[W]Dest MW32004 ---	[W]Width 00016
2						COPYW	[W]Src IW0110 ---	[W]Dest MW32020 ---	[W]Width 00016
3						COPYW	[W]Src IW0120 ---	[W]Dest MW32036 ---	[W]Width 00016
Output									
4						COPYW	[W]Src OW0000 ---	[W]Dest MW32200 ---	[W]Width 00004
5						COPYW	[W]Src OW0100 ---	[W]Dest MW32204 ---	[W]Width 00016
6						COPYW	[W]Src OW0110 ---	[W]Dest MW32220 ---	[W]Width 00016
7						COPYW	[W]Src OW0120 ---	[W]Dest MW32236 ---	[W]Width 00016
운전 조건									
8		FOR	[W]Var I ---	[W]Init 00000	[W]Max 00111	[W]Step 00001			
9	NL 2	MB100200i Servo Ready # 1							MB325000i Servo Ready : ○
10	NL 2	MB100300i Servo On #1							MB325080i Servo On : ○
11	NL 2	MB100400i LUCX ABS CM P							MB325160i ABS Complete : ○
12		END_FOR							
13		FOR	[W]Var DW00020 ---	[W]Init 00000	[W]Max 00007	[W]Step 00001			
14	NL 2					EXPRESSION 'I' = 'DW00020' * 16 I = DW00020 * 16; 'J' = 'DW00020' * 500 * 16 J = DW00020 * 500 * 16;			
15	NL 2	MB040000j Unit1 Servo O N							MB325240i Unit : Servo On ○ MB325330i Unit : Servo On ○
16	NL 2	MB040001j Unit1 Alarm On							MB325241i Unit : Alarm No thing ○ MB325331i Unit : Alarm No thing ○
17	NL 2	MB040002j Unit1 Warning On							MB325242i Unit : Warning Nothing ○ MB325332i Unit : Warning Nothing ○
18	NL 2	MB040008j Running Unit1 ManuCYL MB040009j Running Unit1 ManuPTP							MB325243i Unit : Dont Ma nual Running ○ MB325333i Unit : Dont Ma nual Running ○
19	NL 2	==	[W]FQD]SrcA MW02610 ---	[W]FQD]SrcB 00000					MB325244i Unit : Dont JO G/STP ○ MB325334i Unit : Dont JO G/STP ○
20	NL 2	MB04000Dj Automatic Drivi ng (Unit1)							MB325245i Unit : Dont Aut o Running ○ MB325335i Unit : Dont Aut o Running ○
21	NL 2	MB04000Bj Unit1 Axis ABS Request							MB325246i Unit : Dont AB S Running ○ MB325336i Unit : Dont AB S Running ○

