

```

00001      " Name:PC Command
00002      " Func:Process the PC Command
00003      " From:H40.50
00004
00005      VAR;
00006      END_VAR;
00007
00008 00000      DB00020 = 0;
00009 00001      IF MB000181 == 1
00010 00002          IF MW02782 == 48 | 49
00011 00003              DB00020 = 1;
00012 00004              IEND;
00013 00005          ELSE;
00014 00006              IF MW02782 == 50 | 51
00015 00007                  DB00020 = 1;
00016 00008                  IEND;
00017 00009              IEND;
00018 00010              IF MB000800 == 1;
00019 00011                  DB00020 = 0;
00020 00012              IEND;
00021
00022 00013      MB02600E = 1;
00023
00024 00014      IF DB00020 == 1
00025 00015          IOW MB49440 == 0;
00026 00016          MB49440 = 1;
00027 00017          EOX;
00028 00018          IF MB030035 == 1
00029 00019      uck          IF !MB030036 == 1
00030 00020                  MW04846 = 6;
00031 00021                  MW04848 = 5;
00032 00022                  IF MB030034 == 1;
00033 00023                      MW04946 = 1;
00034 00024                      MW04948 = 2;
00035 00025                      ELSE;
00036 00026                          MW04946 = 2;
00037 00027                          MW04948 = 1;
00038 00028                          IEND;
00039 00029                          MSEE MPS259;
00040 00030                          IOW MB05686F | MB000800 == 1
00041 00031                      ELSE;
00042 00032                          MW04846 = 2;
00043 00033                          MW04848 = 1;
00044 00034                          IF MB030034 == 1;
00045 00035                              MW04946 = 1;
00046 00036                              MW04948 = 2;
00047 00037                              ELSE;
00048 00038                                  MW04946 = 2;
00049 00039                                  MW04948 = 1;
00050 00040                                  IEND;
00051 00041                                  MSEE MPS259;
00052 00042                                  IOW MB09027F | MB000800 == 1
00053 00043                              IEND;
00054 00044                          IEND;
00055 00045                          MB49440 = 0;
00056 00046                          IF MB030035 == 1;
00057 00047                              IF MB09018E == 1
00058                                  " [Request] Moving Position
00059                                  ML16102 = ML45138;
00060                                  ML16104 = ML45238;
00061                                  ML16106 = ML45338;
00062                                  ML16108 = ML45438;
00063                                  ML16110 = ML45538;
00064                                  ML16112 = ML45638;
00065                                  ML16114 = ML45738;
00066                                  ML16116 = ML45838;
00067                                  MOV [SCH1Z]ML16102 [SCH2Z]ML16104 [SCH3Z]ML16106 [SCH4Z]ML16108
00068                                  [SCH5Z]ML16110 [SCH6Z]ML16112 [SCH7Z]ML16114 [SCH8Z]ML16116;
00069                                  IOW MB04574C == 1
00070                                  " All SCHZ Moving Pos Check
00071                                  ELSE;
00072                                  " [Request] Vacuum Position
00073                                  ML16102 = ML70206;
00074                                  ML16104 = ML70406;
00075                                  ML16106 = ML70606;
00076                                  ML16108 = ML70806;
00077                                  ML16110 = ML71006;
00078                                  ML16112 = ML71206;
00079                                  ML16114 = ML71406;
00080                                  ML16116 = ML71606;
00081                                  MOV [SCH1Z]ML16102 [SCH2Z]ML16104 [SCH3Z]ML16106 [SCH4Z]ML16108
00082                                  [SCH5Z]ML16110 [SCH6Z]ML16112 [SCH7Z]ML16114 [SCH8Z]ML16116;
00083                                  IOW MB04574B == 1
00084                                  " All SCHZ Vacuum Pos Check
00085                                  MB09048E = 1;
00086                                  " [Sol] SCT Scribe Chuck All Vacuum On
00087                                  IOW MB09018E == 1
00088                                  " [Sensor] SCT Scribe Chuck All Vacuum On

```

```

00087      " [Request] Moving Position
00088 00071      ML16102 = ML45138;
00089 00072      ML16104 = ML45238;
00090 00073      ML16106 = ML45338;
00091 00074      ML16108 = ML45438;
00092 00075      ML16110 = ML45538;
00093 00076      ML16112 = ML45638;
00094 00077      ML16114 = ML45738;
00095 00078      ML16116 = ML45838;
00096 00079      MOV [SCH1Z]ML16102 [SCH2Z]ML16104 [SCH3Z]ML16106 [SCH4Z]ML16108
00097      [SCH5Z]ML16110 [SCH6Z]ML16112 [SCH7Z]ML16114 [SCH8Z]ML16116;
00098 00080      IOW MB04574C == 1      " All SCHZ Moving Pos Chec
00099 00081      IEND;
00100 00082      ELSE;
00101 00083      MB09052E = 1;      " [Sol] SCT Scribe Chuck All Vacuum Off
00102 00084      MB090560 = 1;      " [Sol] SCT Scribe Chuck 1,2,3,4 Blow On
00103 00085      IOW MB09022E" & MB090260" == 1      " [Sensor] SCT Scribe Chuck All Vacuum Off
00104      " [Sensor] SCT Scribe Chuck 1,2,3,4 Blow On
00105 00086      TIM TMW26214;      " Scribe Chuck Vacuum Break Complete Timer
00106 00087      MB090600 = 1;      " [Sol] SCT Scribe Chuck 1,2,3,4 Blow Off
00107 00088      IOW MB090300 == 1      " [Sensor] SCT Scribe Chuck 1,2,3,4 Blow Off
00108
00109      " [Request] Standby Position
00110 00089      ML16102 = ML45130;
00111 00090      ML16104 = ML45230;
00112 00091      ML16106 = ML45330;
00113 00092      ML16108 = ML45430;
00114 00093      ML16110 = ML45530;
00115 00094      ML16112 = ML45630;
00116 00095      ML16114 = ML45730;
00117 00096      ML16116 = ML45830;
00118 00097      MOV [SCH1Z]ML16102 [SCH2Z]ML16104 [SCH3Z]ML16106 [SCH4Z]ML16108
00119      [SCH5Z]ML16110 [SCH6Z]ML16112 [SCH7Z]ML16114 [SCH8Z]ML16116;
00120 00098      IOW MB04574A == 1      " All SCHZ Standby Pos Check
00121 00099      IEND;
00122 00100      IEND;
00123
00124 00101      MB02600E = 0;      " ABS Runing Panrameter Change
00125
00126 00102      SFORK      MW02780 == 1 ? Label1      " ABS Origin Search
00127      MW02780 == 2 ? Label2      " Step
00128      MW02780 == 3 ? Label3      " Axis Positioning
00129      MW02780 == 4 ? Label4      " Jog
00130      DEFAULT ? LabelD;
00131
00132 00103      Label1:
00133 00104      MSEE MPS113;      " ABS Origin Searc
00134 00105      JOINTO LabelX;
00135 00106      Label2:
00136 00107      MSEE MPS111;      " Step Contro
00137 00108      JOINTO LabelX;
00138 00109      Label3:
00139 00110      MSEE MPS112;      " Axis Positionin
00140 00111      JOINTO LabelX;
00141 00112      Label4:
00142 00113      MSEE MPS116;      " Jog Contro
00143 00114      JOINTO LabelX;
00144 00115      LabelD:
00145 00116      JOINTO LabelX;
00146 00117      LabelX: SJOINT;
00147
00148 00118      IOW MB49440 == 0;
00149 00119      MB49440 = 1;
00150
00151 00120      MW04846 = 10;      " [Cutting, Break] Table Vacuum Non
00152 00121      MW04848 = 6;      " [Cutting, Break] Table Blow Off
00153 00122      MW04946 = 10;      " [Fix] Table Vacuum Non
00154 00123      MW04948 = 2;      " [Fix] Table Blow Off
00155
00156 00124      MSEE MPS259;      " Table Vacuum-Blow Operation DWG
00157
00158 00125      MB49440 = 0;
00159
00160 00126      MB00003D = 1;      " PC COMMAND Complete
00161
00162 00127      END;

```