

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : SC Manual (Sol)
00011 "# Functior :
00012 "# Call Program : H60.2
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017
00018 END_VAR;
00019
00020 *****
00021 ***** Vaccum *****
00022 *****
00023 00000 SFORK MW00041 == 1 ? LBL01 " Scribe Chuck 1 Vacuum On
00024 MW00041 == 2 ? LBL02 " Scribe Chuck 1 Vacuum Off
00025 MW00041 == 3 ? LBL03 " Scribe Chuck 2 Vacuum On
00026 MW00041 == 4 ? LBL04 " Scribe Chuck 2 Vacuum Off
00027 MW00041 == 5 ? LBL05 " Scribe Chuck 3 Vacuum On
00028 MW00041 == 6 ? LBL06 " Scribe Chuck 3 Vacuum Off
00029 MW00041 == 7 ? LBL07 " Scribe Chuck 4 Vacuum On
00030 MW00041 == 8 ? LBL08 " Scribe Chuck 4 Vacuum Off
00031 DEFAULT ? LBL500;
00032
00033 00001 LBL01: " Scribe Chuck 1 Vacuum On
00034 00002 MB09052E = 0;
00035 00003 MB090480 = 1;
00036 00004 MB090520 = 0;
00037 00005 JOINTO LBL0X;
00038
00039 00006 LBL02: " Scribe Chuck 1 Vacuum Off
00040 00007 MB09048E = 0;
00041 00008 MB090480 = 0;
00042 00009 MB090520 = 1;
00043 00010 JOINTO LBL0X;
00044
00045 00011 LBL03: " Scribe Chuck 2 Vacuum On
00046 00012 MB09052E = 0;
00047 00013 MB090481 = 1;
00048 00014 MB090521 = 0;
00049 00015 JOINTO LBL0X;
00050
00051 00016 LBL04: " Scribe Chuck 2 Vacuum Off
00052 00017 MB09048E = 0;
00053 00018 MB090481 = 0;
00054 00019 MB090521 = 1;
00055 00020 JOINTO LBL0X;
00056
00057 00021 LBL05: " Scribe Chuck 3 Vacuum On
00058 00022 MB09052E = 0;
00059 00023 MB090482 = 1;
00060 00024 MB090522 = 0;
00061 00025 JOINTO LBL0X;
00062
00063 00026 LBL06: " Scribe Chuck 3 Vacuum Off
00064 00027 MB09048E = 0;
00065 00028 MB090482 = 0;
00066 00029 MB090522 = 1;
00067 00030 JOINTO LBL0X;
00068
00069 00031 LBL07: " Scribe Chuck 4 Vacuum On
00070 00032 MB09052E = 0;
00071 00033 MB090483 = 1;
00072 00034 MB090523 = 0;
00073 00035 JOINTO LBL0X;
00074
00075 00036 LBL08: " Scribe Chuck 4 Vacuum Off
00076 00037 MB09048E = 0;
00077 00038 MB090483 = 0;
00078 00039 MB090523 = 1;
00079 00040 JOINTO LBL0X;
00080
00081 00041 LBL500:
00082 00042 JOINTO LBL0X;
00083 00043 LBL0X: SJOINT;
00084
00085 00044 SFORK MW00041 == 9 ? LBL09 " Vacuum On
00086 MW00041 == 10 ? LBL10 " Vacuum Off
00087 MW00041 == 11 ? LBL11 " Vacuum On

```

```

00088          MW00041 == 12 ? LBL12      " Vacuum Off
00089          MW00041 == 13 ? LBL13      " Vacuum On
00090          MW00041 == 14 ? LBL14      " Vacuum Off
00091          MW00041 == 15 ? LBL15      " Vacuum On
00092          MW00041 == 16 ? LBL16      " Vacuum Off
00093          DEFAULT      ? LBL501;
00094
00095 00045      LBL09:      " Vacuum On
00096 00046          MB090484 = 1;
00097 00047          MB090524 = 0;
00098 00048          JOINTO LBL1X;
00099
00100 00049      LBL10:      " Vacuum Off
00101 00050          MB090484 = 0;
00102 00051          MB090524 = 1;
00103 00052          JOINTO LBL1X;
00104
00105 00053      LBL11:      " Vacuum On
00106 00054          MB090485 = 1;
00107 00055          MB090525 = 0;
00108 00056          JOINTO LBL1X;
00109
00110 00057      LBL12:      " Vacuum Off
00111 00058          MB090485 = 0;
00112 00059          MB090525 = 1;
00113 00060          JOINTO LBL1X;
00114
00115 00061      LBL13:      " Vacuum On
00116 00062          MB090486 = 1;
00117 00063          MB090526 = 0;
00118 00064          JOINTO LBL1X;
00119
00120 00065      LBL14:      " Vacuum Off
00121 00066          MB090486 = 0;
00122 00067          MB090526 = 1;
00123 00068          JOINTO LBL1X;
00124
00125 00069      LBL15:      " Vacuum On
00126 00070          MB090487 = 1;
00127 00071          MB090527 = 0;
00128 00072          JOINTO LBL1X;
00129
00130 00073      LBL16:      " Vacuum Off
00131 00074          MB090487 = 0;
00132 00075          MB090527 = 1;
00133 00076          JOINTO LBL1X;
00134
00135 00077      LBL501:
00136 00078          JOINTO LBL1X;
00137 00079      LBL1X: SJOINT;
00138
00139
00140
00141 00080      SFORK      MW00041 == 17 ? LBL17      " Fix Table Vacuum 1 On
00142          MW00041 == 18 ? LBL18      " Fix Table Vacuum 1 Off
00143          MW00041 == 19 ? LBL19      " Fix Table Vacuum 2 On
00144          MW00041 == 20 ? LBL20      " Fix Table Vacuum 2 Off
00145          MW00041 == 21 ? LBL21      " Vacuum On
00146          MW00041 == 22 ? LBL22      " Vacuum Off
00147          MW00041 == 23 ? LBL23      " Vacuum On
00148          MW00041 == 24 ? LBL24      " Vacuum Off
00149          DEFAULT      ? LBL502;
00150
00151 00081      LBL17:      " Fix Table Vacuum 1 On
00152 00082          MB09052F = 0;
00153 00083          MB090488 = 1;
00154 00084          MB090528 = 0;
00155
00156 00085          JOINTO LBL2X;
00157
00158 00086      LBL18:      " Fix Table Vacuum 1 Off
00159 00087          MB09048F = 0;
00160 00088          MB090488 = 0;
00161 00089          MB090528 = 1;
00162
00163 00090          JOINTO LBL2X;
00164
00165 00091      LBL19:      " Fix Table Vacuum 2 On
00166 00092          MB09052F = 0;
00167 00093          MB090489 = 1;
00168 00094          MB090529 = 0;
00169
00170 00095          JOINTO LBL2X;
00171
00172 00096      LBL20:      " Fix Table Vacuum 2 Off
00173 00097          MB09048F = 0;
00174 00098          MB090489 = 0;

```

```

00175 00099      MB090529 = 1;
00176
00177 00100      JOINTO LBL2X;
00178
00179 00101      LBL21:                                " Vacuum On
00180
00181 00102      MB09048A = 1;
00182 00103      MB09052A = 0;
00183
00184 00104      JOINTO LBL2X;
00185
00186 00105      LBL22:                                " Vacuum Off
00187
00188 00106      MB09048A = 0;
00189 00107      MB09052A = 1;
00190
00191 00108      JOINTO LBL2X;
00192
00193 00109      LBL23:                                " Vacuum On
00194
00195 00110      MB09048B = 1;
00196 00111      MB09052B = 0;
00197
00198 00112      JOINTO LBL2X;
00199
00200 00113      LBL24:                                " Vacuum Off
00201
00202 00114      MB09048B = 0;
00203 00115      MB09052B = 1;
00204
00205 00116      JOINTO LBL2X;
00206
00207 00117      LBL502:
00208 00118      JOINTO LBL2X;
00209 00119      LBL2X: SJOINT;
00210
00211
00212 00120      SFORK  MW00041 == 25 ? LBL25          " Vacuum On
00213                  MW00041 == 26 ? LBL26          " Vacuum Off
00214                  MW00041 == 27 ? LBL27          " Vacuum On
00215                  MW00041 == 28 ? LBL28          " Vacuum Off
00216                  MW00041 == 29 ? LBL29          " Scribe Chuck All Vacuum On
00217                  MW00041 == 30 ? LBL30          " Scribe Chuck All Vacuum Off
00218                  MW00041 == 31 ? LBL31          " Fix Table All Vacuum On
00219                  MW00041 == 32 ? LBL32          " Fix Table All Vacuum Off
00220                  DEFAULT ? LBL503;
00221
00222 00121      LBL25:                                " Vacuum On
00223 00122      MB09048C = 1;
00224 00123      MB09052C = 0;
00225 00124      JOINTO LBL3X;
00226
00227 00125      LBL26:                                " Vacuum Off
00228 00126      MB09048C = 0;
00229 00127      MB09052C = 1;
00230 00128      JOINTO LBL3X;
00231
00232 00129      LBL27:                                " Vacuum On
00233 00130      MB09048D = 1;
00234 00131      MB09052D = 0;
00235 00132      JOINTO LBL3X;
00236
00237 00133      LBL28:                                " Vacuum Off
00238 00134      MB09048D = 0;
00239 00135      MB09052D = 1;
00240 00136      JOINTO LBL3X;
00241
00242 00137      LBL29:                                " Scribe Chuck All Vacuum On
00243 00138      MB09048E = 1;
00244 00139      MB09052E = 0;
00245 00140      JOINTO LBL3X;
00246
00247 00141      LBL30:                                " Scribe Chuck All Vacuum Off
00248 00142      MB09048E = 0;
00249 00143      MB09052E = 1;
00250 00144      JOINTO LBL3X;
00251
00252 00145      LBL31:                                " Fix Table All Vacuum On
00253 00146      MB09048F = 1;
00254 00147      MB09052F = 0;
00255 00148      JOINTO LBL3X;
00256
00257 00149      LBL32:                                " Fix Table All Vacuum Off
00258 00150      MB09048F = 0;
00259 00151      MB09052F = 1;
00260 00152      JOINTO LBL3X;
00261

```

```

00262 00153      LBL503:
00263 00154          JOINTO LBL3X;
00264 00155      LBL3X: SJOINT;
00265
00266
00267 00156      SFORK    MW00041 == 33 ? LBL33      " Cutting Table Vacuum 1 On
00268                      MW00041 == 34 ? LBL34      " Cutting Table Vacuum 1 Off
00269                      MW00041 == 35 ? LBL35      " Cutting Table Vacuum 2 On
00270                      MW00041 == 36 ? LBL36      " Cutting Table Vacuum 2 Off
00271                      MW00041 == 37 ? LBL37      " Cutting Table Vacuum 3 On
00272                      MW00041 == 38 ? LBL38      " Cutting Table Vacuum 3 Off
00273                      MW00041 == 39 ? LBL39      " Cutting Table Vacuum 4 On
00274                      MW00041 == 40 ? LBL40      " Cutting Table Vacuum 4 Off
00275                      DEFAULT      ? LBL504;
00276
00277 00157      LBL33:      " Cutting Table Vacuum 1 On
00278                      MB09053F = 0;
00279 00159                      MB090490 = 1;
00280 00160                      MB090530 = 0;
00281 00161                      JOINTO LBL4X;
00282
00283 00162      LBL34:      " Cutting Table Vacuum 1 Off
00284                      MB09049F = 0;
00285 00164                      MB090490 = 0;
00286 00165                      MB090530 = 1;
00287 00166                      JOINTO LBL4X;
00288
00289 00167      LBL35:      " Cutting Table Vacuum 2 On
00290                      MB09053F = 0;
00291 00169                      MB090491 = 1;
00292 00170                      MB090531 = 0;
00293 00171                      JOINTO LBL4X;
00294
00295 00172      LBL36:      " Cutting Table Vacuum 2 Off
00296                      MB09049F = 0;
00297 00174                      MB090491 = 0;
00298 00175                      MB090531 = 1;
00299 00176                      JOINTO LBL4X;
0300
00301 00177      LBL37:      " Cutting Table Vacuum 3 On
00302                      MB09053F = 0;
00303 00179                      MB090492 = 1;
00304 00180                      MB090532 = 0;
00305 00181                      JOINTO LBL4X;
0306
00307 00182      LBL38:      " Cutting Table Vacuum 3 Off
00308                      MB09049F = 0;
00309 00184                      MB090492 = 0;
00310 00185                      MB090532 = 1;
00311 00186                      JOINTO LBL4X;
0312
00313 00187      LBL39:      " Cutting Table Vacuum 4 On
00314                      MB09053F = 0;
00315 00189                      MB090493 = 1;
00316 00190                      MB090533 = 0;
00317 00191                      JOINTO LBL4X;
0318
00319 00192      LBL40:      " Cutting Table Vacuum 4 Off
00320                      MB09049F = 0;
00321 00194                      MB090493 = 0;
00322 00195                      MB090533 = 1;
00323 00196                      JOINTO LBL4X;
0324
00325 00197      LBL504:
00326 00198          JOINTO LBL4X;
00327 00199      LBL4X: SJOINT;
00328
00329
00330 00200      SFORK    MW00041 == 41 ? LBL41      " Vacuum On
00331                      MW00041 == 42 ? LBL42      " Vacuum Off
00332                      MW00041 == 43 ? LBL43      " Vacuum On
00333                      MW00041 == 44 ? LBL44      " Vacuum Off
00334                      MW00041 == 45 ? LBL45      " Vacuum On
00335                      MW00041 == 46 ? LBL46      " Vacuum Off
00336                      MW00041 == 47 ? LBL47      " Vacuum On
00337                      MW00041 == 48 ? LBL48      " Vacuum Off
00338                      DEFAULT      ? LBL505;
00339
00340 00201      LBL41:      " Vacuum On
00341                      MB090494 = 1;
00342 00203                      MB090534 = 0;
00343 00204                      JOINTO LBL5X;
0344
00345 00205      LBL42:      " Vacuum Off
00346                      MB090494 = 0;
00347 00207                      MB090534 = 1;
00348 00208                      JOINTO LBL5X;

```

```

00349
00350 00209      LBL43:                " Vacuum On
00351 00210          MB090495 = 1;
00352 00211          MB090535 = 0;
00353 00212          JOINTO LBL5X;
00354
00355 00213      LBL44:                " Vacuum Off
00356 00214          MB090495 = 0;
00357 00215          MB090535 = 1;
00358 00216          JOINTO LBL5X;
00359
00360 00217      LBL45:                " Vacuum On
00361 00218          MB090496 = 1;
00362 00219          MB090536 = 0;
00363 00220          JOINTO LBL5X;
00364
00365 00221      LBL46:                " Vacuum Off
00366 00222          MB090496 = 0;
00367 00223          MB090536 = 1;
00368 00224          JOINTO LBL5X;
00369
00370 00225      LBL47:                " Vacuum On
00371 00226          MB090497 = 1;
00372 00227          MB090537 = 0;
00373 00228          JOINTO LBL5X;
00374
00375 00229      LBL48:                " Vacuum Off
00376 00230          MB090497 = 0;
00377 00231          MB090537 = 1;
00378 00232          JOINTO LBL5X;
00379
00380 00233      LBL505:
00381 00234          JOINTO LBL5X;
00382 00235      LBL5X: SJOINT;
00383
00384
00385 00236      SFORK    MW00041 == 49 ? LBL49      " Vacuum On
00386                      MW00041 == 50 ? LBL50      " Vacuum Off
00387                      MW00041 == 51 ? LBL51      " Vacuum On
00388                      MW00041 == 52 ? LBL52      " Vacuum Off
00389                      MW00041 == 53 ? LBL53      " Vacuum On
00390                      MW00041 == 54 ? LBL54      " Vacuum Off
00391                      MW00041 == 55 ? LBL55      " Vacuum On
00392                      MW00041 == 56 ? LBL56      " Vacuum Off
00393                      DEFAULTI      ? LBL506;
00394
00395 00237      LBL49:                " Vacuum On
00396 00238          MB090498 = 1;
00397 00239          MB090538 = 0;
00398 00240          JOINTO LBL6X;
00399
00400 00241      LBL50:                " Vacuum Off
00401 00242          MB090498 = 0;
00402 00243          MB090538 = 1;
00403 00244          JOINTO LBL6X;
00404
00405 00245      LBL51:                " Vacuum On
00406 00246          MB090499 = 1;
00407 00247          MB090539 = 0;
00408 00248          JOINTO LBL6X;
00409
00410 00249      LBL52:                " Vacuum Off
00411 00250          MB090499 = 0;
00412 00251          MB090539 = 1;
00413 00252          JOINTO LBL6X;
00414
00415 00253      LBL53:                " Vacuum On
00416 00254          MB09049A = 1;
00417 00255          MB09053A = 0;
00418 00256          JOINTO LBL6X;
00419
00420 00257      LBL54:                " Vacuum Off
00421 00258          MB09049A = 0;
00422 00259          MB09053A = 1;
00423 00260          JOINTO LBL6X;
00424
00425 00261      LBL55:                " Vacuum On
00426 00262          MB09049B = 1;
00427 00263          MB09053B = 0;
00428 00264          JOINTO LBL6X;
00429
00430 00265      LBL56:                " Vacuum Off
00431 00266          MB09049B = 0;
00432 00267          MB09053B = 1;
00433 00268          JOINTO LBL6X;
00434
00435 00269      LBL506:

```

```

00436 00270      JOINTO LBL6X;
00437 00271      LBL6X: SJOINT;
00438
00439
00440 00272      SFORK    MW00041 == 57 ? LBL57      " Vacuum On
00441                      MW00041 == 58 ? LBL58      " Vacuum Off
00442                      MW00041 == 59 ? LBL59      " Vacuum On
00443                      MW00041 == 60 ? LBL60      " Vacuum Off
00444                      MW00041 == 61 ? LBL61      " Vacuum On
00445                      MW00041 == 62 ? LBL62      " Vacuum Off
00446                      MW00041 == 63 ? LBL63      " Cutting Table All Vacuum On
00447                      MW00041 == 64 ? LBL64      " Cutting Table All Vacuum Off
00448                      DEFAULTI      ? LBL507;
00449
00450 00273      LBL57:      " Vacuum On
00451 00274                      MB09049C = 1;
00452 00275                      MB09053C = 0;
00453 00276                      JOINTO LBL7X;
00454
00455 00277      LBL58:      " Vacuum Off
00456 00278                      MB09049C = 0;
00457 00279                      MB09053C = 1;
00458 00280                      JOINTO LBL7X;
00459
00460 00281      LBL59:      " Vacuum On
00461 00282                      MB09049D = 1;
00462 00283                      MB09053D = 0;
00463 00284                      JOINTO LBL7X;
00464
00465 00285      LBL60:      " Vacuum Off
00466 00286                      MB09049D = 0;
00467 00287                      MB09053D = 1;
00468 00288                      JOINTO LBL7X;
00469
00470 00289      LBL61:      " Vacuum On
00471 00290                      MB09049E = 1;
00472 00291                      MB09053E = 0;
00473 00292                      JOINTO LBL7X;
00474
00475 00293      LBL62:      " Vacuum Off
00476 00294                      MB09049E = 0;
00477 00295                      MB09053E = 1;
00478 00296                      JOINTO LBL7X;
00479
00480 00297      LBL63:      " Cutting Table All Vacuum On
00481 00298                      MB09049F = 1;
00482 00299                      MB09053F = 0;
00483 00300                      JOINTO LBL7X;
00484
00485 00301      LBL64:      " Cutting Table All Vacuum Off
00486 00302                      MB09049F = 0;
00487 00303                      MB09053F = 1;
00488 00304                      JOINTO LBL7X;
00489
00490 00305      LBL507:
00491 00306                      JOINTO LBL7X;
00492 00307      LBL7X: SJOINT;
00493
00494
00495      *****
00496      ***** Blower *****
00497      *****
00498
00499 00308      SFORK    MW00041 == 65 ? LBL65      " Scribe Chuck 1,2,3,4 Blow On
00500                      MW00041 == 66 ? LBL66      " Scribe Chuck 1,2,3,4 Blow Off
00501                      MW00041 == 67 ? LBL67      " Blow On
00502                      MW00041 == 68 ? LBL68      " Blow Off
00503                      MW00041 == 69 ? LBL69      " Fix Table Blow 1 On
00504                      MW00041 == 70 ? LBL70      " Fix Table Blow 1 Off
00505                      MW00041 == 71 ? LBL71      " Fix Table Blow 2 On
00506                      MW00041 == 72 ? LBL72      " Fix Table Blow 2 Off
00507                      DEFAULTI      ? LBL508;
00508
00509 00309      LBL65:      " Scribe Chuck 1,2,3,4 Blow On
00510 00310                      MB090560 = 1;
00511 00311                      MB090600 = 0;
00512 00312                      JOINTO LBL8X;
00513
00514 00313      LBL66:      " Scribe Chuck 1,2,3,4 Blow Off
00515 00314                      MB090560 = 0;
00516 00315                      MB090600 = 1;
00517 00316                      JOINTO LBL8X;
00518
00519 00317      LBL67:      " Blow On
00520 00318                      MB090561 = 1;
00521 00319                      MB090601 = 0;
00522 00320                      JOINTO LBL8X;

```

```

00523
00524 00321      LBL68:                                " Blow Off
00525 00322          MB090561 = 0;
00526 00323          MB090601 = 1;
00527 00324          JOINTO LBL8X;
00528
00529 00325      LBL69:                                " Fix Table Blow 1 On
00530 00326          MB09061E = 0;
00531 00327          MB090562 = 1;
00532 00328          MB090602 = 0;
00533 00329          JOINTO LBL8X;
00534
00535 00330      LBL70:                                " Fix Table Blow 1 Off
00536 00331          MB09057E = 0;
00537 00332          MB090562 = 0;
00538 00333          MB090602 = 1;
00539 00334          JOINTO LBL8X;
00540
00541 00335      LBL71:                                " Fix Table Blow 2 On
00542 00336          MB09061E = 0;
00543 00337          MB090563 = 1;
00544 00338          MB090603 = 0;
00545 00339          JOINTO LBL8X;
00546
00547 00340      LBL72:                                " Fix Table Blow 2 Off
00548 00341          MB09057E = 0;
00549 00342          MB090563 = 0;
00550 00343          MB090603 = 1;
00551 00344          JOINTO LBL8X;
00552
00553 00345      LBL508:
00554 00346          JOINTO LBL8X;
00555 00347      LBL8X: SJOINT;
00556
00557
00558 00348      SFORK  MW00041 == 73 ? LBL73          " Fix Table Blow 3 On
00559                      MW00041 == 74 ? LBL74          " Fix Table Blow 3 Off
00560                      MW00041 == 75 ? LBL75          " Fix Table Blow 4 On
00561                      MW00041 == 76 ? LBL76          " Fix Table Blow 4 Off
00562                      MW00041 == 77 ? LBL77          " Fix Table Blow 5 On
00563                      MW00041 == 78 ? LBL78          " Fix Table Blow 5 Off
00564                      MW00041 == 79 ? LBL79          " Fix Table Blow 6 On
00565                      MW00041 == 80 ? LBL80          " Fix Table Blow 6 Off
00566                      DEFAULTI      ? LBL509;
00567
00568 00349      LBL73:                                " Fix Table Blow 3 On
00569 00350          MB09061E = 0;
00570 00351          MB090564 = 1;
00571 00352          MB090604 = 0;
00572 00353          JOINTO LBL9X;
00573
00574 00354      LBL74:                                " Fix Table Blow 3 Off
00575 00355          MB09057E = 0;
00576 00356          MB090564 = 0;
00577 00357          MB090604 = 1;
00578 00358          JOINTO LBL9X;
00579
00580 00359      LBL75:                                " Fix Table Blow 4 On
00581 00360          MB09061E = 0;
00582 00361          MB090565 = 1;
00583 00362          MB090605 = 0;
00584 00363          JOINTO LBL9X;
00585
00586 00364      LBL76:                                " Fix Table Blow 4 Off
00587 00365          MB09057E = 0;
00588 00366          MB090565 = 0;
00589 00367          MB090605 = 1;
00590 00368          JOINTO LBL9X;
00591
00592 00369      LBL77:                                " Fix Table Blow 5 On
00593 00370          MB09061E = 0;
00594 00371          MB090566 = 1;
00595 00372          MB090606 = 0;
00596 00373          JOINTO LBL9X;
00597
00598 00374      LBL78:                                " Fix Table Blow 5 Off
00599 00375          MB09057E = 0;
00600 00376          MB090566 = 0;
00601 00377          MB090606 = 1;
00602 00378          JOINTO LBL9X;
00603
00604 00379      LBL79:                                " Fix Table Blow 6 On
00605 00380          MB09061E = 0;
00606 00381          MB090567 = 1;
00607 00382          MB090607 = 0;
00608 00383          JOINTO LBL9X;
00609

```

```

00610 00384      LBL80:                                " Fix Table Blow 6 Off
00611 00385          MB09057E = 0;
00612 00386          MB090567 = 0;
00613 00387          MB090607 = 1;
00614 00388          JOINTO LBL9X;
00615
00616 00389      LBL509:
00617 00390          JOINTO LBL9X;
00618 00391      LBL9X: SJOINT;
00619
00620
00621 00392      SFORK  MW00041 == 81 ? LBL81      " Fix Table Blow 7 On
00622                MW00041 == 82 ? LBL82      " Fix Table Blow 7 Off
00623                MW00041 == 83 ? LBL83      " Fix Table Blow 8 On
00624                MW00041 == 84 ? LBL84      " Fix Table Blow 8 Off
00625                MW00041 == 85 ? LBL85      " Fix Table Blow 9 On
00626                MW00041 == 86 ? LBL86      " Fix Table Blow 9 Off
00627                MW00041 == 87 ? LBL87      " Fix Table Blow 10 On
00628                MW00041 == 88 ? LBL88      " Fix Table Blow 10 Off
00629                DEFAULT ? LBL510;
00630
00631 00393      LBL81:                                " Fix Table Blow 7 On
00632 00394          MB09061E = 0;
00633 00395          MB090568 = 1;
00634 00396          MB090608 = 0;
00635 00397          JOINTO LBL10X;
00636
00637 00398      LBL82:                                " Fix Table Blow 7 Off
00638 00399          MB09057E = 0;
00639 00400          MB090568 = 0;
00640 00401          MB090608 = 1;
00641 00402          JOINTO LBL10X;
00642
00643 00403      LBL83:                                " Fix Table Blow 8 On
00644 00404          MB09061E = 0;
00645 00405          MB090569 = 1;
00646 00406          MB090609 = 0;
00647 00407          JOINTO LBL10X;
00648
00649 00408      LBL84:                                " Fix Table Blow 8 Off
00650 00409          MB09057E = 0;
00651 00410          MB090569 = 0;
00652 00411          MB090609 = 1;
00653 00412          JOINTO LBL10X;
00654
00655 00413      LBL85:                                " Fix Table Blow 9 On
00656 00414          MB09061E = 0;
00657 00415          MB09056A = 1;
00658 00416          MB09060A = 0;
00659 00417          JOINTO LBL10X;
00660
00661 00418      LBL86:                                " Fix Table Blow 9 Off
00662 00419          MB09057E = 0;
00663 00420          MB09056A = 0;
00664 00421          MB09060A = 1;
00665 00422          JOINTO LBL10X;
00666
00667 00423      LBL87:                                " Fix Table Blow 10 On
00668 00424          MB09061E = 0;
00669 00425          MB09056B = 1;
00670 00426          MB09060B = 0;
00671 00427          JOINTO LBL10X;
00672
00673 00428      LBL88:                                " Fix Table Blow 10 Off
00674 00429          MB09057E = 0;
00675 00430          MB09056B = 0;
00676 00431          MB09060B = 1;
00677 00432          JOINTO LBL10X;
00678
00679 00433      LBL510:
00680 00434          JOINTO LBL10X;
00681 00435      LBL10X: SJOINT;
00682
00683
00684 00436      SFORK  MW00041 == 89 ? LBL89      " Fix Table Blow 11 On
00685                MW00041 == 90 ? LBL90      " Fix Table Blow 11 Off
00686                MW00041 == 91 ? LBL91      " Fix Table Blow 12 On
00687                MW00041 == 92 ? LBL92      " Fix Table Blow 12 Off
00688                MW00041 == 93 ? LBL93      " Fix Table Blow 13 On
00689                MW00041 == 94 ? LBL94      " Fix Table Blow 13 Off
00690                MW00041 == 95 ? LBL95      " Fix Table Blow 14 On
00691                MW00041 == 96 ? LBL96      " Fix Table Blow 14 Off
00692                DEFAULT ? LBL511;
00693
00694 00437      LBL89:                                " Fix Table Blow 11 On
00695 00438          MB09061E = 0;
00696 00439          MB09056C = 1;

```



```

00697 00440      MB09060C = 0;
00698 00441      JOINTO LBL11X;
00699
00700 00442      LBL90:                                " Fix Table Blow 11 Off
00701 00443      MB09057E = 0;
00702 00444      MB09056C = 0;
00703 00445      MB09060C = 1;
00704 00446      JOINTO LBL11X;
00705
00706 00447      LBL91:                                " Fix Table Blow 12 On
00707 00448      MB09061E = 0;
00708 00449      MB09056D = 1;
00709 00450      MB09060D = 0;
00710 00451      JOINTO LBL11X;
00711
00712 00452      LBL92:                                " Fix Table Blow 12 Off
00713 00453      MB09057E = 0;
00714 00454      MB09056D = 0;
00715 00455      MB09060D = 1;
00716 00456      JOINTO LBL11X;
00717
00718 00457      LBL93:                                " Fix Table Blow 13 On
00719 00458      MB09061E = 0;
00720 00459      MB09056E = 1;
00721 00460      MB09060E = 0;
00722 00461      JOINTO LBL11X;
00723
00724 00462      LBL94:                                " Fix Table Blow 13 Off
00725 00463      MB09057E = 0;
00726 00464      MB09056E = 0;
00727 00465      MB09060E = 1;
00728 00466      JOINTO LBL11X;
00729
00730 00467      LBL95:                                " Fix Table Blow 14 On
00731 00468      MB09061E = 0;
00732 00469      MB09056F = 1;
00733 00470      MB09060F = 0;
00734 00471      JOINTO LBL11X;
00735
00736 00472      LBL96:                                " Fix Table Blow 14 Off
00737 00473      MB09057E = 0;
00738 00474      MB09056F = 0;
00739 00475      MB09060F = 1;
00740 00476      JOINTO LBL11X;
00741
00742 00477      LBL511:
00743 00478      JOINTO LBL11X;
00744 00479      LBL11X: SJOINT;
00745
00746
00747 00480      SFORK  MW00041 == 97 ? LBL97      " Cutting Table Blow 1 On
00748      MW00041 == 98 ? LBL98      " Cutting Table Blow 1 Off
00749      MW00041 == 99 ? LBL99      " Cutting Table Blow 2 On
00750      MW00041 == 100 ? LBL100     " Cutting Table Blow 2 Off
00751      MW00041 == 101 ? LBL101     " Cutting Table Blow 3 On
00752      MW00041 == 102 ? LBL102     " Cutting Table Blow 3 Off
00753      MW00041 == 103 ? LBL103     " Cutting Table Blow 4 On
00754      MW00041 == 104 ? LBL104     " Cutting Table Blow 4 Off
00755      DEFAULT      ? LBL512;
00756
00757 00481      LBL97:                                " Cutting Table Blow 1 On
00758 00482      MB09061F = 0;
00759 00483      MB090570 = 1;
00760 00484      MB090610 = 0;
00761 00485      JOINTO LBL12X;
00762
00763 00486      LBL98:                                " Cutting Table Blow 1 Off
00764 00487      MB09057F = 0;
00765 00488      MB090570 = 0;
00766 00489      MB090610 = 1;
00767 00490      JOINTO LBL12X;
00768
00769 00491      LBL99:                                " Cutting Table Blow 2 On
00770 00492      MB09061F = 0;
00771 00493      MB090571 = 1;
00772 00494      MB090611 = 0;
00773 00495      JOINTO LBL12X;
00774
00775 00496      LBL100:                               " Cutting Table Blow 2 Off
00776 00497      MB09057F = 0;
00777 00498      MB090571 = 0;
00778 00499      MB090611 = 1;
00779 00500      JOINTO LBL12X;
00780
00781 00501      LBL101:                               " Cutting Table Blow 3 On
00782 00502      MB09061F = 0;
00783 00503      MB090572 = 1;

```

```

00784 00504      MB090612 = 0;
00785 00505      JOINTO LBL12X;
00786
00787 00506      LBL102:                                " Cutting Table Blow 3 Off
00788 00507      MB09057F = 0;
00789 00508      MB090572 = 0;
00790 00509      MB090612 = 1;
00791 00510      JOINTO LBL12X;
00792
00793 00511      LBL103:                                " Cutting Table Blow 4 On
00794 00512      MB09061F = 0;
00795 00513      MB090573 = 1;
00796 00514      MB090613 = 0;
00797 00515      JOINTO LBL12X;
00798
00799 00516      LBL104:                                " Cutting Table Blow 4 Off
00800 00517      MB09057F = 0;
00801 00518      MB090573 = 0;
00802 00519      MB090613 = 1;
00803 00520      JOINTO LBL12X;
00804
00805 00521      LBL512:
00806 00522      JOINTO LBL12X;
00807 00523      LBL12X: SJOINT;
00808
00809
00810 00524      SFORK  MW00041 == 105 ? LBL105      " Cutting Table Blow 5 On
00811      MW00041 == 106 ? LBL106      " Cutting Table Blow 5 Off
00812      MW00041 == 107 ? LBL107      " Cutting Table Blow 6 On
00813      MW00041 == 108 ? LBL108      " Cutting Table Blow 6 Off
00814      MW00041 == 109 ? LBL109      " Cutting Table Low Pressure Blow 1 On
00815      MW00041 == 110 ? LBL110      " Cutting Table Low Pressure Blow 1 Off
00816      MW00041 == 111 ? LBL111      " Cutting Table Low Pressure Blow 2 On
00817      MW00041 == 112 ? LBL112      " Cutting Table Low Pressure Blow 2 Off
00818      DEFAULT ? LBL513;
00819
00820 00525      LBL105:                                " Cutting Table Blow 5 On
00821 00526      MB09061F = 0;
00822 00527      MB090574 = 1;
00823 00528      MB090614 = 0;
00824 00529      JOINTO LBL13X;
00825
00826 00530      LBL106:                                " Cutting Table Blow 5 Off
00827 00531      MB09057F = 0;
00828 00532      MB090574 = 0;
00829 00533      MB090614 = 1;
00830 00534      JOINTO LBL13X;
00831
00832 00535      LBL107:                                " Cutting Table Blow 6 On
00833 00536      MB09061F = 0;
00834 00537      MB090575 = 1;
00835 00538      MB090615 = 0;
00836 00539      JOINTO LBL13X;
00837
00838 00540      LBL108:                                " Cutting Table Blow 6 Off
00839 00541      MB09057F = 0;
00840 00542      MB090575 = 0;
00841 00543      MB090615 = 1;
00842 00544      JOINTO LBL13X;
00843
00844 00545      LBL109:                                " Cutting Table Low Pressure Blow 1 On
00845 00546      MB09061F = 0;
00846 00547      MB090576 = 1;
00847 00548      MB090616 = 0;
00848 00549      JOINTO LBL13X;
00849
00850 00550      LBL110:                                " Cutting Table Low Pressure Blow 1 Off
00851 00551      MB09057F = 0;
00852 00552      MB090576 = 0;
00853 00553      MB090616 = 1;
00854 00554      JOINTO LBL13X;
00855
00856 00555      LBL111:                                " Cutting Table Low Pressure Blow 2 On
00857 00556      MB09061F = 0;
00858 00557      MB090577 = 1;
00859 00558      MB090617 = 0;
00860 00559      JOINTO LBL13X;
00861
00862 00560      LBL112:                                " Cutting Table Low Pressure Blow 2 Off
00863 00561      MB09057F = 0;
00864 00562      MB090577 = 0;
00865 00563      MB090617 = 1;
00866 00564      JOINTO LBL13X;
00867
00868 00565      LBL513:
00869 00566      JOINTO LBL13X;
00870 00567      LBL13X: SJOINT;

```

```

00871
00872
00873 00568   SFORK   MW00041 == 113 ? LBL113   " Cutting Table Low Pressure Blow 3 On
00874         MW00041 == 114 ? LBL114   " Cutting Table Low Pressure Blow 3 Off
00875         MW00041 == 115 ? LBL115   "
00876         MW00041 == 116 ? LBL116   "
00877         MW00041 == 117 ? LBL117   "
00878         MW00041 == 118 ? LBL118   "
00879         MW00041 == 119 ? LBL119   "
00880         MW00041 == 120 ? LBL120   "
00881         DEFAULT   ? LBL514;
00882
00883 00569   LBL113:   " Cutting Table Low Pressure Blow 3 On
00884         MB09061F = 0;
00885         MB090578 = 1;
00886         MB090618 = 0;
00887         JOINTO LBL14X;
00888
00889 00574   LBL114:   " Cutting Table Low Pressure Blow 3 Off
00890         MB09057F = 0;
00891         MB090578 = 0;
00892         MB090618 = 1;
00893         JOINTO LBL14X;
00894
00895 00579   LBL115:   "
00896         MB090579 = 1;
00897         MB090619 = 0;
00898         JOINTO LBL14X;
00899
00900 00583   LBL116:   "
00901         MB090579 = 0;
00902         MB090619 = 1;
00903         JOINTO LBL14X;
00904
00905 00587   LBL117:   "
00906         MB09057A = 1;
00907         MB09061A = 0;
00908         JOINTO LBL14X;
00909
00910 00591   LBL118:   "
00911         MB09057A = 0;
00912         MB09061A = 1;
00913         JOINTO LBL14X;
00914
00915 00595   LBL119:   "
00916         MB09057B = 1;
00917         MB09061B = 0;
00918         JOINTO LBL14X;
00919
00920 00599   LBL120:   "
00921         MB09057B = 0;
00922         MB09061B = 1;
00923         JOINTO LBL14X;
00924
00925 00603   LBL514:
00926         JOINTO LBL14X;
00927 00605   LBL14X: SJOINT;
00928
00929
00930 00606   SFORK   MW00041 == 121 ? LBL121   " Scale / Wheel Blow On
00931         MW00041 == 122 ? LBL122   " Scale / Wheel Blow Off
00932         MW00041 == 123 ? LBL123   " Scribe Chuck Table Blow On
00933         MW00041 == 124 ? LBL124   " Scribe Chuck Table Blow Off
00934         MW00041 == 125 ? LBL125   " Fix Table All Blow On
00935         MW00041 == 126 ? LBL126   " Fix Table All Blow Off
00936         MW00041 == 127 ? LBL127   " Cutting Table All Blow On
00937         MW00041 == 128 ? LBL128   " Cutting Table All Blow Off
00938         DEFAULT   ? LBL515;
00939
00940 00607   LBL121:   " Scale / Wheel Blow On
00941         MB09057C = 1;
00942         MB09061C = 0;
00943         JOINTO LBL15X;
00944
00945 00611   LBL122:   " Scale / Wheel Blow Off
00946         MB09057C = 0;
00947         MB09061C = 1;
00948         JOINTO LBL15X;
00949
00950 00615   LBL123:   " Scribe Chuck Table Blow On
00951         MB09057D = 1;
00952         MB09061D = 0;
00953         JOINTO LBL15X;
00954
00955 00619   LBL124:   " Scribe Chuck Table Blow Off
00956         MB09057D = 0;
00957         MB09061D = 1;

```

```

00958 00622      JOINTO LBL15X;
00959
00960 00623      LBL125:                      " Fix Table All Blow On
00961 00624          MB09057E = 1;
00962 00625          MB09061E = 0;
00963 00626      JOINTO LBL15X;
00964
00965 00627      LBL126:                      " Fix Table All Blow Off
00966 00628          MB09057E = 0;
00967 00629          MB09061E = 1;
00968 00630      JOINTO LBL15X;
00969
00970 00631      LBL127:                      " Cutting Table All Blow On
00971 00632          MB09057F = 1;
00972 00633          MB09061F = 0;
00973 00634      JOINTO LBL15X;
00974
00975 00635      LBL128:                      " Cutting Table All Blow Off
00976 00636          MB09057F = 0;
00977 00637          MB09061F = 1;
00978 00638      JOINTO LBL15X;
00979
00980 00639      LBL515:
00981 00640          JOINTO LBL15X;
00982 00641      LBL15X: SJOINT;
00983
00984
00985 *****
00986 ***** Cyclinder *****
00987 *****
00988
00989 00642      SFORK   MW00041 == 129 ? LBL129      " Fix Table Brush Down (L)
00990          MW00041 == 130 ? LBL130      " Fix Table Brush UP (L)
00991          MW00041 == 131 ? LBL131      " Fix Table Brush Down (R)
00992          MW00041 == 132 ? LBL132      " Fix Table Brush UP (R)
00993          MW00041 == 133 ? LBL133      " Cutting Table Brush Down (L)
00994          MW00041 == 134 ? LBL134      " Cutting Table Brush UP (L)
00995          MW00041 == 135 ? LBL135      " Cutting Table Brush Down (R)
00996          MW00041 == 136 ? LBL136      " Cutting Table Brush UP (R)
00997          DEFAULT      ? LBL516;
00998
00999 00643      LBL129:                      " Fix Table Brush Down (L)
01000          MB090400 = 1;
01001 00645          MB090440 = 0;
01002 00646      JOINTO LBL16X;
01003
01004 00647      LBL130:                      " Fix Table Brush UP (L)
01005          MB090400 = 0;
01006 00649          MB090440 = 1;
01007 00650      JOINTO LBL16X;
01008
01009 00651      LBL131:                      " Fix Table Brush Down (R)
01010          MB090401 = 1;
01011 00653          MB090441 = 0;
01012 00654      JOINTO LBL16X;
01013
01014 00655      LBL132:                      " Fix Table Brush UP (R)
01015          MB090401 = 0;
01016 00657          MB090441 = 1;
01017 00658      JOINTO LBL16X;
01018
01019 00659      LBL133:                      " Cutting Table Brush Down (L)
01020          MB090402 = 1;
01021 00661          MB090442 = 0;
01022 00662      JOINTO LBL16X;
01023
01024 00663      LBL134:                      " Cutting Table Brush UP (L)
01025          MB090402 = 0;
01026 00665          MB090442 = 1;
01027 00666      JOINTO LBL16X;
01028
01029 00667      LBL135:                      " Cutting Table Brush Down (R)
01030          MB090403 = 1;
01031 00669          MB090443 = 0;
01032 00670      JOINTO LBL16X;
01033
01034 00671      LBL136:                      " Cutting Table Brush UP (R)
01035 00672          MB090403 = 0;
01036 00673          MB090443 = 1;
01037 00674      JOINTO LBL16X;
01038
01039 00675      LBL516:
01040 00676          JOINTO LBL16X;
01041 00677      LBL16X: SJOINT;
01042
01043
01044 00678      SFORK   MW00041 == 137 ? LBL137      " Dummy Shutter Fwd (L)

```

```

01045          MW00041 == 138 ? LBL138      " Dummy Shutter Bwd (L)
01046          MW00041 == 139 ? LBL139      " Dummy Shutter Fwd (R)
01047          MW00041 == 140 ? LBL140      " Dummy Shutter Bwd (R)
01048          MW00041 == 141 ? LBL141      " Cylinder Forward
01049          MW00041 == 142 ? LBL142      " Cylinder Backward
01050          MW00041 == 143 ? LBL143      " Cylinder Forward
01051          MW00041 == 144 ? LBL144      " Cylinder Backward
01052          DEFAULT      ? LBL517;
01053
01054 00679      LBL137:          " Dummy Shutter Fwd (L)
01055 00680          MB090404 = 1;
01056 00681          MB090444 = 0;
01057 00682          JOINTO LBL17X;
01058
01059 00683      LBL138:          " Dummy Shutter Bwd (L)
01060 00684          MB090404 = 0;
01061 00685          MB090444 = 1;
01062 00686          JOINTO LBL17X;
01063
01064 00687      LBL139:          " Dummy Shutter Fwd (R)
01065 00688          MB090405 = 1;
01066 00689          MB090445 = 0;
01067 00690          JOINTO LBL17X;
01068
01069 00691      LBL140:          " Dummy Shutter Bwd (R)
01070 00692          MB090405 = 0;
01071 00693          MB090445 = 1;
01072 00694          JOINTO LBL17X;
01073
01074 00695      LBL141:          " Cylinder Forward
01075 00696          MB090406 = 1;
01076 00697          MB090446 = 0;
01077 00698          JOINTO LBL17X;
01078
01079 00699      LBL142:          " Cylinder Backward
01080 00700          MB090406 = 0;
01081 00701          MB090446 = 1;
01082 00702          JOINTO LBL17X;
01083
01084 00703      LBL143:          " Cylinder Forward
01085 00704          MB090407 = 1;
01086 00705          MB090447 = 0;
01087 00706          JOINTO LBL17X;
01088
01089 00707      LBL144:          " Cylinder Backward
01090 00708          MB090407 = 0;
01091 00709          MB090447 = 1;
01092 00710          JOINTO LBL17X;
01093
01094 00711      LBL517:
01095 00712          JOINTO LBL17X;
01096 00713      LBL17X: SJOINT;
01097
01098
01099 00714      SFORK  MW00041 == 145 ? LBL145  " Dummy Stopper Cylinder Down
01100          MW00041 == 146 ? LBL146  " Dummy Stopper Cylinder Up
01101          MW00041 == 147 ? LBL147  " Cylinder Forward
01102          MW00041 == 148 ? LBL148  " Cylinder Backward
01103          MW00041 == 149 ? LBL149  " Cylinder Forward
01104          MW00041 == 150 ? LBL150  " Cylinder Backward
01105          MW00041 == 151 ? LBL151  " Cylinder Forward
01106          MW00041 == 152 ? LBL152  " Cylinder Backward
01107          DEFAULT      ? LBL518;
01108
01109 00715      LBL145:          " Dummy Stopper Cylinder Down
01110 00716          MB090408 = 1;
01111 00717          MB090448 = 0;
01112 00718          JOINTO LBL18X;
01113
01114 00719      LBL146:          " Dummy Stopper Cylinder Up
01115 00720          MB090408 = 0;
01116 00721          MB090448 = 1;
01117 00722          JOINTO LBL18X;
01118
01119 00723      LBL147:          " Cylinder Forward
01120 00724          MB090409 = 1;
01121 00725          MB090449 = 0;
01122 00726          JOINTO LBL18X;
01123
01124 00727      LBL148:          " Cylinder Backward
01125 00728          MB090409 = 0;
01126 00729          MB090449 = 1;
01127 00730          JOINTO LBL18X;
01128
01129 00731      LBL149:          " Cylinder Forward
01130 00732          MB09040A = 1;
01131 00733          MB09044A = 0;

```

```

01132 00734      JOINTO LBL18X;
01133
01134 00735      LBL150:                                " Cylinder Backward
01135 00736          MB09040A = 0;
01136 00737          MB09044A = 1;
01137 00738      JOINTO LBL18X;
01138
01139 00739      LBL151:                                " Cylinder Forward
01140 00740          MB09040B = 1;
01141 00741          MB09044B = 0;
01142 00742      JOINTO LBL18X;
01143
01144 00743      LBL152:                                " Cylinder Backward
01145 00744          MB09040B = 0;
01146 00745          MB09044B = 1;
01147 00746      JOINTO LBL18X;
01148
01149 00747      LBL518:
01150 00748          JOINTO LBL18X;
01151 00749      LBL18X: SJOINT;
01152
01153
01154 00750      SFORK  MW00041 == 153 ? LBL153          " Cylinder Forward
01155                      MW00041 == 154 ? LBL154          " Cylinder Backward
01156                      MW00041 == 155 ? LBL155          " Fix Table Brush Down
01157                      MW00041 == 156 ? LBL156          " Fix Table Brush UP
01158                      MW00041 == 157 ? LBL157          " Cutting Table Brush Down
01159                      MW00041 == 158 ? LBL158          " Cutting Table Brush UP
01160                      MW00041 == 159 ? LBL159          " Dummy Shutter Forward
01161                      MW00041 == 160 ? LBL160          " Dummy Shutter Backward
01162                      DEFAULT ? LBL519;
01163
01164 00751      LBL153:                                " Cylinder Forward
01165 00752          MB09040C = 1;
01166 00753          MB09044C = 0;
01167 00754      JOINTO LBL19X;
01168
01169 00755      LBL154:                                " Cylinder Backward
01170 00756          MB09040C = 0;
01171 00757          MB09044C = 1;
01172 00758      JOINTO LBL19X;
01173
01174 00759      LBL155:                                " Fix Table Brush Down
01175 00760          MB09040D = 1;
01176 00761          MB09044D = 0;
01177 00762      JOINTO LBL19X;
01178
01179 00763      LBL156:                                " Fix Table Brush UP
01180 00764          MB09040D = 0;
01181 00765          MB09044D = 1;
01182 00766      JOINTO LBL19X;
01183
01184 00767      LBL157:                                " Cutting Table Brush Down
01185 00768          MB09040E = 1;
01186 00769          MB09044E = 0;
01187 00770      JOINTO LBL19X;
01188
01189 00771      LBL158:                                " Cutting Table Brush UP
01190 00772          MB09040E = 0;
01191 00773          MB09044E = 1;
01192 00774      JOINTO LBL19X;
01193
01194 00775      LBL159:                                " Dummy Shutter Forward
01195 00776          MB09040F = 1;
01196 00777          MB09044F = 0;
01197 00778      JOINTO LBL19X;
01198
01199 00779      LBL160:                                " Dummy Shutter Backward
01200 00780          MB09040F = 0;
01201 00781          MB09044F = 1;
01202 00782      JOINTO LBL19X;
01203
01204 00783      LBL519:
01205 00784          JOINTO LBL19X;
01206 00785      LBL19X: SJOINT;
01207
01208
01209 00786      SFORK  MW00041 == 161 ? LBL161          " Cylinder Forward
01210                      MW00041 == 162 ? LBL162          " Cylinder Backward
01211                      MW00041 == 163 ? LBL163          " Cylinder Forward
01212                      MW00041 == 164 ? LBL164          " Cylinder Backward
01213                      MW00041 == 165 ? LBL165          " Cylinder Forward
01214                      MW00041 == 166 ? LBL166          " Cylinder Backward
01215                      MW00041 == 167 ? LBL167          " Cylinder Forward
01216                      MW00041 == 168 ? LBL168          " Cylinder Backward
01217                      DEFAULT ? LBL520;
01218

```

```

01219 00787      LBL161:                                " Cylinder Forward
01220 00788          MB090410 = 1;
01221 00789          MB090450 = 0;
01222 00790          JOINTO LBL20X;
01223
01224 00791      LBL162:                                " Cylinder Backward
01225 00792          MB090410 = 0;
01226 00793          MB090450 = 1;
01227 00794          JOINTO LBL20X;
01228
01229 00795      LBL163:                                " Cylinder Forward
01230 00796          MB090411 = 1;
01231 00797          MB090451 = 0;
01232 00798          JOINTO LBL20X;
01233
01234 00799      LBL164:                                " Cylinder Backward
01235 00800          MB090411 = 0;
01236 00801          MB090451 = 1;
01237 00802          JOINTO LBL20X;
01238
01239 00803      LBL165:                                " Cylinder Forward
01240 00804          MB090412 = 1;
01241 00805          MB090452 = 0;
01242 00806          JOINTO LBL20X;
01243
01244 00807      LBL166:                                " Cylinder Backward
01245 00808          MB090412 = 0;
01246 00809          MB090452 = 1;
01247 00810          JOINTO LBL20X;
01248
01249 00811      LBL167:                                " Cylinder Forward
01250 00812          MB090413 = 1;
01251 00813          MB090453 = 0;
01252 00814          JOINTO LBL20X;
01253
01254 00815      LBL168:                                " Cylinder Backward
01255 00816          MB090413 = 0;
01256 00817          MB090453 = 1;
01257 00818          JOINTO LBL20X;
01258
01259 00819      LBL520:
01260 00820          JOINTO LBL20X;
01261 00821      LBL20X: SJOINT;
01262
01263
01264 00822      SFORK  MW00041 == 169 ? LBL169          " Cylinder Forward
01265                  MW00041 == 170 ? LBL170          " Cylinder Backward
01266                  MW00041 == 171 ? LBL171          " Cylinder Forward
01267                  MW00041 == 172 ? LBL172          " Cylinder Backward
01268                  MW00041 == 173 ? LBL173          " Cylinder Forward
01269                  MW00041 == 174 ? LBL174          " Cylinder Backward
01270                  MW00041 == 175 ? LBL175          " Cylinder Forward
01271                  MW00041 == 176 ? LBL176          " Cylinder Backward
01272                  DEFAULT ? LBL521;
01273
01274 00823      LBL169:                                " Cylinder Forward
01275 00824          MB090414 = 1;
01276 00825          MB090454 = 0;
01277 00826          JOINTO LBL21X;
01278
01279 00827      LBL170:                                " Cylinder Backward
01280 00828          MB090414 = 0;
01281 00829          MB090454 = 1;
01282 00830          JOINTO LBL21X;
01283
01284 00831      LBL171:                                " Cylinder Forward
01285 00832          MB090415 = 1;
01286 00833          MB090455 = 0;
01287 00834          JOINTO LBL21X;
01288
01289 00835      LBL172:                                " Cylinder Backward
01290 00836          MB090415 = 0;
01291 00837          MB090455 = 1;
01292 00838          JOINTO LBL21X;
01293
01294 00839      LBL173:                                " Cylinder Forward
01295 00840          MB090416 = 1;
01296 00841          MB090456 = 0;
01297 00842          JOINTO LBL21X;
01298
01299 00843      LBL174:                                " Cylinder Backward
01300 00844          MB090416 = 0;
01301 00845          MB090456 = 1;
01302 00846          JOINTO LBL21X;
01303
01304 00847      LBL175:                                " Cylinder Forward
01305 00848          MB090417 = 1;

```

```

01306 00849      MB090457 = 0;
01307 00850      JOINTO LBL21X;
01308
01309 00851      LBL176:                                " Cylinder Backward
01310 00852      MB090417 = 0;
01311 00853      MB090457 = 1;
01312 00854      JOINTO LBL21X;
01313
01314 00855      LBL521:
01315 00856      JOINTO LBL21X;
01316 00857      LBL21X: SJOINT;
01317
01318
01319 00858      SFORK   MW00041 == 177 ? LBL177      " Cylinder Forward
01320      MW00041 == 178 ? LBL178      " Cylinder Backward
01321      MW00041 == 179 ? LBL179      " Cylinder Forward
01322      MW00041 == 180 ? LBL180      " Cylinder Backward
01323      MW00041 == 181 ? LBL181      " Cylinder Forward
01324      MW00041 == 182 ? LBL182      " Cylinder Backward
01325      MW00041 == 183 ? LBL183      " Cylinder Forward
01326      MW00041 == 184 ? LBL184      " Cylinder Backward
01327      DEFAULT      ? LBL522;
01328
01329 00859      LBL177:                                " Cylinder Forward
01330 00860      MB090418 = 1;
01331 00861      MB090458 = 0;
01332 00862      JOINTO LBL22X;
01333
01334 00863      LBL178:                                " Cylinder Backward
01335 00864      MB090418 = 0;
01336 00865      MB090458 = 1;
01337 00866      JOINTO LBL22X;
01338
01339 00867      LBL179:                                " Cylinder Forward
01340 00868      MB090419 = 1;
01341 00869      MB090459 = 0;
01342 00870      JOINTO LBL22X;
01343
01344 00871      LBL180:                                " Cylinder Backward
01345 00872      MB090419 = 0;
01346 00873      MB090459 = 1;
01347 00874      JOINTO LBL22X;
01348
01349 00875      LBL181:                                " Cylinder Forward
01350 00876      MB09041A = 1;
01351 00877      MB09045A = 0;
01352 00878      JOINTO LBL22X;
01353
01354 00879      LBL182:                                " Cylinder Backward
01355 00880      MB09041A = 0;
01356 00881      MB09045A = 1;
01357 00882      JOINTO LBL22X;
01358
01359 00883      LBL183:                                " Cylinder Forward
01360 00884      MB09041B = 1;
01361 00885      MB09045B = 0;
01362 00886      JOINTO LBL22X;
01363
01364 00887      LBL184:                                " Cylinder Backward
01365 00888      MB09041B = 0;
01366 00889      MB09045B = 1;
01367 00890      JOINTO LBL22X;
01368
01369 00891      LBL522:
01370 00892      JOINTO LBL22X;
01371 00893      LBL22X: SJOINT;
01372
01373
01374 00894      SFORK   MW00041 == 185 ? LBL185      " Cylinder Forward
01375      MW00041 == 186 ? LBL186      " Cylinder Backward
01376      MW00041 == 187 ? LBL187      " Cylinder Forward
01377      MW00041 == 188 ? LBL188      " Cylinder Backward
01378      MW00041 == 189 ? LBL189      " Cylinder Forward
01379      MW00041 == 190 ? LBL190      " Cylinder Backward
01380      MW00041 == 191 ? LBL191      " Cylinder Forward
01381      MW00041 == 192 ? LBL192      " Cylinder Backward
01382      DEFAULT      ? LBL523;
01383
01384 00895      LBL185:                                " Cylinder Forward
01385 00896      MB09041C = 1;
01386 00897      MB09045C = 0;
01387 00898      JOINTO LBL23X;
01388
01389 00899      LBL186:                                " Cylinder Backward
01390 00900      MB09041C = 0;
01391 00901      MB09045C = 1;
01392 00902      JOINTO LBL23X;

```



```
01393
01394 00903      LBL187:                " Cylinder Forward
01395 00904          MB09041D = 1;
01396 00905          MB09045D = 0;
01397 00906          JOINTO LBL23X;
01398
01399 00907      LBL188:                " Cylinder Backward
01400 00908          MB09041D = 0;
01401 00909          MB09045D = 1;
01402 00910          JOINTO LBL23X;
01403
01404 00911      LBL189:                " Cylinder Forward
01405 00912          MB09041E = 1;
01406 00913          MB09045E = 0;
01407 00914          JOINTO LBL23X;
01408
01409 00915      LBL190:                " Cylinder Backward
01410 00916          MB09041E = 0;
01411 00917          MB09045E = 1;
01412 00918          JOINTO LBL23X;
01413
01414 00919      LBL191:                " Cylinder Forward
01415 00920          MB09041F = 1;
01416 00921          MB09045F = 0;
01417 00922          JOINTO LBL23X;
01418
01419 00923      LBL192:                " Cylinder Backward
01420 00924          MB09041F = 0;
01421 00925          MB09045F = 1;
01422 00926          JOINTO LBL23X;
01423
01424 00927      LBL523:
01425 00928          JOINTO LBL23X;
01426 00929      LBL23X: SJOINT,
01427
01428 00930          MB00003E = 1;        " Manual Operation Complete
01429 00931      END;
```