

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (PLS Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name : SC Manual (PtoP)
00011 "# Functior :
00012 "# Call Program : H60.2
00013 "# Sub Program :
00014 "# Func Program
00015
00016 VAR;
00017 " Scribe Cutter
00018 00000 LONG IDX_CX = 32;
00019 00001 LONG IDX_CAMX = 33;
00020 " Scribe Shift
00021 00002 LONG IDX_CS = 35;
00022 " Scribe Chuck
00023 00003 LONG IDX_SCHY1 = 48;
00024 00004 LONG IDX_SCHY2 = 49;
00025 " Scribe Camera
00026 00005 LONG IDX_LCAMY = 37;
00027 00006 LONG IDX_RCAMY = 38
00028 00007 LONG IDX_LCAMZ = 39
00029 00008 LONG IDX_RCAMZ = 40;
00030 END_VAR;
00031
00032 00009 MB045241 = 0; " Scribe Data Update Reset
00033
00034 " All Stop Request Reset
00035 00010 MB045709 = 0;
00036
00037 00011 MW23912 = ML20080 " Recipe ID (Scribe)
00038 00012 MW23916 = ML20080 " Recipe ID (Break)
00039
00040 " Recipe Data Reading
00041 00013 MB214602 = 1; " Parameter Update Request (Scribe)
00042 00014 IOW MB205202 == 1 " Parameter Update Reply (Scribe)
00043 00015 MB214604 = 1; " Parameter Update Request (Break)
00044 00016 IOW MB205204 == 1 " Parameter Update Reply (Break)
00045 00017 MB21462B = 1; " Parameter Update Request (Scribe Pitch)
00046 00018 IOW MB20522B == 1 " Parameter Update Reply (Scribe Pitch)
00047 00019 EOX;
00048
00049 00020 MB045241 = 1; " Scribe Data Update Complete
00050
00051 00021 MSEE MPS150; " Axis Setting
00052 00022 MSEE MPS180; " Data Update
00053
00054 00023 IOW MB55720 & MB50720 == 1 " Unit3 & Unit4 Axis Setting
00055
00056 " Scribe Cutter Z Waiting Position
00057 00024 MW4842 = 41; " Scribe Cutter Z Command Code Setting
00058 00025 MSEE MPS198; " Scribe Cutter Z Move
00059 00026 MW4842 = 0;
00060 00027 IOW MW4842 == 0;
00061
00062 " Scribe Camera StandBy Position
00063 00028 PLD [LCAMY][LCAMZ][RCAMY][RCAMZ]
00064 00029 MOV [LCAMY]ML43730 [RCAMY]ML43830 [LCAMZ]ML43930 [RCAMZ]ML44030;
00065
00066 " Scribe Chuck Check
00067
00068 00030 IF MB030035 == 1 " P Work : Scribe Chuck
00069 00031 IF MB09018E == 1 " [Sensor] SCT Scribe Chuck All Vacuum On
00070 " [Request] Moving Position
00071 00032 MW04820 = 40;
00072 00033 MSEE MPS256;
00073 00034 IOW MB04574C == 1 " All SCHZ Moving Pos Check
00074 00035 ELSE;
00075 " [Request] Vacuum Position
00076 00036 MW04820 = 41;
00077 00037 MSEE MPS256;
00078 00038 IOW MB04574B == 1 " All SCHZ Vacuum Pos Check
00079
00080 00039 MB09048E = 1; " [Sol] SCT Scribe Chuck All Vacuum On
00081 00040 IOW MB09018E == 1 " [Sensor] SCT Scribe Chuck All Vacuum On
00082
00083 " [Request] Moving Position
00084 00041 MW04820 = 40;
00085 00042 MSEE MPS256;
00086 00043 IOW MB04574C == 1 " All SCHZ Moving Pos Check
00087 00044 IEND;

```

```

00088 00045 ELSE;
00089 00046 MB09052E = 1; " [Sol] SCT Scribe Chuck All Vacuum Off
00090 00047 MB090560 = 1; " [Sol] SCT Scribe Chuck 1,2,3,4 Blow On
00091 00048 IOW MB09022E & MB090260 == 1 " [Sensor] SCT Scribe Chuck All Vacuum Off
00092 " [Sensor] SCT Scribe Chuck 1,2,3,4 Blow On
00093 00049 TIM TMW26214; " Scribe Chuck Vacuum Break Complete Timer
00094 00050 MB090600 = 1; " [Sol] SCT Scribe Chuck 1,2,3,4 Blow Off
00095 00051 IOW MB090300 == 1 " [Sensor] SCT Scribe Chuck 1,2,3,4 Blow Off
00096
00097 " [Request] Standby Position
00098 00052 MW04820 = 39;
00099 00053 MSEE MPS256;
00100 00054 IOW MB04574A == 1 " All SCHZ Standby Pos Check
00101 00055 IEND;
00102
00103 " Manual / Auto Type
00104 00056 DB00020 = 0; " Manual Data
00105 00057 IF MB000004 == 1 " Auto Running
00106 00058 DB00020 = 1; " Recipe Data
00107 00059 IEND;
00108 00060 IF MB000004 == 0;
00109 00061 IF MB225580 == 1 " [PCDATA]Select Data
00110 00062 DB00020 = 1; " Recipe Data
00111 00063 IEND;
00112 00064 IEND;
00113
00114 00065 MW04920 = 0;
00115
00116 "*****
00117 "***** Head X LBL1~16 *****
00118 "*****
00119
00120 00066 SFORK MW00051 == 01 ? LBL01 " [CX] Cutter X Waiting Position
00121 MW00051 == 02 ? LBL02 " [CX] Cutter X Align Position
00122 MW00051 == 03 ? LBL03 " [CX] Cutter X Loadcell Position
00123 MW00051 == 04 ? LBL04 " [CX] Cutter X 0 Point Detection Position (Unuse)
00124 MW00051 == 05 ? LBL05 " [CX] Cutter X Wheel Change Position
00125 MW00051 == 06 ? LBL06 " [CX] Cutter X Cutting After Escape Position
00126 MW00051 == 07 ? LBL07 " [CX] Cutter X Cleaning Start Position
00127 MW00051 == 08 ? LBL08 " [CX] Cutter X Cleaning End Position
00128 DEFAULT ? LBL300;
00129
00130 00067 LBL01:
00131 " Cutter X Waiting Position
00132 00068 ML16064 = ML43230 " CX Waiting Position
00133 00069 IOW MB045760 == 1 " CX Wait Position Moving Permission
00134 00070 MOV [CX]ML16064;
00135 00071 IOW MB046000 == 1 " CX Waiting Position Check
00136
00137 00072 JOINTO LBL0X;
00138
00139 00073 LBL02:
00140 " Cutter X Align Position
00141 00074 IF CW00001 == 1 " Scribe Direction (0: Forward / 1: Reverse)
00142 00075 ML16064 = ML01158 " CX Alignment Position
00143 00076 ELSE;
00144 00077 ML16064 = ML01156 " CX Alignment Position
00145 00078 IEND;
00146
00147 00079 IOW MB045761 == 1 " CX Alignment Position Moving Permission
00148 00080 MOV [CX]ML16064;
00149 00081 IOW MB046001 == 1 " CX Alignment Position Check
00150
00151 00082 JOINTO LBL0X;
00152
00153 00083 LBL03:
00154 " Cutter X Loadcell Position
00155 00084 MB225584 = 0; " Head Select (0:Cutter 1:Roller)
00156 00085 ML16064 = ML43242 " CX LoadCell Position
00157 00086 IOW MB045763 == 1 " CX Load Measurement Moving Permission
00158 00087 MOV [CX]ML16064;
00159 00088 IOW MB046003 == 1 " CX Alignment Position Check
00160
00161 00089 JOINTO LBL0X;
00162
00163 00090 LBL04:
00164
00165 00091 JOINTO LBL0X;
00166
00167 00092 LBL05:
00168 " Cutter X Wheel Change Position
00169 00093 MB225584 = 0; " Head Select (0:Cutter 1:Roller)
00170 00094 ML16064 = ML43258 " CX LoadCell Position
00171 00095 IOW MB045767 == 1 " CX Wheel Change Position Moving Permission
00172 00096 MOV [CX]ML16064;
00173 00097 IOW MB046007 == 1 " CX Wheel Change Position
00174

```

```

00175 00098      JOINTO LBL0X;
00176
00177 00099      LBL06:
00178          " Cutter X Cutting After Escape Position
00179 00100      MB225584 = 0;          " Head Select (0:Cutter 1:Roller)
00180 00101      ML16064 = ML43270      " CX LoadCell Position
00181 00102      IOW MB045760 == 1      " CX Wait Position Moving Permission
00182 00103      MOV [CX]ML16064;
00183 00104      IOW MB04600A == 1      " CX Cutting After Escape Position
00184
00185 00105      JOINTO LBL0X;
00186
00187 00106      LBL07:
00188          " Cutter X Cleaning Start Position
00189 00107      MB225584 = 0;          " Head Select (0:Cutter 1:Roller)
00190 00108      ML16064 = ML43278      " CX LoadCell Position
00191 00109      IOW MB045760 == 1      " CX Wait Position Moving Permission
00192 00110      MOV [CX]ML16064;
00193 00111      IOW MB04600C == 1      " CX Wheel Cleaning Start Position
00194
00195 00112      JOINTO LBL0X;
00196
00197 00113      LBL08:
00198          " Cutter X Cleaning Start Position
00199 00114      MB225584 = 0;          " Head Select (0:Cutter 1:Roller)
00200 00115      ML16064 = ML43282      " CX LoadCell Position
00201 00116      IOW MB045760 == 1      " CX Wait Position Moving Permission
00202 00117      MOV [CX]ML16064;
00203 00118      IOW MB04600D == 1      " CX Wheel Cleaning End Position
00204
00205 00119      JOINTO LBL0X;
00206
00207 00120      LBL300:
00208 00121      JOINTO LBL0X;
00209 00122      LBL0X: SJOINT;
00210
00211 00123      SFORK    MW00051 == 09 ? LBL09      " [CAMX] Camera X Waiting Position
00212              MW00051 == 10 ? LBL10      " [CAMX] Camera X Align Position
00213              MW00051 == 11 ? LBL11      "
00214              MW00051 == 12 ? LBL12      "
00215              MW00051 == 13 ? LBL13      "
00216              MW00051 == 14 ? LBL14      "
00217              MW00051 == 15 ? LBL15      "
00218              MW00051 == 16 ? LBL16      "
00219              DEFAULT ? LBL301;
00220
00221 00124      LBL09:
00222          " Camera X Waiting Position
00223 00125      ML16066 = ML43330      " CAMX Waiting Position
00224 00126      IOW MB04577A == 1      " CAMX Moving Permission
00225 00127      MOV [CAMX]ML16066;
00226 00128      IOW MB046010 == 1      " CAMX Waiting Position Check
00227
00228 00129      JOINTO LBL1X;
00229
00230 00130      LBL10:
00231          " Camera X Align Position
00232 00131      IF CW00001 == 1      " Scribe Direction (0: Forward / 1: Reverse)
00233 00132      ML16066 = ML01156      " CX Alignment Position
00234 00133      ELSE;
00235 00134      ML16066 = ML01158      " CX Alignment Position
00236 00135      IEND;
00237
00238 00136      IOW MB04577B == 1      " CAMX Moving Permission
00239 00137      MOV [CAMX]ML16066;
00240 00138      IOW MB046011 == 1      " CAMX Alignment Position Check
00241
00242 00139      JOINTO LBL1X;
00243
00244 00140      LBL11:
00245          "
00246 00141      JOINTO LBL1X;
00247
00248 00142      LBL12:
00249          "
00250 00143      JOINTO LBL1X;
00251
00252 00144      LBL13:
00253          "
00254 00145      JOINTO LBL1X;
00255
00256 00146      LBL14:
00257          "
00258 00147      JOINTO LBL1X;
00259
00260 00148      LBL15:
00261

```

```

00262 00149      JOINTO LBL1X;
00263
00264 00150      LBL16:
00265
00266 00151      JOINTO LBL1X;
00267
00268 00152      LBL301:
00269 00153      JOINTO LBL1X;
00270 00154      LBL1X: SJOINT;
00271
00272      *****
00273      ***** Chuck Y LBL17~24 *****
00274      *****
00275
00276 00155      SFORK   MW00051 == 17 ? LBL17      " [SCHY] Scribe Chuck Waiting Position
00277                MW00051 == 18 ? LBL18      " [SCHY] Scribe Chuck Receive Position
00278                MW00051 == 19 ? LBL19      " [SCHY] Scribe Chuck Alignment Befroe Position
00279                MW00051 == 20 ? LBL20      " [SCHY] Scribe Chuck Alignment Position
00280                MW00051 == 21 ? LBL21      " [SCHY] Scribe Chuck Start Position
00281                MW00051 == 22 ? LBL22      " Reserve
00282                MW00051 == 23 ? LBL23      " Reserve
00283                MW00051 == 24 ? LBL24      " Reserve
00284                DEFAULT ? LBL302;
00285
00286 00156      LBL17:
00287                " Scribe Chuck Y Waiting Position
00288 00157                MW04518 = 1;                " Scribe Chuck : Command Setting
00289 00158                MB045190 = 1;                " Scribe Chuck : Command Execute On
00290 00159                IOW MB045191 == 1            " Scribe Chuck : Command Complete On
00291 00160                MB045190 = 0;                " Scribe Chuck : Command Execute Reset
00292 00161                IOW MB045191 == 0            " Scribe Chuck : Command Complete Reset
00293
00294 00162      JOINTO LBL2X;
00295
00296 00163      LBL18:
00297                " Scribe Chuck Receive Position
00298 00164                MW04518 = 2;                " Scribe Chuck : Command Setting
00299 00165                MB045190 = 1;                " Scribe Chuck : Command Execute On
00300 00166                IOW MB045191 == 1            " Scribe Chuck : Command Complete On
00301 00167                MB045190 = 0;                " Scribe Chuck : Command Execute Reset
00302 00168                IOW MB045191 == 0            " Scribe Chuck : Command Complete Reset
00303
00304 00169      JOINTO LBL2X;
00305
00306 00170      LBL19:
00307                " Scribe Chuck Alignment Befroe Position
00308 00171                MW04518 = 3;                " Scribe Chuck : Command Setting
00309 00172                MB045190 = 1;                " Scribe Chuck : Command Execute On
00310 00173                IOW MB045191 == 1            " Scribe Chuck : Command Complete On
00311 00174                MB045190 = 0;                " Scribe Chuck : Command Execute Reset
00312 00175                IOW MB045191 == 0            " Scribe Chuck : Command Complete Reset
00313
00314 00176      JOINTO LBL2X;
00315
00316 00177      LBL20:
00317                " Scribe Chuck Alignment Position
00318 00178                MW04518 = 4;                " Scribe Chuck : Command Setting
00319 00179                MB045190 = 1;                " Scribe Chuck : Command Execute On
00320 00180                IOW MB045191 == 1            " Scribe Chuck : Command Complete On
00321 00181                MB045190 = 0;                " Scribe Chuck : Command Execute Reset
00322 00182                IOW MB045191 == 0            " Scribe Chuck : Command Complete Reset
00323
00324 00183      JOINTO LBL2X;
00325
00326 00184      LBL21:
00327                " Scribe Chuck Scribe Start Position
00328 00185                MW04518 = 5;                " Scribe Chuck : Command Setting
00329 00186                MB045190 = 1;                " Scribe Chuck : Command Execute On
00330 00187                IOW MB045191 == 1            " Scribe Chuck : Command Complete On
00331 00188                MB045190 = 0;                " Scribe Chuck : Command Execute Reset
00332 00189                IOW MB045191 == 0            " Scribe Chuck : Command Complete Reset
00333
00334 00190      JOINTO LBL2X;
00335
00336 00191      LBL22:
00337 00192      JOINTO LBL2X;
00338
00339 00193      LBL23:
00340 00194      JOINTO LBL2X;
00341
00342 00195      LBL24:
00343 00196      JOINTO LBL2X;
00344
00345 00197      LBL302:
00346 00198      JOINTO LBL2X;
00347 00199      LBL2X: SJOINT;
00348

```

```

00349 *****
00350 ***** SP LBL25~32 *****
00351 *****
00352
00353 00200      SFORK    MW00051 == 25 ? LBL25      "
00354          MW00051 == 26 ? LBL26      "
00355          MW00051 == 27 ? LBL27      "
00356          MW00051 == 28 ? LBL28      "
00357          MW00051 == 29 ? LBL29      "
00358          MW00051 == 30 ? LBL30      "
00359          MW00051 == 31 ? LBL31      "
00360          MW00051 == 32 ? LBL32      "
00361          DEFAULTI    ? LBL303;
00362
00363 00201      LBL25:
00364 00202          JOINTO LBL3X;
00365
00366 00203      LBL26:
00367 00204          JOINTO LBL3X;
00368
00369 00205      LBL27:
00370 00206          JOINTO LBL3X;
00371
00372 00207      LBL28:
00373 00208          JOINTO LBL3X;
00374
00375 00209      LBL29:
00376 00210          JOINTO LBL3X;
00377
00378 00211      LBL30:
00379 00212          JOINTO LBL3X;
00380
00381 00213      LBL31:
00382 00214          JOINTO LBL3X;
00383
00384 00215      LBL32:
00385 00216          JOINTO LBL3X;
00386
00387 00217      LBL303:
00388 00218          JOINTO LBL3X;
00389 00219      LBL3X: SJOINT
00390
00391 *****
00392 ***** Cutter Z LBL33~40 *****
00393 *****
00394
00395 00220      SFORK    MW00051 == 33 ? LBL33      " [CZ] Cutter Z Wait Position
00396          MW00051 == 34 ? LBL34      "
00397          MW00051 == 35 ? LBL35      " [CZ] Cutter Z Loadcell Position
00398          MW00051 == 36 ? LBL36      "
00399          MW00051 == 37 ? LBL37      " [CZ] Cutter Z Wheel Cleaning Start Position
00400          MW00051 == 38 ? LBL38      "
00401          MW00051 == 39 ? LBL39      "
00402          MW00051 == 40 ? LBL40      "
00403          DEFAULTI    ? LBL304;
00404
00405 00221      LBL33:
00406          " Cutter Z Wait Position
00407 00222          MW04842 = 1;
00408 00223          MSEE MPS198;
00409 00224          MW04842 = 0;
00410 00225          JOINTO LBL4X;
00411
00412 00226      LBL34:
00413 00227          JOINTO LBL4X;
00414
00415 00228      LBL35:
00416          " Cutter Z Loadcell Position
00417 00229          MW04842 = 3;
00418 00230          MSEE MPS198;
00419 00231          MW04842 = 0;
00420
00421 00232          JOINTO LBL4X;
00422
00423 00233      LBL36:
00424 00234          JOINTO LBL4X;
00425
00426 00235      LBL37:
00427          " Cutter Z Wheel Cleaning Position
00428 00236          MW04842 = 12;
00429 00237          MSEE MPS198;
00430 00238          MW04842 = 0;
00431
00432 00239          JOINTO LBL4X;
00433
00434 00240      LBL38:
00435 00241          JOINTO LBL4X;

```

```

00436
00437 00242      LBL39:
00438 00243      JOINTO LBL4X;
00439
00440 00244      LBL40:
00441 00245      JOINTO LBL4X;
00442
00443 00246      LBL304:
00444 00247      JOINTO LBL4X;
00445 00248      LBL4X: SJOINT;
00446
00447 *****
00448 ***** Cutter Shift LBL41~48 *****
00449 *****
00450
00451 00249      SFORK   MW00051 == 41 ? LBL41      " [CS] Cutter Shift Standby Position
00452              MW00051 == 42 ? LBL42      " [CS] Cutter Shift Loadcell Position
00453              MW00051 == 43 ? LBL43      " [CS] Cutter Shift Wheel Cleaning Position
00454              MW00051 == 44 ? LBL44      "
00455              MW00051 == 45 ? LBL45      "
00456              MW00051 == 46 ? LBL46      "
00457              MW00051 == 47 ? LBL47      "
00458              MW00051 == 48 ? LBL48      "
00459              DEFAULTI      ? LBL305;
00460
00461 00250      LBL41:
00462              " Cutter Shift Standby Position
00463              ML16070 = ML43530
00464 00252      MOV [CS]ML16070;
00465 00253      IOW MB046030 == 1;
00466 00254      JOINTO LBL5X;
00467
00468 00255      LBL42:
00469              " Cutter Shift Loadcell Position
00470              ML16070 = ML43542
00471 00257      MOV [CS]ML16070;
00472 00258      IOW MB046033 == 1;
00473 00259      JOINTO LBL5X;
00474
00475 00260      LBL43:
00476              " Cutter Shift Wheel Cleaning Position
00477 00261      ML16070 = ML43570
00478 00262      MOV [CS]ML16070;
00479 00263      IOW MB04603A == 1;
00480
00481 00264      JOINTO LBL5X;
00482
00483 00265      LBL44:
00484 00266      JOINTO LBL5X;
00485
00486 00267      LBL45:
00487
00488 00268      JOINTO LBL5X;
00489
00490 00269      LBL46:
00491
00492 00270      JOINTO LBL5X;
00493
00494 00271      LBL47:
00495
00496 00272      JOINTO LBL5X;
00497
00498 00273      LBL48:
00499
00500 00274      JOINTO LBL5X;
00501
00502 00275      LBL305:
00503 00276      JOINTO LBL5X;
00504 00277      LBL5X: SJOINT;
00505
00506 *****
00507 ***** Position LBL49~64 *****
00508 *****
00509
00510 00278      SFORK   MW00051 == 49 ? LBL49      " [SCH1Z] Chuck 1 Z Standby Position
00511              MW00051 == 50 ? LBL50      " [SCH1Z] Chuck 1 Z Moving Position
00512              MW00051 == 51 ? LBL51      " [SCH1Z] Chuck 1 Z Vacuum Position
00513              MW00051 == 52 ? LBL52      " [SCH2Z] Chuck 2 Z Standby Position
00514              MW00051 == 53 ? LBL53      " [SCH2Z] Chuck 2 Z Moving Position
00515              MW00051 == 54 ? LBL54      " [SCH2Z] Chuck 2 Z Vacuum Position
00516              MW00051 == 55 ? LBL55      " [SCH3Z] Chuck 3 Z Standby Position
00517              MW00051 == 56 ? LBL56      " [SCH3Z] Chuck 3 Z Moving Position
00518              DEFAULTI      ? LBL306;
00519
00520 00279      LBL49:
00521
00522 00280      MW04820 = 10;

```

```

00523 00281      MSEE MPS256;
00524
00525 00282      JOINTO LBL6X;
00526
00527 00283      LBL50:
00528
00529 00284      MW04820 = 11;
00530 00285      MSEE MPS256;
00531
00532 00286      JOINTO LBL6X;
00533
00534 00287      LBL51:
00535
00536 00288      MW04820 = 12;
00537 00289      MSEE MPS256;
00538
00539 00290      JOINTO LBL6X;
00540
00541 00291      LBL52:
00542
00543 00292      MW04820 = 13;
00544 00293      MSEE MPS256;
00545
00546 00294      JOINTO LBL6X;
00547
00548 00295      LBL53:
00549
00550 00296      MW04820 = 14;
00551 00297      MSEE MPS256;
00552
00553 00298      JOINTO LBL6X;
00554
00555 00299      LBL54:
00556
00557 00300      MW04820 = 15;
00558 00301      MSEE MPS256;
00559
00560 00302      JOINTO LBL6X;
00561
00562 00303      LBL55:
00563
00564 00304      MW04820 = 16;
00565 00305      MSEE MPS256;
00566
00567 00306      JOINTO LBL6X;
00568
00569 00307      LBL56:
00570
00571 00308      MW04820 = 17;
00572 00309      MSEE MPS256;
00573
00574 00310      JOINTO LBL6X;
00575
00576 00311      LBL306:
00577 00312      JOINTO LBL6X;
00578 00313      LBL6X: SJOINT,
00579
00580 00314      SFORK  MW00051 == 57 ? LBL57      " [SCH3Z] Chuck 3 Z Vacuum Position
00581      MW00051 == 58 ? LBL58      " [SCH4Z] Chuck 4 Z Standby Position
00582      MW00051 == 59 ? LBL59      " [SCH4Z] Chuck 4 Z Moving Position
00583      MW00051 == 60 ? LBL60      " [SCH4Z] Chuck 4 Z Vacuum Position
00584      MW00051 == 61 ? LBL61      " [SCH5Z] Chuck 5 Z Standby Position
00585      MW00051 == 62 ? LBL62      " [SCH5Z] Chuck 5 Z Moving Position
00586      MW00051 == 63 ? LBL63      " [SCH5Z] Chuck 5 Z Vacuum Position
00587      MW00051 == 64 ? LBL64      " [SCH6Z] Chuck 6 Z Standby Position
00588      DEFAULT      ? LBL307;
00589
00590 00315      LBL57:
00591
00592 00316      MW04820 = 18;
00593 00317      MSEE MPS256;
00594
00595 00318      JOINTO LBL7X;
00596
00597 00319      LBL58:
00598
00599 00320      MW04820 = 19;
00600 00321      MSEE MPS256;
00601
00602 00322      JOINTO LBL7X;
00603
00604 00323      LBL59:
00605
00606 00324      MW04820 = 20;
00607 00325      MSEE MPS256;
00608
00609 00326      JOINTO LBL7X;

```

```

00610
00611 00327      LBL60:
00612
00613 00328      MW04820 = 21;
00614 00329      MSEE MPS256;
00615
00616 00330      JOINTO LBL7X;
00617
00618 00331      LBL61:
00619
00620 00332      MW04820 = 22;
00621 00333      MSEE MPS256;
00622
00623 00334      JOINTO LBL7X;
00624
00625 00335      LBL62:
00626
00627 00336      MW04820 = 23;
00628 00337      MSEE MPS256;
00629
00630 00338      JOINTO LBL7X;
00631
00632 00339      LBL63:
00633
00634 00340      MW04820 = 24;
00635 00341      MSEE MPS256;
00636
00637 00342      JOINTO LBL7X;
00638
00639 00343      LBL64:
00640
00641 00344      MW04820 = 25;
00642 00345      MSEE MPS256;
00643
00644 00346      JOINTO LBL7X;
00645
00646 00347      LBL307:
00647 00348      JOINTO LBL7X;
00648 00349      LBL7X: SJOINT
00649
00650      *****
00651      ***** Position LBL65~77 *****
00652      *****
00653
00654 00350      SFORK   MW00051 == 65 ? LBL65           " [SCH6Z] Chuck 6 Z Moving Position
00655      MW00051 == 66 ? LBL66           " [SCH6Z] Chuck 6 Z Vacuum Position
00656      MW00051 == 67 ? LBL67           " [SCH7Z] Chuck 7 Z Standby Position
00657      MW00051 == 68 ? LBL68           " [SCH7Z] Chuck 7 Z Moving Position
00658      MW00051 == 69 ? LBL69           " [SCH7Z] Chuck 7 Z Vacuum Position
00659      MW00051 == 70 ? LBL70           " [SCH8Z] Chuck 8 Z Standby Position
00660      MW00051 == 71 ? LBL71           " [SCH8Z] Chuck 8 Z Moving Position
00661      MW00051 == 72 ? LBL72           " [SCH8Z] Chuck 8 Z Vacuum Position
00662      DEFAULT   ? LBL308;
00663
00664 00351      LBL65:
00665
00666 00352      MW04820 = 26;
00667 00353      MSEE MPS256;
00668
00669 00354      JOINTO LBL8X;
00670
00671 00355      LBL66:
00672
00673 00356      MW04820 = 27;
00674 00357      MSEE MPS256;
00675
00676 00358      JOINTO LBL8X;
00677
00678 00359      LBL67:
00679
00680 00360      MW04820 = 28;
00681 00361      MSEE MPS256;
00682
00683 00362      JOINTO LBL8X;
00684
00685 00363      LBL68:
00686
00687 00364      MW04820 = 29;
00688 00365      MSEE MPS256;
00689
00690 00366      JOINTO LBL8X;
00691
00692 00367      LBL69:
00693
00694 00368      MW04820 = 30;
00695 00369      MSEE MPS256;
00696

```

```

00697 00370      JOINTO LBL8X;
00698
00699 00371      LBL70:
00700
00701 00372      MW04820 = 31;
00702 00373      MSEE MPS256;
00703
00704 00374      JOINTO LBL8X;
00705
00706 00375      LBL71:
00707
00708 00376      MW04820 = 32;
00709 00377      MSEE MPS256;
00710
00711 00378      JOINTO LBL8X;
00712
00713 00379      LBL72:
00714
00715 00380      MW04820 = 33;
00716 00381      MSEE MPS256;
00717
00718 00382      JOINTO LBL8X;
00719
00720 00383      LBL308:
00721 00384      JOINTO LBL8X;
00722 00385      LBL8X: SJOINT
00723
00724 00386      SFORK   MW00051 == 73 ? LBL73      "
00725                  MW00051 == 74 ? LBL74      "
00726                  MW00051 == 75 ? LBL75      "
00727                  MW00051 == 76 ? LBL76      "
00728                  MW00051 == 77 ? LBL77      "
00729                  MW00051 == 78 ? LBL78      "
00730                  MW00051 == 79 ? LBL79      "
00731                  MW00051 == 80 ? LBL80      "
00732                  DEFAULT ? LBL309;
00733
00734 00387      LBL73:
00735 00388      JOINTO LBL9X;
00736
00737 00389      LBL74:
00738 00390      JOINTO LBL9X;
00739
00740 00391      LBL75:
00741 00392      JOINTO LBL9X;
00742
00743 00393      LBL76:
00744 00394      JOINTO LBL9X;
00745
00746 00395      LBL77:
00747 00396      JOINTO LBL9X;
00748
00749 00397      LBL78:
00750
00751 00398      MW04820 = 39;
00752 00399      MSEE MPS256;
00753
00754 00400      JOINTO LBL9X;
00755
00756 00401      LBL79:
00757
00758 00402      MW04820 = 40;
00759 00403      MSEE MPS256;
00760
00761 00404      JOINTO LBL9X;
00762
00763 00405      LBL80:
00764
00765 00406      MW04820 = 41;
00766 00407      MSEE MPS256;
00767
00768 00408      JOINTO LBL9X;
00769
00770 00409      LBL309:
00771 00410      JOINTO LBL9X;
00772 00411      LBL9X: SJOINT
00773
00774      "*****
00775      "***** Position LBL81 ~ 96 *****
00776      "*****
00777
00778 00412      SFORK   MW00051 == 81 ? LBL81      "
00779                  MW00051 == 82 ? LBL82      " [Position] Alignment Position
00780                  MW00051 == 83 ? LBL83      " [Position] Scribe Start Position
00781                  MW00051 == 84 ? LBL84      " [Position] Scribe End Position
00782                  MW00051 == 85 ? LBL85      " [Position] Camera Scribe Start Position
00783                  MW00051 == 86 ? LBL86      " [Position] Camera Scribe End Position

```

```

00784          MW00051 == 87 ? LBL87          " [Position] Loadcell Position
00785          MW00051 == 88 ? LBL88          " [Position] 0 Point Detection Position
00786          DEFAULT ? LBL310;
00787 00413      LBL81:
00788 00414          JOINTO LBL10X;
00789
00790 00415      LBL82:
00791          " Cutter X Cutting After Escape Position
00792 00416          IF !MB045741 == 1;
00793 00417          MW04514 = 1;
00794 00418          MB045150 = 1;          " Scribe Req Scribe Cutter Command Execute B
it ON
00795 00419          IOW MB045151 == 1          " Scribe Res Scribe Cutter Command Complete
Bit ON
00796 00420          MB045150 = 0;          " Scribe Req Scribe Cutter Command Execute B
it OFF
00797 00421          IOW MB045151 == 0          " Scribe Res Scribe Cutter Command Complete
Bit ON
00798 00422          IEND;
00799
00800          " Alignment Position
00801 00423          MSEE MPS181;          " Alignment Execute 1 Cycle
00802
00803 00424          JOINTO LBL10X;
00804
00805 00425      LBL83:
00806          " Scribe Start Position
00807 00426          IF DB00020 == 1;
00808 00427          MB045158 = 0;          " Alignment 1Cycle Complete(Manual)
00809 00428          MSEE MPS181;          " [Step.03] Alignment Exec 1 Cycle
00810 00429          MB045158 = 1;          " Alignment 1Cycle Complete(Manual)
00811 00430          ELSE;
00812 00431          IOW MW04514 == 0;
00813 00432          MW04514 = 1;          " Scribe Cutter Command Code Setting
00814 00433          MB045150 = 1;          " Scribe Cutter Command Execute Bit On
00815 00434          IOW MB045151 == 1          " Scribe Cutter Command Complete Bit On
00816 00435          MB045150 = 0;          " Scribe Cutter Command Execute Bit Off
00817 00436          IOW MB045151 == 0          " Scribe Cutter Command Complete Bit
00818 00437          IEND;
00819 00438          EOX;
00820
00821 00439          MSEE MPS182;          " Scribe Start Position
00822
00823 00440          JOINTO LBL10X;
00824
00825 00441      LBL84:
00826          " Scribe End Position
00827 00442          IF DB00020 == 1;
00828 00443          MB045158 = 0;          " Alignment 1Cycle Complete(Manual)
00829 00444          MSEE MPS181;          " [Step.03] Alignment Exec 1 Cycle
00830 00445          MB045158 = 1;          " Alignment 1Cycle Complete(Manual)
00831 00446          ELSE;
00832 00447          IOW MW04514 == 0;
00833 00448          MW04514 = 1;          " Scribe Cutter Command Code Setting
00834 00449          MB045150 = 1;          " Scribe Cutter Command Execute Bit On
00835 00450          IOW MB045151 == 1          " Scribe Cutter Command Complete Bit On
00836 00451          MB045150 = 0;          " Scribe Cutter Command Execute Bit Off
00837 00452          IOW MB045151 == 0          " Scribe Cutter Command Complete Bit On
00838 00453          IEND;
00839 00454          EOX;
00840
00841 00455          MSEE MPS182;          " Scribe Complete Position
00842
00843 00456          JOINTO LBL10X;
00844
00845 00457      LBL85:
00846          " L-Camera Scribe Start Position(Upper)
00847          " Scribe Start Position
00848 00458          MB21813E = 1;
00849 00459          MB21813F = 0;
00850
00851 00460          MW04862 = 13;
00852          " L Camera Line Check Position Move
00853 00461          MSEE MPS192;
00854 00462          MW04862 = 0;
00855
00856 00463          JOINTO LBL10X;
00857
00858 00464      LBL86:
00859          " L-Camera Scribe Complete Position(Upper)
00860          " Scribe End Position
00861 00465          MB21813E = 0;
00862 00466          MB21813F = 1;
00863
00864 00467          MW04862 = 14;
00865          " L Camera Line Check Position Move
00866 00468          MSEE MPS192;

```

```

00867 00469      MW04862 = 0;
00868
00869 00470      JOINTO LBL10X;
00870
00871 00471      LBL87:
00872      " Loadcell Position
00873      IOW MW04514 == 0;
00874 00473      MW04514 = 4;
00875 00474      MB045150 = 1;
00876 00475      IOW MB045151 == 1
00877 00476      MB045150 = 0;
00878 00477      IOW MB045151 == 0
00879
00880 00478      JOINTO LBL10X;
00881
00882 00479      LBL88:
00883      " 0 Detection Position
00884 00480      IF MB045740 == 0
00885 00481      MW04842 = 41;
00886 00482      MSEE MPS198;
00887 00483      MW04842 = 0;
00888 00484      IOW MW04842 == 0;
00889 00485      IEND;
00890
00891 00486      MSEE MPS257;
00892
00893 00487      MSEE MPS246;
00894
00895 00488      MB154219 = 0;
00896 00489      EOX;
00897
00898 00490      MW04812 = 0;
00899      " Cutter X, Cutter Shift Y 0 Point Position
00900 00491      IOW MW04514 == 0;
00901 00492      MW04514 = 7;
00902 00493      MB045150 = 1;
00903 00494      IOW MB045151 == 1
00904 00495      MB045150 = 0;
00905 00496      IOW MB045151 == 0
00906
00907 00497      JOINTO LBL10X;
00908
00909 00498      LBL310:
00910 00499      JOINTO LBL10X;
00911 00500      LBL10X: SJOINT;
00912
00913 00501      SFORK   MW00051 == 89 ? LBL89      " [Position] Cutter Z All Waiting Position
00914      MW00051 == 90 ? LBL90      " [Position] Cutter X All Waiting Position
00915      MW00051 == 91 ? LBL91      " [Position] Cutter Shift All Waiting Position
00916      MW00051 == 92 ? LBL92      "
00917      MW00051 == 93 ? LBL93      "
00918      MW00051 == 94 ? LBL94      "
00919      MW00051 == 95 ? LBL95      "
00920      MW00051 == 96 ? LBL96      "
00921      DEFAULTI      ? LBL311;
00922
00923
00924 00502      LBL89:
00925      " Scribe Cutter Z Waiting Position
00926 00503      MW4842 = 41;
00927 00504      MSEE MPS198;
00928 00505      MW4842 = 0;
00929 00506      IOW MW4842 == 0;
00930
00931 00507      JOINTO LBL11X;
00932
00933 00508      LBL90:
00934      " Scribe Cutter X Waiting Position
00935 00509      IOW MW04514 == 0;
00936 00510      MW04514 = 1;
00937 00511      MB045150 = 1;
00938 00512      IOW MB045151 == 1
00939 00513      MB045150 = 0;
00940 00514      IOW MB045151 == 0
00941
00942 00515      JOINTO LBL11X;
00943
00944 00516      LBL91:
00945      " Cutter Shift All Waiting Position
00946 00517      PLD [CS];
00947 00518      VEL [CS]ML43512;
00948 00519      ML16070 = ML43530
00949 00520      MOV [CS]ML16070
00950
00951 00521      JOINTO LBL11X;
00952
00953 00522      LBL92:

```

```

00954 00523      JOINTO LBL11X;
00955
00956 00524      LBL93:
00957 00525      JOINTO LBL11X;
00958
00959 00526      LBL94:
00960 00527      JOINTO LBL11X;
00961
00962 00528      LBL95:
00963 00529      JOINTO LBL11X;
00964
00965 00530      LBL96:
00966 00531      JOINTO LBL11X;
00967
00968 00532      LBL311:
00969 00533      JOINTO LBL11X;
00970 00534      LBL11X: SJOINT,
00971
00972      *****
00973      ***** 1Cycle LBL97 ~ 105 *****
00974      *****
00975
00976 00535      SFORK   MW00051 == 97 ? LBL97           " [1Cycle] Alignment Execute 1 Cycle
00977                  MW00051 == 98 ? LBL98           " [1Cycle] Scribe Execute 1 Cycle
00978                  MW00051 == 99 ? LBL99           " [1Cycle] Load CalibratiOn
00979                  MW00051 == 100 ? LBL100          " [1Cycle] Load Measurement
00980                  MW00051 == 101 ? LBL101          " [1Cycle] Auto Offset Set
00981                  MW00051 == 102 ? LBL102          " [1Cycle] 0 Point Detect Execute 1 Cycle
00982                  MW00051 == 103 ? LBL103          " [1Cycle] Line Check 1 Cycle
00983                  MW00051 == 104 ? LBL104          " [1Cycle] Wheel Cleaning 1 Cycle
00984                  DEFAULT ? LBL312;
00985 00536      LBL97:
00986                  " Alignment Execute 1 Cycle
00987 00537          MB045158 = 0;                      " Alignment 1Cycle Complete(Manual)
00988 00538          MSEE MPS181;                        " Alignment Execute 1 Cycle
00989 00539          MB045158 = 1;                        " Alignment 1Cycle Complete(Manual)
00990
00991 00540          JOINTO LBL12X;
00992
00993 00541      LBL98:
00994                  " Scribe Execute 1 Cycle
00995 00542          DB00030 = 0;
00996 00543          IF ML04860 == 3,                      " Last Dummy Continue Scribe
00997 00544              IF MB09022E & !MB030035 & MB030036 == 1;
00998 00545              DB00030 = 1;                        " Recipe Data
00999 00546              IEND;
01000 00547          IEND;
01001
01002 00548          IF !DB00030 & DB00020 == 1;
01003 00549              MB045158 = 0;                      " Alignment 1Cycle Complete(Manual)
01004 00550              MSEE MPS181;                        " Alignment Execute
01005 00551              MB045158 = 1;                      " Alignment 1Cycle Complete(Manual)
01006 00552          IEND;
01007
01008 00553          IF DB00030 == 1,                      " Last Dummy Continue Scribe
01009 00554              // MSEE MPS257;                      " Chuck, Table Break Escape Position
01010 00555              MB045158 = 0;                      " Alignment 1Cycle Complete(Manual)
01011 00556              IF CW00055 == 1;
01012 00557                  MSEE MPS215;                      // Aignment Execute
01013 00558              ELSE;
01014 00559                  MSEE MPS217;                      // Aignment Execute
01015 00560              IEND;
01016 00561              MB045158 = 1;                      " Alignment 1Cycle Complete(Manual)
01017 00562          IEND;
01018
01019 00563          MSEE MPS182;                      " Scribe Complete Position
01020
01021          " Cutter X Cutting After Escape Position
01022 00564          IF !MB045741 == 1;
01023 00565              MW04514 = 1;
01024 00566              MB045150 = 1;                      " Scribe Req Scribe Cutter Command Execute B
01025 00567          it ON      IOW MB045151 == 1              " Scribe Res Scribe Cutter Command Complete
01026 00568          Bit ON   MB045150 = 0;                  " Scribe Req Scribe Cutter Command Execute B
01027 00569          it OFF    IOW MB045151 == 0              " Scribe Res Scribe Cutter Command Complete
01028 00570          Bit ON   IEND;
01029
01030 00571          JOINTO LBL12X;
01031
01032 00572      LBL99:
01033 00573          " Load CalibratiOn 1 Cycle
01034 00574          MSEE MPS212;                      " Load Calibration
01035 00575          JOINTO LBL12X;
01036

```

```

01037 00574      LBL100:
01038              " Load Measurement 1 Cycle
01039 00575      MSEE MPS214;
01040 00576      JOINTO LBL12X;
01041
01042 00577      LBL101:
01043              " Auto Offset Set 1 Cycle
01044 00578      MSEE MPS216;
01045 00579      JOINTO LBL12X;
01046
01047 00580      LBL102:
01048              " 0 Point Detect Execute 1 Cycle
01049 00581      MB045748 = 0;
01050 00582      MSEE MPS245;
01051
01052 00583      JOINTO LBL12X;
01053
01054 00584      LBL103:
01055              " Line Check 1 Cycle
01056 00585      MSEE MPS187;
01057
01058 00586      JOINTO LBL12X;
01059
01060 00587      LBL104:
01061              " Wheel Cleaning 1 Cycle
01062 00588      MSEE MPS241;
01063 00589      JOINTO LBL12X;
01064
01065 00590      LBL312:
01066 00591      JOINTO LBL12X;
01067 00592      LBL12X: SJOINT;
01068
01069
01070      *****
01071      ***** 1Cycle LBL106 ~ 112 *****
01072      *****
01073
01074 00593      SFORK    MW00051 == 105 ? LBL105      "
01075              MW00051 == 106 ? LBL106      "
01076              MW00051 == 107 ? LBL107      "
01077              MW00051 == 108 ? LBL108      "
01078              MW00051 == 109 ? LBL109      " [1Cycle] Break Pusher Bar Breaking Execute 1 Cycle
01079              MW00051 == 110 ? LBL110      " [1Cycle] Break Table Breaking Execute 1 Cycle
01080              MW00051 == 111 ? LBL111      " [1Cycle] Last Break Pusher Bar Breaking Execute 1 Cycle
01081
01082              MW00051 == 112 ? LBL112      "
01083              DEFAULT ? LBL313;
01084
01085 00594      LBL105:
01086 00595      JOINTO LBL13X;
01087
01088 00596      LBL106:
01089 00597      JOINTO LBL13X;
01090
01091 00598      LBL107:
01092 00599      JOINTO LBL13X;
01093
01094 00600      LBL108:
01095 00601      JOINTO LBL13X;
01096
01097 00602      LBL109:
01098              " Break Pusher Bar Breaking Execute 1 Cycle
01099 00603      IF ML05308 == 1
01100 00604      MSEE MPS183;
01101 00605      IEND;
01102
01103 00606      JOINTO LBL13X;
01104
01105 00607      LBL110:
01106              " Break Table Breaking Execute 1 Cycle
01107 00608      IF ML05810 == 1
01108 00609      MSEE MPS185;
01109 00610      IEND;
01110 00611      JOINTO LBL13X;
01111
01112 00612      LBL111:
01113              " Last Break Pusher Bar Breaking Execute 1 Cycle
01114 00613      IF ML05310 == 1
01115 00614      MSEE MPS184;
01116 00615      IEND;
01117 00616      JOINTO LBL13X;
01118
01119 00617      LBL112:
01120 00618      JOINTO LBL13X;
01121
01122 00619      LBL313:

```

```
01123 00620      JOINTO LBL13X;  
01124 00621      LBL13X: SJOINT,  
01125  
01126      " All Stop Request Reset  
01127 00622      MB045709 = 1;  
01128  
01129 00623      MW04920 = MW00051;  
01130 00624      MB00003E = 1;  
01131 00625      END;
```