

```

00001      ** DL Register Area - 120Word
00002      **
00003      ** DW00000 - DW00009 (PLS Use)
00004      ** DW00010 - DW00039 (Bit Use)
00005      ** DW00040 - DW00089 (Word Use)
00006      ** DW00090 - DW00119 (Timer)
00007      ****
00008
00009      "# Program Name      : [Loading] SC Interface
00010      "# Functionior      :
00011      "# Call Program     :
00012      "# Sub Program      :
00013      "# Func Program     :
00014
00015      VAR;
00016
00017      END_VAR;
00018
00019      " MTR Req SC Interface Start
00020 00000      MB04570F = 1;
00021
00022 00001      IF MB00004 & !MB030034 & !MB045013 == 1;
00023 00002          DB000012 = 0;
00024 00003          WHILE DB000012 == 0;
00025 00004              IF MB045690 & MB04574E == 1
00026 00005                  MB045280 = 1;
00027 00006                  DB000012 = 1;
00028 00007              IEND;
00029
00030 00008              IF MB045013 == 1;
00031 00009                  DB000012 = 1;
00032 00010              IEND;
00033 00011              EOX;
00034 00012          WEND;
00035
00036 00013          DB000014 = 0;
00037 00014          WHILE DB000014 == 0;
00038 00015              IF MB070270 & MB045280 == 1;
00039 00016                  MB045281 = 1;
00040 00017                  MB045780 = 1;
00041 00018                  IOW MB49440 == 0;
00042 00019                  MB49440 = 1;
00043 00020                  MB09061E = 1;
00044 00021                  IOW MB09031E == 1;
00045 00022                  MB49440 = 0;
00046 00023                  DB000014 = 1;
00047 00024              IEND;
00048 00025              IF MB045013 == 1;
00049 00026                  DB000014 = 1;
00050 00027              IEND;
00051 00028              EOX;
00052 00029          WEND;
00053 00030          IF !MB045013 == 1;
00054 00031              DB000022 = 0;
00055 00032              WHILE DB000022 == 0;
00056 00033                  IF MB071003 == 1
00057 00034                      IF MB070275 == 1
00058 00035                          IOW MB49440 == 0;
00059 00036                          MB49440 = 1;
00060 00037                          MB09048F = 1;
00061 00038                          IOW MB09018F = 1;
00062 00039                          MB49440 = 0;
00063
00064 00040                          IF MB09018F | MB00800 == 1
00065 00041                              MB002482 = 1;
00066 00042                      IOW MB02003 == 1
00067 00043                      MB045282 = 1;
00068 00044                      IOW MB070272 == 1;
00069 00045                      DB000022 = 1;
00070 00046                      IEND;
00071 00047                      IEND;
00072 00048                      IEND;
00073 00049                      IF MB030034 == 1
00074 00050                          MB045282 = 1;
00075 00051                      IF MB070272 == 1
00076 00052                          DB000022 = 1;
00077 00053                      IEND;
00078 00054                      IEND;
00079 00055                      EOX;
00080 00056                  WEND;
00081 00057              IEND;
00082
00083 00058          IF !MB045013 == 1;

```

" MTR Req SC Interface Start
 " SCHY - MTR Non Interference Pos
 " [SC Req MTR] Receive Possible
 " [SC Req MTR] Receive Start
 " Fix Table PIO Permission
 " Fix Table All Blow OFF
 " MTR Z Carry Out Pos
 " [MTR -> SCT Fix Table] Vacuum On R
 equest On
 " Fix Table All Vac. On
 " Fix Table All Vac. On Check
 " Work Move : SCT Main Transfer -> S
 CT Scribe Fix Table
 " P Wokr : SCT Fix Table
 " Scribe -> Main Transfer Receive Co
 mplete
 " P Wokr : Fix Table
 " Scribe -> Main Transfer Receive Co
 mplete

```

00084 00059          DB000018 = 0;
00085 00060          WHILE DB000018 == 0;
00086 00061              IF MB071020 & MB070272 & MB030034 == 1;
00087 00062                  MW04528 = 0;                " SC PIO Clear
00088 00063                  IEND;
00089 00064                  IF MW07027 == 0              " MTR PIO Clear Check
00090 00065                      DB000018 = 1;
00091 00066                  IEND;
00092          //          IF MB045013 == 1;
00093          //          DB000018 = 1;
00094          //          IEND;
00095 00067          EOX;
00096 00068          WEND;
00097 00069          IEND;
00098 00070          IEND;
00099
00100 00071          MB04570F = 0;                " LD Req SC Interface Start
00101
00102 00072  RET;

```

			MPS234 : [Loading] SC Interface	P00002
--	--	--	---------------------------------	--------