

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      :
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017     CONST LONG AXIS_MTRY1 = 3;
00018     CONST LONG AXIS_MTRY2 = 4;
00019 END_VAR;
00020
00021 00000     PLD [MTRY1][MTRY2];
00022 00001     VEL [MTRY1]ML40312 [MTRY2]ML40312;
00023
00024 00002     DW00030 = MW07340                                " Main Transfer Y Motion Code Setting
00025
00026 00003     SFORK    DW00030 == 1 ? LBL01                    " Main Transfer Y StandBy Pos
00027                  DW00030 == 2 ? LBL02                    " Main Transfer Y Tunrning Pos
00028                  DW00030 == 3 ? LBL03                    " Main Transfer Y Carry In Pos
00029                  DW00030 == 4 ? LBL04                    " Main Transfer Y Carry Out Pos
00030                  DW00030 == 5 ? LBL05                    " Main Transfer Y PreAlign Pos
00031                  DW00030 == 6 ? LBL06                    " Main Transfer Y MCR Pos
00032                  DW00030 == 7 ? LBL07                    "
00033                  DW00030 == 8 ? LBL08                    "
00034                  DEFAULT ? LBL100;
00035
00036 00004     LBL01:
00037
00038 00005         IOW MB070760 == 1                                " Main Transfer Y StandBy Pos Enable
00039
00040 00006         ML16006 = ML60602                                " Move Data:Main Transfer Y StandBy Pos
00041 00007         MOV [MTRY1]ML16006 [MTRY2]ML16006 ;
00042
00043 00008         IOW MB071000 == 1                                " Main Transfer Y StandBy Pos Moving Com
00044 p Check
00045 00009         JOINTO LBL0X;
00046
00047 00010     LBL02:
00048
00049 00011         IOW MB070761 == 1                                " Main Transfer Y Turning Pos Enable
00050
00051 00012         ML16006 = ML60622                                " Move Data:Main Transfer Y Turning Pos
00052 00013         MOV [MTRY1]ML16006 [MTRY2]ML16006 ;
00053
00054 00014         IOW MB071001 == 1                                " Main Transfer Y Turning Pos Moving Com
00055 p Check
00056 00015         JOINTO LBL0X;
00057
00058 00016     LBL03:
00059
00059 00017         IOW MB070762 == 1                                " Main Transfer Y Carry In Pos Enable
00060
00061 00018         ML16006 = ML60606                                " Move Data:Main Transfer Y Carry In Pos
00062 00019         MOV [MTRY1]ML16006 [MTRY2]ML16006;
00063
00064 00020         IOW MB071002 == 1                                " Main Transfer Y Carry In Pos Moving Co
00065 mp Check
00066 00021         JOINTO LBL0X;
00067
00068 00022     LBL04:
00069
00069 00023         IOW MB070763 == 1                                " Main Transfer Y Carry Out Pos Enable
00070
00071 00024         ML16006 = ML60610                                " Move Data:Main Transfer Y Carry Out Po
00072 s
00073 00025         MOV [MTRY1]ML16006 [MTRY2]ML16006 ;
00074 00026         IOW MB071003 == 1                                " Main Transfer Y Carry Out Pos Moving C
00075 omp Check
00076 00027         JOINTO LBL0X;
00077
00078 00028     LBL05:
00079
00079 00029         IOW MB070764 == 1                                " Main Transfer Y PreAlign Pos Enable
00080
00081 00030         ML16006 = ML60626                                " Move Data:Main Transfer Y PreAlign Pos
00082 00031         MOV [MTRY1]ML16006 [MTRY2]ML16006 ;

```

```
00083
00084 00032      IOW MB071004 == 1      " Main Transfer Y PreAlign Pos Moving Co
mp Check
00085
00086 00033      JOINTO LBL0X;
00087
00088 00034      LBL06:
00089
00090 00035      IOW MB070765 == 1      " Main Transfer Y MCR Pos Enable
00091
00092 00036      ML16006 = ML60630      " Move Data:Main Transfer Y MCR Pos
00093 00037      MOV [MTRY1]ML16006 [MTRY2]ML16006 ;
00094
00095 00038      IOW MB071005 == 1      " Main Transfer Y MCR Pos Moving Comp Ch
eck
00096
00097 00039      JOINTO LBL0X;
00098
00099 00040      LBL07:
00100
00101 00041      JOINTO LBL0X;
00102
00103 00042      LBL08:
00104
00105 00043      JOINTO LBL0X;
00106
00107 00044      LBL100:
00108 00045      JOINTO LBL0X;
00109 00046      LBL0X: SJOINT;
00110
00111 00047      DW00030 = 0;      " Unit7 Main Transfer Y Motion Code Rese
t
00112 00048      MW07340 = 0;      " Unit7 Main Transfer Y Motion Code Rese
t
00113
00114 00049      RET;
```