

```

00001 *****
00002 ** DL Register Area - 120Word
00003 **
00004 ** DW00000 - DW00009 (Pls Use)
00005 ** DW00010 - DW00039 (Bit Use)
00006 ** DW00040 - DW00089 (Word Use)
00007 ** DW00090 - DW00119 (Timer)
00008 *****
00009
00010 "# Program Name      :
00011 "# Function          :
00012 "# Call Program      :
00013 "# Sub Program       :
00014 "# Func Program      :
00015
00016 VAR;
00017     CONST LONG AXIS_MTRZ1 = 6;
00018     CONST LONG AXIS_MTRZ2 = 7;
00019 END_VAR;
00020
00021 00000     PLD [MTRZ1][MTRZ2];
00022 00001     VEL [MTRZ1]ML40612 [MTRZ2]ML40612;
00023
00024 00002     DW00030 = MW07344                                " Main Transfer Z Motion Code Setting
00025
00026 00003     SFORK    DW00030 == 1 ? LBL01                    " Main Transfer Z Stand By Pos
00027                  DW00030 == 2 ? LBL02                    "
00028                  DW00030 == 3 ? LBL03                    " Main Transfer Z Carry In Pos
00029                  DW00030 == 4 ? LBL04                    " Main Transfer Z Carry Out Pos
00030                  DW00030 == 5 ? LBL05                    " Main Transfer Z PreAlign Pos
00031                  DW00030 == 6 ? LBL06                    " Main Transfer Z MCR Pos
00032                  DW00030 == 7 ? LBL07                    "
00033                  DW00030 == 8 ? LBL08                    "
00034                  DEFAULT ? LBL100;
00035
00036 00004     LBL01:
00037
00038 00005         IOW MB070778 == 1                                " Unit1 Motor IL:Main Transfer Z Standby
00039         Pos Enable
00040
00041 00006         ML16012 = ML61202                                " Axis3 Move Data:Main Transfer Z StandB
00042 y Pos
00043 00007         MOV [MTRZ1]ML16012 [MTRZ2]ML16012;
00044
00045 00008         IOW MB071020 == 1                                " Main Transfer Z Standby Pos Moving Com
00046 p Check
00047
00048 00009         JOINTO LBL0X;
00049
00050 00010         LBL02:
00051
00052 00011         JOINTO LBL0X;
00053
00054 00012         LBL03:
00055
00056 00013         IOW MB07077A == 1                                " Unit1 Motor IL:Main Transfer Z Carry I
00057 n Pos Enable
00058
00059 00014         ML16012 = ML61206                                " Axis3 Move Data:Main Transfer Z Carry
00060 In Pos
00061 00015         MOV [MTRZ1]ML16012 [MTRZ2]ML16012;
00062
00063 00016         IOW MB071022 == 1                                " Main Transfer Z Carry In Pos Moving Co
00064 mp Check
00065
00066 00017         JOINTO LBL0X;
00067
00068 00018         LBL04:
00069
00070 00019         IOW MB07077B == 1                                " Unit1 Motor IL:Main Transfer Z Carry O
00071 ut Pos Enable
00072
00073 00020         ML16012 = ML61210                                " Axis3 Move Data:Main Transfer Z Carry
00074 Out Pos
00075 00021         MOV [MTRZ1]ML16012 [MTRZ2]ML16012;
00076
00077 00022         IOW MB071023 == 1                                " Main Transfer Z Carry Out Pos Moving C
00078 omp Check
00079
00080 00023         JOINTO LBL0X;
00081
00082 00024         LBL05:
00083
00084 00025         IOW MB07077C == 1                                " Unit1 Motor IL:Main Transfer Z PreAlign
00085 n Pos Enable
00086
00087 00026         ML16012 = ML40642                                " Axis3 Move Data:Main Transfer Z PreAli

```

```

      gn Pos
00078 00027      MOV [MTRZ1]ML16012 [MTRZ2]ML16012;
00079
00080 00028      IOW MB071024 == 1          " Main Transfer Z PreAlign Pos Moving Co
      mp Check
00081
00082 00029      JOINTO LBL0X;
00083
00084 00030      LBL06:
00085
00086 00031      IOW MB07077D == 1          " Unit1 Motor IL:Main Transfer Z MCR Pos
      Enable
00087
00088 00032      ML16012 = ML40646          " Axis3 Move Data:Main Transfer Z MCR Po
      s
00089 00033      MOV [MTRZ1]ML16012 [MTRZ2]ML16012;
00090
00091 00034      IOW MB071025 == 1          " Main Transfer Z MCR Pos Moving Comp Ch
      eck
00092
00093 00035      JOINTO LBL0X;
00094
00095 00036      LBL07:;
00096
00097 00037      JOINTO LBL0X;
00098
00099 00038      LBL08:;
00100
00101 00039      JOINTO LBL0X;
00102
00103 00040      LBL100:
00104 00041      JOINTO LBL0X;
00105 00042      LBL0X: SJOINT;
00106
00107
00108 00043      SFORK   DW00030 == 9   ? LBL09          " Main Transfer Z 2 Pos Carry In Before
      Pos
00109      DW00030 == 10   ? LBL10          " Main Transfer Z 2 Pos Carry In Pos
00110      DW00030 == 11   ? LBL11          " Main Transfer Z 2 Pos Carry Out Before
      Pos
00111      DW00030 == 12   ? LBL12          " Main Transfer Z 2 Pos Carry Out Pos
00112      DW00030 == 13   ? LBL13          " Main Transfer Z Vacuum Retry Pos
00113      DW00030 == 14   ? LBL14          "
00114      DW00030 == 15   ? LBL15          "
00115      DW00030 == 16   ? LBL16          "
00116      DEFAULT      ? LBL101;
00117
00118 00044      LBL09:
00119
00120 00045      IOW MB07077A == 1          " Main Transfer Z Carry In Pos Enable
00121
00122 00046      ML16012 = ML61206 - GL49106          " Move Data:Main Transfer Z 2 Pos Carry
      In Before Pos
00123 00047      IF MB070005 == 1;
00124 00048      VEL [MTRZ1]5000 [MTRZ2]5000;
00125 00049      ML16012 = ML61206 - 5000;
00126 00050      IEND;
00127 00051      MOV [MTRZ1]ML16012 [MTRZ2]ML16012;
00128
00129 00052      JOINTO LBL1X;
00130
00131 00053      LBL10:
00132
00133 00054      IOW MB07077A == 1          " Main Transfer Z Carry In Pos Enable
00134
00135 00055      ML16012 = ML61206          " Move Data:Main Transfer Z 2 Pos Carry
      In Pos
00136 00056      VEL [MTRZ1]GL49104 [MTRZ2]GL49104;
00137 00057      IF GL49104 == 0;
00138 00058      VEL [MTRZ1]ML40612 [MTRZ2]ML40612;
00139 00059      IEND;
00140 00060      MOV [MTRZ1]ML16012 [MTRZ2]ML16012;
00141 00061      IOW MB071022 == 1          " Main Transfer Z Carry In Pos Moving Co
      mp Check
00142
00143 00062      JOINTO LBL1X;
00144
00145 00063      LBL11:
00146
00147 00064      IOW MB07077B == 1          " Main Transfer Z Carry Out Pos Enable
00148
00149 00065      ML16012 = ML61210 - GL49112          " Move Data:Main Transfer Z 2 Pos Carry
      Out Before Pos
00150 00066      IF MB070005 == 1;
00151 00067      VEL [MTRZ1]5000 [MTRZ2]5000;
00152 00068      ML16012 = ML61210 - 5000;
00153 00069      IEND;

```

```
00154 00070      MOV [MTRZ1]ML16012 [MTRZ2]ML1601:
00155
00156 00071      JOINTO LBL1X;
00157
00158 00072      LBL12:
00159
00160 00073      IOW MB07077B == 1                      " Main Transfer Z Carry Out Pos Enable
00161
00162 00074      ML16012 = ML61210                      " Move Data:Main Transfer Z 2 Pos Carry
Out Pos
00163 00075      VEL [MTRZ1]GL49110 [MTRZ2]GL49110;
00164 00076      IF GL49110 == 0;
00165 00077          VEL [MTRZ1]ML40612 [MTRZ2]ML40612;
00166 00078      IEND;
00167 00079      MOV [MTRZ1]ML16012 [MTRZ2]ML16012;
00168
00169 00080      IOW MB071023 == 1                      " Main Transfer Z Carry Out Pos Moving C
omp Check
00170 00081      JOINTO LBL1X;
00171
00172 00082      LBL13:
00173
00174 00083      IOW MB07077A == 1                      " Main Transfer Z Carry In Pos Enable
00175
00176 00084      ML16012 = ML61206 - GL49102          " Move Data:Main Transfer Z 2 Pos Carry
In Vacuum Retry Pos
00177 00085      MOV [MTRZ1]ML16012 [MTRZ2]ML16012;
00178
00179 00086      IOW MB071029 == 1                      " Main Transfer Z Carry In Vacuum Retry
Pos Moving Comp Check
00180
00181 00087      JOINTO LBL1X;
00182
00183 00088      LBL14:
00184
00185 00089      JOINTO LBL1X;
00186
00187 00090      LBL15:
00188
00189 00091      JOINTO LBL1X;
00190
00191 00092      LBL16:
00192
00193 00093      JOINTO LBL1X;
00194
00195 00094      LBL101:
00196 00095          JOINTO LBL1X;
00197 00096      LBL1X: SJOINT;
00198
00199
00200 00097      DW00030 = 0;                      " Main Transfer Z Motion Code Reset
00201 00098      MW07344 = 0;                      " Main Transfer Z Motion Code Reset
00202
00203 00099      RET;
```