

Stage right house crowd mic



Utility

Crowd

32 Bottom 16

Direct

Crowd Right

## **Full Band Setup**

Date Updated: 2025-03-24 Mic/DI **Musician Position** Mixer **IEM Box Sub Snake** Stand Input **Notes** Top 1 Drum 1 **Chad Vocals** Shure Beta 56A Overhead Stand Light reverb. Light Delay 2 Top 2 Drum 2 Kick Shure Beta 52A Internal Suspended inside bass drum Drums Top 3 Drum 3 Snare Shure Beta 56A Drum Clamp 48V provided by IEM Box 4 Top 4 Drum 4 Hi-Hat Shure SM137 Drum Clamp Top 5 Drum 5 Tom 1 Shure Beta 98AMP/C Drum Clamp 48V provided by IEM Box 6 Top 6 48V provided by IEM Box Drum 6 Tom 2 Shure Beta 98AMP/C Drum Clamp Top 7 Drum 7 Tom 3 Shure Beta 98AMP/C **Drum Clamp** 48V provided by IEM Box 8 Top 8 Drum 8 Tom 4 Shure Beta 98AMP/C Drum Clamp 48V provided by IEM Box 9 Top 9 Drum 9 Overhead Ride Shure SM137 **Boom Stand** 48V provided by IEM Box 10 Top 10 Drum 10 Overhead Hat Shure SM137 **Boom Stand** 48V provided by IEM Box 11 Top 11 Unused 12 Top 12 Unused 13 Top 13 Unused 14 Top 14 Unused 15 Top 15 Direct Bluetooth Left Direct N/A Utility Bluetooth 16 Top 16 N/A Direct Bluetooth Right Direct Gordon 17 Bottom 1 DSR<sub>1</sub> Gordon Vocals Shure Beta 58 **Boom Stand** Light reverb. Light Delay Stage Right 18 Bottom 2 **Bass** DSR 2 **Gordon Bass** Behringer BDI 21 Direct 19 Bottom 3 DSR 3 Unused Jessica 20 Bottom 4 DSR 4 Jessica Vocals Shure Beta 58A **Boom Stand** EQ up low and mid. Heavy reverb. Center Guitar Stage Right 21 Bottom 5 DSR 5 Jessica Acoustic DI Box Direct 22 Bottom 6 DSL<sub>1</sub> **Paul Vocals** Shure 55SH **Boom Stand** Light reverb. Light Delay Paul Center 23 Bottom 7 USL 1 Paul Electric Sennheiser E609 **Amp Hang Stage Left** Guitar 24 Bottom 8 USL 2 Paul Electric Behringer B906 **Amp Hang** 25 Bottom 9 Unused 26 Bottom 10 DSL 2 Kenzi Vocals Telefunken M80 **Overhead Stand** Light reverb. Light Delay Kenzi 27 Bottom 11 DSL 3 Kenzi Piano Behringer DI4800A Piano Stand Stage 28 Bottom 12 DSL 4 Kenzi Keyboard Behringer DI4800A Piano Stand Left 29 Bottom 13 USL 3 Shure SM57 Kenzi Electric Floor Stand 30 Bottom 14 DSL 5 Behringer DI4800A Kenzi Acoustic Floor Stand 31 Bottom 15 Direct Crowd Left Stage left house crowd mic House House

House

House



## **Full Band Setup**

## www.theperfectstrangers.band

Date Updated: 2025-03-24

Drum & Utility Snake (Top Snake) Input							
1	2	3	4	5	6	7	8
Chad Vocals	Kick	Snare	Hi-Hat	Tom 1	Tom 2	Tom 3	Tom 4
9	10	11	12	13	14	15	16
Overhd	Overhd					BT	BT
Ride	Hat					Left	Right

Output							
1	2	3	4	5	6	7	8
Chad Vocals	Tom 1	Tom 2	Tom 3	Tom 4	Hi-Hat		

Band & IEM Snake (Bottom Snake) Input								
1	2	3	4	5	6	7	8	
Gordon	Gordon		Jessica	Jessica	Davil Vacale	Paul		
Vocals	Bass		Vocals	Acstc	Paul Vocals	Electric		
9	10	11	12	13	14	15	16	
	Kenzi	Kenzi	Kenzi	Kenzi	Kenzi	Crowd	Crowd	
	Vocals	Piano	Keys	Electrc	Acstc	Left	Right	

Output							
1	2	3	4	5	6	7	8
Chad IEM	Gordon IEM	Jessica IEM	Paul IEM	Kenzi IEM		Main Left	Main Right

Notes						
1	Drum Snake outputs are used to extend splitter					
2	Paul's IEM transmitter Port 1 does not work (capped)					
3	Colored cables = band vocals & instruments					
4	Black patch cables in the box are not to be unplugged					
5	Crowd mic L/R is on ports 30/31 on bottom splitter. May require gender changer.					
6	Talkback is on port 32 of the bottom splitter. May require gender changer.					

IEM Operating Frequencies						
Device	Model	Frequencies				
Chad's IEM	Shure PSM 200	518 - 554 MHz				
Paul's IEM	Shure PSM 200	518 - 554 MHz				
Jessica's IEM	Shure PSM 200	518 - 554 MHz				
Kenzi's IEM	Shure PSM 300	488–937.5 MHz				
Gordon's IEM	Shure PSM 200	518 - 554 MHz				