

Full Band Setup

Musician	Position	Channel	Input	Sub Snake	Input Name	Mic/DI	Stand	Notes
Chad	Drums	1	L1	Drum 1	Chad Vocals	Shure Beta 56A	Overhead Stand	Light reverb. Light Delay
		2	L2	Drum 2	Kick	Shure Beta 52A	Internal	Suspended inside bass drum
		3	L3	Drum 3	Snare (Top)	Shure Beta 56A	Drum Clamp	
		4	L4	Drum 4	Snare (Bottom)	Shure SM57	Base Stand	
		5	L5	Drum 5	Aux	Shure SM137	Drum Clamp	48V provided by IEM Box
		6	L6	Drum 6	Tom 1	Shure Beta 98AMP/C	Drum Clamp	48V provided by IEM Box
		7	L7	Drum 7	Tom 2	Shure Beta 98AMP/C	Drum Clamp	48V provided by IEM Box
		8	L8	Drum 8	Tom 3	Shure Beta 98AMP/C	Drum Clamp	48V provided by IEM Box
		9	L9	Drum 9	Tom 4	Shure Beta 98AMP/C	Drum Clamp	48V provided by IEM Box
		10	L10	Drum 10	Overhead Ride	Shure SM137	Boom Stand	48V provided by IEM Box
		11	L11	Drum 11	Overhead Hat	Shure SM137	Boom Stand	48V provided by IEM Box
		12					Unused	
		13					Unused	
Billy Bass	Upstage Left	14	A1		Billy Vocals	Shure Beta 58	Boom Stand	Not for live shows, only practice space.
		15	A2	USR 1	Billy Bass	Behringer BDI 21	Direct	
		16					Unused	
Jessica Vocals	Downstage Center	17	A3	DSR 1	Jessica Vocals	Shure Beta 58A	Boom Stand	Increase EQ on lows & mids, heavy reverb
Paul Guitar	Downstage Right	18	A4	DSL 1	Paul Vocals	Shure 55SH	Boom Stand	Light reverb. Light Delay
		19	A5	Direct 5	Paul Amp SL	Sennheiser E609	Amp Hang	
		20	A6	Direct 6	Paul Amp SR	Sennheiser E609	Amp Hang	
		21	A7	DSL 2	Paul Acoustic	Behringer DI4800A	Floor Stand	
		22					Unused	
Mike Guitar	Upstage Right	23	A8	DSR 2	Mike Vocals	Shure PGA48	Boom Stand	Light reverb. Light Delay
		24	A9	USR 2	Mike Amp SL	Shure SM57	Floor Stand	
		25	A10	USR 3	Mike Amp SR	Shure SM57	Floor Stand	
		26	A11	DSR 3	Mike Acoustic	DI Box	Direct	
Kenzi Keys	Downstage Left	27	A12	DSL 3	Kenzi Vocals	Telefunken M80	Overhead Stand	Light reverb. Light Delay
		28	A13	DSL 4	Kenzi Piano	Behringer DI4800A	Piano Stand	
		29	A14	DSL 5	Kenzi Keyboard	Behringer DI4800A	Piano Stand	
		30	A15	DSL 6	Kenzi Acoustic	Behringer DI4800A	Floor Stand	
		31	A16	Direct 16	Kenzi Amp	Shure SM57	Floor Stand	
Guest	Downstage	32	A17	DSR 4 DSL 7	Guest Vocals	Shure SM57	Boom Stand	Light reverb. Light Delay. May not need.
Utility	Crowd	33	L17		Crowd Left	House	House	Stage left house crowd mic
	Crowd	34	L18		Crowd Right	House	House	Stage right house crowd mic
		35						Unused
		36						Unused
		37						Unused
	Bluetooth	38	L21/22		Bluetooth Left	Direct	N/A	
		39						Unused
	Talkback	40	L24/A32		Talkback	Direct	N/A	Front (A32) Rear (L24)



Full Band Setup

theperfectstrangers.band

Date Updated: 2026.09.04

WING Rack Rear Input (Local)							
1	2	3	4	5	6	7	8
Chad Vocals	Kick	Snare (Top)	Snare (Bottom)	Hi-Hat	Tom 1	Tom 2	Tom 3
17	18	19	20	21	22	23	24
Crowd Left	Crowd Right			BT Left	BT Right		Talkback

WING Rack Rear Input (Local)							
9	10	11	12	13	14	15	16
Tom 4	Overhd Ride	Overhd Hat					
Output							
1	2	3	4	5	6	7	8
Chad IEM Left	Chad IEM Right						

Midas DL32 Front Input (AES50A)							
Input							
1	2	3	4	5	6	7	8
Billy Vocals	Billy Bass	Jessica Vocals	Paul Vocals	Paul Amp SL	Paul Amp SR	Paul Acoustic	Mike Vocals
Input							
17	18	19	20	21	22	23	24
Guest Vocals							
Output							
1	2	3	4	5	6	7	8
Billy IEM Left	Billy IEM Right	Jessica IEM Left	Jessica IEM Right	Paul IEM Left	Paul IEM Right	Kenzi IEM Left	Kenzi IEM Right

Midas DL32 Front Input (AES50A)							
Input							
9	10	11	12	13	14	15	16
Mike Amp SL	Mike Amp SR	Mike Acstc	Kenzi Vocals	Kenzi Piano	Kenzi Keys	Kenzi Acstc	Kenzi Amp
Input							
25	26	27	28	29	30	31	32
							Talkback
Output							
9	10	11	12	13	14	15	16
Mike IEM Left	Mike IEM Right	Wedge 1	Wedge 2	Subs Left	Subs Right	Main Left	Main Right

IEM Operating Frequencies		
Device	Model	Frequencies
Chad's IEM	Sennheiser XSW	476 - 500 MHz
Kenzi's IEM	Shure PSM 300	488-512 MHz
Jessica & Paul 's IEM	Shure PSM 200	518 - 554 MHz
Mike & Billy's IEM	Shure PSM 200	518 - 554 MHz

Notes	
1	Paul's IEM transmitter Port 1 does not work (capped)
2	USB out on back of IEM box is controlled by USB switch underneath the port
3	Colored cables = band vocals & instruments
4	All WING Rack Local Inputs are patched to rear patch panel or to racked devices
5	Talkback is set to Auto. Can be activated by using Wing Edit app.
6	Talkback is supported on front and back of IEM Box. Inform band of preference.
7	Guest Vocals is optional and may not appear at all performances

Label
Drum 1Chad Vocals
Drum 2Kick
Drum 3Snare (Top)
Drum 4Snare (Bottom)
Drum 5Aux
Drum 6Tom 1
Drum 7Tom 2
Drum 8Tom 3
Drum 9Tom 4
Drum 10Overhead Ride
Drum 11Overhead Hat
USR 1Billy Bass
DSR 1Jessica Vocals
DSL 1Paul Vocals
DirectPaul Amp SL
DirectPaul Amp SR
DSL 2Paul Acoustic
DSR 2Mike Vocals
USR 2Mike Amp SL
USR 3Mike Amp SR
DSR 3Mike Acoustic
DSL 3Kenzi Vocals
DSL 4Kenzi Piano
DSL 5Kenzi Keyboard
DSL 6Kenzi Acoustic
DirectKenzi Amp
DSR 4 DSL 7Guest Vocals