

Full Band Setup

Musician	Position	Channel	Input	Sub Snake	Input Name	Mic/DI	Stand	Notes
Chad	Drums	1	L1	Drum 1	Chad Vocals	Shure Beta 56A	Overhead Stand	Light reverb. Light Delay
		2	L2	Drum 2	Kick	Shure Beta 52A	Internal	Suspended inside bass drum
		3	L3	Drum 3	Snare (Top)	Shure Beta 56A	Drum Clamp	
		4	L4	Drum 4	Snare (Bottom)	Shure SM57	Base Stand	
		5	L5	Drum 5	Hi-Hat	Shure SM137	Drum Clamp	48V provided by IEM Box
		6	L6	Drum 6	Tom 1	Shure Beta 98AMP/C	Drum Clamp	48V provided by IEM Box
		7	L7	Drum 7	Tom 2	Shure Beta 98AMP/C	Drum Clamp	48V provided by IEM Box
		8	L8	Drum 8	Tom 3	Shure Beta 98AMP/C	Drum Clamp	48V provided by IEM Box
		9	L9	Drum 9	Tom 4	Shure Beta 98AMP/C	Drum Clamp	48V provided by IEM Box
		10	L10	Drum 10	Overhead Ride	Shure SM137	Boom Stand	48V provided by IEM Box
		11	L11	Drum 11	Overhead Hat	Shure SM137	Boom Stand	48V provided by IEM Box
		12					Unused	
		13					Unused	
Billy Bass	Upstage Left	14	A1		Billy Vocals	Shure Beta 58	Boom Stand	Not for live shows, only practice space.
		15	A2	USR 1	Billy Bass	Behringer BDI 21	Direct	
		16					Unused	
Jessica Vocals	Downstage Center	17	A3	DSR 1	Jessica Vocals	Shure Beta 58A	Boom Stand	Increase EQ on lows & mids, heavy reverb
Paul Guitar	Downstage Right	18	A4	DSL 1	Paul Vocals	Shure 55SH	Boom Stand	Light reverb. Light Delay
		19	A5		Paul Vox	Sennheiser E609	Amp Hang	
		20	A6		Paul Fender	Sennheiser E609	Amp Hang	
		21	A7	DSL 2	Paul Acoustic	Behringer DI4800A	Floor Stand	
		22					Unused	
Mike Guitar	Upstage Right	23	A8	DSR 2	Mike Vocals	Shure SM57	Boom Stand	Light reverb. Light Delay
		24	A9	USR 2	Mike Amp 1	Shure SM57	Floor Stand	
		25	A10	USR 3	Mike Amp 2	Shure SM57	Floor Stand	
		26	A11	DSR 3	Mike Acoustic	DI Box	Direct	
Kenzi Keys	Downstage Left	27	A12	DSL 3	Kenzi Vocals	Telefunken M80	Overhead Stand	Light reverb. Light Delay
		28	A13	DSL 4	Kenzi Piano	Behringer DI4800A	Piano Stand	
		29	A14	DSL 5	Kenzi Keyboard	Behringer DI4800A	Piano Stand	
		30	A15	DSL 6	Kenzi Acoustic	Behringer DI4800A	Floor Stand	
		31					Unused	
Guest	Downstage	32	A16	DSR 4/DSL 7	Guest Vocals	Shure SM57	Boom Stand	Light reverb. Light Delay. May not need.
Utility	Crowd	33	L17/18		Crowd Left	House	House	Stage left house crowd mic
		34					Unused	
		35					Unused	
		36					Unused	
		37					Unused	
	Bluetooth	38	L21/22		Bluetooth Left	Direct	N/A	
		39					Unused	
	Talkback	40	L24		Bluetooth Left	Direct	N/A	



Full Band Setup

theperfectstrangers.band

Date Updated: 2026.06.20

WING Rack Rear Input (Local)							
1	2	3	4	5	6	7	8
Chad Vocals	Kick	Snare (Top)	Snare (Bottom)	Hi-Hat	Tom 1	Tom 2	Tom 3

17	18	19	20	21	22	23	24
Crowd Left	Crowd Right			BT Left	BT Right		Talkback

Midas DL32 Front Input (AES50A)							
Input							
1	2	3	4	5	6	7	8
Billy Vocals	Billy Bass	Jessica Vocals	Paul Vocals	Paul Vox	Paul Fender	Paul Acoustic	Mike Vocals

Input							
17	18	19	20	21	22	23	24

Output							
1	2	3	4	5	6	7	8
Billy IEM Left	Billy IEM Right	Jessica IEM Left	Jessica IEM Right	Paul IEM Left	Paul IEM Right	Kenzi IEM Left	Kenzi IEM Right

IEM Operating Frequencies		
Device	Model	Frequencies
Chad's IEM	Sennheiser XSW	476 - 500 MHz
Kenzi's IEM	Shure PSM 300	488-512 MHz
Jessica & Paul 's IEM	Shure PSM 200	518 - 554 MHz
Mike & Billy's IEM	Shure PSM 200	518 - 554 MHz

WING Rack Rear Input (Local)							
9	10	11	12	13	14	15	16
Tom 4	Overhd Ride	Overhd Hat					

Output							
1	2	3	4	5	6	7	8
Chad IEM Left	Chad IEM Right						

Midas DL32 Front Input (AES50A)							
Input							
9	10	11	12	13	14	15	16
Mike Amp 1	Mike Amp 2	Mike Acstc	Kenzi Vocals	Kenzi Piano	Kenzi Keys	Kenzi Acstc	Guest Vocals

Input							
25	26	27	28	29	30	31	32

Output							
9	10	11	12	13	14	15	16
Mike IEM Left	Mike IEM Right	Wedge 1	Wedge 2	Subs Left	Subs Right	Main Left	Main Right

Notes	
1	Paul's IEM transmitter Port 1 does not work (capped)
2	USB out on back of IEM box is controlled by USB switch underneath the port
3	Colored cables = band vocals & instruments
4	All WING Rack Local Inputs are patched to rear patch panel or to racked devices
5	Talkback is set to Auto. Can be activated by using Wing Edit app
6	Guest Vocals is optional and may not appear at all performances