Mass properties of MADCST_Sat
Configuration: Default
Coordinate system: -- default --

Mass = 511.18 grams

Volume = 298480.79 cubic millimeters

Surface area = 236517.39 square millimeters

Center of mass: (millimeters)
X = 50.00
Y = -50.00
Z = 46.13

Principal axes of inertia and principal moments of inertia: (grams * square millimeters)
Taken at the center of mass.

Ix = (0.98, 0.12, 0.13)	Px = 621727.27
Iy = (-0.17, 0.81, 0.56)	Py = 727658.57
Iz = (-0.04, -0.57, 0.82)	Pz = 778484.34

Moments of inertia: (grams * square millimeters)
Taken at the center of mass and aligned with the output coordinate system. (Using positive tensor notation.)

Lxx = 625033.80	Lxy = 11265.34	Lxz = 14972.46
Lyx = 11265.34	Lyy = 742611.31	Lyz = 25362.64
Lzx = 14972.46	Lzy = 25362.64	Lzz = 760225.08

Moments of inertia: (grams * square millimeters)
Taken at the output coordinate system. (Using positive tensor notation.)

Ixx = 2991040.97	Ixy = -1266752.52	Ixz = 1194176.27
Iyx = -1266752.52	Iyy = 3108662.32	Iyz = -1153820.95
Izx = 1194176.27	Izy = -1153820.95	Izz = 3316260.79

One or more components have overridden mass properties:
External_Rib<1><Predeterminado>@Structure_Sub_Assembly<1><Default>
External_Rib<2><Predeterminado>@Structure_Sub_Assembly<1><Default>
Internal_Rib<1><Predeterminado>@Structure_Sub_Assembly<1><Default>
Internal_Rib<2><Predeterminado>@Structure_Sub_Assembly<1><Default>
Internal_Rib<3><Predeterminado>@Structure_Sub_Assembly<1><Default>
Internal_Rib<4><Predeterminado>@Structure_Sub_Assembly<1><Default>
OBC_Baseplate<1><Default>@OBC_Sub_Assembly<1><Default>
ESP32_dev_Kit_v1<1><Default>@OBC_Sub_Assembly<1><Default>
L298N_Motor_Driver<1><Default>@OBC_Sub_Assembly<1><Default>
Spacer_2mm<1><Default>@OBC_Sub_Assembly<1><Default>
Spacer_2mm<2><Default>@OBC_Sub_Assembly<1><Default>
Spacer_2mm<3><Default>@OBC_Sub_Assembly<1><Default>
Spacer_2mm<4><Default>@OBC_Sub_Assembly<1><Default>
Spacer_3mm<1><Default>@OBC_Sub_Assembly<1><Default>
Spacer_3mm<2><Default>@OBC_Sub_Assembly<1><Default>
Spacer_3mm<3><Default>@OBC_Sub_Assembly<1><Default>
Spacer_3mm<4><Default>@OBC_Sub_Assembly<1><Default>
Z_Magnetorquer<1><Default>
Y_Magnetorquer<1><Default>
X_Magnetorquer<1><Default>
Sensor_Plate<1><Default>@SOB_Sub_Assembly<1><Default>
RM3100<1><Default>@SOB_Sub_Assembly<1><Default>
Battery_Bay<1><Default>@EPS_Sub_Assembly<1><Default>
Battery<1><Default>@EPS_Sub_Assembly<1><Default>
Battery_Bay<1><Default>@EPS_Sub_Assembly<2><Default>
Battery<1><Default>@EPS_Sub_Assembly<2><Default>
Spacer_A<1><Default>
Spacer_A<2><Default>
Spacer_A<3><Default>
Spacer_A<4><Default>

Spacer_B<1><Default>
Spacer_B<2><Default>
Spacer_B<3><Default>
Spacer_B<4><Default>
Spacer_C<1><Default>
Spacer_C<2><Default>
Spacer_C<3><Default>
Spacer_C<4><Default>
Spacer_D<1><Default>
Spacer_D<2><Default>
Spacer_D<3><Default>
Spacer_D<4><Default>
Espiras<1><Default>
Espiras<2><Default>
Espiras<3><Default>