CPE 325: Intro to Embedded Computer Systems

Lab10

Analog-to-Digital Converter

Submitted by: Michael Agnew

Date of Experiment: 4/1/2024

Report Deadline: 4/2/2024

Demonstration Deadline: 4/9/2024

Introduction:

The aim of this lab was to learn about ADC and DAC in the realm of the MSP430 microcontroller. Analog-to-digital converters, or ADC bridge the gap that exists between the digital and analog worlds. This also holds true for Digital-to-Analog converters, or DAC. This lab includes the use of an accelerometer that transmits telemetry signals to the MSP430 which performs a gravity calculation on it before using it to control the LEDs located on the board based on angular deviation. The other part of this lab includes outputting signals to an oscilloscope in various ways at a set frequency.

Theory:

ADC: ADC components convert analog signals such as sound, light temperature or other real-world data into the digital landscape where it can be graphed, charted, used and more. These digital signals that this data is converted into are typically represented digitally as voltage. This voltage can then be interpreted in the context of whatever data is being collected. This component allows the trivial collection of real-world data where it can easily be stored and interpreted in the necessary manner.

DAC: The same, but inversely can be said for DAC systems, which convert digital signals and information into the real world proportions that are desired. These can include things such as heaters or audio playback systems. This works in the same way as ADC, where data will be coveted into a voltage signal which will then be emulated by the system outputting it. Overall, the use of these components are instrumental in daily life as we know it and are extremely important to learn about and use.

Accelerometers: Accelerometers, like the one that was used for this lab, are used for retrieving telemetry data such as position, orientation, velocity, and sending it back to whatever program is taking it in. This telemetry data is then taken and used to figure out the position or speed of the accelerometer for whatever purposes it might serve. In the case of this lab, the accelerometer was used in order to figure out the angular deviation of it at different positions made by the user, which were then calculated by the program which activated the different LEDs based on the position of the accelerometer.

Problem 01:

The first problem of this lab was implementing a C program that interfaces with a 3-dimensional accelerometer. The telemetry data that the accelerometer passed back to the program needed to be calculated in terms of gravity before being properly utilized. Demo code was provided for this assignment, but only worked for two dimensions, so in order to solve this problem, a third axis was implemented in order to have a three dimensional setup with a z-axis. The gravity calculation was also done in the following way:

```
// GRAVITY CALCULATIONS
float x_g = (((float)ADCXval * 3.0 / 4095.0 * 100.0 / 3.0) / 10.0 - 5.0);
float y_g = (((float)ADCYval * 3.0 / 4095.0 * 100.0 / 3.0) / 10.0 - 2.5);
float z_g = (((float)ADCZval * 3.0 / 4095.0 * 100.0 / 3.0) / 10.0 - 5.0);
```

Figure 1. Gravity Calculations in CCS.

These values are multiplied by 3 because the voltage value is 3, and are then divided by 4095 because the ADC component is done in 12 bits. The multiplication by 100 then scales up the

calculation in the proper way. The subtraction at the end is to negate any sort of bias that might occur in the sensor readings. The output for this program in the serial app is shown here:




Figure 2. Serial App Output for Problem 01. Red is X, Blue is Y, and Green is Z.

Problem 02:

The second problem in this lab was to make a bubble level out of the accelerometer program by calculating the angular deviation and turning on the LEDs accordingly to illustrate the current angle of the accelerometer. The way that this would be done, is when the angular deviation of the accelerometer was above 15 degrees, the red LED would come on, and when the angular deviation was lower than 15 degrees, the green LED would be turned on. When the angular deviation was between -15 and 15 degrees, both of the LEDs would remain off. The angular

deviation was calculated by taking the arctangent of x and y with respect to the z axis, multiplied by 180 for degrees and then divided by pi. This calculation is shown here:

```
// CALCULATING ANGULAR DEVIATION OF X AND Y WITH RESPECT TO Z
float x_deviation = atan2(x_g, z_g) * 180 / M_PI;
float y_deviation = atan2(y_g, z_g) * 180 / M_PI;
```

Figure 3. Angular Deviation Formula Used in Program.

The deliverables for this project also required a flowchart be made for problem 2, this can be found below:




Figure 4. Flowchart for Problem 2.

Questions to Answer:

1. Explain why you chose the sampling rate you used for the accelerometer.

ANS: The sampling rate that was chosen for the accelerometer was 1. This was chosen because it was the rate that allowed the serial app to output the accelerometer data at a good rate that properly illustrated the data being processed.

2. Explain how you chose a threshold value for the bubble level.

ANS: A threshold value of 15 was chosen for the bubble level because the assignment required that the level sit between the values of -15 and 15. So, the logical choice for this program was to set the threshold value to 15 in order to properly activate the LEDs when the angular deviation was at the proper value.

Problem 03:

The third part of this lab had to do with outputting different waveform graphs to an oscilloscope at a set frequency. The MSP430 is not entirely capable of doing complex trigonometry, so a lookup table was generated first by using a MATLAB script. This is shown here:

```
Matlab CODE( ".m" file):

x=(0:2*pi/256:2*pi);
y=1.25*(1+sin(x));
dac12=y*4095/2.5;
dac12r = round(dac12);
dlmwrite('sine_lut_256.h',dac12r, ',');

Output Format:
unsigned char lut256[] = {127,.....,250,249};
```

Figure 5. Matlab Script for Generating Lookup Table.

The first of these waveforms was meant to be a sine wave at 30hz. When switch 1 is held, a triangular waveform is generated on the fly at the same 30hz. When switch 2 is held, the frequency of the sine wave is doubled to 60 hz. Below is the output of these waveforms on the oscilloscope:




Figure 6. Sine Waveform at 30Hz.




Figure 7. Sine Waveform with Doubled Frequency (60Hz).




Figure 8. Triangular Waveform at 30Hz.

Conclusion:

Thankfully, no issues were encountered over the course of this lab. There was a lot to go over and a lot to learn and implement with this lab, especially since there were three parts instead of the normal two. Overall however, everything that was meant to be completed was done so and in the proper amount of time. The accelerometer was able to be instantiated with a C program, and the 3-dimensional setup in the serial app output the proper results. The bubble level for part 2 was also properly implemented with the LEDs turning on when the angular deviation is at the proper values. Finally, for part 3, the correct waveforms at the correct frequency were output with the switches being able to make the required changes as described in the assignment.

Overall, ADC and DAC, along with accelerometers are very important components and instruments that one must learn to use as the real-world applications are extremely important for any aspiring engineer.

Appendix:

Problem 01-02:

/*_____

* File: Lab10P1P2.c

* Function: Accelerometer Telemetry Processor

* Description: This code performs calculations on data passed from accelerometer and turns on LEDs based on angular deviation.

* Input: None

* Output: LEDs on the circuit board and waveform in serial app.

* Author(s): Michael Agnew, ma0133@uah.edu

* Date: April 1, 2024

_____/

```
#include <msp430.h>
#include <math.h>
#include <stdint.h>
#define samplerate 10 // sample rate
#define threshhold 15 // threshold for angular deviation
#define grav 10 // gravity
volatile uint16 t ADCXval, ADCYval, ADCZval;
void TimerA setup(void)
      TA0CCR0 = 3277 / samplerate; // Calculate CCR0 for desired sampling rate
      TAOCTL = TASSEL 1 + MC 1; // ACLK, up mode
      TA0CCTL0 = CCIE; // Enabled interrupt
void ADC setup(void)
      P6DIR &= \sim(BIT3 + BIT4 + BIT5); // Configure P6.3, P6.4, P6.5 as input pins
      P6SEL |= BIT3 + BIT4 + BIT5; // Configure P6.3, P6.4, P6.5 as analog pins
      ADC12CTL0 = ADC12ON + ADC12SHT0 8 + ADC12MSC; // Configure ADC
converter
      ADC12CTL1 = ADC12SHP + ADC12CONSEQ 1; // Use sample timer, single
sequence
      ADC12MCTL0 = ADC12INCH 3; // ADC A3 pin - X-axis
      ADC12MCTL1 = ADC12INCH 4; // ADC A4 pin - Y-axis
      ADC12MCTL2 = ADC12INCH 5 + ADC12EOS; // ADC A5 pin - Z-axis, End of
Sequence
      ADC12IE |= ADC12IE2; // Enable ADC12IFG.2
      ADC12CTL0 |= ADC12ENC; // Enable conversions
void UART putCharacter(uint8 t c)
      while (!(UCA0IFG & UCTXIFG)); // Wait for previous character to be sent
      UCA0TXBUF = c; // Send byte to the buffer for transmitting
void UART setup(void)
      P3SEL = BIT3 + BIT4;
                                        // Set up Rx and Tx bits
```

```
UCA0CTL0 = 0;
                                   // Set up default RS-232 protocol
      UCA0CTL1 |= BIT0 + UCSSEL 2;
                                                 // Disable device, set clock
                                 // 1048576 Hz / 38400
      UCA0BR0 = 27;
      UCA0BR1 = 0;
      UCA0MCTL = 0x94;
      UCA0CTL1 &= ~BIT0;
                                          // Start UART device
void sendData(void)
      int i;
      // grav CALCULATIONS
      float yGrav = (((float)ADCYval*3.0/4095.0*100.0/3.0)/10.0-2.5);
      float zGrav = (((float)ADCZval*3.0/4095.0*100.0/3.0)/10.0-5.0);
       float xGrav = (((float)ADCXval*3.0/4095.0*100.0/3.0)/10.0-5.0);
      UART putCharacter(0x55);
      uint8 t *y pointer = (uint8 t *)&yGrav;
       uint8 t *x pointer = (uint8 t *) &x Grav;
      uint8 t *z pointer = (uint8 t *)&zGrav;
      for (i = 0; i < 4; i++)
       { // Send x acceleration - one byte at a time
      UART putCharacter(x pointer[i]);
       for (i = 0; i < 4; i++)
       { // Send y acceleration - one byte at a time
      UART putCharacter(y pointer[i]);
       for (i = 0; i < 4; i++)
       { // Send z acceleration - one byte at a time
      UART putCharacter(z pointer[i]);
void sendDataDebug(float data)
```

```
int i;
      uint8 t *data pointer = (uint8 t *)&data;
      for (i = 0; i < 4; i++)
      UART putCharacter(data pointer[i]);
void bubbleLevel(void) {
      float xGrav = (((float)ADCXval*3.0/4095.0*100.0/3.0)/10.0-5.0);
      float yGrav = (((float)ADCYval*3.0/4095.0*100.0/3.0)/10.0-5.0);
      float zGrav = (((float)ADCZval*3.0/4095.0*100.0/3.0)/10.0-5.0);
      // CALCULATING ANGULAR DEVIATION OF X AND Y WITH RESPECT TO Z
      float x deviation = atan2(xGrav, zGrav) * 180 / M PI;
      float y deviation = atan2(yGrav, zGrav) * 180 / M PI;
      // X AXIS LED
      if (x deviation > threshhold)
      P1OUT |= BIT0; // activate red LED
       } else if (x deviation < -threshhold)
      P1OUT &= ~BIT0;
       } else {
      P1OUT &= ~BIT0;
      // Y AXIS LED
      if (y deviation > threshhold)
      P4OUT |= BIT7; // turn on green LED
      else if (y deviation < -threshhold)
      P4OUT &= ~BIT7;
      else
      P4OUT &= ∼BIT7;
```

```
void main(void)
      WDTCTL = WDTPW + WDTHOLD; // Stop WDT
      TimerA setup(); // Setup timer to send ADC data
      ADC setup(); // Setup ADC
      UART setup(); // Setup UART for RS-232
      P1DIR |= BIT0 + BIT1; // Set P1.0 and P1.1 as output for LEDs
      P4DIR = BIT7;
       enable interrupt(); // Enable global interrupt
      while (1)
      ADC12CTL0 |= ADC12SC; // Start conversions
        bis SR register(LPM0 bits + GIE); // Enter LPM0
      sendData(); // Send data to serial app
      bubbleLevel(); // Check bubble level and control LEDs
#pragma vector = ADC12 VECTOR
 interrupt void ADC12ISR(void)
      ADCXval = ADC12MEM0; // X-axis
      ADCYval = ADC12MEM1; // Y-axis
      ADCZval = ADC12MEM2; // Z-axis
        bic SR register on exit(LPM0 bits); // Exit LPM0
#pragma vector = TIMER0 A0 VECTOR
  interrupt void timerA isr()
       bic SR register on exit(LPM0 bits); // Exit LPM0
```

Problem 03:

```
/*-----* File: Lab10Part3.c
```

```
* Function: Generates Waveforms on Oscilloscope
* Description: Generates Sine wave and triangle wave at 30-60hz based on switch presses.
* Input:
             Switches
* Output:
             Oscilloscope waveforms
* Author(s): Michael Agnew, ma0133@uah.edu
* Date:
* Date: April 1, 2024
*-----*/
             April 1, 2024
#include <msp430.h>
#include "sine lut 256.h"
#define S1 P2IN&BIT1 // Switch 1
#define S2 P1IN&BIT1 // Switch 2
unsigned char index = 0;
unsigned int value= 127;
unsigned int i = 0;
volatile int up = 1;
int main(void)
      WDTCTL = WDTPW | WDTHOLD; // stop watchdog timer
      // SWITCH 1 SETUP
      P2DIR &= ~BIT1; // Set P2.1 as input for S1 input
      P2REN |= BIT1; // Enable the pull-up resistor at P2.1
      P2OUT |= BIT1; // Required for proper IO
      // SWITCH 2 SETUP
      P1DIR &= ~BIT1; // Set P1.1 as input for S2 input
      P1REN |= BIT1; // Enable the pull-up resistor at P1.1
      P1OUT |= BIT1; // Required for proper IO
      // Timer B Configuration
      TB0CCTL0 = CCIE; // Timer Count Triggers Interrupt
      TB0CTL = TBSSEL 2 + MC 1; // SMCLK is source, and set to up mode
      TB0CCR0 = 135; // 30hz
      P3DIR = 0xFF; // Enable All pins on Port 3 as outputs.
      P3OUT = 0;
```

```
_bis_SR_register(LPM0_bits + GIE);
       return 0;
#pragma vector=TIMERB0_VECTOR
 interrupt void timerISR2(void)
       // Check if S2 is pressed
       if ((S2) == 0)
       TB0CCR0 = 67; // 60hz
       else
       TB0CCR0 = 135; // 30hz
       if ((S1) == 0)
       TB0CCR0 = 205; // for triangle
       // When S1 is held
       if (up)
       value += 3;
       if (value == 255) // once value reaches max
              up = 0; // go down
       else
       value -= 3;
       if (value == 0) // once value reaches min
              up = 1; // go up again
```

```
P3OUT = value; // output value to p3
}
else
{
// If S1 is not pressed, continue using the sine lookup table
index += 1;
P3OUT = lut256[index % 256]; // Ensure index wraps around
}
}
```

LUT Lookup Table Script:

```
Matlab CODE(".m" file):

x=(0:2*pi/256:2*pi);
y=1.25*(1+sin(x));
dac12=y*4095/2.5;
dac12r = round(dac12);
dlmwrite('sine_lut_256.h',dac12r, ',');
```